



SEW
EURODRIVE

Manual



MOVIPRO[®] SDC with PROFIBUS Interface





Contents

1	General Information	5
1.1	How to use this documentation	5
1.2	Structure of the safety notes	5
1.3	Rights to claim under limited warranty	6
1.4	Exclusion of liability	6
1.5	Other applicable documentation	6
1.6	General safety notes for bus systems.....	6
1.7	Safety functions	6
1.8	Hoist applications	7
1.9	Copyright.....	7
2	Application Modules in MOVITOOLS® MotionStudio	8
2.1	Application modules for MOVIPRO® SDC	8
3	Startup.....	14
3.1	Startup procedure	14
3.2	Check list for startup	14
4	Installation Notes	16
4.1	Fieldbus connection	16
4.2	Shielding and routing the bus cables	19
4.3	Setting the station address (PROFIBUS).....	20
4.4	Status and error messages	21
5	Configuration and Startup on the PROFIBUS DP-V1 Fieldbus	26
5.1	Configuring a PROFIBUS DP master	26
6	Operating Behavior in Conjunction with PROFIBUS DP-V1	34
6.1	Process data exchange with MOVIPRO®	34
6.2	PROFIBUS-DP-V1 timeout	36
6.3	Parameterization via PROFIBUS DP	37
6.4	Parameterization – return codes	43
6.5	Special cases	44
7	PROFIBUS DP-V1 Functions.....	46
7.1	PROFIBUS DP-V1 – introduction	46
7.2	Features of SEW fieldbus interfaces.....	48
7.3	Structure of the DP-V1 parameter channel	49
7.4	Project planning for a C1 master	60
8	Error Diagnostics	64
8.1	Diagnostics procedure – PROFIBUS DP-V1 operation	64
8.2	Fieldbus timeout	65
9	Process Data Description.....	66
9.1	Overview of process data	66
9.2	MOVIPRO® control word	66
9.3	MOVIPRO® status word.....	67
9.4	Digital inputs and outputs.....	68
9.5	Process data of power section	69



10	MOVITOOLS® MotionStudio – Operation.....	78
10.1	About MOVITOOLS® MotionStudio	78
10.2	First steps	79
10.3	Connection mode	80
10.4	Communication via Ethernet	82
10.5	Executing functions with the units	87
11	MOVIPRO® – Parameterization	89
11.1	Encoder configuration	89
11.2	Motor startup	103
11.3	Storing unit data	108
11.4	"PFA-..." power section parameter overview	110
11.5	"PFA-..." power section parameter information	115
11.6	Parameter overview of the encoder option	153
12	Service	155
12.1	Unit replacement	155
12.2	Encoder exchange	157
12.3	Service unit	157
12.4	MOVIPRO® SDC error list	158
13	Additional Documentation	169
	Index.....	170



1 General Information

1.1 How to use this documentation

The documentation is an integral part of the product and contains important information on operation and service. The documentation is written for all employees who assemble, install, startup, and service this product.

The documentation must be accessible and legible. Make sure that persons responsible for the system and its operation, as well as persons who work independently on the unit, have read through the documentation carefully and understood it. If you are unclear about any of the information in this documentation, or if you require further information, contact SEW-EURODRIVE.

1.2 Structure of the safety notes

1.2.1 Meaning of the signal words

The following table shows the grading and meaning of the signal words for safety notes, notes on potential risks of damage to property, and other notes.

Signal word	Meaning	Consequences if disregarded
▲ DANGER	Imminent danger	Severe or fatal injuries
▲ WARNING	Possible dangerous situation	Severe or fatal injuries
▲ CAUTION	Possible dangerous situation	Minor injuries
NOTICE	Possible damage to property	Damage to the drive system or its environment
INFORMATION	Useful information or tip: Simplifies the handling of the drive system.	

1.2.2 Structure of the section-related safety notes

Section safety notes do not apply to a specific action, but to several actions pertaining to one subject. The used symbols indicate either a general or a specific hazard.

This is the formal structure of a section safety note:



▲ SIGNAL WORD

Type and source of danger.

Possible consequence(s) if disregarded.

- Measure(s) to prevent the danger.

1.2.3 Structure of the embedded safety notes

Embedded safety notes are directly integrated in the instructions just before the description of the dangerous action.

This is the formal structure of an embedded safety note:

- **▲ SIGNAL WORD** Nature and source of hazard.
Possible consequence(s) if disregarded.
– Measure(s) to prevent the danger.



1.3 Rights to claim under limited warranty

A requirement of fault-free operation and fulfillment of any rights to claim under limited warranty is that you adhere to the information in the documentation. Read the documentation before you start working with the unit!

1.4 Exclusion of liability

You must comply with the information contained in this documentation to ensure safe operation of MOVIPRO® and to achieve the specified product characteristics and performance features. SEW-EURODRIVE assumes no liability for injury to persons or damage to equipment or property resulting from non-observance of these operating instructions. In such cases, any liability for defects is excluded.

1.5 Other applicable documentation

This document does not replace the detailed operating instructions. Only electrical specialists are allowed to install and start up MOVIPRO® observing the applicable accident prevention regulations and the MOVIPRO® SDC operating instructions.

1.6 General safety notes for bus systems

This communication system allows you to adapt the MOVIPRO® SDC to your application. As with all bus systems, there is a danger of modifications to the parameters that are not visible from outside (in relation to the inverter), which give rise to changes in the inverter behavior. This may result in unexpected (not uncontrolled) system behavior.

1.7 Safety functions

MOVIPRO® may not perform any safety functions unless they are described and expressly approved.

For safety applications, ensure that the information in the following publication is observed:

- MOVIPRO® SDC – Functional Safety

Use only those components in safety applications that were explicitly designed and delivered for this purpose by SEW-EURODRIVE.



1.8 Hoist applications

- Hoist applications can only be implemented with MOVIPRO® SDC under the following conditions:
 - A hoist startup must be performed.
- MOVIPRO® is not designed for use as a safety device in hoist applications.
Use monitoring systems or mechanical protection devices as safety equipment to avoid possible damage to property or injury to people.

1.9 Copyright

© 2010 – SEW-EURODRIVE. All rights reserved.

Unauthorized duplication, modification, distribution or any other use of the whole or any part of this documentation is strictly prohibited.



2 Application Modules in MOVITOOLS® MotionStudio

2.1 Application modules for MOVIPRO® SDC

2.1.1 Description

Drive task Industrial drive tasks usually require more than motor speed control. The inverter often has to control complex motion sequences and take on typical PLC tasks.

Solution with MOVIPRO® SDC SEW-EURODRIVE offers various standardized control programs, so-called application modules, for positioning.

The application module has a user-friendly GUI to assist with parameterization. You merely have to specify the parameters required for your application. The application module uses this information to create the control program and loads it into the inverter. MOVIPRO® SDC then takes over the entire motion control. Thus the application module takes load off the higher-level controller.

Benefits The application modules offer the following benefits:

- A wide range of functions
- A user-friendly GUI
- Only the parameters necessary for the application must be entered
- Guided parameter setting instead of complicated programming
- No programming experience required
- Quick familiarization, therefore quicker configuration and startup
- All movement functions are controlled directly in the MOVIPRO®

Scope of delivery and documentation The application modules are included in the MOVITOOLS® MotionStudio software and can be used with all MOVIPRO® SDC units.



INFORMATION

For information on how to operate the application modules, refer to the MOVIDRIVE® B application manuals. They are available on the SEW homepage.



2.1.2 Available application modules


The following application modules are available for MOVIPRO® SDC.

- Bus positioning
- Extended positioning via bus
- Modulo positioning
- Table positioning
- Sensor based positioning via bus
- Automotive AMA0801

Bus positioning

The "Bus positioning" application module has the following functions:

- Variable and unlimited number of target positions
- Freely adjustable travel speed for positioning
- Maximum travel distance ± 32700 mm




1984436491



Extended bus positioning

The "Extended bus positioning" application module has the following functions:


- Variable number of target positions
- The travel speed for positioning and the acceleration and deceleration ramps are specified variably by the PLC.
- Maximum travel distance ± 262100 mm
- Operation is possible with 4 instead of 6 process data words. The variable specification of the ramp type is not used in this case.



1984444811



- Modulo positioning** The "Modulo positioning" application module has the following functions:
- Fieldbuses with 4 or 6 process data words are supported.
 - Target position specified via 2 process data words
 - Freely adjustable travel speed
 - Two different ramps can be selected when 4 process data words are used for control.
 - The acceleration or deceleration ramps can be specified using process data word 5 or 6 for control via 6 process data words.
 - For a non-positive connection (= with slip) between the motor shaft and application, the distance measurement can be taken via an external incremental or absolute encoder. The encoder must be mounted to the application without slip.
- Table positioning** The "Table positioning" application module has the following functions:
- Control via fieldbus
 - 32 table positions in inverter
 - Freely adjustable travel speed




1984678283



Sensor-based positioning

The "Sensor-based positioning" application module has the following functions:

- Variable and unlimited number of target positions
- Freely adjustable travel speed (changes can be made during travel for linear positioning ramps)
- Maximum travel distance ± 32700 m




1984845707



Automotive AMA0801

The "Automotive AMA0801" application module offers the following functions:

- The "Automotive AMA0801" application module makes it possible to implement lifting devices, conveyor systems and machinery with drives that have to move at a synchronous angle to one another occasionally or permanently.
- The "Automotive AMA0801" application module has a selectable process data interface. Setpoints specification is either variable or binary.
- The program is used to control individual drives. In synchronous operation mode, these drives can be synchronized to a master drive.




2123860875



3 Startup

3.1 Startup procedure

The following illustration gives an overview of the MOVIPRO® startup procedure and lists other applicable documentation:




3.2 Check list for startup

3.2.1 Preliminary work

Make sure that the following preliminary steps have been carried out:

- MOVITOOLS® MotionStudio version 5.60 or later is installed on the engineering PC.
- The GSD file, "SEW_600E.GSD" is available.
- The Ethernet service interface is configured. For more information, refer to section "Communication via Ethernet (page 82)".
- The MOVIPRO® unit is connected to the fieldbus.
- A connection has been established between the engineering PC and the MOVIPRO® unit.
 - Except for the lower byte, the engineering PC and the MOVIPRO® unit have the same IP address (page 82).
 - The engineering PC and the MOVIPRO® unit have identical subnet masks.
 - The MOVIPRO® can be addressed via the engineering PC using the ping command.



3.2.2 Unit installation

Perform the following steps:

1. Install the components according to the information in the MOVIPRO® operating instructions:
 - Supply system cable
 - Motor cable
 - Braking resistor
 - DC 24 V backup voltage
2. Switch on all power supplies of the MOVIPRO® unit.

3.2.3 Configuration of MOVIPRO®



INFORMATION

For information about using MOVITOOLS® MotionStudio, refer to section "Operation of MOVITOOLS® MotionStudio (page 78)".

Proceed as follows to configure the MOVIPRO®:

1. Start MOVITOOLS® MotionStudio.
2. Create a new project.
3. Set the communication properties to "Ethernet".
4. Perform a unit scan.
5. Mark the MOVIPRO® unit.
6. Right-click on it and select [Startup] / [Startup] from the context menu.
7. Perform a motor startup (page 103).
8. Load the respective application module into MOVIPRO®, if necessary.
9. Check whether the process data exchange between the controller and the MOVIPRO® is working properly.
10. Enable the MOVIPRO® unit.



4 Installation Notes



INFORMATION


For information on the assembly and the installation of MOVIPRO®, refer to the "MOVIPRO® SDC" operating instructions.

For a simple application, this section contains information on how to install the Ethernet.

4.1 Fieldbus connection

4.1.1 X4201: PROFIBUS input


The following table provides information about this connection:

Function		
PROFIBUS input		
Connection type		
M12, 5-pole, male, B-coded		
Wiring diagram		
		
2461813259		
Assignment		
No.	Name	Function
1	res.	Reserved
2	A	PROFIBUS data line A (green)
3	res.	Reserved
4	B	PROFIBUS data line B (red)
5	res.	Reserved



4.1.2 X4202: PROFIBUS output

The following table provides information about this connection:

Function		
PROFIBUS output		
Connection type		
M12, 5-pole, female, B-coded		
Wiring diagram		
		
2354431115		
Assignment		
No.	Name	Function
1	+5V	DC 5 V output
2	A	PROFIBUS data line A (green)
3	0V5	0V5 reference potential
4	B	PROFIBUS data line B (red)
5	res.	Reserved

Bus termination



INFORMATION

If the unit is the last station in the bus, you must provide for a bus termination by connecting an according resistor to plug connector X4202.



4.1.3 MOVIPRO® – PROFIBUS connection

According to the PROFIBUS specification, the bus has to be implemented with a line structure. The maximum permitted cable length depends on the baud rate setting:

Baud rate	Maximum cable length
9.6 kBd	1200 m
19.2 kBd	
93.75 kBd	
187.5 kBd	1000 m
500 kBd	400 m
1.5 MBaud	200 m
12 MBaud	100 m



4.2 Shielding and routing the bus cables

The PROFIBUS interface supports RS485 transmission technology and requires the cable type A to IEC 61158 specified as the physical medium for PROFIBUS. This cable must be a shielded, twisted-pair cable.

Correct shielding of the bus cable attenuates electrical interference that can occur in industrial environments. The following measures ensure the best possible shielding:

- Manually tighten the mounting screws on the connectors, modules, and equipotential bonding conductors.
- Use only connectors with a metal housing or a metallized housing.
- Connect the shielding in the connector over a wide surface area.
- Apply the shielding of the bus cables on both ends.
- Route signal and bus cables in separate cable ducts. Do not route them parallel to power cables (motor leads).
- Use metallic, grounded cable racks in industrial environments.
- Route the signal cable and the corresponding equipotential bonding close to each other using the shortest possible route.
- Avoid using plug connectors to extend bus cables.
- Route the bus cables closely along existing grounding surfaces.



NOTICE

In case of fluctuations in the ground potential, a compensating current may flow via the bilaterally connected shield that is also connected to the protective earth (PE). Make sure you supply adequate equipotential bonding in accordance with relevant VDE regulations in such a case.



Installation Notes

Setting the station address (PROFIBUS)


4.3 Setting the station address (PROFIBUS)



INFORMATION

Any changes to the station address during operation become effective after the power supply has been interrupted (DC 24 V reset).

Use the S2 DIP switch in the PROFIBUS[®] module to set the station address of the MOVIPRO[®]. The default setting for the station address is 4. The following figure shows the DIP switch S2 and its position on the PROFIBUS module:




1642743307

[1] DIP switch S2

[2] Knurled screw

The DIP switch S2 is located on the top of the PROFIBUS module. You have to remove the PROFIBUS module to reach it. This does not interrupt the PROFIBUS network. Proceed as follows when removing the module:

1. Loosen the knurled screws.
2. Pull the PROFIBUS module from the MOVIPRO[®] unit to the front.
3. Use DIP switches 1 to 7 to set the PROFIBUS address. The following example shows the settings of the DIP switches for PROFIBUS address 17.



1946073995

[1] Example: Address 17

[2] Switch 8 = Reserved

Addresses 1 to 125:

valid addresses

Addresses 0, 126, 127:

are not supported



The following table uses PROFIBUS address 17 as an example to show how to determine the DIP switch settings for any bus address:

DIP switch setting	Significance
DIP 1 = ON	1
DIP 2 = OFF	2
DIP 3 = OFF	4
DIP 4 = OFF	8
DIP 5 = ON	16
DIP 6 = OFF	32
DIP 7 = OFF	64

4. Connect the bus terminating resistor to the MOVIPRO® at the last bus station.
 - If MOVIPRO® is located at the end of a PROFIBUS segment, the unit can only be connected to the PROFIBUS network via the incoming PROFIBUS line.
 - To prevent malfunctions in the bus system due to reflections, etc., the PROFIBUS segment must be terminated using bus terminating resistors at the first and last stations.
5. Once plugged-in, secure the PROFIBUS module with both knurled screws.

4.4 Status and error messages

The 7-segment display informs about the status of the MOVIPRO® unit. In case of repeated malfunctions, contact the SEW Service staff.

The display of the three-digit 7-segment display shows the current status of the unit. If several statuses or errors are active at the same time, the error with the highest priority is displayed.

4.4.1 Unit status

The following unit statuses are possible:

Display	Description
	Maintenance switch is switched off
	Initialization: Trying to establish a connection to all internal components. This can take several minutes after a unit replacement.
	The connection has been established. The statuses of the components or the application are displayed after 3 s.
	Flashing dot: Application module running
	Fieldbus error
	Unit waiting for DC 24 V reset
	Communication error with the power section
	Error in external periphery



Installation Notes

Status and error messages

Display	Description
	Non-enabled application module loaded
	Configuration with Application Configurator not completed
	Data backup on SD memory card failed, upload aborted
	Data backup on SD memory card failed, SD memory card is write-protected
	Data recovery in MOVIPRO® failed, download aborted
	Data recovery in MOVIPRO® failed, controller not inhibited
	Internal system error
	Actuator voltage overload
	Overload sensor voltage group 1
	Overload sensor voltage group 2
	Internal communication error



4.4.2 Inverter status

The inverter status is indicated by displaying the address/number of the axis and the corresponding status code in the form of A1.y.



INFORMATION

The unit status display takes priority over the inverter status display. If the maintenance switch is switched off or a fieldbus error occurs, no inverter status is displayed.

The following figure shows the display for the "Enable" status of axis 1:



1820269707

The following table shows the various status codes:

7-segment display	Unit status (high byte in status word 1)	Meaning
0	0 _{dec}	DC 24 V operation (inverter not ready)
1	1 _{dec}	Controller inhibit active
2	2 _{dec}	No enable
3	3 _{dec}	Standstill current
4	4 _{dec}	Enable
5	5 _{dec}	n-control (speed control)
6	6 _{dec}	M-control (torque control)
7	7 _{dec}	Hold control
8	8 _{dec}	Factory setting
9	9 _{dec}	Limit switch contacted
A	10 _{dec}	Technology option
c	12 _{dec}	IPOS ^{plus} ® reference travel
d	13 _{dec}	Flying start
E	14 _{dec}	Calibrate encoder
F	Error code (page 158)	Error indicator (flashing)
U	17 _{dec}	"Safe Stop" active
• (blinking dot)	–	Application module running



⚠ WARNING

Incorrect interpretation of display **U** = "Safe stop" active.

Severe or fatal injuries.

The display **U** = "Safe stop" active is not safety-related and must not be used as a safety function.




Installation Notes

Status and error messages

4.4.3 Inverter error

In case of an inverter error, the status display alternatively shows the address/number of the axis and 3 times the corresponding error code.

The following figure shows the display for an "Overtemperature" error of axis 1:




1806505867

For a list of error codes, refer to section "Service / Error list of MOVIPRO® SDC" (page 158).

4.4.4 Status LED

The status LEDs are located on the service unit of MOVIPRO®. They show the fieldbus and unit status.



1954344587

[1] Status LEDs S1, S2, S3

Status LED S1 PROFIBUS

LED status	Status or cause of error	Remedy
Off	<ul style="list-style-type: none"> Unit is currently exchanging data with the DP master (data exchange). 	—
Flashing	<ul style="list-style-type: none"> Unit has detected the baud rate, but is not addressed by DP master. Unit was not configured in DP master or configured incorrectly. 	<ul style="list-style-type: none"> Check the PROFIBUS address setting in MOVIPRO® and in the configuration software of the DP master. Check configuration of the DP master.
Lights up red	<ul style="list-style-type: none"> Connection to the DP master has failed. Unit does not detect PROFIBUS baud rate. Possible bus interruption. DP master not in operation 	<ul style="list-style-type: none"> Check the PROFIBUS-DP connection on the MOVIPRO® unit. Check the project planning of the DP master. Check the cabling of your PROFIBUS network.




Status LED S2

LED status	Status or cause of error	Remedy
Flashing green	<ul style="list-style-type: none"> The firmware of the fieldbus gateway is running properly. 	–
Flashing green/orange	<ul style="list-style-type: none"> Data backup is created/restored. 	–
Lights up orange	<ul style="list-style-type: none"> Boot process is active. 	–
Flashing orange	<ul style="list-style-type: none"> Firmware is being updated 	–
Flashing red	<ul style="list-style-type: none"> No SD card plugged in. File system of the SD card corrupt. Boot process has failed. 	<ul style="list-style-type: none"> Switch the unit off and back on again. If the error occurs repeatedly, contact the SEW Service staff.

Status LED S3

LED status	Status or cause of error	Remedy
Lights up green	<ul style="list-style-type: none"> Program is running. 	–
Off	<ul style="list-style-type: none"> No program is loaded. 	<ul style="list-style-type: none"> Replace the SD card.



5 Configuration and Startup on the PROFIBUS DP-V1 Fieldbus

5.1 Configuring a PROFIBUS DP master

A GSD file is required for the project planning of the PROFIBUS DP master for the MOVIPRO®.



INFORMATION

The latest versions of the GSD files are available on the SEW website (www.sew-eurodrive.de) via "Software" for the decentralized drive controller, MOVIPRO® SDC.

5.1.1 GSD file for PROFIBUS DP / DP-V1

The GSD file "SEW_600E.GSD" corresponds to GSD revision 5. The device master data files standardized by the PROFIBUS user organization can be read by all PROFIBUS DP masters.

Project planning tool	DP master	File name
All DP project planning tools to IEC 61158	for standard DP master	SEW_600E.GSD
Siemens S7 hardware configuration	for all S7 DP masters	



INFORMATION


Do not edit or amend the entries in the GSD file. SEW assumes no liability for MOVIPRO® malfunctions caused by a modified GSD file.

5.1.2 General project planning procedure

Proceed as follows to perform the project planning for MOVIPRO® with PROFIBUS-DP interface:

1. Install the GSD file according to the requirements of your project planning software. For further information, refer to the documentation of your project planning software and to section "Installing the GSD file in STEP7" (page 27). Once the file has been installed correctly, the device appears next to the slave stations with the designation MOVIPRO®.
2. For project planning, add MOVIPRO® under the name MOVIPRO® to the PROFIBUS structure and assign the PROFIBUS station address.
3. Select the process data configuration required for your application. For more information, see the section "DP configurations (page 32)".
4. Enter the I/O or peripheral addresses for the configured data widths.

After project planning you can start PROFIBUS-DP. The LED S1 PROFIBUS shows the project planning status. For information on the LED S1, refer to section "Status LED (page 24)".



5.1.3 Installing the GSD file in STEP7

Proceed as follows to install the GSD file in STEP7:

1. Start the Simatic Manager.
2. Open an existing project and start the hardware configuration.
3. Close the project window in the HW Config. You cannot install a new file version if the project window is open.
4. In the menu, click on [Extras] / [Install new GSD...] and select SEW_600E.GSD.

The software installs the GSD file and the associated bitmap files in the STEP7 system.

The SEW drive is available under the following path in the hardware catalog:

```
PROFIBUS DP
+-- Other field units
    +-- Drives
        +-- SEW
            +-- DPV1
                +-- MOVIPRO
```

The installation of the new GSD file is now complete.




Configuration and Startup on the PROFIBUS DP-V1 Fieldbus

Configuring a PROFIBUS DP master


5.1.4 Project planning with STEP7

Proceed as follows to perform the project planning for MOVIPRO® with PROFIBUS-DP interface:


1. Add the interface module with the name MOVIPRO® into the PROFIBUS structure using drag and drop and assign the station address.



2426019851



- Now the MOVIPRO® is configured with "2PD". To change the PD configuration, you have to delete the 2PD module in slot 3. Then insert another PD module from the "MOVIPRO" folder in slot 3 via drag-and-drop, in this example 1 PD:



2426021771




Configuration and Startup on the PROFIBUS DP-V1 Fieldbus

Configuring a PROFIBUS DP master


Slots 4 to 18 can be configured in the same way. In the following figure, a conventional configuration of 8 PD is distributed to 3 slots (*mapping 8 data words to smaller peripheral areas*).

Slot	DP ID	Order Number / Designation	I Address	Q Address	Comment
1	0	Empty			
2	0	Empty			
3	192	1 PD (1 word)	512-513	512-513	
4	192	1 PD (1 word)	514-515	514-515	
5	192	1 PD (1 word)	516-517	516-517	
6	0	Empty			
7	0	Empty			
8	0	Empty			
9	0	Empty			
10	0	Empty			
11	0	Empty			
12	0	Empty			
13	0	Empty			
14	0	Empty			
15	0	Empty			
16	0	Empty			
17	0	Empty			
18	0	Empty			

2426023691



3. Enter the I/O or peripheral addresses for the configured data widths in the "I Address" [1] and "Q Address" [2] columns.



2426025611



5.1.5 DP configurations

To enable MOVIPRO® to support the type and number of the input and output data used for transmission, the DP master must transmit the corresponding DP configuration to MOVIPRO®. The configuration telegram comprises the DP configurations for slots 1 to 18. The number of process data depends on the number of slave units and their process data width. You can control the MOVIPRO® via process data.

The following tables contain additional information on possible DP configurations.

- The "Parameter data configuration" and "Process data configuration" columns display the name of the configuration. These names also appear in a selection list in the configuration software for the DP master.
- The "DP configurations" column shows the configuration data that are sent to the MOVIPRO® when the link to the PROFIBUS DP system is being established.

Slot 1:


Parameter data configuration	Meaning	DP configurations
Empty	Reserved	0x00
F module I/O (2 byte)	Project planning for PROFIsafe channel completed	0xC6, 0x85, 0x05, 0x05, 0x05, 0x0A, 0x05, 0x05, 0x0A

Slot 2:

Parameter data configuration	Meaning	DP configurations
Empty	Reserved	0x00
Param (4words)	Project planning for MOVILINK® parameter channel completed	0xC0, 0x87, 0x87

Slots 4 to 18:

Process data configuration	Meaning	DP configurations
1 PD	Process data exchange via 1 process data word	0xC0, 0xC0, 0xC0
2 PD	Process data exchange via 2 process data words	0xC0, 0xC1, 0xC1
3 PD	Process data exchange via 3 process data words	0xC0, 0xC2, 0xC2
4 PD	Process data exchange via 4 process data words	0xC0, 0xC3, 0xC3
5 PD	Process data exchange via 5 process data words	0xC0, 0xC4, 0xC4
6 PD	Process data exchange via 6 process data words	0xC0, 0xC5, 0xC5
7 PD	Process data exchange via 7 process data words	0xC0, 0xC6, 0xC6
8 PD	Process data exchange via 8 process data words	0xC0, 0xC7, 0xC7
9 PD	Process data exchange via 9 process data words	0xC0, 0xC8, 0xC8
10 PD	Process data exchange via 10 process data words	0xC0, 0xC9, 0xC9
11 PD	Process data exchange via 11 process data words	0xC0, 0xCA, 0xCA
12 PD	Process data exchange via 12 process data words	0xC0, 0xC7, 0xC7
13 PD	Process data exchange via 13 process data words	0xC0, 0xCC, 0xCC
14 PD	Process data exchange via 14 process data words	0xC0, 0xCD, 0xCD
15 PD	Process data exchange via 15 process data words	0xC0, 0xCE, 0xCE
16 PD	Process data exchange via 16 process data words	0xC0, 0xCF, 0xCF
32 PD	Process data exchange via 32 process data words	0xC0, 0xDF, 0xDF
64 PD	Process data exchange via 64 process data words	0xC0, 0xFF, 0xFF



Configuration example

Slot 1: Empty

Slot 2: Param (4 words)

Slot 3: 10 PD

Configuration telegram sent to the MOVIPRO®:

0x00 0xC0 0xC87 0x87 0xC0 0xC9 0xC9



INFORMATION

MOVIPRO® does not support the "Special identifier formats" coding. Only use the "Integrity over entire length" setting for data transmission.

Data consistency

Consistent data is data that always has to be transmitted between the higher-level controller and the MOVIPRO® as one block and must never be transmitted separately.

Data integrity is particularly important for transmitting position values or complete positioning tasks. The reason for this is that data which is not transmitted consistently could be from different program cycles of the higher-level controller, which would lead to undefined values being transmitted to the MOVIPRO®.

For PROFIBUS DP, data communication between the higher-level controller and the MOVIPRO® is carried out with the setting "Data integrity over entire length".




6 Operating Behavior in Conjunction with PROFIBUS DP-V1

This section describes the basic characteristics of the MOVIPRO® in conjunction with the PROFIBUS-DP system.

6.1 Process data exchange with MOVIPRO®

The MOVIPRO® is controlled via the process data channel comprising up to 8 I/O words. These process data words are reproduced in the I/O or peripheral area of the MOVIPRO®, for example when a higher-level programmable logic controller is used as DP master. Thus, they can be addressed in the usual manner.



6.1.1 Control example for Simatic S7

Depending on the selected process data configuration, the process data exchange with MOVIPRO® via Simatic S7 is carried out via special system functions, *SFC 14 DPRD_DAT* und *SFC15 DPWR_DAT*.



STEP7 example program

In this project planning example, the MOVIPRO® with process data configuration 8 PD is assigned to the input addresses PIW512... and the output addresses POW512...

A data block DB3 is created with about 50 data words.

When SFC14 is called, the process input data is copied to data block DB3, data words 0 to 14. When SFC15 is called after the control program has been processed, the process output data is copied from data words 20 – 34 to the output address POW 512....

Note the length information in bytes for the *RECORD* parameter. The length information must correspond to the configured length.

Refer to the online help for STEP7 for further information about the system functions.



INFORMATION

This sample program is a free service to demonstrate the basic approach to generating a PLC program as a non-binding example. SEW is not liable for the contents of the sample program.

```
//Start of cyclical program processing in OB1
BEGIN
NETWORK
TITLE = Copy PI data from MOVIPRO to DB3, words 0...14
CALL SFC 14 (DPRD_DAT)           //Read DP slave record
    LADDR := W#16#200             //Input address 512
    RET_VAL:= MW 30               //Result in flag word 30
    RECORD := P#DB3.DBX 0.0 BYTE 16 //Pointer

NETWORK
TITLE =PLC program with drive application
// PLC program uses the process data in DB3 for data exchange
// with MOVIPRO

L DB3.DBW 0 //Load PE1
L DB3.DBW 2 //Load PE2
L DB3.DBW 4 //Load PE3
// etc.

L W#16#0006
T DB3.DBW 20 //Write 6hex to PO1
L 1500
T DB3.DBW 22 //Write 1500dec to PO2
L W#16#0000
T DB3.DBW 24 //Write 0hex to PO3
// etc.


NETWORK
TITLE = Copy PO data from DB3, word 20...34 to MOVIPRO
CALL SFC 15 (DPWR_DAT)           //Write DP slave record
    LADDR := W#16#200             //Output address 512 = 200hex
    RECORD := P#DB3.DBX 20.0 BYTE 16 //Pointer to DB/DW
    RET_VAL:= MW 32               //Result in flag word 32
```



Operating Behavior in Conjunction with PROFIBUS DP-V1

PROFIBUS-DP-V1 timeout

The following figure shows the corresponding project planning for the MOVIPRO® in the hardware configuration of STEP7. For more information, see the section "DP configurations (page 32)".



2426027531

6.2 PROFIBUS-DP-V1 timeout

The response monitoring time of the MOVIPRO® elapses if data transfer via the PROFIBUS DP system is disrupted or interrupted (according to the project planning for the DP master). The LED S1 lights up to indicate that no new user data is being received.




6.3 Parameterization via PROFIBUS DP

In the PROFIBUS-DP system, the parameters are accessed via the 8-byte MOVILINK[®] parameter channel. This parameter channel offers extra parameter services in addition to the conventional *Read* and *Write* services.

6.3.1 Structure of the 8-byte MOVILINK[®] parameter channel

With PROFIBUS DP, the MOVIPRO[®] parameters are accessed via the "parameter process data object" (PPO). This PPO is transmitted cyclically and contains the process data channel as well as a parameter channel that is used to exchange acyclical parameter values.



2426118795

The following table shows the structure of the 8-byte MOVILINK[®] parameter channel. Its basic structure is as follows:

- One management byte
- One reserved byte
- Two index bytes
- Four data bytes

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
Management	Subindex	Index high	Index low	Data MSB	Data	Data	Data LSB
		Parameter index		4-byte data			



*Management of
the 8-byte
MOVILINK®
parameter channel*

The entire procedure for setting parameters is coordinated using management byte 0. This byte provides important service parameters such as service identifier, data length, version and status of the service performed.

The following table shows the structure of the 8-byte MOVILINK® parameter channel.

7/MSB	6	5	4	3	2	1	0/LSB
		Data length 00 = 1 byte 01 = 2 bytes 10 = 3 bytes 11 = 4 bytes (must be set)	Service identifier 0000 = No service 0001 = Read parameter 0010 = Write parameter 0011 = Write parameter volatile 0100 = Read minimum 0101 = Read maximum 0110 = Read default 0111 = Read scale 1000 = Read attribute				
			Handshake bit Must be changed on every new task in cyclical transmission.				
			Status bit 0 = No error during execution of service 1 = Error during execution of service				

- Bits 0, 1, 2 and 3 contain the service identifier. These bits determine which service is to be executed.
- Bit 4 and bit 5 specify the data length in bytes for the write service; For MOVIPRO®, it should be set to 4 bytes.
- Bit 6 serves as the handshake between the higher-level controller and the MOVIPRO®. Bit 6 triggers the implementation of the transmitted service in the control card. In PROFIBUS DP the parameter channel is transmitted cyclically with the process data. This is why the implementation of the service in the MOVIPRO® must be triggered by edge control using the handshake bit 6. For this purpose, the value of this bit is toggled for each new service to be executed. The MOVIPRO® uses handshake bit 6 to signal whether the service has been executed or not. The service was executed if the handshake bit received in the controller is identical with the transmitted handshake bit.
- Status bit 7 indicates whether the service was carried out properly or if errors occurred.



Index addressing "Byte 2: Index high" and "Byte 3: Index low" determines the parameter that is to be read or written via the fieldbus system. The parameters of the MOVIPRO® are addressed with a uniform index regardless of the connected fieldbus system.

Byte 1 is the subindex.

Data range As shown in the following table, the data is contained in byte 4 through byte 7 of the parameter channel. This means up to 4 bytes of data can be transmitted per service. The data is always entered with right-justification; that is, byte 7 contains the least significant data byte (Data LSB) whereas byte 4 is the most significant data byte (Data MSB).

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
Management	Subindex	Index high	Index low	Data MSB	Data	Data	Data LSB
				High byte 1	Low byte 1	High byte 2	Low byte 2
				High word		Low word	
				Double word			

Incorrect service execution The status bit in management byte 0 is set to signal that a service has been executed incorrectly. If the received handshake bit is identical to the transmitted handshake bit, the MOVIPRO® has executed the service. If the status bit now signals an error, the error code is entered in the data range of the parameter telegram. Bytes 4 – 7 send back the return code in a structured format. For further information, refer to section "Parameterization – return codes" (page 43).

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
Management	Subindex	Index high	Index low	Error class	Error code	Add. code high	Add. code low
Status bit = 1: Incorrect service execution							



6.3.2 Reading a parameter via PROFIBUS DP (Read)

Due to the cyclical transfer of the parameter channel, to execute a read service via the 8 byte MOVILINK[®] parameter channel, the handshake bit may only be changed if the complete parameter channel has been set up for the specific service. Observe the following sequence when reading a parameter:

1. Enter the index of the parameter to be read in byte 2 (index high) and byte 3 (index low).
2. Enter the service identifier for the read service in the management byte (byte 0).
3. Change the handshake bit to assign the read service to the MOVIPRO[®].

Since this is a read service, the sent data bytes (bytes 4 – 7) and the data length in the management byte are ignored and do not need to be set.

Now the MOVIPRO[®] processes the read service and returns the confirmation once the handshake bit changes.

7/MSB	6	5	4	3	2	1	0/LSB
0	0/1 ¹⁾	X ²⁾	X ²⁾	0	0	0	1
				Service identifier 0001 = Read parameter			
				Data length Irrelevant for read service			
				Handshake bit Must be changed on every new task in cyclical transmission.			
Status bit 0 = No error during execution of service 1 = Error during execution of service							

1) Bit value is changed

2) Not relevant

The table above illustrates the coding of a read service in management byte 0. The data length is irrelevant, you merely have to enter the service identifier for the read service. This service is now activated in the MOVIPRO[®] when the handshake bit changes. You could, for example, activate the read service with the management byte coding 01hex or 41_{hex}.



6.3.3 Writing a parameter via PROFIBUS DP (Write)

Due to the cyclical transfer of the parameter channel, to execute a write service via the 8 byte MOVILINK[®] parameter channel, the handshake bit may only be changed if the complete parameter channel has been set up for the specific service. Observe the following sequence when writing a parameter:

1. Enter the index of the parameter to be written in byte 2 (index high) and byte 3 (index low).
2. Enter the data to be written in bytes 4 – 7.
3. Enter the service identifier and the data length for the write service in the management byte (byte 0).
4. Change the handshake bit to assign the write service to the MOVIPRO[®].

Now the MOVIPRO[®] processes the write service and returns the confirmation once the handshake bit changes.

The following table illustrates the coding of a write service management byte 0. The data length for all MOVIPRO[®] parameters is 4 bytes. Now this service is assigned to the MOVIPRO[®] once the handshake bit changes. Thus, a write service to MOVIPRO[®] generally has the coding of the management byte 32_{hex} or 72_{hex}.

7/MSB	6	5	4	3	2	1	0/LSB
0	0/1 ¹⁾	1	1	0	0	1	0
			Service identifier 0010 = Write parameter				
			Data length 11 = 4 bytes				
			Handshake bit Must be changed on every new task in cyclical transmission.				
			Status bit 0 = No error during execution of service 1 = Error during execution of service				

1) Bit value is changed



6.3.4 Parameter setting sequence with PROFIBUS DP

Taking the example of the write service, the following table illustrates the parameterization sequence between the higher-level controller and MOVIPRO® via PROFIBUS DP. To simplify the sequence, only the management byte of the parameter channel is shown here.

While the parameter channel is being prepared for the write service by the higher-level controller, the MOVIPRO® merely sends and returns it. The service is not activated until the handshake bit has changed (in this example from 0 to 1). The MOVIPRO® interprets the parameter channel and processes the write service. However, it continues to respond to all telegrams with handshake bit = 0.

Confirmation that the service has been performed occurs when the handshake bit in the response telegram of the MOVIPRO® is changed. The higher-level controller detects that the received handshake bit is the same as the one that was sent. It can prepare another parameterization.

Controller	PROFIBUS-DP(V0)	MOVIPRO® (Slave)
	– 00110010XXX... →	Parameter channel is received, but not evaluated
	← 00110010XXX... –	
Parameter channel is prepared for write service		
Handshake bit changes and the service is assigned to the MOVIPRO®	– 01110010XXX... →	
	← 00110010XXX... –	
	– 01110010XXX... →	
	← 00110010XXX... –	Write service is performed, handshake bit is changed
Service confirmation is received as the send and receive handshake bits are the same again	← 01110010XXX... –	
	– 01110010XXX... →	Parameter channel is received, but not evaluated

6.3.5 Parameter data format

Parameterization via the fieldbus interface uses the same parameter coding as parameterization via the serial RS485 interface or the system bus.



6.4 Parameterization – return codes

6.4.1 Elements

In the event of an incorrect parameterization, the MOVIPRO® sends back various return codes to the respective master. These codes provide detailed information about the cause for the error. Generally, these return codes are structured. SEW distinguishes between the following elements:

- *Error class*
- *Error code*
- *Additional code*

These return codes are described in detail in the Fieldbus Communications Profile manual and are not included in this documentation. However, the following special cases can occur in connection with PROFIBUS:

6.4.2 Error class

The *error class* element provides a more exact classification of the error type. The MOVIPRO® supports the following error classes defined according to EN 50170(V2):

Class (hex)	Designation	Meaning
1	vfd state	Status error of the virtual field device
2	application reference	Error in application program
3	definition	Definition error
4	resource	Resource error
5	service	Error during execution of service
6	access	Access error
7	ov	Error in the object list
8	other	Other error (→ Additional code)

6.4.3 Error code

The *Error code* element allows you to clearly identify the cause for the error within the *Error class*. It is generated by the communication software of the fieldbus card in the event of a faulty communication. For *Error class 8 = Other error*, only *Error code = 0 (Other error code)* is defined. In this case, detailed identification is made using the *additional code*.

6.4.4 Additional code

The *Additional code* contains SEW-specific return codes for incorrect parameterization of the MOVIPRO®. These codes are returned to the master under *Error class 8 = Other error*. The following table shows all possible coding for the *Additional code*.

Add. code high (hex)	Add. code low (hex)	Meaning
00	00	No error
00	10	Illegal parameter index
00	11	Function/parameter not implemented
00	12	Read access only
00	13	Parameter lock is active
00	14	Factory setting is active
00	15	Value for parameter too large
00	16	Value for parameter too small
00	17	Reserved



Add. code high (hex)	Add. code low (hex)	Meaning
00	18	Error in system software
00	19	Reserved
00	1A	Parameter access only via RS485 interface
00	1B	Parameter is access-protected
00	1C	Reserved
00	1D	Invalid value for parameter
00	1E	Factory setting was activated
00	1F	Reserved
00	20	Reserved

6.5 Special cases

6.5.1 Special return codes

Parameterization errors that cannot be identified either automatically by the application layer of the fieldbus system or by the system software of the MOVIPRO® are treated as special cases. These errors are:

- incorrect coding of a service via parameter channel
- incorrect length specification of a service via parameter channel
- internal communication error

Incorrect service code in the parameter channel

Incorrect code was specified in the management and reserved byte during parameterization via the parameter channel. The following table shows the return code for this special case.

	Code (dec)	Meaning
Error class:	5	Service
Error code:	5	Illegal parameter
Add. code high:	0	-
Add. code low:	0	-

Troubleshooting:

Check bits 0 and 1 in the parameter channel.


Incorrect length specification in parameter channel

A data length other than 4 data bytes was specified in a read or write service during parameterization via the parameter channel. The following table displays the return codes.

	Code (dec)	Meaning
Error class:	6	Access
Error code:	8	Type conflict
Add. code high:	0	-
Add. code low:	0	-

Troubleshooting:

Check bit 4 and bit 5 for the data length in management byte 0 of the parameter channel. Both bits must be set to "1".



Internal communication error

The return code listed in the following table is sent back if an internal communication error has occurred. The parameter service transferred via the fieldbus may not have been performed and should be repeated. If this error reoccurs, switch the MOVIPRO® off and on again to reinitialize the unit.

	Code (dec)	Meaning
Error class:	6	Access
Error code:	2	Hardware fault
Add. code high:	0	-
Add. code low:	0	-

Troubleshooting:

Repeat the read or write service. If the error reoccurs, briefly disconnect the MOVIPRO® from the power supply and switch the system on again. If the error persists, consult SEW Service.



7 PROFIBUS DP-V1 Functions

This section provides you with information about the PROFIBUS DP-V1 functions.

7.1 PROFIBUS DP-V1 – introduction

This section describes the functions and terms used for operating SEW units on PROFIBUS DP-V1. Refer to the PROFIBUS user organization or visit www.profibus.com for detailed technical information on PROFIBUS DP-V1.


The PROFIBUS DP-V1 specification introduced new acyclical *READ/WRITE* services within the context of the PROFIBUS DP-V1 expansions. These acyclical services are inserted in special telegrams during cyclical bus operation to ensure compatibility between PROFIBUS DP (version 0) and PROFIBUS DP-V1 (version 1).

The acyclical *READ/WRITE* services can be used to exchange larger data quantities between master and slave (inverter) than it would be possible to transfer in the cyclical input or output data using the 8-byte parameter channel, for example. The advantage of the acyclical data exchange via DP-V1 lies in the minimum load on the cyclical bus operation since DP-V1 telegrams are only added to the bus cycle if required.


The DP-V1 parameter channel provides 2 options:

- The higher-level controller can access all the device information of the SEW DP-V1 slaves. This means that cyclical process data and unit settings can be read, stored in the controller and modified in the slave.
- It is also possible to route the service and startup tool MOVITOOLS® MotionStudio via the DP-V1 parameter channel instead of using the Ethernet service interface. Once you have installed MOVITOOLS® MotionStudio, you can access detailed information in the folder "...\\SEW\\MOVITOOLS\\Fieldbus".

The main features of PROFIBUS DP-V1 are explained below.



2347372555



7.1.1 Class 1 master (C1 master)

The PROFIBUS DP-V1 network differentiates between master classes. The C1 master essentially performs the cyclical data exchange with the slaves. A typical C1 master is a control system, such as a PLC, that exchanges cyclical process data with the slave. If the DP-V1 function has been activated via the GSD file, the acyclical connection between C1 master and slave is established automatically when the cyclical connection of the PROFIBUS DP-V1 is being established. Only one C1 master can be operated in a PROFIBUS DP-V1 network.

7.1.2 Class 2 master (C2 master)

The C2 master itself does not perform cyclical data exchange with the slaves. Examples for a typical C2 master are visualization systems or temporary installed programming devices (Notebook / PC). The C2 master uses exclusively acyclical connections for communication with the slaves. The acyclical connections between C2 master and slave are established by the *Initiate* service. The connection is established once the *Initiate* service has been performed successfully. An established connection enables cyclical data exchange with the slaves using *READ* or *WRITE* services. Several C2 masters can be active in a DP-V1 network. The number of C2 connections, established simultaneously for a slave, is determined by the slave. SEW inverters support two parallel C2 connections.

7.1.3 Data sets (DS)

User data transported via a DP-V1 service is collected in data sets. Each data set is represented uniquely by its length, a slot number and an index. The structure of data set 47 is used for DP-V1 communication with the SEW inverter. This data set is defined as the DP-V1 parameter channel for drives as of V3.1 in the PROFIdrive profile "Drive engineering" of the PROFIBUS Nutzerorganisation (user group). Different procedures for accessing parameter data in the inverter are provided via this parameter channel.

7.1.4 DP-V1 services

The DP-V1 expansions offer new services, which can be used for acyclical data exchange between master and slave. The system distinguishes between the following services:

C1 master	Connection type: MSAC1 (master/slave acyclical C1)
READ	Read data set
WRITE	Write data set
C2 master	Connection type: MSAC2 (master/slave acyclical C2)
INITIATE	Establish C2 connection
ABORT	Disconnect C2 connection
READ	Read data set
WRITE	Write data set


7.1.5 DP-V1 alarm handling

In addition to the acyclical services, the DP-V1 specification also defines extended alarm handling. Alarm handling now distinguishes between different alarm types. As a result, unit-specific diagnostics cannot be evaluated in DP-V1 operation using the "DDL_M_SlaveDiag" DP-V0 service. DP-V1 alarm handling has not been defined for drive engineering as an inverter does not usually transfer its status information via cyclical process data communication.


7.2 Features of SEW fieldbus interfaces

The SEW fieldbus interfaces to PROFIBUS DP-V1 have the same communication features for the DP-V1 interface. The drives are usually controlled via a C1 master with cyclical process data in accordance with the DP-V1 standard. The READ and WRITE services give the C1 master access to the parameters of the fieldbus gateway and lower-level stations via the DP-V1 C1 channel.

Two additional C2 channels can be connected in parallel to these parameterization channels. The first C2 master as a visualization device, for example could use these channels to read parameter data, and a second C2 master in the form of a notebook could use them to configure the drive using the MOVITOOLS® MotionStudio software.




2344619659



7.3 Structure of the DP-V1 parameter channel

Generally, the parameterization of the drives is implemented via data set 47 according to the PROFIdrive Base Mode Parameter Access of profile version 4.0. The *Request ID* entry is used to distinguish between parameter access based on the PROFIdrive profile or via SEW MOVILINK® services. The following table shows the possible codes of the individual elements. The dataset structure is the same for PROFIdrive and MOVILINK® access.



2348887051

The following MOVILINK® services are supported:

- 8-byte MOVILINK® parameter channel with all the services supported by the SEW device such as
 - READ parameter
 - WRITE parameter
 - WRITE parameter volatile
 - etc.

The following PROFIdrive services are supported:

- Reading (request parameter) individual parameters of the type *double word*
- Writing (change parameter) individual parameters of the type *double word*

Field	Data type	Values
Request reference	Unsigned8	0x00 Reserved 0x01 – 0xFF
Request ID	Unsigned8	0x01 Request parameter (PROFIdrive) 0x02 Change parameter (PROFIdrive) 0x40 SEW MOVILINK® service
Response ID	Unsigned8	<u>Response (+):</u> 0x00 Reserved 0x01 Request parameter (+) (PROFIdrive) 0x02 Change parameter (+) (PROFIdrive) 0x40 SEW MOVILINK® service (+) <u>Response (-):</u> 0x81 Request parameter (-) (PROFIdrive) 0x82 Change parameter (-) (PROFIdrive) 0xC0 SEW MOVILINK® service (-)
Axis	Unsigned8	0x00 – 0xFF Number of axes 0 – 255
No. of parameters	Unsigned8	0x01 – 0x13 1 – 19 DWORDs (240 data bytes)
Attributes	Unsigned8	0x10 Value For SEW MOVILINK® (Request ID = 0x40): 0x00 No service 0x10 READ parameter 0x20 WRITE parameter 0x30 WRITE parameter volatile 0x40 – 0xF0 Reserved
No. of elements	Unsigned8	0x00 For parameters that are not indexed 0x01 – 0x75 Quantity 1 – 117
Parameter Number	Unsigned16	0x0000 – 0xFFFF MOVILINK® parameter index
Subindex	Unsigned16	0x0000 SEW: always 0




Field	Data type	Values
Format	Unsigned8	0x43 Double word 0x44 Error
No. of Values	Unsigned8	0x00 – 0xEA Quantity 0 – 234
Error Value	Unsigned16	0x0000 – 0x0064 PROFIdrive error codes 0x0080 + MOVILINK® additional code low For SEW MOVILINK® 16 Bit error value

7.3.1 Parameterization procedure via data set 47


Parameter access is provided by the combination of the DP-V1 services WRITE and READ. The parameter setting service is transferred to the slave with WRITE.request, followed by slave-internal processing.

The master now sends a READ.request to pick up the parameterization response. The master repeats the READ.request if the READ.response from the slave is negative. It sends a positive READ.response once the parameter processing in the inverter has been completed. The user data now comprise the parameterization response to the parameterization order sent with WRITE.request. This mechanism applies to both, C1 and C2 masters.

The following figure shows the telegram sequence for the parameter access via PROFIBUS DP-V1:




2348900235



7.3.2 Processing sequence for DP-V1 masters

If the bus cycles are very short, the request for the parameter response arrives before the SEW device has concluded the parameter access in the device. This means that the response data from the SEW device is not available yet. In this case, the inverter sends a negative answer with the Error_Code _1 = 0xB5 (status conflict) to the DP-V1 level. The DP-V1 master must continue to send the READ.request header mentioned above until it receives a positive response from the inverter.



2349546507




7.3.3 Addressing a MOVIPRO® in a PROFIBUS network

The structure of the DS47 data set defines an *axis* element. This element is used to reach multi-axis drives that are operated via one PROFIBUS interface. The *Axis* element addresses one of the units connected via the PROFIBUS interface. This approach is used for the following SEW bus modules:

- DHF
- UFF
- MOVIFIT®
- MOVIPRO®
- MQP for MOVIMOT®
- DFP for MOVITRAC® B

Addressing a
MOVIPRO® via
PROFIBUS DP-V1

With the setting *Axis* = 0, the parameters of the MOVIPRO® are accessed. In order to access the internal "PFA-.." power section, set *Axis* = 20.



2349586187

Axis = 0 → MOVIPRO® "PFH-.." communication and control unit
Axis = 20 → MOVIPRO® "PFA-.." power section

7.3.4 MOVILINK® parameter requests


The MOVILINK® parameter channel of the SEW inverter is directly mapped in the structure of dataset 47. The Request ID 0x40 (SEW MOVILINK® service) is used to exchange MOVILINK® parameter setting requests. Parameter access with MOVILINK® services usually takes place according to the structure described below. The typical message sequence for dataset 47 is used.

Request ID: 0x40 SEW MOVILINK® service

The actual service is defined by the dataset element *Attribute* in the MOVILINK® parameter channel. The high nibble of the element corresponds to the MOVILINK® service code.

Example for reading a parameter via MOVILINK®

The following tables show an example of the structure of the WRITE.request and READ.response user data for reading an individual parameter via the MOVILINK® parameter channel. In this example, the firmware of the "PFA-.." power section connected



to CAN 1 of the "PFH-.." communication and power section with SBus address 20 is read.

Sending a parameter request

The table shows the coding of the user data for the WRITE.request service specifying the DP-V1 header. The WRITE.request service is used to transfer the parameterization request to the inverter. The firmware version is read.

Service	WRITE. request	Description
Slot_Number	0	Random (is not evaluated)
Index	47	Index of the data set; constant index 47
Length	10	10 byte user data for parameter request

Byte	Field	Value	Description
0	Request reference	0x01	Individual reference number for the parameterization request is mirrored in the parameterization response
1	Request ID	0x40	SEW MOVILINK® service
2	SBus address of the MOVIPRO® power section	0x14	Axis number; 0x14 = SBus address 20 at CAN 1
3	No. of parameters	0x01	1 parameter
4	Attributes	0x10	MOVILINK® "READ Parameter" service
5	No. of elements	0x00	0 = access to direct value, no subelement
6, 7	Parameter Number	0x206C	MOVILINK® index 8300 = "Firmware version"
8, 9	Subindex	0x0000	Subindex 0

Query parameter response

The following table shows the coding of the READ.request user data including the PROFIBUS header.

Service	READ. request	Description
Slot_Number	0	Random (is not evaluated)
Index	47	Index of the data set; constant index 47
Length	240	Maximum length of response buffer in the DP-V1 master



Positive
MOVILINK®
parameterization
response

The table shows the READ.response user data with the positive response data of the parameter setting request. The parameter value for index 8300 (firmware version) is returned as an example.

Service	READ. request	Description
Slot_Number	0	Random (is not evaluated)
Index	47	Index of the data set; constant index 47
Length	10	10 byte user data in response buffer

Byte	Field	Value	Description
0	Response reference	0x01	Mirrored reference number from the parameterization request
1	Response ID	0x40	Positive MOVILINK® response
2	Axis	0x14	Mirrored axis number; 0x14 = SBus address 20
3	No. of parameters	0x01	1 parameter
4	Format	0x43	Parameter format: Double word
5	No. of values	0x01	1 value
6, 7	Value High	0x311C	Higher-order part of the parameter
8, 9	Value Low	0x7289	Lower-order part of the parameter
			Decoding: 0x311C 7289 = 823947913 _{dec} → firmware version 823 947 9.1

Example for writing
a parameter via
MOVILINK®


The following tables show the structure of the *WRITE* and *READ* services for volatile writing of the value 1500 to parameter *P302 maximum speed 1* (parameter list 8517). The MOVILINK® *WRITE Parameter volatile* service is used for this purpose. In this example, the power section with SBus address 20 is also connected to the control unit.

Send "WRITE
parameter volatile"
request

Service:	WRITE.request	Description
Slot_Number	0	Random (is not evaluated)
Index	47	Index of the data set; constant index 47
Length	16	16-byte user data for order buffer

Byte	Field	Value	Description
0	Request reference	0x01	Individual reference number for the parameter setting request is mirrored in the parameter response.
1	Request ID	0x40	SEW MOVILINK® service
2	Axis	0x14	Axis number; 0x14 = SBus address 20 of the power section
3	No. of parameters	0x01	1 parameter
4	Attributes	0x30	MOVILINK® "Write parameter volatile" service
5	No. of elements	0x00	0 = access to direct value, no subelement
6, 7	Parameter Number	0x2145	Parameter index 8517 = "maximum speed 1"
8, 9	Subindex	0x0000	Subindex 0
10	Format	0x43	Double word
11	No. of values	0x01	Change 1 parameter value
12, 13	Value HiWord	0x0000	Higher-order part of the parameter value
14, 15	Value LoWord	0x05DC	Lower-order part of the parameter value

After sending this WRITE.request, the WRITE.response is received. If there was no status conflict in processing the parameter channel, a positive WRITE.response occurs. Otherwise, the status error is located in Error_code_1.



Query parameter response

The following table shows the coding of the WRITE.request user data including the DP-V1 header.

Service	READ. request	Description
Function_Num		READ.req
Slot_Number	X	Slot_Number not used
Index	47	Index of the data set
Length	240	Maximum length of response buffer in the DP master

Positive response to "WRITE parameter volatile"

Service	READ. response	Description
Slot_Number	0	Random (is not evaluated)
Index	47	Index of the data set; constant index 47
Length	4	4 byte user data in response buffer

Byte	Field	Value	Description
0	Response reference	0x01	Mirrored reference number from the parameterization request
1	Response ID	0x40	Positive MOVILINK® response
2	Axis	0x14	Mirrored axis number; 0x14 = SBus address 20
3	No. of parameters	0x01	1 parameter

Negative parameter response

The following tables show the coding of a negative response of a MOVILINK® service. Bit 7 is entered in the Response ID if the response is negative.

Service	WRITE.response	Description
Slot_Number	0	Random (is not evaluated)
Index	47	Index of the data set; constant index 47
Length	8	8 byte user data in response buffer

Byte	Field	Value	Description
0	Response reference	0x01	Mirrored reference number from the parameterization request
1	Response ID	0xC0	Negative MOVILINK® response
2	Axis	0x14	Mirrored axis number; 0x14 = SBus address 20
3	No. of parameters	0x01	1 parameter
4	Format	0x44	Error
5	No. of values	0x01	1 Error code
6, 7	Error value	0x0811	MOVILINK® return codes e.g. error class 0x08, Add. code 0x11

MOVILINK® return codes for DP-V1

The following table shows the return codes that are returned by the SEW DP-V1 interface if an error occurs during DP-V1 parameter access.

MOVILINK® return code (hex)	Description
0x0810	Invalid index, parameter index does not exist in the unit
0x0811	Function/parameter not implemented
0x0812	Read access only
0x0813	Parameter lock activated
0x0814	Factory setting is active
0x0815	Value for parameter too large
0x0816	Value for parameter too small



MOVILINK® return code (hex)	Description
0x0817	Required option card not installed
0x0818	Error in system software
0x0819	Parameter access only via RS-485 process interface
0x081A	Parameter access only via RS-485 diagnostics interface
0x081B	Parameter is access-protected
0x081C	Controller inhibit is required
0x081D	Invalid value for parameter
0x081E	Factory setting was activated
0x081F	Parameter was not saved in EEPROM
0x0820	Parameter cannot be changed with output stage enabled / reserved
0x0821	Reserved
0x0822	Reserved
0x0823	Parameter may only be changed at IPOS program stop
0x0824	Parameter may only be changed when auto setup is deactivated
0x0505	Incorrect coding of management and reserved byte
0x0602	Communication error between inverter system and fieldbus interface
0x0502	Timeout of secondary connection (e.g. during reset or with Sys-Fault)

7.3.5 PROFIdrive parameter requests

The PROFIdrive parameter channel of SEW inverters is directly mapped in the structure of data set 47. Parameter access with PROFIdrive services usually takes place according to the structure described below. The typical telegram sequence is used for data set 47. PROFIdrive only defines the two request IDs

Request ID: 0x01 request parameter (PROFIdrive)

Request ID: 0x02 change parameter (PROFIdrive)

. This means there is restricted data access in comparison with the MOVILINK® services.




INFORMATION

The request ID = 0x02 = change parameter (PROFIdrive) results in remanent write access to the selected parameter. Consequently, the internal flash/EEPROM of the inverter is written with each write access. Use the MOVILINK® "WRITE Parameter volatile" service if parameters must be written cyclically at short intervals. With this service, you only alter the parameter values in the RAM of the inverter.

Example for reading a parameter via PROFIdrive

The following tables show an example of the structure of the WRITE.request and READ.response user data for reading an individual parameter via the MOVILINK® parameter channel.



Sending a parameter request

The table shows the coding of the user data for the WRITE.request service specifying the DP-V1 header. The WRITE.request service is used to transfer the parameterization request to the inverter.

Service:	WRITE.request	Description
Slot_Number	0	Random (is not evaluated)
Index	47	Index of the data set; constant index 47
Length	10	10 byte user data for parameter request

Byte	Field	Value	Description
0	Request reference	0x01	Individual reference number for the parameterization request is mirrored in the parameterization response
1	Request ID	0x01	Request parameter (PROFIdrive)
2	Axis	0x14	Axis number; 0x14 = SBus address 20
3	No. of parameters	0x01	1 parameter
4	Attributes	0x10	Access to parameter value
5	No. of elements	0x00	0 = access to direct value, no subelement
6, 7	Parameter Number	0x206C	MOVILINK® index 8300 = "Firmware version"
8, 9	Subindex	0x0000	Subindex 0

Query parameter response

The following table shows the coding of the READ.request user data including the DP-V1 header.

Service:	READ.request	Description
Slot_Number	0	Random (is not evaluated)
Index	47	Index of the data set; constant index 47
Length	240	Maximum length of response buffer in the DP-V1 master

Positive PROFIdrive parameterization response

The table shows the READ.response user data with the positive response data of the parameter setting request. The parameter value for index 8300 (firmware version) is returned as an example.

Service:	READ.request	Description
Slot_Number	0	Random (is not evaluated)
Index	47	Index of the data set; constant index 47
Length	10	10 byte user data in response buffer

Byte	Field	Value	Description
0	Response reference	0x01	Mirrored reference number from the parameterization request
1	Response ID	0x01	Positive response for "Request Parameter"
2	Axis	0x14	Mirrored axis number; 0x14 = SBus address 20
3	No. of parameters	0x01	1 parameter
4	Format	0x43	Parameter format: Double word
5	No. of Values	0x01	1 value
6, 7	Value High	0x311C	Higher-order part of the parameter
8, 9	Value Low	0x7289	Lower-order part of the parameter
			Decoding: 0x311C 7289 = 823947913 _{dec} → firmware version 823 947 9.13

Example for writing a parameter via PROFIdrive

The following tables show the structure of the WRITE and READ services for remanent writing of the internal setpoint n11. For this purpose, the PROFIdrive service *Change parameter* is used.



Send "WRITE
parameter" request

Service:	WRITE.request	Description
Slot_Number	0	Random (is not evaluated)
Index	47	Index of the data set; constant index 47
Length	16	16-byte user data for order buffer


Byte	Field	Value	Description
0	Request reference	0x01	Individual reference number for the parameterization request is mirrored in the parameterization response
1	Request ID	0x02	Change parameter (PROFIdrive)
2	Axis	0x14	Axis number; 0x14 = SBus address 20
3	No. of parameters	0x01	1 parameter
4	Attributes	0x10	Access to parameter value
5	No. of elements	0x00	0 = access to direct value, no subelement
6, 7	Parameter Number	0x2145	Parameter index 8517 = P302 maximum speed
8, 9	Subindex	0x0000	Subindex 0
10	Format	0x43	Double word
11	No. of Values	0x01	Change 1 parameter value
12, 13	Value High word	0x0000	Higher-order part of the parameter value
14, 15	Value Low word	0x0BB8	Lower-order part of the parameter value

After sending this WRITE.request, the WRITE.response is received. If there was no status conflict in processing the parameter channel, a positive WRITE.response occurs. Otherwise, the status error is located in Error_code_1.

Query parameter
response

The following table shows the coding of the WRITE.request user data including the DPV1 header.

Service	Write.request	Description
Function_Num		READ.req
Slot_Number	X	Random (is not evaluated)
Index	47	Index of the data set
Length	240	Maximum length of response buffer in the DP-V1 master



Positive response
to "WRITE parameter"

Service:	READ.response	Description
Slot_Number	0	Random (is not evaluated)
Index	47	Index of the data set; constant index 47
Length	4	4 byte user data in response buffer

Byte	Field	Value	Description
0	Response reference	0x01	Mirrored reference number from the parameterization request
1	Response ID	0x02	Positive PROFIdrive response
2	Axis	0x14	Mirrored axis number; 0x14 = SBus address 20
3	No. of parameters	0x01	1 parameter

Negative parameter response

The following table shows the coding of a negative response of a PROFIdrive service. Bit 7 is entered in the response ID if the response is negative.

Service:	READ.response	Description
Slot_Number	0	Random (is not evaluated)
Index	47	Index of the data set; constant index 47
Length	8	8 byte user data in response buffer

Byte	Field	Value	Description
0	Response reference	0x01	Mirrored reference number from the parameterization request
1	Response ID	0x810x82	Negative response for "Request Parameter" Negative response for "Change Parameter"
2	Axis	0x14	Mirrored axis number; 0x14 = SBus address 20
3	No. of parameters	0x01	1 parameter
4	Format	0x44	Error
5	No. of values	0x01	1 Error code
6, 7	Error value	0x0811	MOVILINK® return code e.g. error class 0x08, Add. code 0x11

PROFIdrive return codes for DP-V1

The following table shows the coding of the error number in the PROFIdrive parameter response according to PROFIdrive profile V3.1. This table applies if you use the PROFIdrive services "Request parameter" and/or "Change parameter".

Error no.	Meaning	Used for
0x00	Invalid parameter number.	Access to non-existent parameters
0x01	Parameter value cannot be changed	An attempt was made to change a parameter value that cannot be changed
0x02	Minimum or maximum value exceeded	An attempt was made to change a value to one that is outside of the limit values
0x03	Incorrect subindex	Access to non-existent subindex
0x04	No assignment	Access with subindex to parameter that is not indexed
0x05	Incorrect data type	An attempt was made to change a replace a value with one that does not correspond to the data type of the parameter
0x06	Setting not permitted (can only be reset)	An attempt was made to set a value to one larger than 0 where this is not permitted
0x07	Description element cannot be changed	Access to description element that cannot be changed
0x08	Reserved	(PROFIdrive Profile V2: PPO write query for IR not available)




Error no.	Meaning	Used for
0x09	Description does not exist	Access to description that is not accessible (parameter value exists)
0x0A	Reserved	(PROFIdrive Profile V2: incorrect access group)
0x0B	No operation priority	An attempt was made to change a parameter without change rights
0x0C	Reserved	(PROFIdrive Profile V2: incorrect password)
0x0D	Reserved	(PROFIdrive Profile V2: text cannot be read in cyclic data transfer)
0x0E	Reserved	(PROFIdrive Profile V2: name cannot be read in cyclic data transfer)
0x0F	No text assignment available	Access to text assignment that is not accessible (parameter value exists)
0x10	Reserved	(PROFIdrive Profile V2: no PPO write)
0x11	Request cannot be executed due to the operating mode	Access is currently not possible and the reason is not explained
0x12	Reserved	(PROFIdrive Profile V2: other error)
0x13	Reserved	(PROFIdrive Profile V2: data cannot be read in cyclic exchange)
0x14	Incorrect value	An attempt was made to change a value to one that is in the permitted range but is not permitted due to other long-term reasons (parameter with specified individual values)
0x15	Response is too long	The length of the current response exceeds the maximum transmittable length
0x16	Invalid parameter address	Invalid value or value that is not valid for this attribute, number of elements, parameter number, subindex or a combination of these factors.
0x17	Incorrect format	Write request: Invalid format or parameter data format that is not supported
0x18	Number of values is not consistent	Write request: Number of values of parameter data does not correspond to the number of elements in the parameter address
0x19	Axis does not exist	Access to an axis that does not exist
up to 0x64	Reserved	–
0x65–0xFF	Depends on the manufacturer	–

7.4 Project planning for a C1 master

The GSD file, SEW_600E.GSD, is required for the project planning of a DP-V1 C1 master. This file activates the DP-V1 functions of the MOVIPRO®.

7.4.1 Operating mode (DP-V1 mode)

The DP-V1 operating mode can usually be activated during project planning for a C1 master. All DP slaves, which have the DP-V1 functions enabled in their GSD files and which support DP-V1, will then be operated in DP-V1 mode. Standard DP slaves will still run via PROFIBUS DP-V0. This ensures mixed mode for DP-V1 and DP-V0 capable modules. Depending on the specification of the master functionality, a DP-V1-capable station that was configured using the DP-V1 GSD file, can run in the "DP-V0" operating mode.




7.4.2 SIMATIC S7 sample program



INFORMATION

- The MOVILINK® parameter channel sample program is available via the SEW homepage (www.sew-eurodrive.de)
- This example is a special and free service that demonstrates only the basic approach to generating a PLC program. SEW is not liable for the contents of the sample program.

Calling the function
module:



1747628683



Comment regarding the function module:


```
Write service: x2h, fixed setpoint: P160, index 8489d = 2129h

Wiring of FB:
"Drive_IO_Address": (INT)   Input address of the process data =>Hardware config.
"bService":         (BYTE)  Read: 01h; Write 02h, volatile writing 03h
"bAxis":            (BYTE)  Sub address/SBUS address of lower-level MC07
"wParameterindex": (WORD)   Parameter index => "MC07 Communication" manual
"wSubIndex":        (WORD)  MOVILINK subindex = 0
"dwWriteData":      (DWORD)  Parameter data for WRITE service
"InstanzDB_SFB52 (BLOCK_DB) Instance DB for the SFB52
"InstanzDB_SFB53 (BLOCK_DB) Instance DB for the SFB53
"fActivate"         (BOOL)   Activation bit
"fBusy":            (BOOL)   Parameter service is active
"fDone":            (BOOL)   Parameter service was executed
"bError":           (BYTE)   No error = 0; S7 error = 1; TimeOut = 2;
                        MOVILINK error = 3
"dwData":           (DWORD)  bError = 0 => Parameter value after READ service
                        bError = 1 => S7 error code
```

1748164107


7.4.3 Technical data DP-V1 for MOVIPRO®

DP-V1 for MOVIPRO®	
GSD file for DP-V1	SEW_600E.GSD
Module name for project planning	MOVIPRO
Number of parallel C2 connections	2
Supported data record	Index 47
Supported slot number	Recommended: 0
Manufacturer code	10A hex (SEW-EURODRIVE)
Profiles ID	3A
C2 response timeout	1 s
Max. length C1 channel	240 bytes
Max. length C2 channel	240 bytes



7.4.4 Error codes of the DP-V1 services

This table shows possible error codes of DP-V1 services that may occur in the event of an error in the communication on DP-V1 telegram level. This table is relevant if you want to write your own parameter assignment block because the error codes are directly reported back on the telegram level.



2433588491

Error_Class (from DP-V1 specification)	Error_Code (from DP-V1 specification)	DP-V1 parameter channel
0x0 – 0x9 hex = reserved		
0xA = application	0x0 = read error 0x1 = write error 0x2 = module failure 0x3 to 0x7 = reserved 0x8 = version conflict 0x9 = feature not supported 0xA to 0xF = user specific	
0xB = access	0x0 = invalid index	0xB0 = No data block Index 47 (DB47); parameter requests are not supported
	0x1 = write length error 0x2 = invalid slot 0x3 = type conflict 0x4 = invalid area	
	0x5 = state conflict	0xB5 = Access to DB 47 temporarily not possible due to internal processing status
	0x6 = access denied	
	0x7 = invalid range	0xB7 = WRITE DB 47 with error in the DB 47 header
	0x8 = invalid parameter 0x9 = invalid type 0xA to 0xF = user specific	
0xC = resource	0x0 = read constraint conflict 0x1 = write constraint conflict 0x2 = resource busy 0x3 = resource unavailable 0x4 – 0x7 = reserved 0x8 – 0xF = user-specific	
0xD – 0xF = user-specific		




8 Error Diagnostics

8.1 Diagnostics procedure – PROFIBUS DP-V1 operation

The following diagnostics procedure illustrates the error analysis procedure if the MOVIPRO® SDC unit is not working with PROFIBUS DP-V1.

Proceed as follows:





8.2 Fieldbus timeout

A fieldbus timeout can occur in MOVIPRO® when you switch off the fieldbus master or if there is a wire break in the fieldbus cabling. The "S1" LED indicates that no new user data is being received. The process data for all units have been set to "0". This means that all drives connected to MOVIPRO® are stopped. In addition, the digital outputs are set to "0".




DANGER

Risk of crushing if the drive starts up automatically.

Severe or fatal injuries.


- The "Fieldbus timeout" error resets automatically. Thus, the drives receive the current process output data from the controller once the fieldbus communication has restarted.
- If, for safety reasons, this is not permitted for the driven machine, disconnect the unit from the supply system before correcting the error.



9 Process Data Description


9.1 Overview of process data

The following illustration provides an overview of the assignment of the process output/ input data (PO/PI) of MOVIPRO® SDC:




9.2 MOVIPRO® control word

The following figure shows the assignment of the MOVIPRO® control word:




The following table shows the functions of the MOVIPRO® control word:

Bit	Meaning	Explanation
0 – 4	Reserved	0 = reserved
5	Reset application	If there is an error in the "PFH.." communication and control unit, an error reset is requested by changing this bit from 0 to 1 to 0.
6	Reset system	If there is an error in the "PFH.." communication and control unit, an error reset is requested by changing this bit from 0 to 1 to 0.
7 – 15	Reserved	0 = reserved



9.3 MOVIPRO® status word

The following figure shows the assignment of the MOVIPRO® status word:



Bits 8 – 15 are assigned depending on the value of bits 6 and 7 according to the following table:

Bit 6	Bit 7	Assignment of bits 8 – 15
0	0	MOVIPRO® unit status
1	0	MOVIPRO® warning
0	1	MOVIPRO® error

The following table shows the diagnostics information of the MOVIPRO® unit that is processed in the higher-level PLC application. The signals are transferred to the controller via parameters and, if necessary, via the process data channel.


The logical communication status "0" signals the status "OK" for each signal to ensure that no asynchronous startup sequences from the bus master and the PLC can cause incorrect diagnostic messages when the systems are started up (bus startup with user data = 0).


Bit	Diagnostic name via bus	Function and coding
0	Maintenance switch (mains OFF)	Maintenance switch (mains OFF) 1 = Maintenance switch activated (mains off) 0 = OK (not activated)
1 – 5	Reserved	0 = reserved
6	MOVIPRO® warning	MOVIPRO® warning 1 = MOVIPRO® warning present 0 = OK
7	MOVIPRO® error	MOVIPRO® error 1 = MOVIPRO® error present 0 = OK
8 – 15	Unit status/warning/error number/	Unit status (bit 6 = 0, bit 7 = 0): <ul style="list-style-type: none"> • 0: System startup • 1: Ready Warning (bit 6 = 1, bit 7 = 0) Error number (bit 6 = 0, bit 7 = 1) <ul style="list-style-type: none"> • 1: Configuration → no configuration available • 2: Configuration → Connection to configured units could not be established • 5: Process data to lower-level units stopped • 99: Internal system error • 110: Actuator voltage overload • 120: Overload sensor voltage group 1 • 121: Overload sensor voltage group 2



9.4 Digital inputs and outputs

The following figure shows the assignment of the output and input data for the digital inputs/outputs (12 DI/4 DIO):





9.5 *Process data of power section*

The process data words of the integrated power section on the MOVIDRIVE® platform are assigned differently depending on the application module used. The number of process data words can vary between 1 - 6 depending on the application module.

9.5.1 **Speed-controlled drive**

The process output/input data words of a speed-controlled drive (no application module loaded) are assigned as follows:

PO:

- PO1: Control word 1
- PO2: Setpoint speed
- PO3: Ramp

PI:

- PI1: Status word 1
- PI2: Actual speed
- PI3: Active current




Process Data Description

Process data of power section


Control word 1

The integrated power section is controlled via control word 1. The following illustration shows the assignment of control word 1:




The following table shows the assignment of control word 1:

Bit	Meaning	Explanation
0	Controller inhibit	0 = Enable 1 = Inhibit controller, activate brake
1	Enable/stop	0 = Stop 1 = Enable
2	Enable/stop	0 = Stop at the integrator or process ramp 1 = Enable
3	Hold control	0 = Hold control not activated 1 = Hold control activated
4	Integrator switchover	0 = Integrator 1 1 = Integrator 2
5	Parameter set switchover	0 = Parameter set 1 1 = Parameter set 2
6	Reset	If there is an error in the inverter power section, an error reset is requested by changing this bit from 0 to 1 to 1.




Bit	Meaning	Explanation
7	Reserved	For reserved bits, the value 0 must be transferred for later use
8	Direction of rotation for motor potentiometer	0 = CW direction of rotation 1 = CCW direction of rotation
9 – 10	Motor potentiometer acceleration/deceleration	10 9 0 0 = No change 1 0 = Down 0 1 = Up 1 1 = No change
11 – 12	Selection of the internal fixed setpoints n11 – n13 and n21 – n23	12 11 0 0 = Speed setpoint via PO2 0 1 = Internal setpoint n11 (n21) 1 0 = Internal setpoint n12 (n22) 1 1 = Internal setpoint n13 (n23)
13	Changing the fixed setpoint	0 = Fixed setpoints of the active parameter set selectable via bit 11/12 1 = Fixed setpoints of the other parameter set selectable via bit 11/12
14 – 15	Reserved	For reserved bits, the value 0 must be transferred for later use

The following figure shows the prioritization for the evaluation of bits relevant for enable in control word 1:



9007200623660683



Process Data Description

Process data of power section

Setpoint speed

Set to SPEED, the power section considers the setpoint value transferred via this process data word to be the speed setpoint if the selected operating mode (*P700/P701 operating mode 1/2*) allows a speed setpoint. If there is no speed setpoint programmed although a communication interface (FIELD BUS) has been set as setpoint source, the power section will use speed setpoint = 0.

Coding: 1 digit = 0.2 rpm

Example: 1000 rpm, direction of rotation CCW

Calculation: $-1000/0.2 = -5000_{\text{dec}} = \text{EC78}_{\text{hex}}$

Ramp

Set to RAMP, the power section considers the transmitted setpoint value to be an acceleration or deceleration ramp. The determined value corresponds to a time in ms and refers to a speed change of 3000 rpm. The stop and emergency stop functions are not affected by this process ramp. When transmitting the process ramp via fieldbus system, ramps t11, t12, t21 and t22 become ineffective.

Coding: 1 digit = 1 ms


Range: 100 ms - 65 s


Calculation: $2.0 \text{ s} = 2000 \text{ ms} = 2000_{\text{dec}} = \text{07D0}_{\text{hex}}$

Status word 1

In addition to the most important status information in the basic status block, status word 1 alternately contains information on the "unit status" or the "error number" in the higher-level status byte. Depending on the error bit, the unit status is displayed for error bit = 0, and the error number for error bit = 1 (fault). The error bit is reset by resetting the error, and the current unit status is displayed.

For the meaning of error numbers, refer to chapter "Error list of MOVIPRO® SDC" (page 158).





Bits 8 – 15 are assigned depending on the value of bit 5 according to the following table:

Bit 5		Assignment of bits 8 – 15	
0	No error/warning	MOVIPRO® unit status	Unit status: • 00: 24 V operation • 02: No enable
1	Fault/warning present	MOVIPRO® error	Error number: • 01: Overcurrent • 02: ...

Actual speed

Set to SPEED, the power section returns the current actual speed in "rpm" to the higher-level automation system. The exact actual speed can only be sent back when the power section can determine the actual motor speed using speed feedback. For applications with slip compensation, the deviation from the real motor speed solely depends on the accuracy of the slip compensation set by the user.

Coding: 1 digit = 0.2 rpm

Active current

By assigning a process input word ACTIVE CURRENT, the power section provides the actual active current value in "% I_N" to the higher-level automation system.

Coding: 1 digit = 0.1 % I_N

9.5.2 "Bus positioning" application module

The process output and input data words of the "Bus positioning" application module are assigned as follows:

PO:

- PO1: Control word 2
- PO2: Setpoint speed
- PO3: Target position

PI:

- PI1: Status word
- PI2: Actual velocity
- PI3: Actual position

For further information, refer to the following documentation:

Documentation	Publication number
"MOVIDRIVE® MD_60A Bus Positioning Application Module" manual	0918421x/EN



9.5.3 "Extended bus positioning" application module

The process output and input data words of the "Extended bus positioning" application module are assigned as follows:

PO:


- PO1: Control word 2
- PO2: Target pos. high
- PO3: Target pos. low
- PO4: Setpoint speed
- PO5: Acceleration ramp
- PO6: Deceleration ramp

PI:

- PI1: Status word
- PI2: Actual pos. high
- PI3: Actual pos. low
- PI4: Actual velocity
- PI5: Active current
- PI6: Unit utilization

For further information, refer to the following documentation:

Documentation	Publication number
"MOVIDRIVE® MDX61B Extended Bus Positioning Application Module" manual	11335114/EN



9.5.4 "Modulo positioning" application module

The process output and input data words of the "Modulo positioning" application module are assigned as follows:

PO:

- PO1: Control word 2
- PO2: Target pos. high
- PO3: Target pos. low
- PO4: Setpoint speed
- PO5: Acceleration ramp
- PO6: Deceleration ramp

PI:

- PI1: Status word
- PI2: Actual pos. high
- PI3: Actual pos. low
- PI4: Actual velocity
- PI5: Active current
- PI6: Unit utilization

For further information, refer to the following documentation:

Documentation	Publication number
"MOVIDRIVE® MDX60B/61B Modulo Positioning Application" manual	11349212/EN



9.5.5 "Table positioning" application module

The process output and input data words of the "Table positioning" application module are assigned as follows:

PO:

- PO1: Control word 2

PI:

- PI1: Status word

For further information, refer to the following documentation:

Documentation	Publication number
"MOVIDRIVE® MDX61B Table Positioning Application" manual	11640626/EN

9.5.6 "Sensor-based positioning via bus" application module

The process output and input data words of the "Sensor-based positioning" application module are assigned as follows:

PO:


- PO1: Control word 2
- PO2: Setpoint speed
- PO3: Setpoint position

PI:

- PI1: Status word
- PI2: Actual velocity
- PI3: Actual position

For further information, refer to the following documentation:

Documentation	Publication number
"MOVIDRIVE MDX61B Sensor-Based Positioning Via Bus Application" manual	11313528/EN



9.5.7 "Automotive AMA0801" application module

Depending on the operating mode, the process output and input data words of the "Automotive AMA0801" application module are assigned as follows:

PO:

- PO1: Control word 2
- PO2: Target position high or 16 single-bit positions
- PO3: Target position low or correction value high
- PO4: Setpoint speed or correction value low
- PO5: Ramp up/down or reserved
- PO6: Sync offset

PI:

- PI1: Status word
- PI2: Actual pos. high
- PI3: Actual pos. low
- PI4: Actual speed or single-bit position signal and drive does not rotate
- PI5: Position difference master-slave or 16 single-bit cams
- PI6: Active current

For further information, refer to the following documentation:

Documentation	Publication number
"MOVIDRIVE® MDX61B AMA0801 Automotive Application Module" manual	16629612/EN



10 MOVITOOLS® MotionStudio – Operation

10.1 About MOVITOOLS® MotionStudio

10.1.1 Tasks

The software package enables you to perform the following tasks with consistency:

- Establishing communication with units
- Executing functions with the units

10.1.2 Establishing communication with other units

The SEW Communication Server is integrated into the MOVITOOLS® MotionStudio software package for establishing communication with the units.

The SEW Communication Server allows you to create **communication channels**. Once the channels are established, the units communicate via these communication channels using their communication options. You can operate up to four communication channels at the same time.

MOVITOOLS® MotionStudio supports the following types of communication channels:

- Serial (RS-485) via interface adapters
- System bus (SBus) via interface adapters
- Ethernet
- EtherCAT
- Fieldbus (PROFIBUS DP/DP-V1)
- Tool Calling Interface

The available channels can vary depending on the units and its communication options.

10.1.3 Executing functions with the units


The software package offer uniformity in executing the following functions:

- Parameterization (for example in the parameter tree of the unit)
- Startup
- Visualization and diagnostics
- Programming

The following basic components are integrated into the MOVITOOLS® MotionStudio software package, allowing you to use the units to execute functions:

- MotionStudio
- MOVITOOLS®

All functions communicate using **tools**. MOVITOOLS® MotionStudio provides the right tools for every unit type.



10.2 First steps

10.2.1 Starting the software and creating a project


Proceed as follows to start MOVITOOLS® MotionStudio and create a project:

1. Start the MOVITOOLS® MotionStudio from the Windows start menu via:
[Start]/[Programs]/[SEW]/[MOVITOOLS-MotionStudio]/[MOVITOOLS-MotionStudio]
2. Create a project with name and storage location.

10.2.2 Establishing communication and scanning the network

Proceed as follows to establish a communication with MOVITOOLS® MotionStudio and scan your network:

1. Set up a communication channel to communicate with your units.
For detailed information on how to configure a communication channel, see the section regarding the relevant communication type.
2. Scan your network (unit scan). Press the [Start network scan] button [1] in the toolbar.



[1]

2451045515

3. Select the unit you want to configure.
4. Right-click to open the context menu.
As a result you will see a number of unit-specific tools to execute various functions with the units.




10.3 Connection mode

10.3.1 Overview

MOVITOOLS® MotionStudio differentiates between "online" and "offline" communication mode. You can select the communication mode yourself. Depending on the selected communication mode, you can choose offline or online tools specific to your unit.

The following figure illustrates the two types of tools:



2451049995

- [1] Hard drive of the engineering PC
- [2] RAM of the engineering PC
- [3] Engineering PC
- [4] Unit

Tools	Description
Offline tools	Changes made using offline tools affect "ONLY" the RAM [2]. <ul style="list-style-type: none"> • Save your project so that the changes can be stored on the hard disk [1] of your engineering PC [3]. • Perform the "Download (PC->unit)" function if you want to transfer the changes to your unit [4] as well.
Online tools	Changes made using online tools affect "ONLY" the unit [4]. <ul style="list-style-type: none"> • Perform the "Upload (unit->PC)" function if you want to transfer the changes to your RAM. • Save your project so that the changes can be stored on the hard disk [1] of your engineering PC [3].



INFORMATION

- The "online" communication mode is **NOT** a response message which informs you that you are currently connected to the unit or that your unit is ready for communication. Should you require this feedback, observe section "Setting the cyclical accessibility test" in the online help (or the manual) of MOVITOOLS® MotionStudio.
- Project management commands (such as download and upload), the online unit status, and the unit scan work independent of the set communication mode.
- MOVITOOLS® MotionStudio starts up in the communication mode that you set before you closed down.

10.3.2 Selecting the communication mode (online or offline)

Proceed as follows to select the communication mode:

1. Select the communication mode:
 - "Switch to online mode" [1] for functions (online tools) that should directly influence the unit.
 - "Switch to offline mode" [2] for functions (offline tools) that should influence your project.



2451057163

[1] "Switch to online mode" symbol

[2] "Switch to offline mode" symbol


2. Select the unit node.
3. Right-click to open the context menu and display the tools for configuring the unit.



10.4 Communication via Ethernet

10.4.1 Connection of PC/laptop

The following figure shows the connection between a PC/laptop and the engineering interface of the MOVIPRO®:



1204936459

- | | |
|---|--------------------------------------|
| [1] Service interface (Ethernet RJ45) of MOVIPRO® | [2] Conventional Ethernet cable |
| | [3] Ethernet interface of the laptop |

The following table shows the IP address and the subnet mask of the MOVIPRO®:

Standard IP address	192.168.10.4
Subnet mask	255.255.255.0

Setting the IP address of the engineering computer

Proceed as follows to set the IP address of the engineering computer:

1. Under [Start] / [Setup] / [Network connections], choose the PC interface you require and select the properties window of the PC interface from the context menu.
2. Activate the option "Use this IP address" in the property window of the "Internet protocol (TCP/IP)" entry.
3. Enter the net mask set in the MOVIPRO® (e.g. 255.255.255.0).
4. Set the IP address depending on the net mask. Apart from the sections determined by the net mask, the IP addresses of the MOVIPRO® unit and the PC interface must differ. In the area defined by the net mask, the IP addresses must be the same. The last block of the IP address must not be 0, 4, or 255.



10.4.2 Adjusting the engineering PC to the network (address)

Proceed as follows to adjust (address) the engineering PC to the network:

1. Select the following item from the Windows start menu:
[Start] / [Setup] / [Network connections]
2. Select the corresponding PC interface.
3. Select "Properties" from the context menu.
4. Activate the checkbox with the entry "Internet protocol (TCP/IP)".
5. Click on "Properties".
6. Activate the "Use the following IP address" checkbox.
7. Enter the same IP addresses for the subnet mask and the standard gateway as for the other Ethernet stations in this local network.
8. For the engineering PC, enter an IP address that meets the following conditions:
 - In the blocks that define the **network**, the address segment for the engineering PC must correspond to the other Ethernet stations.
 - In the blocks that define the **station**, the address segment for the engineering PC must differ from the other stations.
 - The last block must not contain the values "0", "4", "127" or "255".

NOTE: In the IP address of the subnetwork mask (such as 255.255.255.0), the values in the blocks have the following meaning:


- "255", defines the address of the network where the stations are located.
- "0", defines the address of the actual station to distinguish it from other stations.



10.4.3 Configuring the communication channel via Ethernet

Proceed as follows to configure a communication channel for Ethernet:

1. Click on "Configure communication plugs" [1] in the toolbar.




[1]

2451145227

[1] "Configure communication plugs" symbol

This opens the "Configure communication plugs" window.



2451132171

[1] "Type of communication" selection list

[2] "Activate" checkbox

[3] [Edit...] button

2. From the list [1], select "Ethernet" as the communication type.

In the example, "ETHERNET" is activated as the communication type for the first communication channel [2].

3. Click [Edit] [3] in the right section of the window.

This will display the settings for the "Ethernet" communication type.

4. Set up the SMLP protocol. To do so, select the "SMLP settings" tab.

SMLP stands for **S**imple **MOVILINK**® **P**rotocol. It is the SEW-EURODRIVE unit protocol and is transmitted directly via TCP/IP.

5. Set the parameters. Follow the instructions described in the section "Setting communication parameters for SMLP".




10.4.4 Setting communication parameters for SMLP

Proceed as follows to set the Ethernet communication parameters:

1. Change the set communication parameters if necessary. Refer to the detailed description of the communication parameters for SMLP.

NOTE: During a unit scan, the system recognizes only units that are in the same (local) network segment as the PC that is running on MOVITOOLS® MotionStudio. If you have units that are outside the local network segment, add the IP addresses of these units to the list of SMLP servers.

2. Add an IP address by opening the context menu and selecting [Add IP address] [1]..



[1] [Add IP address] button

[2] "IP address" input field

3. Enter the IP address in the input field [2] and click the [OK] button.

2451339787



10.4.5 Communication parameters for SMLP

The following table describes the communication parameters for SMLP:

Communication parameters	Description	Note
Timeout	Waiting time in ms that the client waits for a response from the server after it has made a request.	<ul style="list-style-type: none"> • Default setting: 1000 ms • Increase the value as required if a delay in communication is causing malfunctions.
Broadcast IP address	IP address of the local network segment within which the unit scan is carried out.	In the default setting, the unit scan only detects units that are in the local network segment.
IP address of SMLP server	IP address of the SMLP server or of other units that are to be included in the unit scan but are outside the local network segment.	<ul style="list-style-type: none"> • Enter the IP address of units that are to be included in the unit scan but are outside the local network segment. • Enter the IP address of the SIMATIC S7 control, if you are operating an indirect Ethernet to PROFIBUS communication via SIMATIC S7.
Excluded IP address	IP addresses of units that should not be included in the unit scan	Enter the IP address of units that should not be included in the unit scan. This can be units that are not ready for communication (for example because they have not been started up yet)



10.5 Executing functions with the units

10.5.1 Parameterizing units


Units are parameterized in the parameter tree. It displays all unit parameters, grouped into folders.

You can manage the unit parameters using the context menu and the toolbar. The following steps illustrate how to read/edit unit parameters.

10.5.2 Reading or changing unit parameters

To read or change unit parameters, proceed as follows:


1. Switch to the required view (project view or network view).
2. Select the communication mode:
 - Click the "Switch to online mode" button [1] if you want to read or change parameters directly on the **unit**.
 - Click the "Switch to offline mode" button [2] if you want to read or change parameters in the **project**.



2451057163

- [1] "Switch to online mode" symbol
[2] "Switch to offline mode" symbol

3. Select the unit you want to set parameters for.
4. Open the context menu and select the [Parameter tree] command.
Then, the "Parameter tree" view opens on the right section of the screen.
5. Expand the "Parameter tree" up to the node you require.



2451390987

6. Double-click to display a particular group of unit parameters.



7. Press the enter key to finalize any changes you make to numerical values in the input fields.

INFORMATION



- Refer to the parameter list in the unit documentation for detailed information on the unit parameters.

10.5.3 Starting up units (online)

Proceed as follows to start up the units (online):

1. Switch to the network view.
2. Click on "Switch to online mode" [1] in the toolbar.




[1]

2451061643

[1] "Switch to online mode" symbol

3. Select the unit you want to startup.
4. Open the context menu and select the command [Startup] / [Startup].
The Startup wizard opens.
5. Follow the instructions of the startup wizard and then load the startup data onto your unit.



11 MOVIPRO® – Parameterization

11.1 Encoder configuration

11.1.1 General information regarding the encoder configuration



INFORMATION

The general information regarding the encoder configuration applies to the following encoder options:

- PFA-MD...B-**G20**-B...-/C../000
- PFA-MD...B-**G21**-B...-/C../000
- PFA-MD...B-**G22**-B...-/C../000



INFORMATION

For startup, you require **MOVITOOLS® MotionStudio 5.60 SP2** or a later version.

Startup with an earlier version is **not permitted**.

- Start up the drive in conjunction with MOVIPRO® according to section "Motor startup". It must be possible to move the drive, e.g. via the "Manual mode PRO" plug-in".

Make sure that

- the cabling,
- the terminal assignment and
- the safety cut-outs

have been configured correctly and are suited to the application.

- There is no need to activate the factory settings. If you call up a factory setting, the "PFA-..." power section parameters will be reset to the default values.




⚠ WARNING

Encoder startup aborted with an earlier version of MOVITOOLS® MotionStudio.

Severe or fatal injuries due to uncontrolled motor startup.

- Always use MOVITOOLS® MotionStudio 5.60 SP2 or a later version.



11.1.2 Encoder parameterization

Observe the following information when you parameterize the encoders listed here:

- **HEIDENHAIN ROQ 424 (AV1Y)**

The SSI version with 10 ... 30 V is supported. The unit designation specifies all additional conditions.

- **T&R CE 58, CE 65, LE 100 SSI, LE 200, LA 41K-SSI**

- Make a setting of 24 data bits and program signal bits to logical 0. Bit no. 25 may either contain 0 or an error or power fail bit. Other special bits following the position will not be evaluated. The 25-bit version is not supported.
- The output mode must be "Direct".
- The interface must be set to "SSI".

- **T&R CE 58 CANopen**

- The termination switch must be set to "ON".
- The node ID must be set to 1 via the 6-fold DIP switch.
- The number of increments per revolution must be set to the standard value, 4096.

- **T&R LE200 CANopen**

- Terminating resistor for bus termination required.
- The node ID must be set to 1 via the 8-fold DIP switch.

- **SICK STEGMANN AG100 MSSSI, AG626, ATM90, ATM60**

Only the 24-bit version is supported.

- **SICK STEGMANN ARS60**


Only the 15-bit version is supported.

- **SICK DME-5000-x11, DME-4000-x11**

- The interface must be set to "SSI".
- You have to set "24 data bits + error bit".
- The resolution must be set to 0.1 mm or 1 mm.
- The plausibility must be set to "Normal".

- **SICK DME-5000-x17, DME-4000-x17**

- The interface must be set to "Hiperface®".
- Set the resolution to 1 mm.
- The plausibility must be set to "Normal".



- **SICK DME-4000-x19**
 - The interface must be set to "CANopen".
 - The node ID must be set to 1.
 - The resolution must be set to 0.1 mm or 1 mm.
 - The plausibility must be set to "Normal".

- **Pepperl & Fuchs WCS2(A)-LS311, WCS3(A)-LS311**

The unit designation specifies all necessary conditions. The line length to the encoder is not to exceed 10 m (33 ft.).

- **Pepperl & Fuchs WCS3B-LS410**
 - The node ID must be set to 1 (switches 1 – 6 of the 8-fold DIP switch)
 - The baud rate must be set to 250 kBaud (switches 6 – 7 of the 8-fold DIP switch)
 - The transmission mode must be set to "asynchronous 0 ms / 10 ms" (switches 1 – 3 of the 4-fold DIP switch)
 - The data protocol must be set to "data protocol 2" (switch 4 of the 4-fold DIP switch to "on")

- **Pepperl & Fuchs EDM 30/120/140 - 2347/2440**
 - All modes are supported. Recommendation: Mode 0 (DIP switches 3 and 4 in ON position) or mode 3 (DIP switches 3 and 4 in OFF position) and measuring for triple reflector (DIP switch 2 in OFF position).

- **Pepperl & Fuchs VDM 100-150**
 - The operating mode must be set to mode 3 ([Menu] / [Parameters] / [operating modes] / [Mode 3]).
 - The coding must be set to "Gray".
 - The resolution must be set to 0.1 mm or 1 mm.

- **LEUZE AMS200, OMS1, OMS2, BPS37**
 - You have to set "24 data bits + error bit".
 - Set the resolution to 0.1 mm.



INFORMATION


The following applies for all parameterizable SSI encoders:

- The interface must be set to "SSI".
- You have to set "24 data bits + error bit" or "0 in bit 25".
- Plausibility must be set to "normal = 0" when the plausibility check is activated.
- The coding must be set to "Gray".




11.1.3 Encoder startup

1. Start MOVITOOLS® MotionStudio and create a new project. For more information, refer to section "Operation of MOVITOOLS® MotionStudio" (page 78).
2. Click on the [Startup] button [1] to call the startup wizard.



2097970443

[1] [Startup] button




3. Click on the [Next] button [1] to go to the next step of the startup wizard. You can go back and forth in the wizard using the [Back] and [Next] buttons. The settings are not lost.



3024650891

4. If the drive is equipped with an electronic nameplate, you can transfer the read-off data. The buttons have the following functions:

Button	Function
[Accept data permanently] [1]	Encoder data is uploaded into the startup wizard. It is not possible to edit the encoder data.
[Accept data as suggestion] [2]	Encoder data is uploaded into the startup wizard. You can edit the encoder data manually.
[Do not apply data] [3]	Encoder data is not uploaded into the startup wizard. You must edit the encoder data manually.




2071861387



5. Select the encoder settings for the motor and – if applicable – for the distance encoder. You have the following options:
 - "Manual editing", in order to select and parameterize an encoder.
 - "Automatic detection", in order to read out the connected encoder. This is only possible with the following SEW encoders:
 - Ex7S
 - ExxH
 - Ax7W
 - AxxH
 - "Deselect", if there is no encoder connected or if the application does not require an encoder.
 - "Position monitoring on" in order to determine the source of the actual values.




1942875915




Editing SEW encoders manually

Proceed as follows to select an SEW encoder manually

1. Click [SEW encoder].
2. Enter the encoder designation in the respective fields according to the specification on the encoder name plate.



1942880907




MOVIPRO® – Parameterization

Encoder configuration

Editing approved encoders

Proceed as follows to manually select a non-SEW encoder approved by SEW-EURO-DRIVE:

1. Click [Approved encoder].
2. Select the respective encoder from the SEW database



1942882827

3. Select the "Mounting" tab and define the type of mounting.

Defining the encoder mounting


Proceed as follows to define the encoder mounting:

1. Enter the counting direction of the encoder.
The following options are possible:
 - "in direction of motor rotation"
 - "Inverse to direction of motor rotation"
2. Specify the ratio between the motor and the encoder.




INFORMATION

You can measure the ratio with the startup software. This is only possible once the entire application has been installed.




Measuring the ratio Proceed as follows to measure the ratio with the startup software:

1. Click the [Measure ratio] button.



3027605515



MOVIPRO® – Parameterization

Encoder configuration

2. Provide for the measure requested under **1** in the following figure and check the "Completed" checkbox.
3. Click [Start].
4. Click [Manual mode] to start the manual mode.

Distance encoder

Encoder selection Mounting

Encoder mounting

Counting direction of the encoder
in sense of rotation of motor

Ratio between encoder and motor

Direct mounting
Measurement finished

1 Please ensure the following:
Encoder 1 (motor encoder) was put into operation completely
Encoder 2 (synchronous encoder) was put into operation except for the gear ratio
☒ Executed


2 Start measuring!

3 Move axis
Move the axis by at least one motor revolution
Stop axis after measurement (apply brake)


4 Please ensure the following:
 $i = \frac{???}{???} = ???$
Measurement quality 99.457888 %
☒ Apply data

MOVITOOLS®-MotionStudio OK Cancel

3027663755



5. Start the manual mode and move the axis by at least one motor revolution. Then stop the drive (apply brake).



3027750923



MOVIPRO® – Parameterization

Encoder configuration

6. The determined data is displayed under **4**. Further, there is information regarding the validity of the data under **3**.

Distance encoder

Encoder selection Mounting

Encoder mounting

Counting direction of the encoder
in sense of rotation of motor

Ratio between encoder and motor

1 U 1 U

Direct mounting
Measurement finished

1 Please ensure the following:
Encoder 1 (motor encoder) was put into operation completely
Encoder 2 (synchronous encoder) was put into operation except for the gear ratio
☒ Executed

2 Start measuring!
Start

3 Move axis
Move the axis by at least one motor revolution
Stop axis after measurement (apply brake)
Data valid
Manual mode


4 Please ensure the following:
$$i = \frac{30047}{500000} = 0,060094$$

Measurement quality 99,992043 %
☒ Apply data

MOVITOOLS®-MotionStudio OK Cancel

3027897867

7. If the data is valid, click [Quit manual mode] and [OK] to quit the manual mode.



8. Click [Apply data] to apply the determined data. Now the data is entered as ratio value.

Distance encoder

Encoder selection Mounting

Encoder mounting

Counting direction of the encoder
in sense of rotation of motor

Ratio between encoder and motor

30047 U
500000 U

Direct mounting
Measurement finished

1 Please ensure the following:
Encoder 1 (motor encoder) was put into operation completely
Encoder 2 (synchronous encoder) was put into operation except for the gear ratio

2 Start measuring!

3 Move axis
Move the axis by at least one motor revolution
Stop axis after measurement (apply brake)

4 Please ensure the following:
 $i = \frac{30047}{500000} = 0,060094$
Measurement quality 99,992043 %

Apply data

MOVITOOLS®-MotionStudio

OK Cancel

3027977611




MOVIPRO® – Parameterization

Encoder configuration

Completing the encoder startup

To complete the encoder startup, click on [Load into unit (PC → target system)] or on [Download and motor startup]. The buttons have the following functions:

Button	Function
[Load into unit (PC → target system)]	Transferring encoder data to MOVIPRO®
[Download and motor startup]	Transferring encoder data to MOVIPRO® and initializing motor startup




2071854091




INFORMATION

To enable quick unit replacement, you have to manually download the unit data to the memory card after startup.



11.2 Motor startup

1. Perform an encoder startup (page 92) and complete it by clicking on the [Download and motor startup] button.
2. To select the parameter set for startup, open the tab "Parameter set 1" [1] or "Parameter set 2" [2]. To confirm your selection, click on [Startup set 1] or [Startup set 2] [3].



9007201326614539

- [1] "Parameter set 1" tab
[2] "Parameter set 2" tab
[3] [Startup set 1]/[Startup set 2] button

3. Select the startup type as follows:


Situation	Type of startup
<ul style="list-style-type: none"> Initial startup of the motor Performing extensive modifications [e.g. motor or encoder replacement] 	Complete startup (page 104)
<ul style="list-style-type: none"> Adapting data [e.g. changing the line or motor voltage] 	Partial startup (page 107)
<ul style="list-style-type: none"> Optimizing a speed controller that has already been started up 	Optimizing a speed controller (page 108)

4. Click [Next] to continue.



INFORMATION

To enable quick unit replacement, you have to manually download the unit data to the memory card after startup.



11.2.1 Complete startup

Perform a complete startup to make all the necessary settings for operation of the drive.

1. Select a motor configuration:

- **Stand-alone motor [1]**


MOVIPRO® controls a single motor. First, select the operating mode "vector-controlled/servo". This is the best setting for operation of SEW motors. If operation of a non-SEW motor with vector control does not achieve a satisfactory result, you can select the operating mode "Standard (U/f)".

- **Several identical motors [2]**

MOVIPRO® controls several motors of the same power rating. In this case, you have to specify whether the motor coupling is mechanically rigid or loose/non-existent.

- **Several different motors [3]**

MOVIPRO® controls several motors of a different power rating.



2071868683


[1] "Stand-alone motor" radio button

[2] "Several identical motors" radio button

[3] "Several different motors" radio button

2. Click [Next] to continue.

3. Check the displayed data of the motor encoder and click [Next].



4. Select the motor type and click [Next].

Enter the following values according to the motor configuration:

- Nominal motor voltage [1]
- Nominal motor frequency [2]
- Nominal line voltage [3]
- Error response [4]
- Temperature sensor type [5]

2071890571

- [1] "Rated motor voltage" edit box
- [2] "Rated motor frequency" edit box
- [3] "Rated line voltage" edit box
- [4] "Error response" selection list
- [5] "Temperature sensor type" selection list

5. Choose whether you want to use the encoder and click [Next].

6. Select the operating mode of the drive.


To use the drive as a hoist, select the "Hoist" operating mode. The required parameters are now set automatically.

NOTE: Startup as a hoist is not possible in "CFC" operating mode.

To use an application module, select the "Positioning with IPOS®" operating mode. For more information about application modules, refer to section "Application modules in MOVITOOLS® MotionStudio (page 8)".

Click [Next] to continue.

7. Select the control mode of the drive and click [Next].



8. Enter the values of the speed controller and click [Next].

Enter the download values of the drive parameters. Download values deviating from the suggested values are highlighted in yellow. To accept all suggested download values, click on [Apply proposal] [1].

		Proposal	Download value
130	Ramp t11 UP CW	[s] 0.21	0.21
131	Ramp t11 DOWN CW	[s] 0.21	0.21
132	Ramp t11 up CCW	[s] 0.21	0.21
133	Ramp t11 down CCW	[s] 0.21	0.21
136	Stop ramp t13	[s] 0.21	44
137	Emergency ramp t14	[s] 0.21	0.21
301	Minimum speed 1	[rpm] 0	0
302	Maximum speed 1	[rpm] 1500	1500
730	Brake function 1	ON	ON
731	Brake release time 1	[s] 0.1	0.1
732	Brake application time 1	[s] 0.2	0.2


.....>
Apply proposal

< Zurück Weiter > Abbrechen

[1]


2071878411

[1] [Apply proposal] button



9. To save the startup parameters, click on [Download 1] or [Next] [2]. The buttons have the following functions:

Button	Function
[Download]	Downloading the startup parameters to MOVIPRO®
[Finish]	Downloading the startup parameters to MOVIPRO® and completing startup



2071875979

[1] [Download] button

[2] [Finish] button



INFORMATION

To enable quick unit replacement, you have to manually download the unit data to the memory card after startup.

11.2.2 Partial startup

Perform a partial startup to make the following settings:

- Rated motor voltage
- Rated motor frequency
- Rated line voltage
- Error response
- Temperature sensor type
- Download values of the drive parameters



11.2.3 Optimizing a speed controller

Optimize the speed controller by changing the download values of the drive parameters.

11.3 Storing unit data

The MOVIPRO® unit allows for a quick unit replacement. The MOVIPRO® unit is equipped with a replaceable memory card on which all unit data can be stored.

If a unit has to be replaced, the plant can be started up again quickly by simply re-plugging the memory card.



INFORMATION


To enable quick unit replacement, you have to manually download the unit data to the memory card after startup.

Proceed as follows to store the unit data on the memory card:

1. Right-click on the object "PFH-.." in MOVITOOLS® MotionStudio and select [Startup] / [Data management] from the context menu.

The "Data management" tool opens.

2. Select "Upload" in order to store unit data on the memory card.
3. Activate the "Enabled" checkbox of the unit types PFA-.. (power section) [1] and PFH-.. (communication and control unit) [2].
4. Activate the "Auto restore" checkbox [4]. This ensures that the data is automatically restored when unit replacement is detected. If the "Auto restore" checkbox [4] is not activated during the upload process, the data can only be restored manually via "Download".



5. Click the [Start upload] [3] button to start data backup.



2069868555

- [1] "Enable" checkbox for PFH-.. unit type
- [2] "Enable" checkbox for PFA-.. unit type
- [3] [Start upload] button
- [4] "Auto restore" checkbox

INFORMATION



Note that each time after changing unit parameters using MOVITOOLS® MotionStudio, the changed data set must also be copied to the SD card. The data on the SD card is not automatically updated.

INFORMATION




Performing a reference travel will change several parameters. This is why you should perform a data backup and store your data on the SD card **prior** to the reference travel.



11.4 "PFA-..." power section parameter overview

The following table shows an overview of all parameters. Factory settings are underlined. Numerical values are displayed with the complete setting range.

Parameter	Name	Value
0xx	Display values	
00x	Process values	
000	Speed	Display value
001	User display	Display value
002	Frequency	Display value
003	Actual position	Display value
004	Output current	Display value
005	Active current	Display value
006 / 007	Motor utilization 1 / 2	Display value
008	DC link voltage	Display value
009	Output current	Display value
01x	Status displays	
010	Inverter status	Display value
011	Operating state	Display value
012	Error status	Display value
013	Current parameter set	Display value
014	Heat sink temperature	Display value
015	Operating hours	Display value
016	Enable hours	Display value
017	Work	Display value
018 / 019	KTY utilization 1 / 2	Display value
02x	Analog setpoints	
020	Analog input AI1	Display value
03x	Binary inputs of basic unit	
030	Binary input DI00	Display value
032 – 035	Binary inputs DI02 – DI05	Display value
05x	Binary outputs of basic unit	
050	Binary output DB00	Display value
07x	Unit data	
070	Unit type	Display value
071	Rated output current	Display value
072	Encoder slot option/firmware	Display value
076	Basic unit firmware	Display value
078	Technology function	Display value
079	Unit type	Display value
08x	Error memory	
080 – 084	Error t-0 – t-4	Display value
094 – 096	PO1 – PO3 setpoint	Display value
097 – 099	PI1 – PI3 actual value	Display value
1xx	Setpoints/ramp generators	
13x / 14x	Speed ramps 1 / 2	
130 / 140	Ramp t11 / t21up CW	0 – <u>2</u> – 2000 s
131 / 141	Ramp t11 / t21 down CW	0 – <u>2</u> – 2000 s
132 / 142	Ramp t11 / t21up CCW	0 – <u>2</u> – 2000 s




Parameter	Name	Value
133 / 143	Ramp t11 / t21 down CCW	0 – <u>2</u> – 2000 s
134 / 144	Ramp t12 / t22 UP = DOWN	0 – <u>10</u> – 2000 s
135 / 145	S pattern t12 / t22	<u>0</u> – 3
136 / 146	Stop ramp t13/t23	0 – <u>2</u> – 20 s
137 / 147	Emergency ramp t14 / t24	0 – <u>2</u> – 20 s
139 / 149	Ramp monitoring 1 / 2	<u>Off</u>
16x / 17x	Fixed setpoints 1 / 2	
160 / 170	Internal setpoint n11 / n21	-6000 – <u>150</u> – 6000 rpm
161 / 171	Internal setpoint n12 / n22	-6000 – <u>750</u> – 6000 rpm
162 / 172	Internal setpoint n13 / n23	-6000 – <u>1500</u> – 6000 rpm
2xx	Controller parameters	
20x	Speed control	
200	P gain n-controller	0.01 – <u>2</u> – 32
201	Time constant n-controller	0 – <u>10</u> – 3000 ms
202	Gain Acceleration precontrol	<u>0</u> – 65
203	Filter acceleration precontrol	<u>0</u> – 100 ms
204	Filter actual speed value	<u>0</u> – 32 ms
205	Load precontrol CFC	-150 – <u>0</u> – 150 %
206	Sampling time n-controller	<u>1.0 ms</u> / 0.5 ms
207	Load precontrol VFC	-150 – <u>0</u> – 150 %
21x	Hold controller	
210	P gain hold controller	0.1 – <u>0.5</u> – 32
3xx	Motor parameters	
30x / 31x	Limits 1 / 2	
300 / 310	Start/stop speed 1 / 2	0 – 150 rpm
301 / 311	Minimum speed 1 / 2	0 – <u>15</u> – 6100 rpm
302 / 312	Maximum speed 1 / 2	0 – <u>1500</u> – 6100 rpm
303 / 313	Current limit 1 / 2	0 – 150 % I _N
304	Torque limit	<u>0</u> – 150 %
32x / 33x	Motor adjustment 1 / 2	
320 / 330	Automatic adjustment 1/2	<u>On</u>
321 / 331	Boost 1/2	<u>0</u> – 100 %
322 / 332	IxR compensation 1/2	<u>0</u> – 100 %
323 / 333	Premagnetization time 1 / 2	0 – 2 s
324 / 334	Slip compensation 1 / 2	0 – 500 rpm
34x	Motor protection	
340 / 342	Motor protection 1/2	<u>Off</u>
341 / 343	Type of cooling 1/2	<u>Fan cooled</u>
344	Motor protection interval	0.1 – <u>4</u> – 20 s
345 / 346	In-UL monitoring 1 / 2	0.1 – 500 A
35x	Direction of rotation of the motor	
350 / 351	Direction of rotation reversal 1 / 2	<u>Off</u>
5xx	Monitoring functions	
50x	Speed monitoring	
500 / 502	Speed monitoring 1 / 2	<u>Motor/regenerative</u>
501 / 503	Delay time 1/2	0 – <u>1</u> – 10 s
504	Encoder monitoring motor	<u>Off</u>




MOVIPRO® – Parameterization

"PFA-..." power section parameter overview

Parameter	Name	Value
505	Synchronous encoder monitoring	<u>Off</u>
52x	Mains OFF monitoring	
520	Mains OFF response time	<u>0</u> – 5 s
521	Mains OFF response	<u>On</u>
522	Phase failure monitoring	<u>On</u>
53x	Motor temperature protection	
530	Sensor type 1	<u>No sensor</u>
531	Sensor type 2	<u>No sensor</u>
54x	Gear unit/motor monitoring	
540	Response to vibration/warning	<u>Display error</u>
541	Response to vibration/error	<u>Rapid stop/warning</u>
542	Response to oil aging/warning	<u>Display error</u>
543	Response to oil aging/error	<u>Display error</u>
544	Response to oil aging/overtemperature	<u>Display error</u>
545	Response to oil aging/ready	<u>Display error</u>
549	Response to brake wear	<u>Display error</u>
56x	Ex-e motor current limitation	
560	Ex-e motor current limit	<u>Off</u>
561	Frequency A	0 – <u>5</u> – 60
562	Current limit A	0 – <u>50</u> – 150 %
563	Frequency B	0 – <u>10</u> – 104 Hz
564	Current limit B	0 – <u>80</u> – 200 %
565	Frequency C	0 – <u>25</u> – 104 Hz
566	Current limit C	0 – <u>100</u> – 200 %
6xx	Terminal assignment	
60x	Binary inputs of basic unit	
601	Binary input DIØ2	<u>No function</u>
602	Binary input DIØ3	<u>No function</u>
603	Binary input DIØ4	<u>No function</u>
604	Binary input DIØ5	<u>No function</u>
7xx	Control functions	
70x	Duty types	
700 / 701	Operating mode 1 / 2	<u>VFC</u>
702	Motor category	<u>Rotatory</u>
71x	Standstill current	
710 / 711	Standstill current 1 / 2	<u>0</u> – 50 % I _{Mot}
72x	Setpoint stop function	
720 / 723	Setpoint stop function 1 / 2	<u>Off</u>
721 / 724	Stop setpoint 1 / 2	0 – <u>30</u> – 500 rpm
722 / 725	Start offset 1 / 2	0 – <u>30</u> – 500 rpm
73x	Brake function	
730 / 733	Brake function 1 / 2	<u>On</u>
731 / 734	Brake release time 1 / 2	0 – 2 s
732 / 735	Brake application time 1 / 2	0 – 2 s
74x	Speed skip function	
740 / 742	Skip window center 1 / 2	0 – <u>1500</u> – 6000 rpm
741 / 743	Skip width 1/2	<u>0</u> – 300 rpm




Parameter	Name	Value
77x	Energy-saving function	
770	Energy-saving function	<u>Off</u>
8xx	Unit functions	
80x	Setup	
802	Factory setting	<u>No</u>
803	Parameter lock	<u>Off</u>
804	Reset statistics data	<u>No action</u>
82x	Brake operation	
820 / 821	4-quadrant operation 1/2	<u>On</u>
83x	Error responses	
830	Response to "external error"	<u>Emergency stop/malfunction</u>
832	Response to "motor overload"	<u>Emergency stop/malfunction</u>
834	Response to "lag error"	<u>Emergency stop/malfunction</u>
835	Response to "TF signal"	<u>No response</u>
836	Response to "timeout SBus 1"	<u>Emergency stop/malfunction</u>
838	Response to "SW limit switch"	<u>Emergency stop/malfunction</u>
839	Response to "positioning interruption"	<u>No response</u>
84x	Reset behavior	
840	Manual reset	<u>No</u>
841	Auto reset	<u>No</u>
842	Restart time	<u>1 – 3 – 30 s</u>
85x	Scaling actual speed value	
850	Scaling factor numerator	<u>1 – 65535</u>
851	Scaling factor denominator	<u>1 – 65535</u>
852	User-defined unit	<u>rpm</u>
86x	Modulation	
860 / 861	PWM frequency 1 / 2	<u>4 / 8 / 12 / 16 kHz</u>
862 / 863	PWM fix 1 / 2	<u>Off</u>
864	PWM frequency CFC	<u>4 / 8 / 16 kHz</u>
87x	Process data description	
870	Setpoint description PO1	<u>Control word 1</u>
871	Setpoint description PO2	<u>Setpoint speed</u>
872	Setpoint description PO3	<u>Ramp</u>
873	Actual value description PI1	<u>Status word 1</u>
874	Actual value description PI2	<u>Actual speed</u>
875	Actual value description PI3	<u>Output current</u>
876	PO data enable	<u>Yes</u>
9xx	IPOS parameters	
90x	IPOS reference travel	
900	Reference offset	<u>-(2³¹-1) – 0 – (2³¹-1)</u>
901	Reference speed 1	<u>0 – 200 – 6000 rpm</u>
902	Reference speed 2	<u>0 – 50 – 6000 rpm</u>
903	Reference travel type	<u>[0] Left zero pulse</u>
904	Reference travel to zero pulse	<u>Yes</u>
905	Hiperface offset (motor)	<u>-(2³¹-1) – (2³¹-1)</u>
906	Cam distance	<u>Display value</u>
91x	IPOS travel parameters	



MOVIPRO® – Parameterization

"PFA-..." power section parameter overview

Parameter	Name	Value
910	Gain X controller	0.1 – <u>0.5</u> – 32
911	Positioning ramp 1	0.01 – <u>1</u> – 20 s
912	Positioning ramp 2	0.01 – <u>1</u> – 20 s
913	Travel speed CW	0 – <u>1500</u> – 6000 rpm
914	Travel speed CCW	0 – <u>1500</u> – 6000 rpm
915	Velocity precontrol	-99.99 – 0 – <u>100</u> – 199.99 %
916	Ramp type	<u>Linear</u>
917	Ramp mode	<u>Mode 1</u>
918	Bus setpoint source	0 – <u>499</u> – 1023
92x	IPOS Monitoring	
920	SW limit switch CW	-($2^{31}-1$) – <u>0</u> – ($2^{31}-1$)
921	SW limit switch CCW	-($2^{31}-1$) – <u>0</u> – ($2^{31}-1$)
922	Position window	0 – <u>50</u> – 32767 increments
923	Lag error window	0 – <u>5000</u> – ($2^{31}-1$)
924	"Positioning interruption" detection	<u>On</u>
93x	IPOS Special functions	
930	Override	<u>Off</u>
933	Jerk time	<u>0.005</u> – 2 s
938	IPOS speed task 1	<u>0</u> – 9
939	IPOS speed task 2	<u>0</u> – 9
94x	IPOS encoder	
941	Actual position source	<u>Motor encoder</u>
948	Automatic encoder replacement detection	<u>On</u>
96x	IPOS Modulo function	
960	Modulo function	<u>Off</u>
961	Modulo numerator	<u>1</u> – ($2^{31}-1$)
962	Modulo denominator	<u>1</u> – 2^{31}
963	Modulo encoder resolution	1 – <u>4096</u> – 65535



11.5 "PFA-..." power section parameter information

The parameters are explained below. The parameters are divided into 10 groups. The parameter names correspond to their representation in the parameter tree. The factory setting is underlined.

11.5.1 Symbols

The following symbols explain the parameters:



These parameters are switch-selectable and available in parameter sets 1 and 2.



These parameters can only be changed in inverter status "Inhibited" (= output stage at high resistance).



The startup function automatically changes this parameter.

11.5.2 P0xx display values

This parameter group contains the following information:

- Process values and states of the basic unit
- Process values and states of the installed options
- Error memory
- Fieldbus parameters

P00x process values

P000 speed

Resolution: ± 0.2 rpm

In VFC or U/f mode without connected encoder, the speed results from the setpoint speed and the set slip compensation. The speed is established from the encoder or resolver signals and is displayed when there is an encoder connection.

P001 User display

The user display is defined by the following parameters:

- *P850 Scaling factor numerator* (page 143)
- *P851 Scaling factor denominator* (page 143)
- *P852 User-defined unit* (page 143)

P002 frequency

Output frequency of the inverter.

P003 actual position

Position of the drive as a value in increments observing the signs in the range $0 - \pm (2^{31}-1)$ increments (with encoder connection). Without encoder connection, the value is zero.

P004 Output current


Apparent current in the range $0 - 200\%$ of the rated unit current.

P005 Active current

Active current in the range $0 - 200\% I_N$. The display value is positive when torque is in positive sense of rotation; negative when torque is in negative sense of rotation.



<i>P006 / P007 motor utilization 1 / 2</i>	The current thermal motor utilization of the connected motor in parameter set 1 / 2 in the range 0 – 200% is displayed. It is calculated using the motor temperature emulation in the inverter. The synchronous motor with KTY and the asynchronous motor is turned off when 110 % is reached.
<i>P008 DC link voltage</i>	The displayed value is the voltage measured in the DC link circuit.
<i>P009 Output current</i>	Apparent current, displayed in AC A.
<i>P01x Status displays</i>	
<i>P010 Inverter status</i>	Status of the unit output stage ("inhibited" or "enabled").
<i>P011 Operating status</i>	<p>The following operating states are possible:</p> <ul style="list-style-type: none"> • "24 V operation" • "Controller inhibit" • "No enable" • "Standstill current" • "Enable (VFC)" • "Enable (N-control)" • "Torque control" • "Hold control" • "Factory setting" • "Limit switches" • "Technology option" • "Reference mode" • "Flying start in progress" • "Calibrating encoder" • "Error" • "Safe stop"
<i>P012 error status</i>	Error number and error in plain text.
<i>P013 Current parameter set</i>	Parameter set 1 or 2.
<i>P014 Heat sink temperature</i>	Heat sink temperature of the inverter in the range –40 – 125 °C.
<i>P015 Operating hours</i>	Total number of hours for which the inverter has been connected to the mains or an external DC 24 V supply. Storage cycle every 15 min.
<i>P016 Enable hours</i>	Total number of hours for which the inverter was in "Enabled" operating status; storage cycle every 15 min.



P017 Work Total of the active electrical energy the motor has consumed; storage cycle every 15 min.

P018 / P019 KTY utilization 1 / 2 Display 0 %: Motor is not in operation at max. ambient temperature.
 Display 110 %: Cut-off point of motor.

P02x Analog setpoints

P020 Analog input AI1 Voltage (–10 V – +10 V) at analog input AI1 (020).

P03x Binary inputs of basic unit

P030, P032 – P035 binary inputs DI00, DI02 – DI05 Displays the current status of the input terminals DI00 and DI02 – DI05 and the current function assignment. For possible terminal assignments, refer to *P601 – P604 binary inputs DI02 – DI05* (page 133).



INFORMATION

The binary input DI00 is always assigned the function “controller inhibit”.

P05x Binary outputs of basic unit

P050 Binary output DB00 Displays the current state of the binary output on the basic unit with the current function assignment.

P07x Unit data

P070 Unit type Displays the complete designation of the unit, e.g. PFA-MD0040B-5A3.

P071 Rated output current Displays the r.m.s. value of the rated output current.

P072 Encoder slot option/firmware Displays the installed encoder card and its program version.

P076 Basic unit firmware Displays the program version of the firmware used in the basic unit.

P078 Technology function Displays the currently set technology function.
 "Standard": Setting for operating the inverter with the standard functions (positioning, speed control, etc.).

P079 Unit version Displays the unit version.
 "Technology": Application modules and technology functions are available.



P08x Error memory

P080 – P084 error
t-0 – t-4

There are 5 error memories (t-0 – t-4). The errors are stored in a chronological sequence with the most recent error event being stored in error memory t-0. If there are more than 5 errors, the error event of longest standing stored in t-4 is deleted.

For a list of possible error responses, refer to *P83x error responses* (page 141).

The following information is stored at the time of the error and can be displayed in the event of a error:

- Status ("0" or "1") of the binary inputs/outputs
- Operating state of the inverter
- Inverter status
- Heat sink temperature
- Speed
- Output current
- Active current
- Unit utilization
- DC link voltage
- Operating hours
- Enable hours
- Parameter set
- Motor utilization 1 and 2

P09x Bus diagnostics

P094 – P096
PO1 – PO3 set-
point


Displays the value currently transferred on the process data word in hexadecimal form.

PO setpoint	Description
P094 PO1 setpoint	P870 Setpoint description PO1 (page 144)
P095 PO2 setpoint	P871 Setpoint description PO2 (page 144)
P096 PO3 setpoint	P872 Setpoint description PO3 (page 144)

P097 – P099 PI1 –
PI3 actual value

Displays the value currently transferred on the process data word in hexadecimal form.

PI setpoint	Description
P097 PI1 actual value	P873 Actual value description PI1 (page 145)
P098 PI2 actual value	P874 Actual value description PI2 (page 145)
P099 PI3 actual value	P875 Actual value description PI3 (page 145)



11.5.3 P1xx Setpoints/ramp generators

P13x / P14x Speed ramps 1/2


P130 – P133 /
P140 – P143 ramp
t11 / t21 up/down
CW/CCW

1 2

P130 Ramp t11 up CW / P140 Ramp t21 up CW
P131 Ramp t11 down CW / P141 Ramp t21 down CW
P132 Ramp t11 up CCW / P142 Ramp t21 up CCW
P133 Ramp t11 down CCW / P143 Ramp t21 down CCW

Setting range: 0 – 2 – 2000 s

The ramp times refer to a setpoint step change of $\Delta n = 3000$ rpm. The ramp takes effect when the speed setpoint is changed and the enable is revoked via the CW/CCW terminal.



277883403

P134 / P144 Ramp
t12 / t22 UP =
DOWN

1 2

Setting range: 0 – 10 – 2000 s

The following applies to this ramp: UP = DOWN and CW = CCW.


Ramps t12/t22 are activated via a binary input, which is set to the function "Ramp switchover". For information about binary input assignment, refer to P601 – P604 Binary inputs DIØ2 – DIØ5 (page 133).

P135 / P145 S pattern
t12 / t22

1 2

Setting range: 0 / 1 / 2 / 3 (0 = off, 1 = weak, 2 = medium, 3 = strong)

The 2nd ramp (t12/ t22) of parameter sets 1 and 2 can be rounded with 3 pattern grades to achieve a smoother acceleration of the drive.



277886731


A started S pattern is interrupted by the stop ramp t13 / t23 and a changeover to ramp t11 / t21. Withdrawing the setpoint or a stop using the input terminals causes the started S curve to be completed. This allows the drive to continue to accelerate despite the fact that the setpoint has been withdrawn.

P136 / P146 stop
ramp t13 / t23

1 2

Setting range: 0 – 2 – 20 s

The stop ramp is activated by withdrawing the ENABLE terminal or by an error. For information about possible error responses, refer to P83x Error responses (page 141).



MOVIPRO® – Parameterization

"PFA-..." power section parameter information

P137 / P147 Emergency ramp t14 / t24



Setting range: 0 – 2 – 20 s

The emergency ramp is activated by an error. For information about possible error responses, refer to *P83x error responses* (page 141). The system monitors whether the drive reaches zero speed within the set time. After the set time expires, the output stage is inhibited and the brake applied even if zero speed has not yet been reached.

P139 / P149 Ramp monitoring 1 / 2



Setting range: Yes/No

If you set the deceleration ramps to a value that is a lot shorter than can be physically accomplished in this system, the turning drive will be stopped after expiration of the monitoring time. Such a setting will cause an error signal and increase brake wear.

The respective ramp time also has to be increased, if the ramp timeout is definitely triggered by a preset ramp that cannot be traveled.

This parameter is an additional monitoring function for speed monitoring. This parameter only applies to the deceleration ramp. This means the parameter can be used to monitor the downwards ramp, stop ramp or emergency stop ramp if speed monitoring is not desired.

P16x / P17x Fixed setpoints 1 / 2



Setting range: -6000 – +6000 rpm

3 internal setpoints (= fixed setpoints) can be set separately for parameter sets 1 and 2. The internal setpoints are active when an input terminal programmed to n11 / n21 or n12 / n22 (*P6xx Terminal assignment*) has a "1" signal.


Setting range: 0 – 6000 rpm

Fixed setpoint	Factory setting
P160 / P170 Internal setpoint n11 / n21	n11 / n21 = 150 rpm
P161 / P171 Internal setpoint n12 / n22	n12 / n22 = 750 rpm
P162 / P172 Internal setpoint n13 / n23	n13 / n23 = 1500 rpm

Programming the input terminals:

Response	Terminal			
	n11/n21	n12/n22	Enable/stop	Parameter set 1/2
Stop with t13/t23	X	X	"0"	X
Fixed setpoint not active	"0"	"0"	"1"	"0"
n11 effective	"1"	"0"	"1"	"0"
n12 effective	"0"	"1"	"1"	"0"
n13 effective	"1"	"1"	"1"	"0"
n21 effective	"1"	"0"	"1"	"1"
n22 effective	"0"	"1"	"1"	"1"
n23 effective	"1"	"1"	"1"	"1"

The fixed setpoints of the currently inactive parameter set come into effect when this terminal is actuated (= "1") if an input terminal is programmed to "Fixed setpoint switch-over". This changeover is possible when the unit is inhibited and enabled.



11.5.4 P2xx Controller parameters


P20x Speed control

Speed control only in parameter set 1.

The speed controller of the power section is a PI-controller. It is active when the following operating modes are set:

- All operating modes with "VFC-n control".
- CFC operating modes: The speed controller is only active in "CFC & torque control" when speed limiting is active (P70x Operating modes).
- Servo operating modes: The speed controller is only active in "Servo & torque control" when speed limiting is active (P70x Operating modes).

The setting of all parameters important for speed control is supported by the startup functions of MOVITOOLS® MotionStudio. Direct alterations to individual controller parameters are reserved for optimization by specialists.



278006411

P200 P-gain n-controller

AUTO

Setting range: 0,01 – 2 – 32

Gain factor of the P-component of the speed controller.

P201 Time constant n-controller

AUTO

Setting range: 0 – 10 – 3000 ms (0 = no I-component)

Integration time constant of the speed controller. The I-component reacts inversely proportionate to the time constant, i.e. a large numerical value results in a small I-component, although 0 = no I-component.

P202 Gain acceleration precontrol

AUTO

Setting range: 0 – 65

Amplification factor of acceleration precontrol. This parameter improves the control response of the speed controller.

P203 Filter acceleration precontrol

AUTO

Setting range: 0 – 100 ms


Filter time constant of acceleration precontrol. This constant influences the control response of the speed controller. The differentiator is programmed.

P204 Filter actual speed value

AUTO

Setting range: 0 – 32 ms

Filter time constant of the actual speed value filter.



MOVIPRO® – Parameterization

"PFA-..." power section parameter information

P205 Load precontrol CFC

Load precontrol CFC is only effective in CFC and servo operating modes.

Setting range: $-150 - \underline{0} - 150 \%$

This parameter determines the initial value of the torque setpoint upon enable. The parameter must be set if increased starting torque is required when the drive is enabled. For example, a setting greater than 0 % makes it possible to prevent the unwanted sagging of hoists when the brake is released. This function should only be used in hoists without counterweight.

Recommended setting: Value of the active current (page 115) when $n = 0$ is specified.

P206 Sampling time n-controller

The sampling time for n-control is only effective in CFC and servo operating modes.

Setting range: $\underline{1 \text{ ms}} / 0.5 \text{ ms}$

Setting the time to 0.5 ms improves speed control for dynamic drives with low moment of inertia.

P207 Load precontrol VFC

The load precontrol VFC is only effective in operating modes with VFC-n control.

Setting range: $-150 - \underline{\text{off}} - 150 \%$

This parameter determines the initial value of slip control upon enable. A setting greater than 0 % causes the slip control to be subject to pre-stressing, which means that the motor develops higher torque when it is enabled. This setting can, for example, prevent the unwanted sagging of hoists when the brake is released. This function should only be used in hoists without counterweight.

Setting values greater than 150 % switches off the function (no pre-stressing).

In "VFC & hoist" mode and with a value greater than 150% set, pre-stressing of $0.5 \times s_N$ is in effect.

Recommended setting: Value of the active current (page 115) at minimal speed.

P21x Hold controller

Hold control only in parameter set 1.


The hold control function is used to make sure that the drive does not drift during standstill. It can only be activated for operating modes with speed control (encoder feedback). Hold control is active when an input terminal programmed to /HOLD CONTROL (P6xx terminal assignment) has a "0" signal. The unit then performs a stop using the "t11 up" or "t21 down" ramp. If the drive reaches speed zero, it is held in the position that is valid at this point. The gain factor setting is supported in the startup function of the speed controller in MOVITOOLS® MotionStudio. The 7-segment display shows status "A1.7" when hold control is active.

P210 P gain hold controller

Setting range: $0,1 - \underline{0,5} - 32$

The parameter corresponds to the proportional gain of a position controller and is only effective in conjunction with the activated "Hold control" function.

AUTO




11.5.5 P3xx Motor parameters

This parameter group is used to adjust the inverter to the motor. The parameters can be set separately for parameter set 1 and 2. This means two different motors can be operated alternately on the same inverter without requiring a new setting.

P30x/P31x limits 1/2

P300 / P310 Start/ stop speed 1 / 2




Setting range: 0 – 150 rpm

During startup in the "VFC & Hoist" operating mode, the rated slip of the connected motor is set. In all other operating modes, 0.5 x the rated slip of the connected motor is set at startup.

Only effective in the VFC and V/f operating modes. The parameter is not relevant in CFC and servo operating modes. This entry defines the smallest speed request which the inverter sends to the motor when enabled. The transition to the speed determined in the setpoint selection is made using the active acceleration ramp.

When a stop command is executed, this setting also determines the lowest speed at which the motor power is switched off or the post-magnetization triggered and, if applicable, the brake applied.

P301 / P311 Mini- mum speed 1 / 2




Setting range: 0 – 15 – 6100 rpm

Speed value, the lower limit of which must not be exceeded even when zero is selected as the setpoint. The minimum speed also applies when $n_{min} < n_{start/stop}$ was set.

Important:

- If the hoist function is active, the slowest speed is 15 rpm even if n_{min} has been set to a lower value.
- To enable the drive to move clear of the limit switches even at low speeds, n_{min} is not active for the hardware limit switch with which the drive has come into contact.


P302 / P312 Maxi- mum speed 1 / 2



Setting range: 0 – 1500 – 6100 rpm

The value set here cannot be exceeded by a setpoint selection. If $n_{min} > n_{max}$ is set, then n_{max} applies. The maximum speed depends on the set operating mode (page 134).

P303 / P313 Cur- rent limit 1 / 2



Setting range: 0 – 150 % I_N

The factory setting for the current limitation is set to 150 % I_N of the matching motor.

The internal current limitation is based on the apparent current. In the field weakening range, the current limit is reduced automatically above the frequency of $1.15 \times f_{base}$ (only applies to V/f and VFC operating modes without speed control). This provides protection against the motor deviating from the optimal operating point.


The current limit effective in the field weakening range can be calculated using the following formula:

$$\text{Current limit} = (1.15 \times f_{base} / f_{act}) \times \text{setting value of P303 / P313}$$

f_{act} is the current speed frequency.



P304 Torque limit



Setting range: 0 – 150 %

The parameter limits the maximum torque of the motor. The entry acts on the setpoint of the motor torque ($k_T \times I_{N_inverter}$). This function is only active in the operating modes "CFC" and "Servo" of parameter *P700/P701 Operating mode 1/2* (page 134).



INFORMATION

In the "CFC" and "Servo" operating modes, *P303 Current limit 1* must always be set \geq *P304 Torque limit* to ensure that speed monitoring is triggered reliably.

P32x/P33x Motor adjustment 1/2

P320/P330 Automatic adjustment 1/2



Setting range: On/off

Only effective in the "VFC" and "V/f" operating modes. The function is only useful for single motor operation. The inverter sets *P322/P332 IxR adjustment 1/2* (page 125) automatically at each enable and stores the value. The inverter determines a basic setting that is adequate for a great number of drive applications. The connected motor is calibrated during the last 20 ms of the pre-magnetization time. The motor is not calibrated in the following cases:

- *P320/P330 Automatic adjustment 1/2* = "off"
- *P700/P701 Operating mode 1/2* = "VFC & group" or "VFC & flying start" (page 134)
- *P323/P333 Premagnetization time 1/2* (page 125) has been reduced by more than 30 ms in relation to the proposed value.
- Operating mode "VFC-n control" is selected and *P730/P733 Brake function 1/2* (page 137) = "off"

In such cases, the set IxR value is used for calculating the winding resistance.

- On: Automatic adjustment.
- Off: No automatic adjustment.


P321/P331 Boost 1/2




Setting range: 0 – 100 %


With "VFC & group": Manual setting to increase the starting torque by increasing the output voltage in the range below the base speed.

With "VFC": Manual setting is usually not required. In exceptional cases, manual setting may be necessary to increase the breakaway torque. In this case, set max. 10 %.





**P322 / P332 IxR
adjustment 1/2**




Setting range: 0 – 100 %

The IxR value of the matching motor is set as the factory setting.

In "VFC" operating mode, this parameter acts on the parameters of the calculated motor model which establish the torque. An automatic setting takes place with *P320/P330 Automatic adjustment 1/2* (page 124) = "on". If set to 100 %, the output voltage of the inverter is increased by 50 V when the rated current of the motor flows. Manual alterations to individual controller parameters are reserved for optimization by specialists.

**P323 / P333 Pre-
magnetization time
1/2**



Setting range: 0 – 2 s


The premagnetization value of the matching motor is set as the factory setting.

Premagnetization serves to establish a high motor torque and starts when the inverter is enabled.

Premagnetization is in effect in "VFC" operating mode with encoder feedback if:

- *P730/P733 Brake function 1/2 is active* (page 137)
- *P710/P711 Standstill current 1/2 is deactivated* (page 135)

**P324 / P334 Slip
compensation 1/2**



Setting range: 0 – 500 rpm

The value of the matching motor is set as the factory setting.

Only effective in "VFC", "VFC-n control" and "V/f" operating modes. Slip compensation increases the speed accuracy of the motor. If values are entered manually, you will have to enter the rated slip of the connected motor. A setting range of ± 20 % of the rated slip is permitted if a value other than the rated slip is entered to compensate for fluctuations between various motors.

P34x Motor protection

**P340/P342 Motor
protection 1/2**



Setting range: OFF / One asynchronous motor / One servomotor

Depending on the motor connected (synchronous or asynchronous motor) this function can have the following effects.

- Off: Function not active
- ON asynchronous motor:

When this function is activated, the power section takes over the thermal protection of the connected motor electronically. In most cases, the motor protection function is comparable to standard thermal protection (motor protection switch) and, furthermore, it takes account of speed-dependent cooling by the integrated fan. The motor utilization is calculated on the basis of:

- Inverter output current
- Type of cooling
- Motor speed
- Time



The thermal motor model is based on the motor data entered during startup with MOVITOOLS® MotionStudio and when the operating conditions specified for the motor are observed.



INFORMATION

If the motor also has to be protected against failure of the ventilation, blockage of air ducts, etc., it is also necessary to employ protection in the form of a TF positive temperature coefficient thermistor or TH bimetallic switch.

The following signal and display functions are available in conjunction with motor protection:

Parameter	Signal and display function
<i>P006/P007 Motor utilization 1/2</i> (page 116)	Display of the motor utilization for parameter set 1/2.
<i>P832 Response to "Motor overload"</i> (page 141)	Error response of the inverter when reaching <i>P006/P007 Motor utilization 1/2</i> of 110 %. Factory setting: Emergency stop/malfunction.

Set the following parameters:

Parameter	Setting/meaning
<i>P341 Type of cooling</i> (page 127)	Self-ventilation or forced cooling
Binary output can be programmed to: /Motor utilization 1/2	Prewarning if motor utilization 1/2 exceeds a value of 100 %. In this case, the programmed output is set to "0" = 0 V.



INFORMATION

Switching off the inverter (mains and 24 V external) always resets the motor utilization to zero; any motor heating existing when the motor is switched back on is not taken into account.


The motor protection function processes the utilization of the connected motors separately for both parameter sets. The motor protection function must not be used if only one motor is permanently connected to the inverter and the "parameter set changeover" function is only used for control purposes. Equally, the motor protection function must not be used with group drives because it is not possible to protect each individual motor reliably.

- ON servomotor:
 - Motor without KTY temperature sensor: The power section calculates and displays the motor utilization based on the current. The goal is to determine after only a few cycles or during startup whether the drive is going to switch off due to an overload with error "A1.F31" (TF trip). This setting is available for parameter set 1 only.

Requirements: Motor utilization is always determined based on the rated motor current. Enter the duration of the machine cycle to receive an exact statement concerning the utilization for the motor powering the machine cycle.

The following signal and display functions are available in conjunction with motor protection:

Parameter	Signal and display function
<i>P006 Motor utilization 1</i> (page 116)	Display of the motor utilization for parameter set 1. Valid after about 10 to 20 cycles or after about 2 s and can be evaluated by a PLC.
<i>P007 Motor utilization 2</i> (page 116)	In setting P340 = "One servomotor" without function
<i>P832 Response to "Motor overload"</i> (page 141)	In setting P340 = "One servomotor" without function



Set the following parameters:

Parameter	Meaning
<i>P344 Motor protection interval</i> (page 127)	Corresponds to the machine cycle of the application. Range: 0.1 s – 20 s.



INFORMATION

Activating the function does not trigger monitoring or protection of the connected motor. Protection must be guaranteed via TF/TH.

Setting a binary output to "Motor utilization_1" or "Motor utilization_2" also has no effect when P340 is set to ON SERVO.

- SEW motor with KTY temperature sensor: Motor utilization is calculated using a motor model stored in the power section (*P006 Motor utilization 1* (page 116), *P018 KTY utilization 1* (page 117)). Once the motor dependent switch-off limit is reached, the inverter will be switched off using the response set in *P832 Response to "Motor overload"* (page 141). In this case, the settings in *P341 Type of cooling 1* (page 127) and *P344 Motor protection interval* (page 127) are not relevant.

P341/P343 Type of cooling 1/2



Setting range: Self-ventilation / Forced cooling

You need to know the cooling type of the motor to calculate the thermal load on the motor as exactly as possible, as described in *P340/P342 Motor protection 1/2* (page 125).

P344 Motor protection interval




Setting range: 0.1 – 4 – 20 s

P344 is not relevant for asynchronous motors. This parameter corresponds to the cycle time of the travel and is used for the function *P006/P007 Motor utilization 1/2* (page 116). The setting range is 100 ms – 20000 ms.

You should always set the time for roundtrip travel (back and forth).

P345/346 In/UL monitoring 1/2



Setting range: 0.1 – 500 A


The function cannot be deactivated. The factory setting is dependent on the rated power of the power section and is set to the rated current of the SEW motor with the same power (for units with resolver input: factory setting = 0).

At 150 % rated motor current, the inverter switches off after 5 minutes with "A1.F84".

At 500 % rated motor current, the inverter switches off after 20 seconds with "A1.F84".

P35x Motor direction of rotation


SEW-EURODRIVE specifies the direction of rotation as seen onto the A-side of the motor. Clockwise (positive) is defined as rotation to the right and counterclockwise as rotation to the left. This definition is implemented when the motor is connected according to the SEW designation.



MOVIPRO® – Parameterization

"PFA-..." power section parameter information

P350/P351 Direction of rotation reversal 1/2



Setting range: On/off

Direction of rotation reversal	Positive setpoint (positive direction of travel)	Negative setpoint (negative direction of travel)
Off	Motor turns clockwise	Motor turns counterclockwise
On	Motor turns counterclockwise	Motor turns clockwise

- On: Above definition is reversed. The assignment of limit switches is maintained. When the motor turns in CLOCKWISE direction, the drive will be properly stopped once it hits the right limit switch. When using this parameter, it is important to carefully check that the limit switch is connected properly and the reference point and travel positions are defined correctly.

NOTE: Altering the "Direction of rotation reversal" parameter after the system has been referenced causes the system to lose its reference point for the absolute position. The result may be undesirable movement of the axis.

- Off: The SEW definition applies.

11.5.6 P5xx Monitoring functions

The following monitoring functions have been implemented to monitor what happens to drive-specific parameters in the specific application and to be able to react in case of impermissible deviations. Some of the monitoring functions are available separately in both parameter sets. The response to the control functions can be set with *P83x error responses* (page 141).

P50x Speed monitoring

P500/P502 Speed monitoring 1/2



Setting range: Off / motor / regenerative / motor/regenerative

The speed required by the setpoint can only be achieved if there is sufficient torque available to meet the load requirements. Once *P303/P313 Current limit 1/2* (page 123) and the external current limit have been reached, the power section assumes that the torque has reached its maximum and the desired speed cannot be attained. Speed monitoring is triggered if this situation persists for the duration specified in *P501/P503 Delay time 1/2* (page 128).


Activate the speed monitoring for hoists and set the delay time to a rather small value. Speed monitoring is not that important for safety since an incorrect movement of the hoist does not necessarily mean operation in the current limitation.

P501/P503 Delay time 1/2



Setting range: 0 – 1 – 10 s

The set current limit can be reached briefly during acceleration, deceleration, or load peaks. You can prevent the speed monitoring from responding too sensitively by setting the delay time accordingly. The current limit must be reached permanently for the duration of the delay time before monitoring responds.



*P504 Encoder
monitoring motor*

Setting range: Yes/No

- No: Wire break between frequency inverter and motor encoder is not detected directly. In case of a defective connection, error "A1.F08" (speed monitoring) will be issued in enabled state unless it was deactivated.
- Yes: Wire break between frequency inverter and motor encoder will be detected directly when using sin/cos encoders and TTL encoders. The error message "A1.F14" (encoder) will be issued in case of an error. This error will also be generated in inhibited state.

NOTE: Encoder monitoring is not a safety function! If you use a HIPERFACE® encoder, encoder monitoring is always active (for the track too) irrespective of the setting in P504.

*P504 Synchron-
ous encoder
monitoring*

Setting range: Yes/No

- No: An open circuit between frequency inverter and synchronous encoder is not directly detected. In case of a defective connection, error "A1.F08" (speed monitoring) will be issued in enabled state unless it was deactivated.
- Yes: A wire breakage between frequency inverter and synchronous encoder will be directly detected when using sin/cos encoders and TTL encoders. The error message "A1.F14" (encoder) will be issued in case of an error. This error will also be generated in inhibited state.

*P52x mains OFF
monitoring*

*P520 mains OFF
response time*

Setting range: 0 – 5 s

*P521 mains OFF
response*

Setting range: Controller inhibit/emergency stop

If the binary input is programmed to "Power on", the response set here will be triggered when the binary input receives a "0" signal.

*P522 Phase fail-
ure monitoring*

Setting range: Off/on


MOVIPRO® monitors the line input phases for failure of a phase. If a phase failure is detected in two phases, then the DC link will be de-energized, which corresponds to a supply system disconnection. Since the line input phases cannot be monitored directly, monitoring has to be done indirectly via the DC link ripple, which increases drastically in case of a phase failure.

The DC link voltage is monitored at a time interval $\Delta t = 1$ ms for dropping below a minimum voltage level that depends on the rated supply voltage of the unit.

The result is the following nominal guide value for detecting a phase failure:

- 50 Hz supply system: Approx. $t_{\max} = 3.0$ s
- 60 Hz supply system: Approx. $t_{\max} = 2.5$ s

Once a phase failure has been detected, the output stage is inhibited and the brake is applied. The error message "A1.F06" (phase failure) is issued. The error response is "Immediate switch-off with inhibit". The error can only be remedied by executing a unit reset.




MOVIPRO® – Parameterization

"PFA-..." power section parameter information

P53x Motor temperature protection

P530 Sensor type
1




Setting range: No sensor / TF/TH / TF/TH DEU / KTY / KTY DEU (KTY only for SEW synchronous motors)

Selection of the sensor used for motor protection in parameter set 1.

- TF/TH: Set the response with *P835 Response to "TF signal"* (page 141).
- KTY: Set *P340 Motor protection 1* (page 125) to "ON servo". The motor model is now activated. Set the response using *P832 Response to "motor overload"* (page 141).

P531 Sensor type
2



Setting range: No sensor / TF/TH

Selection of the sensor used for motor protection in parameter set 2.

P54x Gear unit/motor monitoring

These parameters are used to set the response to be triggered in the event of a motor or gear unit problem. The binary inputs have to be set accordingly for this purpose. The error responses will also be triggered in the "controller inhibit" inverter status.

Response	Description
No response	Neither an error is displayed nor an error response is triggered. The signaled error is ignored.
Error messages	The error is displayed (in the 7-segment display and in MOVITOOLS® Motion-Studio). The unit performs no other error responses. The error can be reset (terminal, fieldbus, auto reset).
Immediate stop/error	The inverter switches off immediately and an error is signaled. The output stage is inhibited and the brake is applied. The ready signal is revoked. A restart is only possible after an error reset has been performed during which the inverter is reinitialized.
Emergency stop/error	The drive is braked with the set emergency stop ramp t14/t24 (page 120). Once the stop speed is reached, the output stage is inhibited and the brake is applied. The error is signaled immediately. The ready signal is revoked. A restart is only possible after an error reset has been performed during which the inverter is reinitialized.
Rapid stop/error	The drive is braked with the set stop ramp t13/t23 (page 119). Once the stop speed is reached, the output stage is inhibited and the brake is applied. The error is signaled immediately. The ready signal is revoked. A restart is only possible after an error reset has been performed during which the inverter is reinitialized.
Immediate stop/warning	The inverter switches off immediately and an error is signaled. The output stage is inhibited and the brake is applied. The ready signal is not revoked. The drive restarts without a unit re-initialization if the error is rectified by an internal procedure or by an error reset.
Emergency stop / warning	The drive is braked with the set emergency stop ramp t14/t24 (page 120). Once the stop speed is reached, the output stage is inhibited and the brake applied. The error is signaled immediately. The ready signal is not revoked. The drive restarts without a unit re-initialization if the error is rectified by an internal procedure or by an error reset.
Rapid stop/warning	The drive is braked with the set stop ramp t13/t23 (page 119). Once the stop speed is reached, the output stage is inhibited and the brake applied. The error is signaled immediately. The ready signal is not revoked. The drive restarts without a unit re-initialization if the error is rectified by an internal procedure or by an error reset.

P540 Response to vibration/warning


Factory setting: Display error

Once the drive vibration sensor signals a warning, the inverter will respond with the set response.

P541 Response to vibration/error

Factory setting: Rapid stop/warning

Once the drive vibration sensor signals an error, the inverter will respond with the set response.



<i>P542 Response to oil aging/warning</i>	Factory setting: <u>Display error</u> If the oil aging sensor signals a warning, the inverter will respond with the set response.
<i>P543 Response to oil aging/error</i>	Factory setting: <u>Display error</u> If the oil aging sensor signals an error, the inverter will respond with the set response.
<i>P544 Oil aging/ overtemperature</i>	Factory setting: <u>Display error</u> If the oil aging sensor signals overtemperature, the inverter will respond with the set response.
<i>P545 Oil aging/ ready</i>	Factory setting: <u>Display error</u> If the oil aging sensor signals ready, the inverter will respond with the set response.
<i>P549 Response to brake wear</i>	Factory setting: <u>Display error</u> If the brake wear sensor trips, the inverter will respond with the set response.




P56x Current limitation Ex-e motor

The parameter group *P56x Current limitation Ex-e motor* contains display and setting values that are specific to the "current limitation in the Ex-e motor on the inverter" function. The factory setting is indicated by underline. The factory settings apply for the delivery status.

Frequencies below frequency A are only permitted to a limited extent. Frequencies higher than the rated motor frequency are permanently illegal. Refer to the "Explosion-Proof AC Motors" operating instructions for more information. The following rules always apply:

- Frequency A < frequency B < frequency C < rated motor frequency
- Current limitation A < current limitation B < current limitation C



1280044043

P560 Current limit Ex-e motor

Setting range: On/off

On: Current limitation for Ex-e motors active.

On startup, the current limitation for Ex-e motors is automatically activated for motors selected and approved for operation in potentially explosive areas.

P561 Frequency A

Setting range: 0 – 5 – 60 Hz

Value for the minimum operating frequency A. The operation time with frequency A is 60 seconds, regardless of the current value. After this time, the inverter switches off and issues the "A1.F110" ("Ex e protection") error message.

P562 Current limit A

Setting range: 0 – 50 – 150 %

Current limitation that is permitted with operating frequency f_A . There is a linear gradient between current limitation A and current limitation B.

P563 Frequency B


Setting range: 0 – 10 – 104 Hz

Value for operating frequency f_B .

P564 Current limit B

Setting range: 0 – 80 – 200 %

Current limitation that is permitted with operating frequency f_B . There is a linear gradient between current limit B and current limit C.



P565 Frequency C Setting range: 0 – 25 – 104 Hz
Value for operating frequency f_C .



P566 Current limit C Setting range: 0 – 100 – 200 %
Current limit that is permitted between operating frequency f_C and rated motor frequency. The rated motor frequency is 50 Hz for star connection and 87 Hz for delta connection. After startup with an Ex-e motor, the current limit C is approximately equal to the rated motor frequency I_N .



11.5.7 P6xx Terminal assignment

P601 – P604
Binary inputs
DIØ2 – DIØ5



The binary inputs can be programmed to the following functions:

Function	Effect when		Effective with inverter status		Factory-set to	see
	"0" signal	"1" signal	Inhibited	Enabled		
No function	–	–	–	–	DIØ2 DIØ3 DIØ4 DIØ5	
Enable/stop	Stop on t13/t23	Enable	no	yes		P13x / P14x (page 119)
CW/halt	Stop on t11/t21 or t12/t22	Enable CW	no	yes		
CCW/halt	Stop on t11/t21 or t12/t22	Enable CCW	no	yes		
n11/n21 n13/n23	External setpoints only	n11/n21 n13/n23	no	yes		P16x / P17x (page 120)
n12/n22	External setpoints only	n12/n22	no	yes		
Fixed setpoint switchover	Fixed setpoints of the active parameter set selected	Fixed setpoints of the active parameter set selected	yes	yes		
Parameter set switchover ¹⁾	Parameter set 1	Parameter set 2	yes	no		
Speed ramp switchover	1. Ramp (t11/t21) active	2. Ramp (t12/t22) active	yes	yes		P13x / P14x (page 119)
/External error	External error	–	no	yes		
Error reset	Reset on positive edge ("0" to "1")		yes	yes		
/Hold control	Hold control active	–	no	yes		P210 (page 122)
/Limit switch CW	Right limit switch reached	Not reached	no	yes		
/Limit switch CCW	Left limit switch reached	Not reached	no	yes		
IPOS input	Function depending on the application module					
Reference cam	Not activated	Activated	no	yes		
Start reference travel	–	Start referencing for the application module	no	yes		
Mains On detection	see P521 (page 129)	Ext. signal "Mains on"	yes	yes		P52x (page 129)
/Vibration warning	Vibration sensor signals warning	Vibration sensor does not signal warning	yes	yes		
/Vibration error	Vibration sensor reports error	Vibration sensor does not report error	yes	yes		
/Oil aging warning	Oil aging sensor signals warning	Oil aging sensor does not signal warning	yes	yes		



MOVIPRO® – Parameterization

"PFA-..." power section parameter information

Function	Effect when		Effective with inverter status		Factory-set to	see
	"0" signal	"1" signal	Inhibited	Enabled		
/Oil aging error	Oil aging sensor signals error	Oil aging sensor does not signal error	yes	yes		
/Oil aging overtemperature	Oil aging sensor reports overtemperature	Oil aging sensor does not signal overtemperature	yes	yes		
Oil aging ready signal	Oil aging sensor is not ready for operation	Oil aging sensor is ready for operation	yes	yes		
Brake wear monitoring	Brake is worn	Brake is ok	yes	yes		

1) Important for operating modes with encoder feedback: The parameter set must not be changed more often than every two seconds.

11.5.8 P7xx Control functions

All settings with regard to the fundamental control properties of the inverter are defined within parameter group 7xx. These are all functions that the inverter executes automatically when activated. They affect how the inverter responds in certain operating modes.




INFORMATION

When using incremental encoders (resolver, push-pull TTL, RS422, sin/cos, HIPERFACE® single-turn), changing the parameter set invalidates the positions H510 and H511. If a valid position is to be maintained after the parameter set has been changed, an absolute encoder (SSI, HIPERFACE® multi-turn) must be used.

P70x Operating modes


P700 / P701 Operating mode 1 / 2



This parameter is used to set the basic operating mode of the inverter for parameter sets 1 and 2. This includes in particular the definition of the motor system, encoder feedback and corresponding control functions. When the inverters are delivered, their parameters are set to the specific motor which matches the power of the inverter.

All operating modes can be set for parameter set 1. Only operating modes without encoder feedback can be set for parameter set 2 (see group 1). Without new startup, the operating mode may only be changed within a group.

Group	Parameter set 1/2 P700 Operating mode 1 P701 Operating mode 2	Unit type and option	Motor
1	"VFC" "VFC & Group" "VFC & Hoist" "VFC & DC braking" "VFC & flying start function" "V/f characteristic curve" "V/f & DC braking"	MOVIPRO® SDC	DR without encoder
2	"VFC n-control" "VFC-n-control & Group" "VFC-n-control & Hoist" "VFC n-control & IPOS"	MOVIPRO® SDC + encoder option	DR with incremental encoder or HIPERFACE® encoder
3	"CFC" "CFC & torque control" "CFC & IPOS"		DR with incremental encoder or HIPERFACE® encoder
4	"Servo" "Servo & torque control" "Servo & IPOS"		CMP with HIPERFACE® encoder or resolver



P702 Motor category



Setting range: Rotatory/Linear

This parameter is set automatically during startup. It shows the connected motor type.

P71x Standstill current

P710/P711 Standstill current 1/2



Setting range: 0 – 50 % I_{Mot}


The standstill current is used for injecting an adjustable current into the motor when the motor is at a standstill and the brake is applied. The standstill current can be switched off by "/controller inhibit = 0". This allows the following functions to be carried out:

- At low ambient temperatures of the motor, it is possible to prevent the danger of condensation formation and freezing (in particular of the disk brake). Overheating the motor must be avoided when setting the current. **Recommendation:** Motor housing should be hand hot.
- It is possible to perform a rapid motor start when standstill current is activated because the motor is kept in an excited state. This means the motor can be started without having to wait for the pre-magnetizing time. **Recommendation:** Set to 45 – 50% for hoists.

The standstill current function is deactivated by P710/P711 = 0. The setting is made in % of the rated motor current. The standstill current is monitored for P303/P313 Current limit 1/2 (page 123) in any case.

- In the "CFC" operating mode, if no other setting is made, the lowest magnetization current according to the motor model is always used. If P710/P711 is set to a higher value, this higher value applies.
- This function does not have any effect in "Servo" operating mode. No current is impressed.
- The rated magnetizing current will always be set for operating modes "VFC & Hoist", and "VFC n-control & Hoist" if P710 is active.
- Else, a rapid start will only take place if the set standstill current is greater than or equal to the rated magnetizing current.

During the standstill current phase, the motor resistance is calibrated in the intervals of the set premagnetization time if the standstill current was constant and greater than or the same as the rated magnetizing current of the motor during the measurement interval. If a new enable takes place before expiration of the measurement interval, there will be no calculation of a new resistance value. The existing resistance value will still be used.




MOVIPRO® – Parameterization

"PFA-..." power section parameter information

P72x Setpoint stop function

The setpoint stop function allows for an enable function created automatically by the inverter depending on the main setpoint. It results in an enable process with all necessary functions, such as premagnetization, brake control, etc. It always requires an additional enable via terminals.



9007199533486731

P720/P723 Setpoint stop function 1/2



Setting range: On/off

P721/P724 Stop setpoint 1/2



Setting range: 0 – 30 – 500 rpm

In the "VFC & Hoist" operating mode, the minimum stop setpoint is internally limited to 16 rpm.


P722/P725 Start offset 1/2



Setting range: 0 – 30 – 500 rpm

There is no enable for stop setpoint + start offset (start setpoint) > n_{\max} .

Movement with n_{\min} is never possible if the stop setpoint is > n_{\min} .




P73x Brake function

The power section is capable of controlling a brake installed on the motor. The brake function acts on the binary output DBØØ, which has the fixed assignment of the "/Brake" function (24 V = brake released). In drives with encoder feedback (speed control), it is possible to select between electrical holding of the load and mechanical application of the brake in halt condition.



INFORMATION

The brake is always applied when "/Controller inhibit" = 0.



278749067


P730/P733 Brake function 1/2



Setting range: On/off

This function determines whether the brake is to be activated when the enable is withdrawn (enable = "0"). The brake is always active in controlled hoist operation.

P731 / P734 Brake release time 1 / 2




Setting range: 0 – 2 s

The brake release time of the matching motor is set as the factory setting.

This parameter determines how long the motor will remain at a standstill after expiration of the premagnetizing time and how much time the brake has to release.

P732 / P735 Brake application time 1 / 2



Setting range: 0 – 2 s

The brake application time of the matching motor is set as the factory setting.

Serves to set the time required for application of the mechanical brake. This parameter prevents a sagging of the drive (particularly in hoists).




MOVIPRO® – Parameterization

"PFA-..." power section parameter information

P74x Speed skip

The skip window center and skip width are values and automatically have an effect on positive and negative setpoints when activated. The function is deactivated by setting the skip width to 0.



278752395

The "Speed skip" function makes it possible to prevent the motor speed from remaining within a certain speed window. This suppresses vibration and noise, in particular in machines with pronounced mechanical resonance.

P740/P742 Skip window center 1/2




Setting range: 0 – 1500 – 600 rpm

P741 / P743 Skip width 1 / 2



Setting range: 0 – 300 rpm



11.5.9 P8xx Unit functions

P80x Setup

P802 Factory setting

Setting range: No / standard / delivery condition

You can use P802 to reset the factory settings stored in the EPROM for almost all parameters.



INFORMATION

The "Standard" setting overwrites almost all parameter values; the setting "Delivery condition" overwrites all parameter values. Save the set parameter values with MOVITOOLS® Motion-Studio before you start resetting the parameters. After resetting, it is necessary to adapt the altered parameter values and terminal assignments to meet the requirements.

- The following data are not reset when "Standard" is selected:

- Application module
- P20x Speed control (page 121)
- P210 P-gain hold controller (page 122)
- P30x/P31x Limits 1/2 (page 123)
- P32x/P33x Motor compensation 1/2 (page 124)
- P344 Motor protection interval (page 127)
- P345/P346 I_N - U_L monitoring 1/2 (page 127)
- P53x Motor temperature protection (page 130)
- P70x Operating modes (page 134)
- P73x Brake function (page 137)
- P905 Hiperface offset (motor) (page 148)
- P910 Gain X controller (page 148)
- P94x IPOS encoder (page 152)
- Error memory
- Statistical data

- The "Delivery condition" setting also resets the data listed above.

"8.8.8" appears on the 7-segment display during the reset. The previous operating status of the inverter appears on the display after the factory settings have been restored. P802 automatically reverts to "No".



P803 Parameter lock

Setting range: On/off



INFORMATION

Startup is not possible when P803 is set to ON.

By setting P803 to "ON", you can prevent any modification of parameters. The parameter lock does not have any effect on the following parameters:

- P803 Parameter lock
- P840 Manual reset
- P876 PO data enable

This makes sense, for example, after the power section setting has been optimized. P803 must be set to "OFF" to enable changes to parameters again.

P804 Reset statistics data

Setting range: No / error memory / kWh counter / operating hours

P804 permits reset of the statistics data stored in the EEPROM, namely the error memory, kilowatt-hour meter and operating hours counter. This data is not affected when selecting "Standard" for P802 Factory setting.


P82x Brake operation

P820/P821 4-quadrant operation 1/2

Setting range: On/off

This setting is only taken into account in operating modes without encoder feedback (VFC, V/f); 4-quadrant operation is assumed in all other operating modes. P820/P821 enables 4-quadrant operation to be switched on and off for parameter sets 1/2. 4-quadrant operation is possible if a braking resistor is connected to MOVIPRO® (CCW/CW; motor/regenerative). P820/P821 must be set to "OFF" if there is no braking resistor connected to MOVIPRO®, which means regenerative operation is not possible. In these operating modes, MOVIPRO® attempts to extend the deceleration ramp so the regenerated power is not too great and the DC link voltage remains below the switch-off threshold.

Despite the fact that the deceleration ramps are automatically extended by MOVIPRO®, it is possible that the regenerated power during braking may be too great, leading to MOVIPRO® switching itself off and issuing error message F07 (DC link overvoltage). In this case you have to extend the deceleration ramps manually.



P83x error responses

The following responses can be programmed:

Response	Description
No response	Neither an error is displayed nor an error response is performed. The signaled error is ignored.
Display error	The error is displayed (on the 7-segment display and in MOVITOOLS® Motion-Studio). The unit performs no other error responses. The error can be reset (terminal, fieldbus, auto reset).
Immediate stop/malfunction	The inverter switches off immediately and an error is signaled. The output stage is inhibited and the brake is applied. The ready signal is revoked. A restart is only possible after an error reset has been performed during which the inverter is reinitialized.
Emergency stop/malfunction	The drive is braked with the set emergency stop ramp t14/t24 (page 120). Once the stop speed is reached, the output stage is inhibited and the brake is applied. The error is signaled immediately. The ready signal is revoked. A restart is only possible after an error reset has been performed during which the inverter is reinitialized.
Rapid stop/malfunction	The drive is braked with the set stop ramp t13/t23 (page 119). Once the stop speed is reached, the output stage is inhibited and the brake is applied. The error is signaled immediately. The ready signal is revoked. A restart is only possible after an error reset has been performed during which the inverter is reinitialized.
Immediate stop/warning	The inverter switches off immediately and an error is signaled. The output stage is inhibited and the brake is applied. The ready signal is not revoked. The drive restarts without unit re-initialization if the error is rectified by an internal procedure or by an error reset.
Emergency stop/warning	The drive is braked with the set emergency stop ramp t14/t24 (page 120). Once the stop speed is reached, the output stage is inhibited and the brake applied. The error is signaled immediately. The ready signal is not revoked. The drive restarts without unit re-initialization if the error is rectified by an internal procedure or by an error reset.
Rapid stop/warning	The drive is braked with the set stop ramp t13/t23 (page 119). Once the stop speed is reached, the output stage is inhibited and the brake applied. The error is signaled immediately. The ready signal is not revoked. The drive restarts without unit re-initialization if the error is rectified by an internal procedure or by an error reset.

P830 Response to 'External error'

Factory setting: Emergency stop/malfunction

The error is only triggered in the ENABLED inverter status. P830 programs the error response that is triggered by an input terminal programmed to "/EXT.ERROR".

P832 Response to "Motor overload"

Factory setting: Emergency stop/malfunction

P832 programs the error response that is triggered in the event of motor overload. Make one of the following settings to monitor motor overload:

- P340 Motor protection 1 (page 125) to "ON asynchronous motor"
- P340 Motor protection 1 (page 125) to "ON servomotor" and P530 Sensor type 1 (page 130) to "KTY"

P834 Response to "Lag error"

Lag error response only with application module.

Factory setting: Emergency stop/malfunction

P834 programs the error response which is triggered via the lag error monitoring function of an application module.

P835 Response to "TF signal"



Factory setting: No response

P835 programs the error response which is triggered by the temperature sensor monitoring of the TF or TH which may be incorporated in the motor winding.



MOVIPRO® – Parameterization

"PFA-..." power section parameter information

P836 Response to "Timeout SBus 1"

Factory setting: Emergency stop/malfunction

P836 programs the error response that is triggered by system bus timeout monitoring.

P838 Response to "SW limit switch"

Factory setting: Emergency stop/malfunction

P838 programs the error response executed by the inverter if a target position for a referenced drive is outside the software limit switch. The software limit switches are set via parameters P920/P921 (page 150).

P839 Response to "Positioning interruption"

Factory setting: No response

If P924 "Positioning interruption" detection (page 151) is set to "On", the response set here is triggered when a positioning sequence is interrupted.

P84x Reset behavior

P840 Manual reset

Setting range: Yes/No

- Yes: The error in the power section is reset. P840 automatically reverts to "No" after the reset. Activating manual reset does not have any effect if there is no error present.
- No: No reset.

P841 Auto reset

Setting range: On/off




! DANGER

Risk of crushing if the motor starts up automatically after an auto reset.


Severe or fatal injuries.

- Do not use auto reset with drives where an automatic restart represents a danger to people or units.
 - Perform a manual reset.
-
- On: The auto reset function is activated. In case of an error, this function automatically resets the unit after *P842 Restart time*. A maximum of five auto resets is possible during an auto reset phase. If five errors occur that are reset by an auto reset, no more auto resets are possible until:
 - a manual reset is performed using the input terminal,
 - a manual reset is performed using the serial interface (MOVITools® MotionStudio, higher-level controller),
 - there is a transition to 24 V backup mode, or the inverter is switched off.

Five automatic resets are then possible.
 - Off: No auto reset.



- P842 Restart time** Setting range: 1 – 3 – 30 s
P842 is used to set the waiting time between the moment an error occurs and the execution of an automatic reset.
- P85x Scaling actual speed value** Scaling actual speed value defines a user-specific display parameter *P001 User display* (page 115). For example, the user display is to be shown in s^{-1} . Such a setting requires a scaling factor of 1/60. This means the numerator scaling factor has to be set to 1 and the denominator scaling factor to 60. The scaling unit s^{-1} is entered in *P852 User-defined unit*.



279044491

- P850 Scaling factor numerator** Setting range: 1 – 65535
- P851 Scaling factor denominator** Setting range: 1 – 65535
- P852 User-defined unit** Factory setting: rpm
Up to eight ASCII characters; is displayed in *P001 User display* (page 115).

P86x Modulation

P860/P861 PWM frequency 1/2



Setting range: 4 / 8 / 12 / 16 kHz

P860/P861 can be used in VFC mode to set the switching frequency at the inverter output for parameter set 1/2. The inverter automatically switches back to lower switching frequencies when the unit utilization reaches a specific level if the clock frequency for parameter set 1/2 is not fixed to the set value using *P862/P863 PWM fixed 1/2* (page 143). The modulation frequency reduces switching losses in the output stage and, consequently, unit utilization.

P862 / P863 PWM fix 1/2



Setting range: On/off

- **On:** Use P862/P863 = "ON" for parameter sets 1/2 to fix the PWM frequency set with *P860/P861 PWM frequency 1/2* when an automatic reduction of the PWM frequency is undesirable (e.g. when output filters are used).
- **Off:** MOVIPRO® automatically reduces the set output frequency (down to a minimum of 4 kHz) when there is a high level of thermal load on the output stage to avoid a switch-off with the "Unit utilization" error.

P864 PWM frequency CFC

Setting range: 4 / 8 / 16 kHz

P864 can be used in "CFC" and "Servo" operating mode to set the switching frequency at the inverter output for parameter set 1. The cycle frequency is set to a fixed value and is not automatically reduced with high unit utilization.



MOVIPRO® – Parameterization

"PFA-..." power section parameter information

P87x Process data description

P870/P871/P872 Setpoint description PO1/PO2/PO3


P870/P871/P872 define the content of the process output data words PO1/PO2/PO3. This is necessary so that the power section can allocate the appropriate setpoints.

Setpoint description	Factory setting
P870 Setpoint description PO1	Control word 1
P871 Setpoint description PO2	Setpoint speed
P872 Setpoint description PO3	Ramp

The following PO assignments are available:

Assignment	Description
No function	The content of the process output data word is ignored.
Setpoint speed	Setpoint speed in rpm
Set current	Current setpoint selection (for torque control)
Set position low	Setpoint position low word
Set position high	Setpoint position high word
Max. speed	Maximum system speed (P302 / P312)
Max. current	Current limitation in % of I_N of the inverter (P303/P313)
Slip speed	Slip compensation (P324/P334)
Ramp	Ramp time for setpoint selection
Control word 1	Control signals for start/stop, etc.
Control word 2	Control signals for start/stop, etc.
Setpoint speed [%]	Selection of a speed setpoint in % of n_{max}
IPOS PO data	Specification of a 16-bit coded value for IPOS ^{plus} ® (application module only)

See the "Fieldbus unit profile with parameter list" manual for detailed explanations.



P873/P874/P875
Actual value
description PI1/
PI2/PI3

P873/P874/P875 define the content of the process input data words PI1/PI2/PI3. This is necessary so MOVIPRO® can allocate the appropriate actual values.

Actual value description	Factory setting
P873 Actual value description PI1	Status word 1
P874 Actual value description PI2	Actual speed
P875 Actual value description PI3	Output current

The following PI assignments are available:

Assignment	Description
No function	The content of the process input data word is 0000 _{hex}
Actual speed	Current speed actual value of the drive in min ⁻¹
Output current	Present output current of the system in % of I _N .
Active current	Present active current of the system in % of I _N : • Positive sign = positive torque • Negative sign = negative torque
Actual position low ¹⁾	Current actual position low word
Actual pos. high ¹⁾	Present actual position high word
Status word 1	Status information of the inverter
Status word 2	Status information of the inverter
Actual speed [%]	Current actual speed value in % of n _{max}
IPOS PI-DATA	Feedback of a 16-bit coded value for IPOS ^{plus} ® (application modules only).
Status word 3	Status information of the inverter

1) Both assignments must always be set.

See the "Fieldbus unit profile with parameter list" manual for a detailed explanation.

P876 PO data
enable

Setting range: On/off

- On: The process output data that was last sent from the fieldbus controller becomes effective.
- Off: The last valid process output data remain in effect.

NOTE: If the process data assignment is changed, P876 is automatically set to "Off".

11.5.10 P9xx IPOS parameters

The IPOS^{plus}® parameters can only be used in connection with an application module.



DANGER


Risk of crushing if the motor starts up unintentionally.

Severe or fatal injuries.

- Ensure that the motor cannot start unintentionally.
- Note that modifying these parameters without knowledge of the IPOS^{plus}® program, which may be active, can cause unexpected movements and place unwanted loads on the mechanical driveline. It is essential that you are familiar with the IPOS^{plus}® manual to make the setting for these parameters.

P90x IPOS refer-
ence travel

The purpose of reference travel is to establish a machine zero to which all absolute positioning commands refer. It is possible to select from various reference travel strategies in P903 Reference travel type (page 146). These strategies define appropriate travel modes, for example to search for a reference cam. Using the reference point determined



by reference travel, the machine zero point can be changed using *P900 Reference offset* (page 146) according to the following equation:

$$\text{Machine zero} = \text{reference point} + \text{reference offset}$$

The speeds of the travel movements required on the basis of the reference travel type are set using *P901 Reference speed 1* (page 146) and *P902 Reference speed 2* (page 146).

P900 Reference offset

Setting range: $-(2^{31}-1) - \underline{0} - (2^{31}-1)$

Reference offset (zero offset) is used to determine the machine zero. The following applies:

$$\text{Machine zero} = \text{reference point} + \text{reference offset}$$

The reference offset always refers to the encoder set via *P941 Source actual position* (page 152).

This encoder can be a motor encoder, an external encoder or a DIP encoder. The corresponding actual positions are indicated by IPOS^{plus}® variables.

- H510 Actual position external encoder
- H511 Actual position motor encoder

The reference offset is activated again after reference travel has been completed successfully.

INFORMATION



In case of reference travel of a drive system with HIPERFACE® encoder, the value of P905 is recalculated and overwritten by the reference travel.

P901 Reference speed 1

Setting range: 0 – 200 – 6000 rpm

Reference speed 1 determines the travel speed for the first part of the reference travel. Speed change always takes place via stop ramp t13 (page 119). The search directions during reference travel are determined by the respective reference travel type. The speed is in effect until the reference cam has been reached.

P902 Reference speed 2

Setting range: 0 – 50 – 6000 rpm

Reference speed 2 determines the travel speed for the second part of the reference travel. Speed change always takes place via stop ramp t13 (page 119). The search directions during reference travel are determined by the respective reference travel type. The speed is used from the time the drive moves away from the reference cam to when it reaches the first zero pulse.

P903 Reference travel type


Setting range: 0 – 8

The reference travel type specifies the reference travel strategy that is used to establish the machine zero of a machine.

This setting also defines the search direction for the reference cam in the individual referencing phases.

Use parameter *P904 Referencing to zero pulse* (page 148) to determine if the reference travel takes place to the edge change of the reference cam or the next zero pulse of the encoder.

Prerequisite for execution of reference travel is a drive that is ready and enabled with the exception of reference travel type 8.



There are also types available that can function without a reference cam.

- Type 0: Left zero pulse
 - First search direction is CCW.
 - Reference position = Left zero pulse from current position
 - Machine zero = reference point + reference offset
- Type 1: CW end of the reference cam
 - First search direction is CCW.
 - Reference position = First zero pulse or falling edge to the left of the reference cam
 - Machine zero = reference point + reference offset
- Type 2: CW end of the reference cam
 - First search direction is CW.
 - Reference position = First zero pulse or falling edge to the right of the reference cam
 - Machine zero = reference point + reference offset
- Type 3: Limit switch right
 - First search direction is CW.
 - Reference position = First zero pulse or falling edge to the left of the right limit switch.
 - Machine zero = reference point + reference offset
 - Reference travel should take place to zero pulse.
- Type 4: Limit switch left
 - First search direction is CCW.
 - Reference position = First zero pulse or falling edge to the right of the left limit switch.
 - Machine zero = reference point + reference offset
 - Reference travel should take place to zero pulse.
- Type 5: No reference travel
 - Reference position = current position
 - Machine zero = reference offset
- Type 6: Reference cam flush with right limit switch
 - First search direction is CW.
 - Reference position = First zero pulse or falling edge to the left of the reference cam
 - Machine zero = reference point + reference offset
 - INFORMATION:** Reference cam and limit switches must be flush.
- Type 7: Reference cam flush with left limit switch
 - First search direction is CCW.
 - Reference position = First zero pulse or falling edge to the right of the reference cam
 - Machine zero = reference point + reference offset
 - INFORMATION:** Reference cam and limit switches must be flush.



- Type 8: Resetting of encoder position for drive not ready for operation
Reference travel can take place when the drive is not enabled.
 - Reference position = current position
 - Machine zero = reference offset

P904 Reference travel to zero pulse

Setting range: Yes/No

- Yes: Reference travel takes place to the zero pulse of the selected IPOS^{plus}® encoder.
- No: Reference travel takes place to the falling edge of the reference cam.

P905 Hiperface offset (motor)

Setting range: $-(2^{31}-1) - \underline{0} - (2^{31}-1)$

This parameter is used to specify the zero point of the motor encoder display.

Use this parameter to define the machine zero without reference travel. It adds or subtracts the offset from the encoder value. P905 has an effect on the actual position of the motor encoder H511:

$$H511 = \text{Encoder value} - P905$$

The actual position is determined directly after the values have been entered. A HIPERFACE® multi-turn encoder must be referenced once, a HIPERFACE® single-turn encoder must always be referenced.

INFORMATION



In case of reference travel of a drive system with HIPERFACE® encoder, the value of P905 is recalculated and overwritten by the reference travel.

The following applies:

$$P905 = \text{Encoder value} - P900$$

P906 Cam distance


The parameter contains the number of increments from the reference cam to the zero pulse of the motor encoder. The cam distance is displayed after a successful reference travel. Ideally, it is half of the encoder resolution after 4-fold evaluation. Relocate the cam if necessary.

P91x IPOS travel parameters

P910 Gain X controller

Setting range: 0,1 – 0,5 – 32

Setting value for the P controller of the position control loop in IPOS^{plus}®. The value from P210 P gain hold controller (page 122) is adopted here in the default setting.



P911/912 Positioning ramp 1/2

Setting range: 0,01 – 1 – 20 s

Value set for the ramp used during the positioning operation. The same ramp (positioning ramp 1) is always used for acceleration and deceleration when *P916 Ramp type* (page 149) is set to "Sine" or "Squared". For a "linear" ramp type, deceleration will be set depending on *P917 Ramp mode* (page 150):

- P917 = Mode 1: Deceleration for travel to target position (spot braking) only takes place with positioning ramp 2. Positioning ramp 1 is used for all other positioning operations.
- P917 = Mode 2: Positioning ramp 2 is always used for deceleration if the travel speed is changed during travel. Positioning ramp 1 is used for acceleration.

P913/P914 Travel speed CW/CCW

Setting range: 0 – 1500 – 6000 rpm

Specifies the speed used for positioning. The setting must be adjusted to the maximum motor speed.



INFORMATION

P302/P312 Maximum speed 1/2 (page 123) limits P913/P914; always set P302/P312 to a value greater (about 10 %) than P913/P914 to prevent lag errors.

P915 Velocity pre-control

Setting range: –199.99 – 0 – 100 – 199.99%

When the setting is 100 %, the drive moves at an optimum speed with a linear speed profile. If a value less than 100% is specified, a larger gap between position setpoint and actual position occurs (lag distance) during a positioning operation. This results in a "soft" run-in to the target position for the acceleration procedure.



INFORMATION

Parameter P915 is only in effect with the "linear" and "jerk limited" ramp types. The function has no effect for the ramp types "Sine" and "Squared".

P916 Ramp type




This parameter specifies the type of positioning ramp. This influences the speed or acceleration characteristics during positioning.


Ramp type	Positioning characteristics
Linear	Optimum time, however block-shaped acceleration characteristic
Square	Softer acceleration and higher torque demand than "linear".
Sine	Very soft acceleration profile, required torque higher than with "Squared" acceleration profile.
Bus ramp	Setting for operation of drive inverter with master controller. This controller generates a cyclical position setpoint that is written directly to the position controller. The ramp generator is deactivated. The position specifications sent cyclically by the external controller are interpolated linearly. For configuration, one process output data word must be set to "position high" and another one to "position low".
Jerk limitation	Jerk limitation is based on the principle of the linear ramp. For jerk limitation, the torque and, therefore, the acceleration is trapezoidal. Over time, jerk limitation builds up the torque in linear form during acceleration until the maximum value is reached. In the same way, the torque is reduced again over time in linear form to zero. This means that system vibrations can be virtually avoided. You can set a value between 0.005 s and 2 s under <i>P933 Jerk time</i> (page 151). The positioning time in comparison to the linear ramp is extended by the set jerk time. The acceleration and torque do not increase in comparison with the linear ramp.



- P917 Ramp mode** Setting range: Mode 1/mode 2
- This parameter determines the use of *P912 Positioning ramp 2* (page 149) with ramp type set to "linear".
- P917 = Mode 1: Deceleration for travel to target position (spot braking) takes place with Positioning ramp 2. Positioning ramp 1 is used for all other positioning operations. If position interpolation 12 bit or 16 bit is active, it runs in mode 1 without dead time compensation.
 - P917 = Mode 2: Positioning ramp 2 is always used for deceleration if the travel speed is changed during travel. Positioning ramp 1 is used for acceleration. If position interpolation 12 bit or 16 bit is active, it runs in mode 1 without dead time compensation.
- P918 Bus setpoint source** Setting range: 0 – 499 – 1023
- In conjunction with EtherCAT, parameter P918 can be used to set the source for the setpoint in IPOS^{plus}®.
- P92x IPOS monitoring**
- P920/P921 SW limit switch CW/CCW** Setting range: $-(2^{31}-1) - \underline{0} - (2^{31}-1)$
- The software limit switches let the user limit the range in which travel commands are accepted. This is implemented via software. The limits of the movement range are specified using these two parameters. If *P941 Source actual position* (page 152) is set to "motor encoder" or "external encoder", then these do not take effect until after performance of a reference travel. If the software limit switches are in effect, the system checks whether the target position H492 of the current travel command is beyond the software limit switches. If the target position is beyond the range limited by the limit switches, the travel command will not be executed. The drive responds according to the error response set in *P838 error response to SW limit switch* (page 142). If P838 is set to ".../warning" or ".../error", then error message "A1.F78" (IPOS SW limit switch) is generated. The software limit switches are only monitored in the "...& IPOS" operating modes.
- If P838 is set to ".../error", then the drive with incremental encoder is no longer referenced after an error reset whereas a drive with absolute encoder is still referenced.
- If the drive is not referenced, the software limit switches have no effect. They are only activated again after the drive has been referenced.
- If P838 is set to ".../warning", the drive will remain referenced after the reset. The drive can move past the target specified due to the mass moment of inertia of the machine or if the parameter settings are set incorrectly in the controller. Software limit switches cannot prevent this from happening.
- Deactivation:** Set both parameter values to 0 for endless travel so that the software limit switch function is deactivated.
- P922 Position window** Setting range: 0 – 50 – 32 767 incr.
- The parameter defines a distance range (position window) around the target position of a travel or stop command. The "Axis in position = Yes" condition applies if a drive is inside the position window around the current target position (H492). The "Axis in position" information is used as a final condition for waiting positioning commands.



<i>P923 Lag error window</i>	<p>Setting range: 0 – <u>5000</u> – 2³¹ – 1 incr.</p> <p>The lag error window defines a permitted difference between the setpoint and actual position value. If the permitted value is exceeded, a lag error response will be triggered. You can set the responses with <i>P834 Response to lag error</i> (page 141).</p> <p>Deactivation: Set value = 0 deactivates lag error monitoring</p>
<i>P924 Positioning interruption detection</i>	<p>Setting range: <u>On/off</u></p> <p>This parameter determines whether the positioning process is monitored for interruptions (enable signal revoked). The response is set in <i>P839 Response to "Positioning interruption"</i> (page 142).</p>
<i>P93x IPOS special functions</i>	
<i>P930 Override</i>	<p>Setting range: <u>On/off</u></p> <p>The override function makes it possible to change the travel speed for positioning operations which is programmed in the IPOS^{plus}® program. The speed can be altered within the range from 0 to 150 % of the specifically programmed speed. This requires an analog input, with 0 to 150 % corresponding to 0 – 10 V at the analog input. The maximum speed value is limited by <i>P302/P312 Maximum speed 1/2</i> (page 123).</p>
<i>P933 Jerk time</i>	<p>Setting range: <u>0.005</u> – 2 s</p> <p>The jerk time indicates the duration of the torque formation. The positioning time in comparison to the linear ramp is extended by the set jerk time. Make sure that <i>P911/P912 Positioning ramp 1/2</i> (page 149) is of a greater or equal value:</p> <p style="margin-left: 40px;">P933 ≤ P911</p> <p style="margin-left: 40px;">P933 ≤ P912</p> <p>If this is not true, torque formation still has a trapezoidal shape with the set jerk time not being the time for the torque formation.</p>
<i>P938 IPOS speed task 1</i>	<p>Setting range: <u>0</u> – 9 additional assembler commands/ms</p> <p>The standard setting for task 1 is "1". The speed can be increased by up to 9 additional assembler commands per millisecond with P938. P938 and <i>P939 IPOS speed task 2</i> (page 151) share the resources for the speed increase; that is, task 1 and task 2 together can be assigned a total of 9 additional assembler commands per millisecond. Example:</p> <p style="margin-left: 40px;">Task 1 + 2 additional assembler commands/ms = 3 assembler commands/ms</p> <p style="margin-left: 40px;">Task 2 + 7 additional assembler commands/ms = 9 assembler commands/ms</p>
<i>P938 IPOS speed task 2</i>	<p>Setting range: <u>0</u> – 9 additional assembler commands/ms</p> <p>The standard setting for task 2 is "2". The speed can be increased by up to 9 additional assembler commands per millisecond with P939. P939 and <i>P938 IPOS speed task 1</i> (page 151) share the resources for the speed increase; that is, task 1 and task 2 together can be assigned a total of 9 additional assembler commands per millisecond. Example:</p> <p style="margin-left: 40px;">Task 1 + 2 additional assembler commands/ms = 3 assembler commands/ms</p> <p style="margin-left: 40px;">Task 2 + 7 additional assembler commands/ms = 9 assembler commands/ms</p>



MOVIPRO® – Parameterization

"PFA-..." power section parameter information

P94x IPOS encoder

P941 Source of actual position

Setting range: Motor encoder / Ext. Encoder

Defines the encoder to which the application module positions.

P948 Automatic encoder replacement detection

Setting range: On/off

This parameter is only effective with HIPERFACE® encoders.

- On: A replaced HIPERFACE® encoder is detected. Reference travel is required before the "IPOS referenced" bit is set.
- Off: The HIPERFACE® encoder is always referenced. The "IPOS referenced" bit is set.

NOTE: If P948 is switched off and on again, the "IPOS referenced" bit is set to "0" once you have restarted the MOVIPRO®. Reference travel is necessary to reset the "IPOS referenced" bit to "1".

P96x IPOS modulo function

The IPOS^{plus}® modulo function is used for endless positioning, for example with circular indexing tables or chain conveyors.

P960 Modulo function

Setting range: Off / Short / CW / CCW

- Off: The modulo function is deactivated.
- In short: The "short travel" modulo function is active. The drive moves from the actual position to the target position taking the shortest possible route. Both directions of rotation are possible.
- Right: The "CW" modulo function is active. The drive moves from its actual position to the target position with a "CW" direction of rotation, even if this means moving a longer distance. The "CCW" direction of rotation is not possible.
- CCW: The "CCW" modulo function is active. The drive moves from its actual position to the target position with a "CCW" direction of rotation, even if this means moving a longer distance. The "CW" direction of rotation is not possible.

P961 Modulo numerator

Setting range: 1 – $(2^{31}-1)$

Simulation of the gear unit by entering the number of teeth of the gear unit and the additional gear.

Modulo numerator = Numerator gear unit $i \times$ numerator additional gear i

P962 Modulo denominator

Setting range: 1 – $(2^{31}-1)$

Simulation of the gear unit by entering the number of teeth of the gear unit and the additional gear.


Modulo denominator = Denominator gear unit $i \times$ denominator additional gear i

P963 Modulo encoder resolution

Setting range: 1 – 4096 – 65535

Resolution of the selected IPOS^{plus}® encoder system in increments.


The IPOS^{plus}® encoder resolution for positioning to the motor encoder is set to 4096 increments (prerequisite is an encoder resolution of 512 to 2048).



11.6 Parameter overview of the encoder option


The encoder option is parameterized during startup (see section "Encoder configuration" (page 89)). You have to specify the encoder connected to MOVIPRO® and the corresponding resolution.

In addition you can make adjustments in the parameter tree, e.g. the counting direction or the clock rate.



3030061067

Parameter	Description
Encoder type	The encoder set via the startup of the MOVIPRO® is displayed
Encoder scaling numerator	The numerator of the encoder scaling set via the startup of the MOVIPRO® is displayed
Encoder scaling denominator	The denominator of the encoder scaling set via the startup of the MOVIPRO® is displayed
Counting direction	Defines the counting direction of the connected encoder. Make the settings so that the encoder counts in positive direction when the motor shaft turns clockwise.
Position mode	<p>With overflow counter:</p> <ul style="list-style-type: none"> Encoder overflows are counted and an internal 32-bit position is generated in the inverter <p>Single-turn absolute position:</p> <ul style="list-style-type: none"> Only via single-turn absolute encoder. The position is displayed according to the encoder information. Encoder overflows are not counted <p>Linear operation:</p> <ul style="list-style-type: none"> The position is displayed according to the encoder information. Encoder overflows are not counted



Parameter	Description
Encoder monitoring motor	<p>NO:</p> <ul style="list-style-type: none"> Wire break between frequency inverter and motor encoder is not detected directly. In case of a defective connection, error F08 speed monitoring will be issued in enabled state unless it was deactivated. <p>YES:</p> <ul style="list-style-type: none"> Wire break between frequency inverter and motor encoder will be detected directly when using sin/cos encoders and TTL encoders. The error message "F14 Encoder error" will be issued in case of an error. This error will also be generated in inhibited state. <p>NOTE Encoder monitoring is not a safety-relevant function. If you use a HIPERFACE® encoder, encoder monitoring is always active (for the track too) irrespective of the setting in P504.</p>
Position offset	<p>Setting range: $(-2^{31} \dots 0 \dots 2^{31}-1)$</p> <p>The position offset only has to be set on incremental encoders. For other encoders, its should be set to "0".</p> <p>NOTE The position value will be recalculated and overwritten automatically after successful completion of the reference travel.</p>
SSI clock rate	<p>Setting range: 125, 250, 500, 1000, 2000 kHz</p> <p>This parameter defines the cycle frequency at which absolute encoder information is transmitted from the encoder to the inverter.</p>
EnDAT clock rate	<p>Setting range: 125, 250, 500, 1000, 2000 kHz</p> <p>This parameter defines the cycle frequency at which absolute encoder information is transmitted from the encoder to the inverter.</p>
CANopen baud rate	<p>Setting range: 125, 250, 500 kBaud, 1 MBaud</p> <p>This parameter determines the transmission speed of the CAN bus.</p>



12 Service

12.1 Unit replacement

12.1.1 Notes on replacing units

The MOVIPRO® unit allows for a quick unit replacement. The MOVIPRO® unit is equipped with a replaceable memory card on which all unit data can be stored.

If a unit has to be replaced, the plant can be started up again quickly by simply re-plugging the memory card.

After the startup procedure, you have to download the unit data to the memory card.



INFORMATION

Observe the following notes when replacing a unit:

- Only insert the memory card when the MOVIPRO® unit is switched off.
- After the replacement, the parameters last saved on the SD card are used.
- If an absolute encoder is used as motor encoder or synchronous encoder, you have to perform a reference travel during initial startup or after a unit or encoder replacement.
- If you use an encoder with HIPERFACE® interface, a unit or encoder replacement is detected automatically and the "IPOS reference" is reset.
- If you use an encoder with SSI interface, you have to adapt the encoder position to the mechanical plant conditions via a reference travel.


12.1.2 Replacing units

Proceed as follows to replace the MOVIPRO®:

1. Perform a data backup now if you are not certain whether the current unit parameterization is stored on the SD card.
2. Disconnect the MOVIPRO® unit from the power supply and remove it from the system.
3. Remove the memory card of the unit via the service cover plate on the MOVIPRO® housing cover.
4. Insert the memory card into a new MOVIPRO® unit via the service cover plate.
5. Install the new MOVIPRO® unit in the system and connect it to the power supply.



6. Switch on the new MOVIPRO® unit.



1952918283

7. Now the parameters stored on the card are available. If you want the new MOVIPRO® unit to have a different parameter set, change the parameter set now, and save the changes on the memory card after startup.
8. For applications with motor encoder or synchronous encoder, you have to perform a reference travel.



12.2 Encoder exchange

12.2.1 Replacing incremental encoders

Incremental encoders for positioning always require a reference travel after startup. This is why there are no special measures required in the event of a unit or encoder (motor) replacement.

12.2.2 Replacing absolute encoders.

MOVIPRO® stores the position of absolute encoders with 32 bit. This allows for representing a larger absolute area than with an encoder with typical 12 bits in the single-turn range and 12 bits in the multi-turn range. However, this also means that you must reference the encoder in case of a unit or encoder (motor) replacement.

12.2.3 Replacing linear encoder systems

If you replace an absolute linear encoder system without encoder overflow in such a way that the encoder system provides the same values as before the replacement, a reference travel is not required.


12.2.4 Replacing HIPERFACE® encoders

With HIPERFACE® encoders, you can use parameter P948 to specify whether or not a reference travel is required after an encoder replacement.

12.3 Service unit

The service unit is used for startup, diagnostics, and maintenance of the MOVIPRO® unit. It is equipped with a status display and a service interface

The following figure shows the service unit:



[1] Service unit
[2] Status indication

[3] Ethernet service interface (Ethernet RJ45)
[4] Status LED

18014399568351371



Status display and LED

The status display and the LED show status or error messages and allow for a quick evaluation of the current status of MOVIPRO®.

Ethernet service interface

For configuration and maintenance purposes, the unit is equipped with an Ethernet service interface that connects MOVIPRO® to an engineering PC.

Ethernet service interface	
Standard IP address	Subnetwork mask
192.168.10.4	255.255.255.0

12.4 MOVIPRO® SDC error list

The factory set error response is listed in the "Response (P)" column. "(P)" means that the response can be set with parameter *P83_error response*.

Error			Suberror		Possible cause	Measure
Code	Designation	Response (P)	Code	Designation		
00	No error					
01	Overcurrent	Immediate disconnection	0	Output stage	<ul style="list-style-type: none"> Short circuit at output Motor too large Faulty output stage Ramp limit is deactivated and set ramp time is too short Braking resistance value too low Short circuit in the braking resistor circuit 	<ul style="list-style-type: none"> Rectify the short circuit Connect a smaller motor Consult SEW Service if the output stage is defective. Extend the ramp time Check technical data of braking resistor Check the supply cable of the braking resistor
			1	V _{CE} monitoring or undervoltage monitoring of the unit driver		
			5	Inverter remains in hardware current limit		
03	Ground fault	Immediate disconnection	0			
04	Brake chopper	Immediate disconnection	0	DC link voltage too high in 4Q operation	<ul style="list-style-type: none"> Too much regenerative power Braking resistor circuit interrupted Short circuit in the braking resistor circuit Brake resistance too high Brake chopper defective 	<ul style="list-style-type: none"> Extend deceleration ramps Check supply cable to braking resistor Check technical data of braking resistor Replace MOVIPRO® if the brake chopper is defective
			1			
06	Line phase failure	Immediate disconnection	0	DC link voltage periodically too low	Phase failure	Check the line cable
07	DC link over-voltage	Immediate disconnection	0	DC link voltage too high in 2Q operation	DC link voltage too high	<ul style="list-style-type: none"> Extend deceleration ramps Check supply cable to the braking resistor Check technical data of braking resistor
			1			



Error			Suberror		Possible cause	Measure
Code	Designation	Response (P)	Code	Designation		
08	Speed monitoring	Immediate disconnection (P)	0	Inverter in current limit or in slip limit	<ul style="list-style-type: none"> Speed/current controller (in VFC operating mode without encoder) operating at setting limit due to mechanical overload or phase failure in the power system or motor. Encoder not connected correctly or incorrect direction of rotation n_{max} is exceeded during torque control. In operating mode VFC: Output frequency > 150 Hz In operating mode V/f: Output frequency > 600 Hz 	<ul style="list-style-type: none"> Reduce load Increase delay time setting (<i>P501</i> or <i>P503</i>). Check encoder connection, swap A/A and B/B pairs if necessary Check encoder voltage supply Check current limitation Extend ramps if necessary Check motor cable and motor Check line phases
			3	"Actual speed" system limit exceeded. Speed difference between ramp set-point and actual value for $2 \times$ ramp time higher than expected slip		
			4	Maximum rotating field speed exceeded Maximum rotating field frequency (with VFC max 150 Hz and V/f max 600 Hz) exceeded		
09	Startup	Immediate disconnection	0	Startup missing	The inverter has not been started up for the selected operating mode or the encoder data has not been loaded yet.	Perform the startup for the respective operating mode or start up the encoder.
			1	Wrong operating mode selected		
			2	Wrong encoder type or defective encoder card		
10	IPOS-ILLOP	Emergency stop	0	Invalid IPOS ^{plus} ® command	<ul style="list-style-type: none"> Incorrect command detected during execution of the IPOS^{plus}® program Incorrect conditions during command execution 	<ul style="list-style-type: none"> Check the content of the program memory and, if necessary, correct. Load the correct program into the program memory Reload the application module
11	Overtemperature	Emergency stop (P)	0	Heat sink temperature too high or defective temperature sensor	Thermal overload of inverter	Reduce load and/or ensure adequate cooling
			3	Overtemperature switched-mode power supply		



Error			Suberror		Possible cause	Measure
Code	Designation	Response (P)	Code	Designation		
14	Encoder	Immediate dis-connection	0	Encoder not connected, defective encoder, defective encoder cable	<ul style="list-style-type: none"> Encoder cable or shield not connected correctly Short circuit/broken encoder wire Encoder defective 	Check encoder cable and shield for correct connection, short circuit and broken wire.
			25	Motor encoder error – Speed range exceeded Encoder exceeds 6542 rpm		
			26	Motor encoder error – Card is defective. Error in the quadrant evaluation.		
			27	Encoder error – encoder connection or encoder is defective		
			28	Encoder error – Communication error RS485 channel.		
			29	External encoder error – Communication error RS485 channel		
			30	Unknown encoder type on the external encoder/motor encoder		
			31	Plausibility error of HIPERFACE® on the external encoder/motor encoder Increments have been lost.		
			32	HIPERFACE® motor encoder error HIPERFACE® encoder on motor encoder reports an error		
			33	HIPERFACE® external encoder error HIPERFACE® encoder on external encoder reports an error		
			34	Revolver motor encoder error Encoder connection or encoder is defective.		
17	System malfunction	Immediate dis-connection	0	"Stack overflow" error	Inverter electronics disrupted, possibly due to effect of EMC	<ul style="list-style-type: none"> Check grounding and shielding and improve, if necessary Consult SEW service if the error occurs again
18			0	"Stack underflow" error		
19			0	"External NMI" error		
20			0	"Undefined opcode" error		
21			0	"Protection fault" error		
22			0	"Illegal word operand access" error		
23			0	"Illegal instruction access" error		
24			0	"Illegal external bus access" error		



Error			Suberror		Possible cause	Measure
Code	Designation	Response (P)	Code	Designation		
25	EEPROM	Rapid stop	0	Read or write error on EEPROM power section	Error while accessing EEPROM	<ul style="list-style-type: none"> Restore factory settings, perform reset and reset parameters. Consult SEW service if the error reoccurs
			11	NV memory read error Internal NVRAM		
			13	NV memory chip card System module defective		
			14	NV memory chip card Memory card defective		
			16	NV memory initialization error		
26	External terminal	Emergency stop (P)	0	External terminal	Read external error signal via programmable input	Eliminate respective cause; reprogram terminal if necessary
27	No limit switches	Emergency stop	0	Both limit switches missing or open circuit	<ul style="list-style-type: none"> Open circuit/both limit switches missing Limit switches are swapped over in relation to direction of rotation of motor 	<ul style="list-style-type: none"> Check wiring of limit switches Swap limit switch connections Reprogram terminals
			2	Limit switch reversed		
			3	Both limit switches are active simultaneously		
29	Limit switch contacted	Emergency stop	0	Hardware limit switch approached	A limit switch has been reached in IPOS ^{plus} ® mode (only with application module).	<ul style="list-style-type: none"> Check travel range Correct operator program
30	Emergency stop Timeout	Immediate disconnection	0	Emergency stop ramp time exceeded	<ul style="list-style-type: none"> Drive overloaded Emergency stop ramp too short 	<ul style="list-style-type: none"> Check configuration Extend emergency stop ramp
31	TF/TH sensor tripped	No response (P)	0	Thermal motor protection error	<ul style="list-style-type: none"> Motor too hot, TF/TH has triggered TF/TH of the motor not connected or connected incorrectly MOVIDRIVE® connection and TF/TH connection on motor interrupted 	<ul style="list-style-type: none"> Let motor cool off and reset error Check connections/link between MOVIDRIVE® and TF/TH. Set P835 to "No response"
32	IPOS index overflow	Emergency stop	0	IPOS ^{plus} ® program is faulty	Programming principles violated leading to system-internal stack overflow	Reload the application module
34	Ramp Timeout	Immediate disconnection	0	Rapid stop ramp timeout	Downward ramps timeout, e.g. due to overload.	<ul style="list-style-type: none"> Extend the downwards ramps Eliminate overload
35	Operating mode	Immediate disconnection	0	Operating mode not available	Operating mode not defined or defined incorrectly	Use P700/P701 to set correct operating mode
			1	Wrong assignment operating mode - hardware		
37	System watchdog	Immediate disconnection	0	"System watchdog overflow" error	Error while executing system software	Consult SEW Service
38	System software	Immediate disconnection	0	"System software" error	System malfunction	Consult SEW Service
39	Reference travel	Immediate disconnection (P)	0	"Reference travel" error	<ul style="list-style-type: none"> The reference cam is missing or does not switch Limit switches are connected incorrectly Reference travel type was changed during reference travel 	<ul style="list-style-type: none"> Check reference cam Check limit switch connection Check reference travel type setting and required parameters.




Error			Suberror		Possible cause	Measure
Code	Designation	Response (P)	Code	Designation		
40	Boot synchronization	Immediate disconnection	0	Timeout during boot synchronization	Error during boot synchronization between inverter and option.	Consult SEW service if the error reoccurs
41	Watchdog option	Immediate disconnection	0	Error – Watchdog timer from/to option.	Error in communication between system software and option software	Consult SEW Service
42	Lag error	Immediate disconnection (P)	0	Positioning lag error	<ul style="list-style-type: none"> Encoder connected incorrectly Acceleration ramps too short P component of positioning controller too small Incorrect speed controller parameters Value of lag error tolerance too small 	<ul style="list-style-type: none"> Check encoder connection Extend ramps Set P component to higher value Reset speed controller parameters Increase lag error tolerance Check wiring of encoder, motor and line phase. Check whether mechanical system components can move freely or if they are blocked
44	Unit utilization	Immediate disconnection	0	Unit utilization error	Unit utilization (IxT value) > 125%	<ul style="list-style-type: none"> Decrease power output Extend ramps If suggested actions are not possible, use a larger inverter Reduce load
			8	U _L monitoring error		
45	Initialization	Immediate disconnection	0	General error during initialization	No parameters set for EEPROM in power section, or parameters set incorrectly	Restore factory settings (P802). Consult SEW service if the error cannot be reset.
			3	Data bus error during RAM check		
			6	CPU clock error		
			7	Error in the current evaluation		
			10	Error when setting flash protection		
			11	Data bus error during RAM check		
47	System bus 1 timeout	Rapid stop (P)	0	Timeout system bus CAN1	Error during communication via system bus 1.	Check system bus connection
57	TTL encoder	Immediate stop	1	TTL encoder: Broken wire		
			512	TTL encoder: Error in amplitude control		
			541	TTL encoder: Incorrectly set numerator/denominator values		Set the correct system numerator/denominator values.
			16385	TTL synchronous encoder: Broken wire		
			16896	TTL synchronous encoder: Error in amplitude control		
			16898	TTL synchronous encoder: Incorrectly set numerator/denominator values		Set the correct system numerator/denominator values.



Error			Suberror		Possible cause	Measure
Code	Designation	Response (P)	Code	Designation		
58	Sin/cos encoder	Immediate stop	1	Sin/cos encoder: Broken wire		
			512	Sin/cos encoder: Error in amplitude control		
			514	Sin/cos encoder: Track signal error		
			515	Sin/cos encoder: Incorrectly set numerator/denominator values		Set the correct system numerator/denominator values.
			16385	Sin/cos synchronous encoder: Broken wire		
			16896	Sin/cos synchronous encoder: Error in amplitude control		
			16898	Sin/cos synchronous encoder: Track signal error		
			16899	Sin/cos synchronous encoder: Incorrectly set numerator/denominator values		Set the correct system numerator/denominator values.
59	Encoder communication	Rapid stop	1	HIPERFACE® encoder: Track signal error		
			2	HIPERFACE® encoder: Calibration error	Incorrect calibration of encoder	<ul style="list-style-type: none"> Restore factory settings (P802) Repeat encoder startup
			16	HIPERFACE® encoder: Communication error	MOVIPRO® and HIPERFACE® encoder connection interrupted	Check wiring
			64			
			128			
			192			
			256			
			320			
			384			
			448			
			512			
			576			
			1024	EnDat encoder: Communication error	MOVIPRO® and EnDat encoder connection interrupted	Check wiring
			1088			
			1152			
			1216			
			1280			
			1388			
			16385	HIPERFACE® synchronous encoder: Track signal error		
			16386	HIPERFACE® synchronous encoder:	Incorrect calibration of encoder	<ul style="list-style-type: none"> Restore factory settings (P802) Repeat encoder startup



Error			Suberror		Possible cause	Measure
Code	Designation	Response (P)	Code	Designation		
59	Encoder communication	Rapid stop	16400	HIPERFACE® synchronous encoder: Communication error	MOVIPRO® and HIPERFACE® synchronous encoder connection interrupted	Check wiring
			16448			
			16512			
			16576			
			16640			
			16704			
			16768			
			16832			
			17408	EnDat synchronous encoder: Communication error	MOVIPRO® and EnDat synchronous encoder connection interrupted	Check wiring
			17472			
			17536			
			17600			
			17664			
			17772			
77	IPOS control word	No response (P)	0	Invalid control word IPOS ^{plus} ®	Only in IPOS^{plus}® mode: <ul style="list-style-type: none"> An attempt was made to set an invalid automatic mode (via external controller). "P916 = Bus ramp" is set. 	<ul style="list-style-type: none"> Check serial connection to external controller Check write values of external controller Set correct value for P916
78	IPOS SW limit switch	No response (P)	0	Software limit switch reached	Only in IPOS^{plus}® mode: Programmed target position is outside travel range delimited by software limit switches.	<ul style="list-style-type: none"> Check the user program Check position of software limit switches
80	RAM test	Immediate disconnection	0	"RAM test" error	Internal unit error, RAM defective.	Consult SEW Service
81	Start condition	Immediate disconnection	0	Start condition error with "VFC & hoist"	Only in "VFC & hoist" mode: The motor could not be supplied with the correct amount of current during the pre-magnetizing time: <ul style="list-style-type: none"> Rated motor power too small in relation to rated inverter power Motor cable cross section too small 	<ul style="list-style-type: none"> Check startup data and perform new startup, if necessary. Check connection between inverter and motor Check cross section of motor cable and increase if necessary
82	Open output	Immediate disconnection	0	Output open with "VFC & hoist"	Only in "VFC & hoist" mode: <ul style="list-style-type: none"> 2 or all output phases interrupted Rated motor power too small in relation to rated inverter power 	<ul style="list-style-type: none"> Check connection between inverter and motor Check startup data and perform new startup, if necessary.
84	Motor protection	Emergency stop (P)	0	"Motor temperature emulation" error	<ul style="list-style-type: none"> Motor utilization too high. I_N-U_L monitoring 1 triggered P530 set later to "KTY" 	<ul style="list-style-type: none"> Reduce load Extend ramps Observe longer pause times Check P345/P346 Select a larger motor
			2	Short circuit or open circuit in the temperature sensor		
			3	No thermal motor model available		
			4	U _L monitoring error		
			11	Temperature sensor short circuit		



Error			Suberror		Possible cause	Measure
Code	Designation	Response (P)	Code	Designation		
88	Flying start	Immediate disconnection	0	"Flying start" error	Only in "VFC n control" mode: Actual speed > 6000 rpm when inverter enabled	Enable not unless current speed ≤ 6000 rpm
94	EEPROM checksum	Immediate disconnection	0	Power section parameters	Inverter electronics disrupted, possibly due to effect of EMC or a defect.	Send unit in for repair.
			5	Control unit data		
			6	Power section data		
			7	Invalid version of the configuration data set		
97	Copy error	Immediate disconnection	0	Parameter set upload is/was faulty	<ul style="list-style-type: none"> Error during data transmission Memory can neither be written nor read 	<ul style="list-style-type: none"> Repeat copying process Restore default setting (P802) and repeat copying process
			1	Parameter set download to unit cancelled		
			2	Not possible to adopt parameters		
98	CRC error	Immediate disconnection	0	"CRC via internal flash" error	Internal unit error Flash memory defective	Send unit in for repair
99	IPOS ramp calculation	Immediate disconnection	0	"Ramp calculation" error	Only in IPOS^{plus}® mode: Positioning ramp is sinusoidal or square and an attempt is made to change ramp times and traveling velocities with enabled inverter.	Rewrite the IPOS ^{plus} ® program so that ramp times and traveling velocities can only be altered when the inverter is inhibited.
100	Vibration warning	Display error (P)	0	Vibrations diagnostics warning	Vibration sensor warning (see "DUV10A" operating instructions)	<ul style="list-style-type: none"> Determine cause of vibrations Continue operation until F101 occurs
101	Vibration error	Rapid stop (P)	0	Vibration diagnostics error	Vibration sensor signals error	SEW-EURODRIVE recommends that you remedy the cause of the vibrations immediately
102	Oil aging warning	Display error (P)	0	Oil aging warning	Error message from the oil aging sensor	Schedule oil change
103	Oil aging error	Display error (P)	0	Oil aging error	Error message from the oil aging sensor	SEW-EURODRIVE recommends that you change the gear unit oil immediately.
104	Oil aging overtemperature	Display error (P)	0	Oil aging overtemperature	Overtemperature signal from the oil aging sensor	<ul style="list-style-type: none"> Let oil cool down Check if the gear unit cools properly
105	Oil aging ready signal	Display error (P)	0	Oil aging ready signal	Oil aging sensor is not ready for operation	<ul style="list-style-type: none"> Check voltage supply of oil aging sensor Check and, if necessary, replace the oil aging sensor
106	Brake wear	Display error (P)	0	Brake wear error	Brake lining worn	Replace brake lining (see "Motors" operating instructions)
110	"Ex-e protection" error	Emergency stop	0	Duration of operation below 5 Hz exceeded	Duration of operation below 5 Hz exceeded	<ul style="list-style-type: none"> Check configuration Shorten duration of operation below 5 Hz
116	"Timeout" error	Rapid stop/warning	0	Internal communication timeout		<ul style="list-style-type: none"> Check startup Check wiring




Error			Suberror		Possible cause	Measure
Code	Designation	Response (P)	Code	Designation		
122	Absolute encoder	Immediate stop	1	Plausibility check		Check the cables of the sine tracks or replace the encoder
			2	HIPERFACE® encoder: Unknown encoder type		
			3	HIPERFACE® encoder: Corrupt encoder nameplate data		
			32	HIPERFACE® encoder: Internal encoder error		Replace the encoder
			33	HIPERFACE® encoder: Analog voltages not within tolerance		
			34	HIPERFACE® encoder: Internal encoder error		Replace the encoder
			35			
			36			
			37			
			38			
			39			
			40			
			41	HIPERFACE® encoder: Communication error	MOVIPRO® and HIPERFACE® encoder connection interrupted	Check wiring
			42			
			43			
			44			
			45	HIPERFACE® encoder: Internal encoder error		Replace the encoder
			46			
			47			
			48			
			49			
			50			
			60	HIPERFACE® encoder: Analog voltages not within tolerance		
			61	HIPERFACE® encoder: Critical transmitter current	<ul style="list-style-type: none"> • Dirt • Transmitter broken 	Replace the encoder
			62	HIPERFACE® encoder: Critical encoder temperature		Replace the encoder
			63	HIPERFACE® encoder: Position error	Speed too high, position cannot be created	set slower speed
			64	HIPERFACE® encoder: Internal encoder error		Replace the encoder
			65			
			66			
			67			
			256	SSI encoder: Voltage dip	12 V voltage supply broken in	Check SSI encoder voltage supply
			257	SSI encoder: Clocking or data line interrupted		Check connection to SSI encoder
			258	SSI encoder: Change of position		



Error			Suberror		Possible cause	Measure
Code	Designation	Response (P)	Code	Designation		
122	Absolute encoder	Immediate stop	259	SSI encoder: Insufficient clock frequency		Set a higher cycle frequency
			260	SSI encoder: Encoder signals programmable error		Check encoder parameterization
			261	SSI encoder: No high level present		<ul style="list-style-type: none"> Replace the encoder Consult SEW Service
			513	EnDat encoder: Plausibility check		
			514	EnDat encoder: Internal encoder error		Replace the encoder
			515			
			516			
			544			
			576	EnDat encoder: Internal encoder warning		Check encoder parameterization
			768	CANopen encoder: PDO timeout	No PDO data from CANopen encoder	<ul style="list-style-type: none"> Check interface Check the configuration
			769	CANopen encoder: Encoder signals programmable error		Check encoder parameterization
			770	CANopen encoder: Change of position		
			771	CANopen encoder: Emergency signal		Check encoder
			772	CANopen encoder: Internal encoder error		Replace the encoder
			773			
			774			
			16385	HIPERFACE® synchronous encoder: Plausibility check		
			16386	HIPERFACE® synchronous encoder: Unknown encoder type		
			16387	HIPERFACE® synchronous encoder: Corrupt encoder nameplate data		
			16417	HIPERFACE® synchronous encoder: Analog voltages not within tolerance		
			16418	HIPERFACE® synchronous encoder: Internal encoder error		Replace the encoder
			16419			
			16420			
			16421			
			16422			
			16423			
			16424			
			16425	HIPERFACE® synchronous encoder: Communication error	MOVIPRO® and HIPERFACE® encoder connection interrupted	Check wiring
			16426			
			16427			
			16428			
			16429			



Error			Suberror		Possible cause	Measure
Code	Designation	Response (P)	Code	Designation		
122	Absolute encoder	Immediate stop	16430	HIPERFACE® sync. enc.: Internal encoder error		Replace the encoder
			16431			
			16432			
			16433			
			16434			
			16444	HIPERFACE® sync. enc.: Analog voltages not within tolerance	<ul style="list-style-type: none"> Dirt Transmitter broken 	Replace the encoder
			16445	HIPERFACE® sync. enc.: Critical transmitter current		
			16446	HIPERFACE® sync. enc.: Critical encoder temperature		
			16447	HIPERFACE® sync. enc.: Position error	Speed too high, position cannot be created	set slower speed
			16448	HIPERFACE® sync. enc.: Internal encoder error		Replace the encoder
			16449			
			16450			
			16451			
			16640	SSI synchronous encoder: Voltage dip	12 V voltage supply broken in	Check SSI encoder voltage supply
			16641	SSI synchronous encoder: Clocking or data line interrupted		Check connection to SSI encoder
			16642	SSI synchronous encoder: Change of position		
			16643	SSI synchronous encoder: Insufficient clock frequency		Set a higher cycle frequency
			16644	SSI synchronous encoder: Encoder signals programmable error		Check encoder parameterization
			16645	SSI synchronous encoder: No high level present		<ul style="list-style-type: none"> Replace the encoder Consult SEW Service
			16897	EnDat synchronous encoder: Plausibility check		
			16898	EnDat synchronous encoder: Internal encoder error		Replace the encoder
			16899			
			16900			
			16928			
			16960	EnDat synchronous encoder: Internal encoder warning		Check encoder parameterization
			17152	CANopen synchronous encoder: PDO timeout	No PDO data from CANopen synchronous encoder	Check interface or configuration
			17153	CANopen synchronous encoder: Encoder signals programmable error		Check encoder parameterization
			17154	CANopen synchronous encoder: Change of position		
			17155	CANopen synchronous encoder: Emergency signal		Check encoder
			17156	CANopen synchronous encoder: Internal encoder error		Replace the encoder
			17157			
			17158			



13 Additional Documentation

For additional information, refer to the following documentation:

Documentation
"MOVITOOLS® MotionStudio" manual
MOVITOOLS® online help
"MOVIDRIVE® MD_60A Bus Positioning Application Module" manual
"MOVIDRIVE® MDX61B Extended Bus Positioning Application Module" manual
"MOVIDRIVE® MDX60B/61B Modulo Positioning Application" manual
"MOVIDRIVE® MDX61B Sensor-Based Positioning Via Bus Application" manual
"MOVIDRIVE® MDX61B Table Positioning Application" manual
"MOVIPRO® SDC" operating instructions



Index

A

Active current	116
Process data	73
Actual position	116
Actual speed	
Process data	73
Actual value description PI1	146
Actual value description PI2	146
Actual value description PI3	146
Additional documentation	6
Addressing lower-level inverters	52
Analog input AI1	118
Analog setpoints	118
Application module	
Process data	73, 74, 75, 76, 77
Application modules	
Automotive AMA0801	13
Available	9
Bus positioning	9
Bus positioning, extended	10
Modulo positioning	11
Overview	8
Sensor-based positioning	12
Table positioning	11
Task	8
Auto reset	143
Automatic adjustment 1	125
Automatic adjustment 2	125
Automatic encoder replacement detection	153
Automotive AMA0801 (application module)	13

B

Basic unit firmware	118
Behavior when master is switched off	65
Binary input DI01	134
Binary input DI02	134
Binary input DI03	134
Binary input DI04	134
Binary input DI05	134
Binary input DI06	134
Binary input DI07	134
Binary inputs of basic unit	118, 134
Binary outputs of basic unit	118
Boost 1	125
Boost 2	125
Brake application time 1	138

Brake application time 2	138
Brake function	138
Brake function 1	138
Brake function 2	138
Brake operation	141
Brake release time 1	138
Brake release time 2	138
Bus cable shielding	19
Bus diagnostics	119
Bus positioning	
Process data	73
Bus positioning (application module)	9
Bus positioning, extended	
Process data	74
Bus positioning, extended (application module)	10
Bus setpoint source	151
Bus setpoint, source	151

C

Cam distance	149
Communication channel	
Configuration	85
Communication connections	
Configuring the communication channel	85
Communication setting	15
Communication type	
Configuring the communication channel	85
Components	
Service unit	158
Configuration	
Communication channel	85
Connection	
Connection with unit not possible	14
PC, laptop	82
PROFIBUS	17
Control functions	135
Control programs, see application modules	8
Control word 1	
Prioritization	71
Process data	70
Controller parameters	122
Controller, processing sequence	51
Cooling type 1	128
Cooling type 2	128
Copyright	7
Current limit A	133



Current limit B	133	Establishing communication with other units	78
Current limit C	134	Ethernet interface	158
Current limit Ex-e motor	133	Exclusion of liability	6
Current limit 1/2	124	Executing functions with the units	78, 88
Current limitation Ex-e motor	133		
Current parameter set	117	F	
C1 master		Factory setting	140
Project planning	60	Features of SEW fieldbus interfaces	48
D		Filter acceleration precontrol	122
Data storage		Filter actual speed value	122
Storing unit data	109	Fixed setpoints 1 / 2	121
DC link voltage	117	Frequency A	133
Delay time 1/2	129	Frequency B	133
Designated use	78	Frequency C	134
Diagnostics information	67	Frequency of the inverter	116
Digital inputs		G	
Process data	68	Gain acceleration precontrol	122
Digital outputs		Gain X controller	149
Process data	68	GSD file	26
Direction of rotation reversal 1	129	Installation in STEP7	27
Direction of rotation reversal 2	129	H	
Display values	116	Heat sink temperature	117
Documentation	169	Hoist applications	7
For startup	14	Hold controller	123
Documentation, additional	6		
Documentation, applicable	169	I	
Drive inverter, see inverter	69	Inputs	
E		Process data	68
Embedded safety notes	5	Installation	16
Emergency ramp t14	120	Installation notes	
Emergency ramp t24	120	Bus cable routing	19
Enable hours	117	MOVIPRO® – PROFIBUS connection	18
Encoder monitoring motor	130	Shielding the bus cables	19
Encoder parameterization	91	Interface	
Encoder slot option	118	Ethernet	158
Engineering computer		Service	158
IP address	82	Internal setpoint n11 / n12 / n13 / n21 / n22 / n23	121
Error codes	159	Inverter	
Error codes of the DP-V1 services	63	Process data	69
Error diagnostics	64	Inverter status	23
Error diagnostics, PROFIBUS DP-V1 operation		Parameters	117
Diagnostics procedure	64	Inverter statuses	24
Error memory	119	IP address	
Error messages	21, 24	Engineering computer	82
Error responses	65, 142, 159	MOVIPRO®	82
Error status (parameters)	117		



IPOS encoder	153	Motor protection 1	126
IPOS modulo function	153	Motor protection 2	126
IPOS monitoring	151	Motor temperature protection	131
IPOS parameters	146	Motor temperature 1 / 2	118
IPOS reference travel	146	Motor utilization, thermal	117
IPOS special functions	152	MOVIDRIVE®	
IPOS travel parameters	149	Process data	69
IxR adjustment 1	125	MOVILINK® parameter channel	37
IxR adjustment 2	125	MOVILINK® parameter channel data range	39
J		MOVILINK® parameter requests	52
Jerk time	152	Reading a parameter	52
L		Writing a parameter	54
Lag error window	152	MOVIPRO®	
Laptop		Control word	66
Connection	82	IP address	82
Limits 1	124	Status word	67
Limits 2	124	Subnet mask	82
Load precontrol CFC	123	MOVIPRO® – PROFIBUS connection	18
Load precontrol VFC	123	MOVITOOLS® MotionStudio	
M		Communication setting	15
Mains off monitoring	130	N	
mains OFF response	130	Notes	
mains OFF response time	130	Designation in the documentation	5
Manual reset	143	O	
Maximum speed 1/2	124	Oil aging/overtemperature	132
Memory card		Oil aging/ready	132
Replacing units	156	Operating behavior in conjunction with PROFIBUS	
Storing unit data	109	DP-V1	34
Minimum speed 1/2	124	Parameter data format	42
Modulation	144	Reading parameters (Read)	40
Modulo denominator	153	Return codes, parameterization	43
Modulo encoder resolution	153	Return codes, parameterization (special cases)	44
Modulo function	153	Writing parameters (Write)	41
Modulo numerator	153	Operating hours	117
Modulo positioning		Operating mode 1	135
Process data	75	Operating mode 2	135
Modulo positioning (application module)	11	Operating modes	135
Monitoring functions	129	Operating status (parameters)	117
MotionStudio, see MOVITOOLS® MotionStudio	15	Optimizing a speed controller	
Motor category	136	Download values	107
Motor compensation (asynchronous) 1 / 2	125	Procedure	109
Motor direction of rotation	128	Other applicable documentation	6
Motor parameters	124	Output current	116, 117
Motor protection	126	Outputs	
Motor protection interval	128	Process data	68
		Override	152

**P**

P gain hold controller	123	Process data	
Parameter channel, structure	49	Active current	73
Parameter description		Actual speed	73
Overview of parameters in table form	111, 154	Control word	66
P2xx Controller parameters	122	Control word 1	70
P3xx Motor parameters	124	Description	66
P5xx Monitoring functions	129	Inputs	68
P6xx Terminal assignment	134	Inverter	69
P7xx Control functions	135	Outputs	68
P8xx Unit functions	140	Ramp	72
P9xx IPOS parameters	146	Setpoint speed	72
Parameter lock	141	Speed-controlled drive	69
Parameterization procedure via data set 47	50	Status word	67
Parameterization via PROFIdrive data set 47		Status word 1	72
Structure of the parameter channel	49	"Bus positioning" application module	73
Parameters		"Extended bus positioning" application module	74
Configuring the communication channel	85	"Modulo positioning" application module	75
For SMLP	87	"Sensor-based positioning" application module	76, 77
Parameterizing units in the parameter tree	88	"Table positioning" application module	76
Reading via MOVILINK®	52	Process data description	145
Reading via PROFIdrive	56	Process data exchange	
Reading/changing unit parameters	88	Diagnostics information	67
Writing via MOVILINK®	54	Process data overview	66
Writing via PROFIdrive	57	Process input data (PI)	66
Partial startup		Process output data (PO)	66
Procedure	108	Process values	116
Settings	106	Processing sequence for the controller	51
PC		PROFIBUS	
Connection	82	Bus termination	17
P-gain n-controller	122	Connection	17
Phase failure monitoring	130	Setting the address	20
PI 1/2/3 actual value	119	PROFIBUS DP-V1	
PI, see process input data	66	Alarm handling	48
PO data enable	146	PROFIBUS-DP	
PO 1/2/3 setpoint	119	Diagnostics procedure	64
Position window	151	PROFIBUS-DP-V1	
Positioning interruption detection	152	Services	47
Positioning ramp 1	150	PROFIdrive parameter requests	56
Positioning ramp 2	150	Reading a parameter	56
PO, see process output data	66	Writing a parameter	57
Premagnetization time 1 / 2	126	Project planning	
Prioritization		C1 master	60
Control word 1	71	Project planning for a PROFIBUS DP master	
Procedure		DP configurations	32
Startup	14	General procedure	26
		Installing the GSD file in STEP7	27
		Project planning with STEP7	28



Project planning for a PROFIBUS DP masters	
GSD file.....	26
PWM fix 1.....	144
PWM fix 2.....	144
PWM frequency CFC.....	144
PWM frequency 1.....	144
PWM frequency 2.....	144
P000 speed.....	116
P001 User display.....	116
P002 frequency.....	116
P003 actual position.....	116
P004 Output current.....	116
P005 Active current.....	116
P008 DC link voltage.....	117
P009 Output current.....	117
P010 Inverter status.....	117
P011 Operating status.....	117
P012 error status.....	117
P013 Current parameter set.....	117
P014 Heat sink temperature.....	117
P015 Operating hours.....	117
P016 Enable hours.....	117
P017 Work.....	118
P02x Analog setpoints.....	118
P03x Binary inputs of basic unit.....	118
P05x Binary outputs of basic unit.....	118
P07x Unit data.....	118
P070 Unit type.....	118
P071 Rated output current.....	118
P072 Encoder slot option.....	118
P076 Basic unit firmware.....	118
P078 Technology function.....	118
P079 Unit version.....	118
P08x Error memory.....	119
P09x Bus diagnostics.....	119
P1xx setpoints/ramp generators.....	119
P13x Speed ramps 1.....	119
P134 Ramp t12 UP=DOWN.....	120
P136/146 stop ramp t13 / t23.....	120
P137 Emergency ramp t14.....	120
P139 Ramp monitoring 1.....	121
P14x Speed ramps 2.....	119
P144 Ramp t22 UP=DOWN.....	120
P147 Emergency ramp t24.....	120
P149 Ramp monitoring 2.....	121
P2xx Controller parameters.....	122
P20x Speed control.....	122
P200 P-gain n-controller.....	122
P201 Time constant n-controller.....	122
P202 Gain acceleration precontrol.....	122
P203 Filter acceleration precontrol.....	122
P204 Filter actual speed value.....	122
P205 Load precontrol CFC.....	123
P206 Sampling time n-controller.....	123
P207 Load precontrol VFC.....	123
P21x Hold controller.....	123
P210 P gain hold controller.....	123
P3xx Motor parameters.....	124
P30x Limits 1.....	124
P304 Torque limit.....	125
P31x Limits 2.....	124
P32x/33x Motor compensation (asynchronous) 1/2.....	125
P320 Automatic adjustment 1.....	125
P321 Boost 1.....	125
P322 IxR adjustment 1.....	125
P323/333 Premagnetization time 1/2.....	126
P324/334 Slip compensation 1/2.....	126
P330 Automatic adjustment 2.....	125
P331 Boost 2.....	125
P332 IxR adjustment 2.....	125
P34x Motor protection.....	126
P340 Motor protection 1.....	126
P341 Type of cooling 1.....	128
P342 Motor protection 2.....	126
P343 Type of cooling 2.....	128
P344 Motor protection interval.....	128
P35x Motor direction of rotation.....	128
P350 Direction of rotation reversal 1.....	129
P351 Direction of rotation reversal 2.....	129
P5xx Monitoring functions.....	129
P50x Speed monitoring.....	129
P500 Speed monitoring 1.....	129
P501 Delay time 1.....	129
P502 Speed monitoring 2.....	129
P503 Delay time 2.....	129
P504 Encoder monitoring motor.....	130
P504 Synchronous encoder monitoring.....	130
P52x mains OFF monitoring.....	130
P520 mains OFF response time.....	130
P521 mains OFF response.....	130
P522 Phase failure monitoring.....	130
P53x Motor temperature protection.....	131
P530 Sensor type 1.....	131
P531 Sensor type 2.....	131
P54x Gear unit/motor monitoring.....	131
P540 Response to vibration/warning.....	131
P541 Response to vibration/error.....	131



P542 Response to oil aging/warning.....	132	P820 4-quadrant operation 1	141
P543 Response to oil aging/error.....	132	P821 4-quadrant operation 2	141
P544 Oil aging/overtemperature	132	P83x error responses	142
P545 Oil aging/ready	132	P830 Response EXT. ERROR	142
P549 Response to brake wear.....	132	P832 Response to "Motor overload"	142
P56x Current limitation Ex-e motor	133	P834 Response to "Lag error"	142
P560 Current limit Ex-e motor.....	133	P835 Response to "TF signal"	142
P561 Frequency A	133	P836 Response to "Timeout SBus 1"	142
P562 Current limit A.....	133	P837 Response to "Timeout SBus 2"	142
P563 Frequency B	133	P838 Response to "SW limit switch"	143
P564 Current limit B.....	133	P839 Response to "Positioning interruption"	143
P565 Frequency C	134	P84x Reset behavior	143
P566 Current limit C.....	134	P840 Manual reset.....	143
P6xx Terminal assignment.....	134	P841 Auto reset	143
P60x Binary inputs of basic unit	134	P842 Restart time	144
P600 Binary input DI01	134	P85x Scaling actual speed value.....	144
P601 Binary input DI02	134	P850 Scaling factor numerator	144
P602 Binary input DI03	134	P851 Scaling factor denominator.....	144
P603 Binary input DI04	134	P852 User-defined unit.....	144
P604 Binary input DI05	134	P86x Modulation	144
P605 Binary input DI06	134	P860 PWM frequency 1	144
P606 Binary input DI07	134	P861 PWM frequency 2.....	144
P7xx Control functions	135	P862 PWM fix 1	144
P70x Operating modes	135	P863 PWM fix 2	144
P700 Operating mode 1	135	P864 PWM frequency CFC	144
P701 Operating mode 2.....	135	P87x Process data description	145
P702 Motor category.....	136	P870 Setpoint description PO1.....	145
P71x Standstill current.....	136	P871 Setpoint description PO2.....	145
P72x Setpoint stop function	137	P872 Setpoint description PO3.....	145
P721 Stop setpoint 1.....	137	P873 Actual value description PI1	146
P723 Setpoint stop function 2	137	P874 Actual value description PI2	146
P724 Stop setpoint 2.....	137	P875 Actual value description PI3	146
P725 Start offset 2	137	P876 PO data enable	146
P73x Brake function.....	138	P9xx IPOS parameters	146
P730 Brake function 1.....	138	P90x IPOS reference travel	146
P731 Brake release time 1.....	138	P900 Reference offset.....	147
P732 Brake application time 1	138	P901 Reference speed 1	147
P733 Brake function 2.....	138	P902 Reference speed 2	147
P734 Brake release time 2.....	138	P903 Reference travel type	147
P735 Brake application time 2	138	P904 Reference travel to zero pulse	149
P74x Speed skip	139	P905 Hiperface offset	149
P742 Skip window center 2.....	139	P906 Cam distance	149
P743 Skip width 2	139	P91x IPOS travel parameters	149
P8xx Unit functions	140	P910 Gain X controller.....	149
P80x Setup	140	P911 Positioning ramp 1.....	150
P802 Factory setting	140	P912 Positioning ramp 2.....	150
P803 Parameter lock	141	P913/P914 Travel speed CW/CCW.....	150
P804 Reset statistics data	141	P915 Velocity precontrol.....	150
P82x Brake operation	141	P916 Ramp type	150



P917 Ramp mode	150	Response to vibration/error	131
P918 Bus setpoint source	151	Response to vibration/warning	131
P92x IPOS monitoring	151	Response to "Lag error"	142
P920 SW limit switch CW	151	Response to "Motor overload"	142
P921 SW limit switch CCW	151	Response to "Positioning interruption"	143
P922 Position window	151	Response to "SW limit switch"	143
P923 Lag error window	152	Response to "TF signal"	142
P924 Positioning interruption detection	152	Response to "Timeout SBus 1"	142
P93x IPOS special functions	152	Response to "Timeout SBus 2"	142
P930 Override	152	Restart time	144
P933 Jerk time	152	Return codes, parameterization	
P938 speed task 1	152	Additional code	43
P94x IPOS encoder	153	Elements	43
P941 Source of actual position	153	Error class	43
P948 Automatic encoder replacement detection	153	Error code	43
P96x IPOS modulo function	153	Rights to claim under limited warranty	6
P960 Modulo function	153	Routing the bus cables	19
P961 Modulo numerator	153		
P962 Modulo denominator	153	S	
P963 Modulo encoder resolution	153	S pattern t12 / t22	120
R		Safety functions	6
Ramp		Safety notes	
Process data	72	Designation in the documentation	5
Ramp generators	119	General safety notes for bus systems	6
Ramp mode	150	Structure of the embedded safety notes	5
Ramp monitoring	121	Structure of the section-related safety notes	5
Ramp monitoring 1	121	Sample program	
Ramp monitoring 2	121	SIMATIC S7	61
Ramp type	150	Sample rate n-controller	123
Ramp t11/t21 up/down CCW/CW	119	Sampling time, see sample rate	123
Ramp t12 UP=DOWN	120	Scaling actual speed value	144
Ramp t22 UP=DOWN	120	Scaling factor denominator	144
Rated output current	118	Scaling factor numerator	144
Reading a parameter		SD card	
Via PROFIdrive	56	Replacing units	156
Reference offset	147	Storing unit data	109
Reference speed 1	147	Section-related safety notes	5
Reference speed 1/2	147	Sensor type 1	131
Reference speed 2	147	Sensor type 2	131
Reference travel to zero pulse	149	Sensor-based positioning	
Reference travel type	147	Process data	76, 77
Repair	21	Service	
Reset behavior	143	Inverter status	23
Reset statistics data	141	Inverter statuses	24
Response EXT. ERROR	142	Replacing units	156
Response to brake wear	132	Unit replacement	156
Response to oil aging/error	132	Unit status	21, 24, 25
Response to oil aging/warning	132	Service interface	158
		Service unit	158



Setpoint description PO1	145	Structure of the parameter channel	49
Setpoint description PO2	145	Addressing lower-level inverters	52
Setpoint description PO3	145	MOVILINK® parameter requests	52
Setpoint speed		Parameterization procedure via data set 47	50
Process data	72	Processing sequence for the controller	51
Setpoint stop function	137	PROFIdrive parameter requests	56
Setpoints	119	Subnet mask	
Setpoints/ramp generators	119	MOVIPRO®	82
Setup	140	SW limit switch CCW	151
SEW fieldbus interfaces, features	48	SW limit switch CW	151
Shielding and routing the bus cables	19	Switch S2	20
Signal words in the safety notes	5	Synchronous angle	13
SIMATIC S7		Synchronous encoder monitoring	130
Sample program	61	T	
Skip width 1 / 2	139	Table positioning	
Skip window center 1/2	139	Process data	76
Slip compensation 1/2	126	Table positioning (application module)	11
Source of actual position	153	Technology function	118
Speed control	122	Terminal assignment	134
Speed monitoring	129	Time constant n-controller	122
Speed monitoring 1	129	Torque limit	125
Speed monitoring 2	129	Travel speed CW/CCW	150
Speed ramps 1	119	U	
Speed ramps 2	119	Unit	
Speed skip	139	Error codes	159
Speed task 1	152	Unit data	
Speed-controlled drive		Storing unit data	109
Process data	69	Unit functions	140
Speed, display	116	Unit not in the network	14
Standstill current	136	Unit replacement	109, 156
Standstill current 1/2	136	Unit status	21, 24, 25
Start offset 1/2	137	Unit type	118
Startup		Unit version	118
Applicable documentation	14	User display	116
Procedure	14	User-defined unit	144
Starting up the unit	89	V	
Start/stop speed 1/2	124	Velocity precontrol	150
Status display		W	
Component description	158	Work	118
Status displays		Writing a parameter	
Parameters	117	Via MOVILINK®	54
Status LED	24	Via PROFIdrive	57
Status messages	21, 24		
Status word 1			
Process data	72		
Stop ramp t13 / t23	120		





X



X4201.....	16
X4202.....	17

0 ... 9

4-quadrant operation 1	141
4-quadrant operation 2	141
7-segment display	21, 158









SEW-EURODRIVE
Driving the world

SEW
EURODRIVE

SEW-EURODRIVE GmbH & Co KG
P.O. Box 3023
D-76642 Bruchsal/Germany
Phone +49 7251 75-0
Fax +49 7251 75-1970
sew@sew-eurodrive.com

→ www.sew-eurodrive.com