

142mm

210mm



Bluetooth

Manual for Retro Style Trolley Speaker with Karaoke

Thank you for choosing the Retro Style Trolley Speaker with Karaoke. Please read the manual carefully before using this speaker.

Features

- Designed to deliver 15 watts of clean amplified sound, bringing more power and life to your party!
- Karaoke feature with Dual Microphone inputs (1 wire microphone included).
- Bluetooth® technology allows you to stream your favourite songs from your smart phone or tablet.
- SD & Flash Drive inputs provide additional options for playing your music.
- Auxiliary input allows you to connect any audio device via an auxiliary cable to play your music.
- Built in carry-handle (extends 37 inches) and rolling wheels allow for easy portability.
- Auxiliary input to connect a guitar.

Specifications:
Bluetooth version 2.1
Speakers Size: 10" / 7.3"
Horn output: 15W(4Ω)
Connections: USB, SD & Aux-inputs
Battery: 1200 mAh
Recharge Power: DC 9V 1.3A
Power input: AC 100-240V
Frequency: 90 Hz-20kHz
Charging time: 4 hours

Product Contents
Speaker
Wired microphone
Home Charger

Front Panel Controls & Functions

- Mode (Select between Bluetooth, Aux In, SD Card or USB Flash drive mode)
- Repeat
- Previous Song
- Play/Stop
- Next song
- Power ON /OFF
- LED indicator
- 110-240V Power Jack
- Microphone Input
- Echo control
- Microphone Volume
- Bass control
- Treble control
- Volume control
- Aux input
- USB Flash Drive input
- Micro SD card input (Note: you can only select the Flash Drive (memory card) or Micro SD Card (TF) mode when a Flash drive or Micro SD card are inserted).

Rechargeable 4h Playing time
1200 mAh
Built-In Battery

Pairing Bluetooth®

- Press the mode button repeatedly on the speaker to enter into BT mode, the display will read "BT" indicating the speaker is in pairing mode. Using your Wireless device with your pairing (smart phone, tablet etc.) search for the wireless speaker called "RETRO SPEAKER" and connect. Speaker will indicate it is "Connected" once paired successfully. After the initial pairing and connection, the unit will stay paired unless manually deleted by the user, or until it is erased due to a reset of the device.

If you need to connect again, press the "play/pause" for 2 second or switch into BT mode. After connecting the device successfully, it will connect automatic when turn on the BT again.

- To play your music wireless you can use the controls on the control panel: "play/pause" "Previous song/Next song" to control playing your music.

Charging
Please charge this speaker for 4 hours to get it to full battery capacity.
Note: remember to charge the speaker after each usage. Also if charging while playing music make sure the volume is not too high as this will cause the sound to be distorted and prolong the charging time.

LED Display Functions

▶| in Memory Card/TF card mode, ▶| this symbol will appear on screen meaning the music is paused.

In Line in/FM mode, ▶| this symbol will appear on screen, meaning the music is being muted. (The display light flash once when muting)

2.In Memory Card/TF card mode, "U/TF" will be illuminated.

3. ↻: Single song repeat, this symbol will be illuminated.

4. 88:88 : Shows "LINE IN" when operating in Aux in mode.

The LED screen will display "FM FREQUENCY" when operating FM mode
The LED screen will display "PLAYING TIME" of the song when playing Memory Card and TF card.
The LED screen will display "BT" when operating in Bluetooth mode.
The LED screen will display "PAUSE" when standby.

5. CB: The battery level indicator will flash when the power is low. Charge the speaker with the home charger included in the box. Also note the volume will automatically drop to 70% when power is low.

Using your Flash Drive or Micro SD Card

- USB Flash Drive/Memory Card: Insert the Flash drive/Memory Card into the speaker to play your music. Make sure you are on the Memory Card/TF mode to play the flash drive.
- Micro SD Card/TF card: Insert your Micro SD Card/TF card into the speaker to play your music. Make sure you are on the Memory Card/TF mode to play the Micro SD Card/TF card.
- Forward/Rewind: Press once the forward or rewind button to move between songs. Hold down the forward or rewind button for forward or rewind within the song you are listening too.
- Play/Pause Button: In USB Flash Drive/Memory Card or the Micro SD/TF card mode, press to play or pause, in LINE IN mode, press to mute.

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by CJ Global is under license. Other trademarks and trade names are those of their respective owners.

FCC Statement
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates noise and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try the following steps to correct the interference: 1) reorient or relocate the receiving antenna; 2) increase the separation between the equipment and receiver; 3) connect the equipment into an outlet on a circuit different from that to which the receiver is connected; 4) consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference from authorized licensed operations.

Manual para Parlante Estilo Retro con Karaoke

Gracias por elegir el Parlante Portátil con Karaoke. Por favor, lea este manual detenidamente antes de usar este altavoz.

Características

- Diseñado para proporcionar 15 vatios de sonido amplificado limpio, aportando más energía y vida a tu fiesta.
- Función karaoke con doble entrada de microfono (1 microfono con cable incluido).
- La tecnología Bluetooth® permite transmitir sus canciones favoritas desde tu telefono inteligente o una tableta.
- Entradas SD & Flash Drive proporcionan opciones adicionales para reproducir su música
- Entrada auxiliar permite conectar cualquier dispositivo de audio mediante un cable auxiliar para reproducir su música
- Construido con asa (se extiende hasta 37 pulgadas/94 cm) y ruedas de facil rodamiento para facilitar la portabilidad
- Entrada auxiliar para conectar una guitarra

Especificaciones:
Bluetooth version 2.1
Parlantes tamaño: 10" / 7.3"
Bocina de salida: 15W(4Ω)
Conexiones: USB, SD y entradas auxiliares.
Batería: 1200 mAh
Potencia de recarga: DC 9V de 1.3.
Entrada de alimentación: CA 100-240 V.
Frecuencia: 90 Hz-20 kHz.
Tiempo de carga: 4 horas

Rechargeable 4h
1200 mAh
Batería Recargable

Contenido:
Parlante
Microfono con cable
Cargador hogareño

Panel de Control Frontal y Funciones

- Modo/Selección entre Bluetooth, Aux in, tarjeta SD o una unidad flash USB)
- Repetir
- Canción anterior
- Reproducir/Detener
- Siguiente canción
- Encendido/Apagado
- Pantalla LED
- Entrada 110-240V de alimentación
- Entrada de microfono
- Control de graves
- Volumen del microfono
- Control de agudos
- Control de volumen
- Entrada Aux
- Entrada de unidad flash USB
- Entrada de tarjeta Micro SD (Nota: Sólo puede seleccionar la unidad flash (tarjeta de memoria) o tarjeta Micro SD (TF) modo cuando una unidad flash o tarjeta SD micro se insertan).

Función de emparejamiento Bluetooth®

- Pulse repetidamente el botón Mode en el altavoz para entrar en modo de BT, la pantalla indicará "BT" indicando que el altavoz está en modo de emparejamiento. Usando el dispositivo Bluetooth que está asociado (teléfono inteligente, tablet, etc.) busque el altavoz inalámbrico llamado "RETRO SPEAKER" y conéctese. El parlante indicará que está "conectado" una vez emparejado correctamente. Tras el emparejamiento y conexión inicial, la unidad permanecerá emparejado salvo que sea eliminado manualmente por el usuario, o hasta que sea borrado debido a un reinicio del dispositivo.
- Si necesita conectar de nuevo, pulse el botón "play/pause" durante 2 segundos o cambiar a modo de BT. Después de conectar el dispositivo correctamente, se conectará automáticamente al encender el BT de nuevo.
- Para reproducir su música de manera inalámbrica puede utilizar los controles del panel de control: "play/pause" "canción anterior/siguiente canción" para el control de la reproducción de música.

Carga
Cargue este altavoz 4 horas para llegar a plena capacidad de la batería.
Nota: no olvide cargar el altavoz después de su uso. También si lo carga mientras reproduce música, asegúrese de bajar el volumen que no sea demasiado alto ya que esto hará que el sonido se distorsione y prolongará el tiempo de carga.

Funciones del display LED

▶| en el modo tarjeta de memoria/TF, ▶| este símbolo aparecerá en pantalla y significa que la música está en pausa.

En línea/modo FM, ▶| este símbolo aparecerá en la pantalla, lo que significa que la música está silenciada. (La luz de la pantalla parpadeará cuando está en silencio)

- En el modo Memory Card/TF, "U/TF" se iluminará en la pantalla.
- ↻ repetición de una canción, este símbolo se iluminará.
- 88:88 muestra "IN LINE" cuando se trabaja en modo Aux In.
- 88:88 muestra "FM FREQUENCY" cuando opere en modo FM
- La pantalla LED mostrará "PLAYING TIME" de la canción cuando esté en modo Memory Card y TF card.
- La pantalla LED mostrará "BT" cuando opere en modo Bluetooth
- La pantalla LED mostrará "—" cuando se encuentre en espera
- La pantalla LED mostrará "PAUSE" cuando se encuentre en espera
- CB el indicador de nivel de batería parpadeará cuando la carga es baja. El altavoz de carga con el cargador incluido en la caja. Tenga en cuenta también el volumen bajará automáticamente al 70% cuando la alimentación es baja.

Utilizando su unidad flash o tarjeta SD micro

- Unidad flash USB/Tarjeta de Memoria: Inserte la unidad flash/Tarjeta de Memoria en el altavoz para reproducir tu música. Asegúrese de que está en la tarjeta de memoria USB en modo reproducir la unidad flash
- Tarjeta Micro SD / TF tarjeta: Inserte su tarjeta micro SD / TF tarjeta en el altavoz para reproducir su música.
- Asegúrese de que está en la tarjeta de memoria/TF en modo reproducir la tarjeta Micro SD / TF tarjeta
- Avance/Rebobinado: Pulse una vez el botón de avance o rebobinado para moverse entre las canciones. Mantenga pulsado el botón de avance o rebobinado para avanzar o retroceder en la canción que está escuchando.
- Botón Play/Pause: En el modo unidad flash USB/Tarjeta de memoria o la tarjeta Micro SD / TF tarjeta, pulse para reproducir o poner en pausa, en modo IN LINE, presione para silenciar.

Reservados todos los derechos. No se permite la explotación económica ni la transformación de esta obra. Queda permitida la impresión en su totalidad. Reservados todos los derechos. No se permite la explotación económica ni la transformación de esta obra. Queda permitida la impresión en su totalidad.

The device has been evaluated to meet general RF exposure requirement.

This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter.

This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.