

尺寸: 280*205mm, 正面

DISCO BLUETOOTH SPEAKER



- ① Music backward/volume - (short press the button for music backward/long press the button volume -)
- ② Play/Pause/light (short press the button for play or pause/keep press button for 3 seconds, short reminding sound with disco light flash to shut off/on the disco light)
- ③ music forward/volume+ (short press the button for music forward/long press the button for volume+, will have the reminding sound when volume is maximum level)
- ④ Answer/hang up the phone call
- ⑤ On/Off
- ⑥ Indicator light
- ⑦ Charge port(Micro USB)
- ⑧ Aux

Specification:

Bluetooth: 3.0

Speaker: 1x3w

Battery: 400mAh

Function: Phone call answer , Aux-in , LED disco ball light jump and flash by music

Accessories: 1xUSB wire and AUX IN wire

Operation:

- 1) Turn on button ⑤, disco light bright and "waiting for connection" voice remind , ⑥ indicator light is blue and keep flashing
- 2) Search from your Bluetooth device for item no. BT-057 and connecting, once it get connected, "connecting" voice reminding
- 3) If you don't need disco ball light , keep press button ② for 3 seconds , a short reminding music come out at the same time disco light flashing and distinguish. If you need re-turn on the disco light, use same way press button ② for 3 seconds , a short reminding music come out at the same time disco light flashing and on.
- 4) During the working, if there has phone call come out, press button ④ to pick up or hang up, make sure when you speak the speaker the button ④ is in front of your side as the mic is built in upward of the button!
- 5) Charging : when charge please press button ⑤ to shut off the speaker first
Make the connection with DC 5V power supply, the indicator will be red , if it get full charge the indicator light will be off
- 6) When you need to use Aux function, please connect Aux wire to the ⑧ and another side connect with music device, disco ball will have the voice reminding "Aux play"

Caution

- 1) When you turn on the speaker and make no connection for around 2 minutes , the Speaker will be automatically power off to save the battery power, when you need to turn on , please shut off and turn on the button ⑤ again
- 2) When you have made the connection with the Bluetooth device, if pause the music or around 20 minutes no any operation, the speaker will be auto power off to save the battery power, if you need turn on , please shut off and turn on the button ⑤ again

רמקול/דיבורית BLUETOOTH עם אורות "דיסקו" דגם ZA-2843



- ① שיר אחורה / הנמך ווליום - בלחיצה ארוכה על הכפתור נוריד את העוצמת המוסיקה (הווליום) , לחיצה קצרה תחזיר שיר אחורה
- ② הפעל/ השהה/ תאורה - בלחיצה קצרה על הכפתור נפעיל או נשהה את המוסיקה , לחיצה ארוכה במשך 3 שניות תפעיל או תכבה את תאורת הדיסקו
- ③ שיר קדימה / הגבר ווליום - בלחיצה ארוכה על הכפתור נגביר את העוצמת המוסיקה (הווליום) , לחיצה קצרה תקפיץ שיר קדימה
- ④ מתג קבלת / ניתוק שיחה
- ⑤ מתג הפעלה On/Off
- ⑥ נורית חייוי סוללה / צימוד Bluetooth
- ⑦ שקע טעינה (Micro USB)
- ⑧ שקע כניסת Aux

תכונות:

גירסת Bluetooth : 3.0

הספק : 3 W וואט

סוללה נטענת : 400 מילי אמפר שעה

שימושים: רמקול , דיבורית , כניסת כבל Aux-in 3.5 מ"מ , כדור דיסקו אקטיבי עם תאורת לד צבעונית עוד באריזה: כבל טעינה USB , כבל Aux-in 3.5 מ"מ

הפעלה:

הפעל את הרמקול בעזרת כפתור ⑤ OFF/ON , תושמע הודעה קולית : "waiting for connection" ונורית הצימוד ⑥, תהבהב בכחול.
הפעל את פונקציית החיפוש Bluetooth במכשיר הטלפון , לחץ לצימוד עם הרמקול: BT-057 , הודעת "connecting" תשמע עם סיום הצימוד בהצלחה. מעתה הרמקול פעיל וישמע מוסיקה מהנייד.
להפעלת תאורת הדיסקו לחץ לחיצה ארוכה של 3 שניות על מתג ② .
לכיבוי תאורת הדיסקו לחץ לחיצה ארוכה של 3 שניות על מתג ② .
לקבלת שיחה בדיבורית בזמן שמיעת מוסיקה לחץ על כפתור ④ קבלת/ניתוק שיחה, לניתוק כנ"ל.
טעינת הרמקול מתבצעת דרך שקע ⑦ (Micro USB) בעזרת כבל הטעינה המצורף. מומלץ לכבות את הרמקול בעת הטעינה בעזרת ⑤ מתג הפעלה On/Off , נורית החיווי ⑥ תידלק באדום בזמן הטעינה ותכבה רק עם כשהסוללה תגיע למצב מלא.
ניתן להשמיע מוסיקה גם בעזרת כבל Aux-in 3.5 מ"מ לשקע ⑧ Aux , עם החיבור תשמע ההודעה "Aux play"

שים לב!

אם עברו 2 דקות ולא התבצע צימוד הרמקול יכבה בכדי לחסוך בסוללה, להמשך הצימוד יש לכבות ולהדליק מחדש בעזרת ⑤ מתג הפעלה On/Off , הרמקול ינסה שוב למשך 2 דקות.
אם יש הפסקה במוסיקה של מעל 20 דקות הרמקול יכבה בכדי לחסוך בסוללה, להפעלה מחדש יש לכבות ולהדליק מחדש בעזרת ⑤ מתג הפעלה On/Off .

尺寸: 280*205mm, 反面

FCC WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.