



CAUTION

**RISK OF ELECTRIC SHOCK
DO NOT OPEN**



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



DANGEROUS VOLTAGE: The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



ATTENTION: The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.



ATTENTION: Users of this product are cautioned not to make modifications or changes that are not approved by Imation Corp. Doing so may void the compliance of this product and may result in the loss of the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules and with RSS-210 of Industry Canada. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- The rating information is located at the bottom of the apparatus.

SURGE PROTECTORS: It is recommended to use a surge protector for AC connection. Lightning and power surges ARE NOT covered under warranty for this product.

WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.

This Class B digital apparatus complies with Canadian ICES-003.

This Class B digital apparatus complies with European Union CE – EMC Directive (2004/108/EC) and European Union CE – Low Voltage Directive (2006/95/EC). This Bluetooth module is in compliance with the essential requirements and other relevant provisions of R&TTE Directive (1999/5/EC). This product is marked with the CE logo and uses radio frequency bands that are harmonized throughout the European Community.

CAUTION: TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT AND FULLY INSERT.

BATTERY PRECAUTIONS

Follow these precautions when using batteries in this device:

1. Warning – Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
2. Use only the size and type of batteries specified.
3. Be sure to follow the correct polarity when installing the batteries as indicated in the battery compartment. A reversed battery may cause damage to the device.
4. Do not mix different types of batteries together (e.g. Alkaline, Rechargeable and Carbon-zinc) or old batteries with fresh ones.
5. If the device is not to be used for a long period of time, remove the batteries to prevent damage or injury from possible battery leakage.
6. Do not try to recharge a battery not intended to be recharged; it can overheat and rupture. (Follow battery manufacturer's directions.)
7. Remove batteries promptly if consumed.
8. Clean the battery contacts and also those of the device prior to battery installation.



1. Discard button batteries carefully.
2. Do not allow children to play with button batteries, and keep button batteries out of your child's reach.
3. Never put button batteries in your mouth for any reason as they are easily swallowed accidentally.
4. Always check medications before ingesting them. Adults have swallowed button batteries mistaken for pills or tablets.
5. Keep electronics out of your child's reach if the battery compartments do not have a screw to secure them. Use tape to help secure the battery compartment.
6. If a button battery is ingested, immediately seek medical attention.

IMPORTANT SAFETY INSTRUCTIONS

1. Read these Instructions.
2. Keep these Instructions.
3. Heed all Warnings.
4. Follow all Instructions.
5. Do not use this apparatus near water.
6. Clean only with a dry cloth.
7. Do not block any of the ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. When the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with a cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
15. WARNING: To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. Do not place objects filled with water, such as a vase, on the apparatus.
16. The AC mains plug is used as the power disconnect device and it should remain readily accessible and operable during intended use. In order to completely disconnect the apparatus from power, the mains plug should be completely removed from the AC outlet socket.
17. CAUTION: To reduce the risk of fire or explosion, do not expose batteries to excessive heat such as sunshine, fire or other heat sources.

PORTABLE CART WARNING
(Symbol provided by IEC/ETAC)



安全上のご注意

本製品は安全に配慮して製造されていますが、誤った使い方をすると、死亡、重傷、傷害などの人身事故、また物的損害を引き起こす原因となり大変危険です。ご使用前には「安全上のご注意」を必ずお読みになり、記載事項を守って安全に正しくご使用ください。

■故障したら使用しないでください。

本製品が正しく動作せず、「こんなときには」の内容をお読みになり対処しても問題が解消されない場合は、ただちにお客様相談室にご連絡ください。

■万一、異常が発生したときは・・・

本製品が異常に発熱したり、異臭、異音、煙が発生したときは、ただちに使用を中止してください。その後はご使用にならず、お客様相談室にご連絡ください。

使用している表示と絵記号

警告表示、注意表示の意味は次の通りです。

	警告	この表示の項目を守らないと、死亡または重傷を負う可能性が想定される内容を表示しています。
	注意	この表示の項目を守らないと、人が傷害を負う可能性または物的損害が発生する可能性が想定される内容を表示しています。

絵記号の意味は次の通りです。

	この絵記号は禁止行為の説明を表示しています。
	この絵記号は必ず実行していただきたい行為の説明を表示しています。

警告

本製品を絶対に分解したり、修理・改造したりしないでください。火災、感電、やけど、故障の原因になります。分解、修理、改造を行った場合は、故障時の保証対象外となります。

本製品の内部に異物を入れないでください。水などの液体や金属片などの異物を入れると、火災、感電、故障の原因になります。液体や異物が内部に入ってしまった場合は、すぐに電源を切り、コンセントから電源プラグを抜いてください。

本製品から煙が出たり、異臭、異音などの異常を感じたりしたら、すぐに使用を中止してください。そのまま継続して使用すると、火災・感電の原因になります。すぐに電源を切り、コンセントから電源プラグを抜いてください。

本製品を濡らしたり、強い衝撃を加えたりしないでください。衝撃を加えてしまった場合は、すぐに電源を切り、コンセントから電源プラグを抜いてください。そのまま継続して使用すると、火災、感電、故障の原因になります。

本製品を濡らしたり、水蒸気や水がかかるような場所で使用しないでください。火災、感電、故障の原因になります。浴室やシャワー室では使用しないでください。雨天、降雪中、海洋、水辺での使用は特にご注意ください。

本製品の近くに水などの入った容器を置かないでください。花びん、植木鉢、コップ、化粧品、薬品など液体の入った容器を置かないでください。こぼれたり、内部に液体が入ると、火災・感電の原因になります。

本製品の放熱をさまたげない場所に設置してください。他の機器、壁等から間隔をとって設置してください。ラックなどに入れる場合はすき間を空け、通風孔をふさがないでください。内部に熱がこもり、火災の原因になります。

電源コードを傷つけないでください。電源コードを傷つけたり、加工したり、無理に曲げたり、ねじったり、引っ張ったり、加熱したりしないでください。電源コードや電源プラグが傷んだ状態(芯線の露出、断線、変形など)で使用すると、火災・感電の原因になります。

雷が降り出したら、本体やケーブル類に触れないでください。感電の原因になります。

表示された電源・電圧(交流100ボルト)以外で使用しないでください。表示された電源・電圧以外で使用すると、火災・感電の原因になります。本製品を使用できるのは日本国内のみです。

電源プラグの清掃を定期的に行ってください。電源プラグにほこりなどがたまっていると、火災の原因になります。電源プラグを抜いて、乾いた布でほこりを取り除いてください。

濡れた手で電源プラグを抜き差ししないでください。感電・故障の原因になります。

電源プラグはコンセントに根元まで確実に差し込んでください。差し込みが不完全だと、発熱したりほこりが付着して火災の原因になります。電源プラグを根元まで差し込んでみゆるみがあるコンセントは使用しないでください。

電源プラグは抜きやすい位置にあるコンセントに差し込んでください。万一の場合に備えて、電源プラグはよく見えて容易に引き抜ける位置にあるコンセントに接続してください。

電源コードの上に重い物を載せたり、本製品の下敷きにしたりしないでください。コードが破損して火災・感電の原因になることがあります。

電池が液漏れしたときは、素手で触らないでください。【電池使用製品】液が目に入ると失明の原因になることがあります。液が目に入ったときは、すぐにきれいな水で十分に洗い流し、ただちに医師の診察を受けてください。液がからだや衣服についたときも皮膚の炎症やけがの原因になることがあります。異常が現れたときは、ただちに医師の診察を受けてください。

本書で指定している以外の電池を使用しないでください。【電池使用製品】火災やけがの原因になることがあります。

病院内や航空機の中などでは使用しないでください。電波が特定の医療機器や航空機の計器類などに影響を及ぼし誤作動による事故の原因になります。

心臓ペースメーカーを装着しているときは、本機を使用しないでください。電波がペースメーカーに影響を与え、誤作動の原因になります。

他の機器に電波障害などの影響が発生したときは、使用を中止してください。ラジオやテレビの近くに使用するとノイズを与えることがあります。また近くにモーターなどの装置があると、誤作動による事故の原因になります。

本機と充電する機器の間に金属片などの異物を置かないでください。【無接点充電製品】発熱によるやけど、火災、感電、故障の原因になることがあります。

注意

本製品を不安定な場所に置かないでください。ぐらついた台の上や傾いた場所、振動する場所に置かないでください。落下したり転倒したりして、けがの原因になることがあります。

高温・多湿・ほこりの多い場所に置かないでください。窓際や車中など直射日光のあたる場所、ストーブのような暖房器具の近くなど高温になる場所、調理台や加湿器の近くなど油煙や湿気のあたる場所、またほこりの多い場所に放置すると火災・感電の原因になることがあります。

音が響んだ状態で長時間使用しないでください。スピーカーが発熱し、火災の原因になることがあります。

機器に接続するときは、機器の音量設定を最小にしてください。始めから音量を上げすぎると、突然大きな音が出て耳を傷めることがあります。音量は少しずつ上げてご使用ください。

同極品以外の電源コードは使用しないでください。火災・感電の原因になることがあります。また、本製品の電源コードを他の機器に使用することもおやめください。

お手入れをするとき、長時間使用しないときは、電源をはずしてください。安全のため、電源を切り、コンセントから電源プラグを抜いてください。電池を取り付けている場合は電池を抜いてください。

電源プラグを抜くときは、電源コードを引っ張らないでください。コードが破損して火災・感電の原因になることがあります。必ずプラグを持って抜いてください。

移動させるときは、電源プラグや接続したコードをはずしてください。コードが破損して火災・感電の原因になることがあります。また、接続機器が落下したり転倒したりして、けがの原因になることがあります。

ブラウン管を使用したディスプレイから離して設置してください。スピーカーの磁気により色むらが発生することがあります。

梱包袋は安全な場所に保管してください。製品を梱包していた袋は、お子様の手の届かない安全な場所に保管してください。窒息などの事故の原因になります。

電池の+(プラス)と-(マイナス)の向きを正しくセットしてください。【電池使用製品】正しくセットしないと、発熱、火災、感電の原因になることがあります。

電池を乳幼児の手の届くところに置かないでください。【電池使用製品】誤って飲み込む恐れがあります。万一、お子様が飲み込んだ場合は、ただちに医師に相談してください。

古い電池と新しい電池、また種類の異なる電池を混在させて使用しないでください。【電池使用製品】破裂や液漏れにより、火災・けがの原因になります。また、周囲を汚損する原因になります。

電池を加熱・分解したり、火や水の中に投下しないでください。【電池使用製品】破裂や液漏れにより、火災・けがの原因になります。また周囲を汚損する原因になります。

電池の+(プラス)と-(マイナス)をショートさせなでください。【電池使用製品】コイン、キー、ネックレスなどの金属類と一緒に携帯・保管すると、発熱、破裂、液漏れにより、火災・けがの原因になります。また周囲を汚損する原因になります。

電池の異常に気づいたら使用を中止してください。【電池使用製品】液漏れ、変色、変形、その他今までと異なることに気づいたらすぐに使用を中止してください。そのまま使い続けると、電池が発熱・破裂する恐れがあります。

ボタン型電池を廃棄するときは、絶縁処理をしてください。【ボタン型電池使用製品】他の金属片と一緒に廃棄すると、ショートして発熱・破裂の原因になることがあります。絶縁テープを貼るなどして、自治体の指示に従って廃棄してください。

磁気に弱いものに近づけないでください。【無接点充電製品】磁気カードや磁気記録メディアなどを近づけると、磁気の影響によりデータが消えたり、壊れることがあります。

電波に関するご注意

●本機は電波法に基づく小電力データ通信システム無線局設備として技術基準適合証明を受けています。従って、本機を使用するときに無線局の免許は必要ありません。ただし、本機に以下の事項を行うと、法律で罰せられることがあります。

- ・分解／改造すること
- ・本機に貼ってある証明ラベルをはがすこと
- 本機は2.4GHzの周波数帯の電波を使用します。2.4GHz帯の電波は、他の無線機器も使用しています。他の無線機器との電波干渉を防止するため、以下の事項に注意してご使用ください。

本機の使用する周波数帯では、電子レンジ等の産業・科学・医療用機器のほか、工場の製造ラインなどで使用される移動体識別用の構内無線局(免許を要するもの)、特定小電力無線局(免許を要しないもの)およびアマチュア無線局(免許を要するもの)が運用されています。

- ・本機を使用する前に、近くで他の無線局が運用されていないことを確認してください。
- ・万一、本機から他の無線局に対して電波干渉が発生した場合は、速やかに使用を中止してお客様相談室にご連絡いただき、混信回避のための処置等についてご相談ください。
- ・その他、本機から移動体識別用の特定小電力無線局に対して電波干渉の事例などが発生した場合などは、お客様相談室までご連絡ください。

- 本機は電波を使用しているため、第三者が故意または偶然に傍受することが考えられます。
- 次の場所では電波干渉により、ノイズや音切れが発生する可能性があります。
 - ・2.4GHz帯を使用する電子レンジ、無線LAN、デジタルコードレス電話、Bluetooth機器の周囲
 - ・アンテナ入力端子を持つAV機器の周囲

本機はすべてのBluetooth機能対応機器とのワイヤレス通信を保証するものではありません。一部の国では、Bluetooth機能対応機器の使用が制限されている場合があります。Bluetooth対応機器の使用については、お住まいの各自体にお問い合わせください。

2.4 FH 4

