

Correction in this Instruction Book

 pg. 9

Skipping unwanted portion — **Skip Search**

Press **SKIP SEARCH** on the Remote once to 4 times during playback. Each press initiates a 30-second period of high speed playback (up to 2 minutes). When the specified portion of the tape is skipped, normal playback resumes automatically. To return to normal playback during Skip Search, press **PLAY** (▶).

Corrección en el manual de instrucciones

 pag. 9

Omisión de las partes no deseadas — **Búsqueda con omisión**

Presione **SKIP SEARCH** en el control remoto 1 a 4 veces durante la reproducción. Cada pulsación inicia un período de 30 segundos de reproducción a alta velocidad (hasta 2 minutos). Cuando se omite la parte especificada de la cinta, la reproducción normal continúa automáticamente. Para regresar a la reproducción normal durante a búsqueda con omisión, presione **PLAY** (▶).