



Instruction Manual

HS-KB050

2.4 GHz Wireless Keyboard and Mouse

Thank you for your purchase of this Hip Street 2.4 GHz Wireless Keyboard and Mouse and we hope you enjoy using them. For further information, visit our website at www.hipstreetonline.com

Please ensure that you fully read and understand the information with this instruction manual prior to using your new keyboard and mouse. It is advised that you keep this instruction manual in a safe place for future reference. We made every effort to insure that these high quality accessories offer you endless hours of reliable use.

Important Safety Precautions

- Do not disassemble, repair or modify the keyboard or mouse by yourself. Refer servicing to qualified personnel.
- Keep the keyboard and mouse away from direct sunlight or heat source.
- Do not expose the keyboard nor the mouse to any liquid or moisture to avoid any malfunction.

first-time use, or any of the features. Just give us a call or send us an email.

Customer & Technical Support: 1-888-4KOBIAN or 1-888-456-2426
Monday through Friday: 8:30am – 5:00pm EST
Email: support@hipstreetonline.com

We want you to start enjoying your new accessories right away!

Content

- Wireless multimedia keyboard
- Wireless optical mouse
- Mini USB receiver
- Instruction manual
- Warranty card

System Requirements

- Microsoft Windows® 98, ME, 2000, XP, Vista, 7 or Mac OS X
- One free USB port

Instructions

- Open the battery cover on the mouse, insert the 2 x AAA batteries (not included) observing the polarity markings shown inside and then replace the cover.
- Open the battery cover on the back of the keyboard, insert the 2 x AAA batteries (not included) observing the polarity markings inside and then replace the cover.
- Plug the mini USB receiver into a free USB port on your computer. The Plug & Play feature will automatically connect the keyboard and mouse to your computer.



Special Features

- To change the speed of the mouse, press the CPI button

to cycle from 800 to 1200dpi.

- To conserve battery power for the mouse, when not in use, press and hold the ON/OFF button on the bottom of the mouse until the red LED light turns off. Press and hold again to turn on.

Multimedia Keys

Mute	Press to mute sound, press again to turn on sound
Vol +	Increase volume
Vol -	Decrease volume
Play/Pause	Press to play or pause media
Stop	Stop media playback



Need assistance? Please call us!

If you encounter any difficulties with these accessories, please visit our website at www.hipstreetonline.com and review our support section or call us. Our representatives are ready to help you with any questions about your product. We can guide you through installation



Guide d'utilisation

HS-KB050

Clavier et souris sans fil 2,4 GHz

Merci d'avoir acheté ce clavier avec souris sans fil 2,4 GHz de marque Hip Street et nous espérons que vous aimerez les utiliser. Pour de plus amples informations, veuillez visiter notre site Web à www.hipstreetonline.com

Veuillez lire attentivement le présent guide d'utilisation avant de faire fonctionner le clavier et la souris et conservez-le dans un endroit sûr afin de pouvoir vous y référer au besoin. Nous avons déployé tous les efforts requis pour faire en sorte que ces accessoires de grande qualité fonctionnent parfaitement pendant d'innombrables heures.

Importante consignes de sécurité

- Ne tentez jamais de démonter, réparer ou modifier le clavier ou la souris vous-même. Confiez toute réparation à du personnel qualifié.
- Évitez de laisser le clavier ou la souris directement au soleil ou à proximité d'une source de chaleur.
- N'exposez pas le clavier ni la souris à quelque liquide que ce soit ou à de l'humidité car ils pourraient mal fonctionner.

Contenu

- Clavier multimédia sans fil
- Souris optique sans fil
- Mini récepteur USB
- Guide d'utilisation
- Carte de garantie

Configuration requise

- Microsoft Windows® 98, ME, 2000, XP, Vista, 7 ou Mac OS X
- Un port USB libre

Directives

- Ouvrez le compartiment à piles de la souris et mettez-y deux (2) piles AAA (non comprises) en respectant les polarités indiquées puis, fermez le compartiment.
- Ouvrez le compartiment à piles du clavier (sous ce dernier) et mettez-y deux (2) piles AAA (non comprises) en respectant les polarités indiquées puis, fermez le compartiment.
- Branchez le mini récepteur sur un port USB libre de votre ordinateur. La fonctionnalité « prêt-à-l'emploi » établira automatiquement la connexion entre le clavier, la souris et votre ordinateur.



Caractéristiques spéciales

- Pour changer la vitesse de la souris, appuyez sur la touche CPI pour passer de 800 à 1200 points par pouce.
- Pour préserver l'énergie des piles dans la souris, lorsque vous ne l'utilisez pas, appuyez sur l'interrupteur (ON/OFF) sous la souris et maintenez-le enfoncé jusqu'à ce le voyant DEL rouge s'éteigne. Appuyez de nouveau sur cet interrupteur pour mettre la souris en marche.

Touches multimédia

Sourdine	Appuyez pour mettre en sourdine, appuyez de nouveau pour rétablir le son
Vol +	Hausse du volume
Vol -	Baisse du volume
Lecture/Pause	Appuyez pour démarrer la lecture ou l'interrompre momentanément
Arrêt	Arrêt de la lecture



Besoin d'aide? Appelez-vous!

Si vous éprouvez des difficultés avec ces accessoires, veuillez visiter notre site Web à www.hipstreetonline.com afin de consulter notre section d'aide ou appelez-nous. Nos représentants sont à votre disposition pour répondre à toutes les questions que vous pourriez avoir concernant vos nouveaux accessoires. Nous pouvons vous guider lors des procédures d'installation, de la première utilisation et vous fournir des explications sur toutes les caractéristiques. Il vous suffit de nous appeler ou de nous envoyer un courriel.

Service d'assistance à la clientèle et de support technique :
1-888-4KOBIAN ou 1-888-456-2426

Du lundi au vendredi : 8 h 30 à 17 h HNE

Adresse électronique : support@hipstreetonline.com

Nous voulons que vous commenciez à profiter de vos nouveaux accessoires dès maintenant!

正面

背面

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF WARNING STATEMENT

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.