



LeapReader™

Get Started & Download your
Included Audio Books,
Music Album & Trivia Challenge

Parent Guide & Instructions

This guide contains important information. Please keep it for future reference.
Ce guide contient des informations importantes. Veuillez le conserver pour toute référence future.

Instructions before starting

Read all the Instructions for Care and Important Safety Instructions before using the LEAPREADER [device, stylus, e.g.].

- 1. Charge** your LEAPREADER by connecting the LEAPREADER to a computer using the included USB cable.
- 2. Install** the LeapFrog® Connect Application by following the simple instructions at www.leapfrog.com/connect
- 3. Follow** the on-screen prompts to complete registration and download your included audio books, music and trivia challenge.

Get Started with *Read, Write, Listen Sampler Book*

- 1. Press** the On/Off button to begin. The green power light will shine when the LEAPREADER is on.
- 2. To begin**, touch the tip of the LEAPREADER to an image or word in the included Read, Write, Listen Sampler Book.

- 3. To listen to audio books**, toggle to the Audio Books mode, scroll to select a title and press the Play button to hear the story.
- 4. To listen to music**, toggle to the Music mode, scroll to select an album and press the Play button to hear songs.
- 5. To listen to trivia challenges**, toggle to the Apps mode, scroll to select an app and press the Play button to hear apps.
- 6. To listen on the go**, simply toggle to the Audio Books mode, scroll to select a title and press the Play button to hear the entire story read aloud.

Install the LEAPFROG® Connect Application

The LEAPFROG Connect Application enables you to download audio for your child's books and access the LEAPFROG App Center/Centre to purchase additional audio books, music albums and more. Parents can also access the LEAPFROG® Learning Path, a powerful online tool that lets you see the skills your child is exploring, get learning ideas tailored to your child's books and more.

- 1. Open** a web browser and go to leapfrog.com/connect
- 2. Click** the LEAPREADER™ product link. Next, click the link to download the LEAPREADER LEAPFROG Connect Application to your PC or MAC® computer.
- 3. Download** and run the installation program. On-screen instructions will guide you through the full installation process.

Download Audio for Other LEAPREADER Books & Maps

- 1. Touch** a page on each LEAPREADER book that you own.
- 2.** If you have not already done so, follow the instructions above to install the LEAPFROG Connect Application.
- 3. Follow** the instructions in the LEAPFROG Connect Application to set up your LEAPREADER and download audio for each of your books.

- 4. Eject and disconnect** the LEAPREADER™ from your computer.
- 5. To begin playing**, simply touch the tip of the LEAPREADER to an image or word in your LEAPREADER book or map.

Troubleshooting

Symptom

LEAPREADER does not turn on or does not respond.

Try this

Make sure the ON/OFF button has been pressed ON.

Symptom

LEAPREADER operates erratically or makes loud noises.

Try this

Make sure battery is fully charged.

Instructions for Care and Use

For Indoor, Dry-Location Use Only.

Do not use the product near a sink or other wet locations. Take care not to spill food or any kind of liquid on this product as it may render it inoperable and not serviceable. In case the unit does a gets wet, unplug all cables and turn it OFF. Allow to dry thoroughly before reusing. Do not attempt to dry with a hair dryer or other heat source. Do not re-connect to the AC outlet if wet or damaged.

Avoid prolonged exposure to extreme temperatures and direct sunlight. Operate in places with temperatures ranging from 5°C (40°F) and 38°C (100°F). Do not leave the product in your car as the temperatures in parked cars can exceed the acceptable storage temperature. Exposure to extreme temperatures can result in shortened battery life or cause the product to temporarily stop working.

Handle with Care.

Do not use the product near a sink or other wet locations. Take care not to spill food or drinks. To avoid injury, damage to this product or other property, avoid dropping and never disassemble, crush, puncture, microwave, incinerate, insert foreign objects or paint the product. Clean your hands before handling the product if they have been exposed to suntan lotions or other chemicals.

Cleaning.

Disconnect all cords before cleaning. Clean your hands before handling the product if they have been exposed to suntan lotions or other chemicals. Clean the product with a slightly damp cloth (cold water). Do not use soap, detergent or other chemicals. Never submerge the unit in water. Allow to dry thoroughly before re-use. Do not connect to the AC outlet if wet or damaged.

Repairing or Modifying the LEAPREADER™ Device.

Never attempt to repair or modify as the LEAPREADER device does not contain any user-serviceable parts. Service should only be provided by LeapFrog Enterprises, Inc.

If the product has been in contact with liquids, punctured, or subjected to a severe impact or fall, immediately remove this product from use and contact LeapFrog Consumer Services for replacement if under warranty.

For service information, go to: www.leapfrog.com/support/LeapReader/service

Instructions d'entretien

A utiliser uniquement en intérieur, dans un endroit sec.

Ne pas utiliser le produit près d'un lavabo ou autres sources d'eau. Faites attention à ne pas renverser de nourriture ou tout autre sorte de liquide sur ce produit car cela pourrait le rendre in opérationnel et inutilisable. Si vous renversez du liquide sur le produit, débranchez tous les câbles et éteignez-le. Laissez le produit sécher complètement avant de le réutiliser. N'essayez pas de le sécher avec un sèche-cheveux ou toutes autres sources de chaleur. Ne pas rebrancher le produit à l'adaptateur si celui-ci est humide ou abimé. Évitez d'exposer le produit à des températures extrêmes ou aux rayons du soleil. Utilisez le produit quand la température se trouve entre 5°C (40°F) et 38°C (100°F). Ne pas laisser le produit dans votre voiture car les voitures garées peuvent excéder les températures pour assurer le bon fonctionnement de votre produit. Exposer ce produit à des températures extrêmes peut diminuer la durée de vie des piles ou peut entraîner l'arrêt de votre produit.

A utiliser soigneusement.

Pour éviter toutes blessures, dommages ou autres, évitez de le faire tomber et ne jamais le démonter, casser, trouser, mettre aux micro-ondes, brûler, incérer un objet ou peindre le produit.


Pour nettoyer.


Débranchez le produit de tous ces câbles. Lavez vos mains avant de manipuler le produit si celles-ci ont été en contact avec de la crème solaire ou autres produits chimiques. Nettoyez le produit avec un chiffon légèrement humide (eau froide). N'utilisez pas de savon, de lessive ou tout autre produits chimiques. Ne jamais immerger le produit dans l'eau. Laisser sécher le produit avant de l'utiliser.


Réparer ou modifier LeapReader.


N'essayez jamais de réparer ou modifier the LEAPREADER device – car celui-ci ne contient aucune pièce pouvant être réparée individuellement. Toutes réparations doivent être faite par LeapFrog Enterprises, Inc. Si le produit a été en contact avec du liquide, troué, ou victime d'un impact fort ou est tombé, arrêtez son utilisation immédiatement et contactez le service client LeapFrog pour remplacer le produit si celui-ci est sous garantie. Pour toute information, visitez www.leapfrog.com/support/LeapReader/service

Important Safety Instructions

 Please read all the Important Safety Instructions prior to using the LEAPREADER device. Failure to follow these safety instructions could result in fire, electric shock, or other injury or damage to LeapReader or other property.

 **CAUTION: This product is not intended for children under 3 years old.** Routinely check this toy for proper and safe condition. If there is any damage or broken parts, remove toy from use.

 **WARNING:** Cords could be a strangulation hazard. Keep out of reach of children under 3 years of age. Children pulling on the cord could cause the computer monitor, TV or other equipment to which the device is connected to fall with the possibility of property damage, serious personal injury, or death.

 **PROTECT YOUR HEARING:** Long-term exposure to loud sounds, at high volume, may result in permanent hearing loss. When using headphones or ear buds, it is recommended that the product is listened to at lower volumes for shorter periods of time. Set the volume while in a quiet environment; turn the volume down if you cannot hear people speaking near you. Limit the listening time to 90 minutes, followed by a quiet period. The louder the volume, the less time required before your hearing may be affected. If you experience ringing in your ears or hear muffled speech, stop listening and have your hearing checked.

Accessories

Read all safety instructions for any accessories or other products before using with the LEAPREADER device. LeapFrog is not responsible for the operation of third-party accessories or their compliance with safety and regulatory standards.

Battery Replacement


 **WARNING:** The lithium rechargeable battery cannot be removed from the

product and should only be replaced by LeapFrog. For your safety, never try to remove the battery. For more information about battery replacement service, go to: www.leapfrog.com/support/LeapReader/service/battery


Charging the Battery

The LEAPREADER device is equipped with a rechargeable lithium-polymer battery. It should be connected to a computer via the USB cord for several hours prior to use. The Charge Status LED is located near the USB jack on the back of the device. When the battery is charging, the charge indicator will display a solid yellow light. When fully charged and connected via the USB port, the charge indicator light will turn green. The charge indicator will be OFF if not connected via USB and if not charging.

Battery Charging Instructions, Cautions & Warnings

 **WARNING:** The adapter or USB cords could be a strangulation hazard. Not for children under 3 years.


 **WARNING:** Not suitable for children under 3 years. Misuse of transformer can cause electric shock.

 **CAUTION:** The battery is only to be charged by adults or children 8+ years of age under the full supervision of parents.

Optional AC Adapter Battery Charger

In order to achieve faster battery charging, an Optional Battery Charger is available from Leapfrog.com or select retailers. The device is a custom AC Adapter equipped with a USB jack, designed expressly for recharging specified LeapFrog products. If this Battery Charger is used, the following additional Battery Charging Instructions, Cautions & Warnings apply. Please note that due to various compliance requirements, the word “transformer” is sometimes substituted for “AC Adapter.”

AC Adapter (transformer) Battery Charger Safety

 **CAUTION:** Use only the recommended AC power adapter (transformer) for charging the battery. The device is a custom AC Adapter equipped with a USB jack, designed expressly for recharging specified LeapFrog products. (Available at leapfrog.com or select retailers) Attempted charging via your computer will require a much longer period of time and may not be successful.

- Connection of the transformer to the wall outlet should be performed only by an adult or child 8+ years of age.
- The transformer is not intended to be used as a toy, and the use of the transformer shall be under the full supervision of parents.

- As with all electrical products, precautions should be observed during handling and use to prevent electrical shock.
- The power adapter may become warm during normal use. Always allow adequate ventilation and use care when handling the power adapter.
- Do not connect or disconnect with wet hands.
- The transformer should be periodically examined for conditions that may result in the risk of fire, electrical shock or injury to persons, such as damage to the cord, plug, blades, housing or other parts, and in the event of such conditions, the transformer must not be used until the damage is repaired. The cord of this transformer cannot be replaced; if the cord is damaged, dispose of the transformer in accordance with your local electrical product recycling regulations.
- **Unplug the Power Adapter (transformer) if any of the following conditions exist:**
 - The power cord or plug, or the USB cord has become frayed or damaged.
 - The power adapter is exposed to rain, liquid, or excessive moisture.
 - The power adapter enclosure has become damaged.
 - You suspect the power adapter needs service or repair.
- Disconnect the LEAPREADER™ device from the transformer before cleaning.
- To clean transformer, disconnect it from the wall and clean with a cloth dampened with water. Do not immerse in water or use soap or other chemicals. Allow to dry before reusing. Do not connect to the AC outlet if wet or damaged.
- This AC adapter can be used to recharge the single cell Li-Poly battery of the LEAPFROG® LEAPREADER™ (3.7Vdc, 760 or 1000mA) and the LEAPFROG® LEAPPAD™ ULTRA 3.7Vdc, 4000mA)
- For Europe - The toy must be used with a transformer for toys.


 **WARNING:** Do not recharge non-rechargeable batteries.


AC Adapter Electrical Ratings:

Input: ~ 120VAC, 60Hz (for US); ~ 230VAC, 50Hz (for UK or EU); ~ 240VAC, 50Hz (for AS/NZL)

Output: DC5V, 1.5A, 7.5VA

Informations Importantes de Sécurité

 **ATTENTION :** Vérifiez régulièrement que ce jouet est en bon état et qu'il ne présente pas de danger. Dans le cas contraire (par exemple, s'il est cassé à certains endroits), tenez ce jouet hors de portée des enfants.


 **PROTÉGEZ VOTRE OÛÏE :** Une exposition durable à des sonorités trop fortes peut entraîner une perte définitive de l'ouïe. Lorsque vous utilisez le casque ou les écouteurs bouton, il est conseillé de baisser le volume et réduire le temps d'écoute. Réglez le son lorsque vous êtes dans un endroit calme et baissez-le si vous n'entendez pas les personnes qui parlent autour de vous. Limitez le temps d'écoute à 90 minutes, puis

accordez-vous un moment de tranquillité. Plus le volume est élevé, plus il y a de chances que votre ouïe soit rapidement touchée. En cas de bourdonnement dans les oreilles ou si vous entendez des voix sourdes, arrêtez immédiatement d'écouter ce produit et faites contrôler votre ouïe dans les plus brefs délais.

Accessoires


Lisez les instructions pour les accessoires ou autres produits avant de les utiliser avec le LeapReader. LeapFrog n'est pas responsable pour les accessoires vendus par d'autres fabricants et leurs standards de sécurité.

Remplacement des Piles

 **ATTENTION :** La pile rechargeable lithium ne peut être retirée du produit et doit être remplacée seulement par LeapFrog. Pour votre sécurité, n'essayez jamais d'enlever la pile. Pour plus d'informations concernant le remplacement de la pile, veuillez visiter : www.leapfrog.com/support/LeapReader/service

Recharger les piles


The LEAPREADER™ device est équipé d'une pile lithium-polymère. Il doit être connecté à un ordinateur avec un câble USB pour plusieurs heures avant d'être utilisé. L'indicateur LED du niveau de pile est situé près du connecteur USB au dos du produit. Quand la pile est entrain de charger, l'indicateur est jaune et quand le produit est chargé, l'indicateur devient vert. L'indicateur sera éteint si le produit n'est pas connecté à un câble USB et ne chargera pas.


 **ATTENTION :** Le câble USB ou les écouteurs peuvent constituer un risque d'étranglement, ils ne doivent pas être utilisés par les enfants de moins de 3 ans.


Adaptateur AC – Option pour recharger le produit

Pour recharger votre pile rapidement, un adaptateur AC optionnel est disponible via LeapFrog. Le produit est un adaptateur AC équipé d'une prise USB spécifiquement adaptée aux produits LeapFrog. Si le chargeur de piles est utilisé, les instructions et conditions de sécurité suivantes doivent être appliquées. Notez que le mot transformateur est des fois remplacé par le terme adaptateur AC.

Instructions et conditions de sécurité concernant la recharge des piles.

 **ATTENTION :** L'adaptateur et le cordon USB peuvent constituer un risque d'étranglement. Ils ne doivent pas être utilisés par les enfants de moins de 3 ans.

 **ATTENTION :** Ne convient pas aux enfants de moins de 36 mois. L'utilisation inadaptée de l'adaptateur peut causer une électrocution.

 **ATTENTION :** La pile ne doit être chargée que par un adulte ou enfants de plus de 8 ans sous la supervision d'un parent exclusivement.

Sécurité concernant la recharge avec l'adaptateur AC

Utilisez uniquement l'adaptateur AC recommandé (transformateur) pour recharger la pile. Ce produit est un adaptateur AC personnalisé équipé d'une prise USB développé exclusivement pour recharger les produits LeapFrog. Recharger le produit via un ordinateur prend plus de temps et parfois peut ne pas fonctionner.

- L'adaptateur doit être branché à la prise murale par un adulte ou un enfant de plus de 8 ans uniquement.
- Ce transformateur n'est pas un jouet, et son utilisation doit être faite uniquement sous la présence d'un adulte.
- Comme avec tous produits électriques, des précautions doivent être utilisées pour éviter des électrocutions.
- Le transformateur peut chauffer pendant son utilisation normale. Vérifiez que la ventilation est adaptée et faites attention quand vous utilisez ce produit.
- Ne branchez ou débranchez pas le produit avec des mains mouillées.
- Le transformateur doit être vérifié régulièrement (les lames, la prise, la prise murale et toutes autres pièces) car si celui-ci est endommagé, il peut être un risque d'incendie, d'électrocution ou autres blessures. Si celui-ci est abimé, arrêter de l'utiliser immédiatement et attendez que celui-ci soit réparé avant de le réutiliser. Le câble de cet adaptateur ne peut pas être remplacé, si le câble est abimé, jetez le transformateur en suivant les règles de recyclage de votre région.
- **Débranchez l'adaptateur si :**
 - Le câble, la prise ou le câble USB sont abimés ou cassés.
 - Le câble, la prise ou le câble USB sont exposés à la pluie, à du liquide ou une humidité excessive.
 - La boîte de protection de l'adaptateur est abimée.
 - Si vous pensez que l'adaptateur a besoin d'être réparé.
- Débranchez le LEAPREADER de l'adaptateur avant de le nettoyer.
- Pour nettoyer l'adaptateur, débranchez -le de la prise murale et nettoyez-le avec un chiffon légèrement humide. Ne l'immergez pas dans l'eau, n'utilisez pas de savon ou autres produits chimiques. Laissez le produit sécher avant de le réutiliser. Ne pas brancher l'adaptateur si celui-ci est mouillé ou abimé.
- Cet adaptateur AC ne peut être utilisé que pour recharger la pile Li-Poly du LEAPREADER LEAPFROG. (3.7Vdc, 1000mA) et le LEAPPAD ULTRA LEAPFROG (3.7Vdc, 4000mA)

 **ATTENTION :** Ne rechargez pas des piles non- rechargeables.

Voltage de l'adaptateur

Voltage d'entrée pour les États-Unis et le Canada: ~120V, 60Hz
Voltage d'entrée pour le Royaume-Uni et l'Europe : ~230V, 50Hz
Voltage d'entrée pour l'Australie et la Nouvelle Zélande : ~240V, 50Hz
Voltage de sortie : DC5V, 1.5A, 7.5VA

NE PAS incinérer les piles usagées.

NE PAS jeter les piles au feu car elles peuvent exploser ou fuir.

NE PAS mélanger piles usagées et piles neuves, ni différents types de piles (c'est-à-dire alcalines/standard).

NE PAS recharger des piles non rechargeables. Les piles rechargeables ne doivent être chargées que sous la supervision d'un adulte.

NE PAS court-circuiter les terminaux d'alimentation.

USB Cable

Use only the USB cable provided by LeapFrog Enterprises, Inc. The USB cable provided with this product complies with FCC and other regulatory Emission limits. Using any other cable may exceed FCC and other regulatory emissions limits. The product must be used only with the recommended USB connection.


The USB cable is not a toy. Disconnect the product from the USB connection before cleaning. USB connectors and cable used with the product must be regularly examined for damage to the cord, plug and other parts and, in the event of such damage, the cable must not be used until the damage has been repaired.


Câble USB

Utilisez exclusivement le câble USB fourni par LeapFrog Enterprises, Inc. Le câble USB fourni avec ce produit est conforme aux normes FCC et d'autres limites d'émission réglementaires. L'utilisation d'un autre câble peut dépasser les limites de la FCC (Commission fédérale américaine des communications) et autres limites réglementaires en matière d'émission. Le câble USB n'est pas un jouet. Déconnectez le jouet du port USB avant d'entamer toute opération de nettoyage.

This toy is not intended for children under 3 years old.

Ce jouet ne convient pas aux enfants de moins de 3 ans.

 **WARNING:** Cords are a strangulation hazard. Keep out of reach of children under 3 years of age. Children pulling on the cord could cause the computer monitor, TV or other equipment to which the device is connected to fall with the possibility of property damage, serious personal injury or death. Adult supervision required during play.

 **AVERTISSEMENT :** Les cordons peuvent représenter un risque d'étranglement. Tenez-les hors de portée des enfants de moins de 3 ans. En tirant sur le cordon, un enfant peut causer la chute de l'écran de l'ordinateur, de la télévision ou d'un autre appareil connecté à ce dispositif et provoquer des risques de dommages matériels, de blessures graves, voire même la mort. L'utilisation de ce jouet doit avoir lieu sous la supervision d'un adulte

 **PROTECT YOUR HEARING**

It is rare but possible for seizures to be triggered by light flashes or patterns such as those on computer or TV screens. To reduce exposure to this potential hazard, play/watch in a well-lit room, sit an appropriate distance from the screen and take 10- to 15-minute breaks every hour.



PROTÉGEZ VOTRE OÛÏE

Une exposition durable à des sonorités trop fortes peut entraîner une perte définitive de l'ouïe. Lorsque vous utilisez le casque ou les écouteurs bouton, il est conseillé de baisser le volume et réduire le temps d'écoute. Réglez le son lorsque vous êtes dans un endroit calme et baissez-le si vous n'entendez pas les personnes qui parlent autour de vous.

Limitez le temps d'écoute à 90 minutes, puis accordez-vous un moment de tranquillité. Plus le volume est élevé, plus il y a de chances que votre ouïe soit rapidement touchée. En cas de bourdonnement dans les oreilles ou si vous entendez des voix sourdes, arrêtez immédiatement d'écouter ce produit et faites contrôler votre ouïe dans les plus brefs délais. Lors de l'utilisation du produit sans écouteurs ou sans écouteurs boutons, ne le tenez ou placez pas proche de vos oreilles.

FCC NOTICE:

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) This device may not cause harmful interference, and 2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE: Changes or modifications to this unit not expressly approved by LeapFrog Enterprises, Inc., could void the user's authority to operate the equipment.

CANADA: This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Environmental Phenomena

- The unit may malfunction if subjected to radio-frequency interference. It should revert to normal operation when the interference stops. If not, it may become necessary to turn the power OFF and then back ON.
- In the unlikely event of an electrostatic discharge, the unit may malfunction and lose memory, requiring the user to reset the device by turning the power OFF and then back ON.

Impact de l'environnement

- Une défaillance de fonctionnement de l'appareil peut survenir s'il est sujet à des interférences avec les fréquences radioélectriques. Le fonctionnement normal de l'appareil devrait reprendre avec l'arrêt des interférences. Si ce n'est pas le cas, il peut s'avérer nécessaire d'éteindre et rallumer l'appareil ou de retirer et réinstaller les piles. Si ce problème survient pendant un téléchargement, redémarrez le logiciel, puis recommencez le téléchargement.
- Dans l'éventualité peu probable d'une décharge électrostatique, un mauvais fonctionnement et une perte de mémoire de l'appareil peuvent se produire. L'utilisateur doit alors retirer et réinstaller les piles pour réinitialiser l'appareil.

Consumer Support

U.S. Consumer Service Contact: Visit our Consumer Support website at www.leapfrog.com/support 24 hours a day.

Canada Consumer Service Contact: Visit our Consumer Support website at www.leapfrog.ca/support 24 hours a day.

U.K. Consumer Service Contact: Visit our Consumer Support website at www.leapfrog.co.uk/support 24 hours a day.

Australia Consumer Service Contact: Please submit questions to our support staff via email at info@funtastic.com.au.

LIMITED WARRANTY: Subject to a limited three (3) month warranty. Visit our website at www.leapfrog.com/warranty for full details of the warranty provided in your country. LeapFrog shall not be liable for any incidental or consequential damages for the breach of any warranty on this product. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, or limitation on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you.

For information on how this product might be recycled, visit www.leapfrog.com/recycle or call (800) 701-5327.

TM & © 2013 LeapFrog Enterprises, Inc. All rights reserved.

leapfrog.com/leapreader

For ages 4-8 years. Convient aux enfants de 4 à 8 ans.

LEAPREADER Models: **21301 and 21302**

LeapFrog Enterprises, Inc.
6401 Hollis Street, Suite 100
Emeryville, CA 94608
(800) 701-LEAP (5327)

Part number: 605-11949-A