





VCE 3GX

User Manual

Basic Knowledge

Introduction

- Thank you for choose our digital color screen mobile phone. By reading these guidelines before using your mobile phone you will have an overall knowledge of this phone set and understand its simple but outstanding functions.
- This phone set is designed for GSM/GPRS networks. On top of basic functions, it enables you to use name card style contacts, clock/ alarm, calendar, calculator, games, audio player, camera, video recorder, image/FM radio and other functions. It serves your work and leisure time. Having unique interface and perfect feature designing this phone set meets all your expectation.
- Our phone set meets the GSM/GPRS standard and has the qualification from related organizations worldwide.
- Our company reserves the rights modifying the content in this instruction without pre-notify.
- Safety information:**
 - Under the circumstance of stealing and lost, contact the telecom branch or sales outlet immediately.
 - When you contact with telecom branch and sales outlet, it is necessary to provide them with IMEI number (printed on the back of the phone set, remove the battery to discover it). Please record the IMEI number and keep it safe for future use.
 - To prevent miss usage of your phone set please take precautions such as:
 - Set the PIN number of the SIM card, and update it timely
 - When get off the car. Please do not leave the phone set unattended, keep it with you or in the suitcase.
 - Set call barring.
- Safety and health precautions**
 - Read the guidelines before using your phone. Failure to comply with them may be dangerous.

Description of Keys

Name of key	Letters or functions
1key	1/12/13/14/15
2key	ABCabc2
3key	DEFdef3
4key	GHIghi4
5key	JKLjkl5
6key	MNOmno6

- 1 -

7key	PQRpqrs7
8key	TUVtuv8
9key	WXYZwxyz9
0key	0
*key	1. Later inputting telephone number, if you want to input extension number, please press twice asterisk key, after the display screen shows "+", please input your extension number. 2. ...*0...#5...#5...#5...#5...
#key	1. In text editing interface, press "9" key to switch test the input method. 2. On the standby interface Press and hold "#" key to transfer the profile of General/Silent/Vibrate.
Scrolling Up	Move cursor up
Scrolling down	Move cursor down
Scrolling left	Move cursor left
Scrolling right	Move cursor right
Left soft key/ Right soft key	In the standby mode, press Left Soft key to access Main menu, Right Soft key to access Contacts.
Ok key	determining options
Dial key	dial telephone numbers and receive incoming calls
End	Return to idle screen 2.End calls or reject incoming calls.

Description of functions

	The SIM1 card's signal strength of the cellular network at your current location.
	The SIM2 card's signal strength of the cellular network at your current location.
	The battery charge level.
	Contacts

- 2 -

	Message
	Call logs
	Settings
	Multimedia
	File manager
	Application
	Profiles
	Internet
	FM Radio
	Audio
	Calendar

In the main display, you may see several icons shown on your status bar.

1. Contacts

You can use the Contacts features business card information will be stored to mobile phones.

- 1.1.Quick search**
Enter the name of the first letter in the contacts to find qualified records.
- 1.2.New**
In the options, add a telephone number to phone or SIM card.
- 1.3.Delete multiple**
choose to delete phone numbers from SIM or Phone, you can mark all of the phone numbers then choose "OK" to delete . you can also choose to delete them one by one.

- 3 -

- 1.4.Import/Export**
Copy
Copy contacts from phone/SIM card to SIM card/phone.
Import contacts
Import contacts file from phone or memory card to Contacts.
Export contacts
Choose some phone numbers in contacts then export them to phone or memory card.
- 1.5.Others**
Own number
To edit the name and the number of your SIM card.
Service number
Support the steps for reaching actual people to solve your problem.
Memory status
To view the capacity of SIM card and phone.
1.6.groups
You can view and edit the details of the group and members of the group to remove or add operation. Your phone provides the following selections for your option:
Family/Friends/Business/Classmates
New group
Add a new group
Mass texting
Send SMS to many phone numbers that you select from Contacts.

2. Message

- 2.1. Write message**
You could write new message by using this function. When you input the message to be sent, press left soft key to send, to insert the templates, to add contact person information, to add photo and to save, etc. Within the write message menu you can write and edit text message up to 160 characters.
After you have an incoming text message, The phone stores the message in the inbox folder of the SMS menu.
- 2.2.Delete**
When you fail to send a message, The phone stores the message in the outbox folder.

- 4 -

- 2.4.Sentbox**
When you send a message successfully,The phone stores the message in the sentbox folder.
- 2.5.Drafts**
When you save a message you have written,The phone stores the message in the drafts folder.
- 2.6.Security inbox**
You can move a message from inbox, outbox,drafts,sentbox to security inbox.
To enter the security inbox,you should input the security inbox password.
- 2.7.Templates**
Your phone offers you a list of templates that you can use in replying to messages. You can also use templates when writing messages.
- 2.8.Broadcast message**
Send or receive message to same area subscribers in Broadcast Message mode. You also can turn this function on/off here.
Receive mode: ON/OFF broadcasting function.
Language: Turn On/Off all languages.
Channel Setting: Set Broadcasting Message parameter.
- 2.9.Voice mail server**
Line 1 number /Fax number/Data number
- 2.10.SMS Settings**
SIM1 message center/SIM2 message center/to show your text message center.
Message validity period:8 hours/24 hours/72 hours/1 week/maximum
Status report/You can request the network to send status reports on your text message(network service).A status report is indicated in by front of the message header.
Save sent message:prompt user/save/don't save
Preferred storage:phone/SIM
- 2.11.Message capacity**
to view the SMS memory of SIM card and phone.

- 5 -

3. Call logs

- 3.1.Mixed calls**
In Call logs menu, choose Mixed calls and press "OK key" to view the records.
Your phone provides the option to Recent Contacts with the same.
- 3.2.Dialed number**
In Call logs menu, choose Dialed number and press "OK key" to view the records.
Your phone provides the option to Recent Contacts with the same.
- 3.3.Received calls**
In Call logs menu, choose Received calls and press "OK key" to view the records.
Your phone provides the option to Recent Contacts with the same.
- 3.4.Rejected calls**
In Call logs menu, choose Rejected calls and press "OK key" to view the records.
- 3.5.Delete call**
Your phone allows you to delete all of call logs.
- 3.6.Call timers**
Your phone allows you to view the timers for calls made and received.
In Call logs menu, choose Call timers, press "OK key" to view the content.
 - Last Call: List out the last call time of your conversation
 - Received calls: Sum of total call time you have received.
 - Dialed calls:Sum of total call time you have dialed.
 - Reset All: Reset the time counter to zero.

4. Settings

- 4.1.Call Settings**
Your phone provides the following selections for your option:
Dual SIM Standby mode/Reply by original SIM/Set SIM name
Call divert/call forwarding unconditional/call forwarding on busy/call forwarding on no reply/divert if unreachable/cancel all divers
Call waiting: Activate/Deactivate/Query Status.

- 6 -

- Call barring: All outgoing calls/All incoming calls/incoming calls when roaming/SD calling/Dial when INTL roaming/cancel all barring/change password
Hide ID/Hide ID/Display own ID/Display ID by network
Other IP prefix/Call time reminder/Auto redial/Vibration when connected
/Reply SMS after reject/Auto record voice call
- 4.2.Phone settings**
Into the phone set up sub-menu, you can set the following:
Date and time: At the time and date menu, you can set the time, date.
Language setting: Includes languages type.
Shortcut settings:to define the shortcut functions.
Auto power on/off:In this menu, you can set the timer switch machine.
Restore factory settings:input password to restore factory settings.
- 4.3.Display**
Wallpaper settings/Idle display settings/Contrast/keypad backlight/auto keypad lock
- 4.4.Security settings**
Your phone provides the following selections for your option:
PIN/on/off/Modify PIN
Modify PIN2 to modify PIN2 number
Phone locked on/off
Modify the cellphone password
Privacy: to choose the functions that you need to enter password when entering.
Lock screen by end-key-to lock screen by end-key.
Guardlock/status/change password
Fixed dialing: fixed dialing/Fixed dialing number
Black list: blacklist list/blacklist settings
- 4.5.Connectivity**
Network selection/Auto select/Manual select

5. Multimedia

- 5.1. Camera**
The camera lens is on the top of the phone, and the display of the phone works as a viewfinder. If there's not enough memory for camera, you need to delete old photos to free some spaces for new photos or you can choose to save

- 7 -

- photos in memory card. The status of your camera setting will be displayed on the top of preview mode.
- Store photos**
You can review pictures you have taken by pressing OK
- DV mode**
Switch to DV mode
- Effect**
Set photo color
- Settings**
Size/Set photo size
Quality/Set photo quality
Banding to avoid flashing
Shutter sound/activate/off
Auto save/activate/off
Storage:phone/memory card

- 5.2.DV**
You can record the video clip through built-in camera.The status of your video recorder setting will be displayed on the top of preview mode.To start using Video recorder in Multimedia menu, select Video recorder and press "OK key" Press Options to personalize your camera setting.
- 5.3.Video**
Key Video Play Function
Press can play or pause video
Short press can choose the previous and next
Video/long press can fast back or fast forward.
Note: You can adjust this volume +/- through scrolling right/left key.Press Sky key to adjust brightness.
Play: Allows you to play the video saved in the My stuff.
Local play list list the video files of phone and memory card.
Shuffle:whether to shuffle play
Repeat:to set the play mode/off/repeat all/repeat one
Settings:Local video play mode/settings reset/help
Details to view the details of a video file
- 5.4.Images**
View the images
- 5.5.Recorder**

6. File manager

- To view the file manager.

- 8 -

7. Application

- 7.1. Calculator**
This function enables you to add, subtract, multiply and divide.
The screen will initially display the number "0". Enter the first number to be calculated.
7.2.Alarm
To set a new alarm, alarm clock icon will be displayed when an alarm is active.
At the same time, three groups can be set up alarm clock.
7.3.Bluetooth
Your phone provides the following selections for your option:
Bluetooth/Bluetooth visibility/Paired device/Transferring files/device name/Bluetooth file storage/help
According to the menu, will enter the corresponding function set.

8. Profiles

- Normal:** Suitable for normal use.
Silent: Suitable for silent use.
Meeting: During the meeting, suitable for use.
Outdoor: Suitable for outdoor use
Indoor: Suitable for indoor use.

9. Internet

- The service is provided by network operator. If SIM card or network operator fails to provide the service, the function can not be available. Contact network service operator, if you want to have more information.

10. FM radio

- You can listen to FM radio freely with plug in the earphone.
Enter the radio interface, search the frequency. (87.5-108.)
Auto search and save/Channel list/save/Manual search/close/open speaker/background play
-Auto search and save/Search frequency available automatically.

- 9 -

- Channel list: You can view all the broadcasting stations you saved.
-save:Save a channel to channel list.
-Manual search: Search the broadcasting station by input frequency manually.
-close/open speaker:You can start up/loudspeaker to make the sound louder.
-background play:you can do other operations while listening to the radio.
-Record to record a channel.
-Timing record:to set the time of recording and the channel.
-Record file list:the record file you have recorded.

11. Audio

- Key Audio Play Function**
Press can play or pause music
Short press can choose the previous and next
Music/long press can fast back or fast forward.
Note: You can adjust this volume +/- through scrolling up/down key.
Music list to list the music of your phone and memory card.
Add to saved play list to new play list
Set as ringtone/set as incoming call ringtone/set as alarm ringtone
Shuffle/whether to shuffle play
Repeat:to set the play mode/off/repeat all/repeat one
Settings:Equalizer/BT stereo output/BT stereo headset
Open review to review music

12. Calendar

- To view the calendar.

- 10 -

Warning

- Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules and Industry Canada license-exempt RSS standard (s). Operation is subject to the following two conditions:
(1) This device may not cause interference
(2) This device must accept any interference, including interference that may cause undesired operation of the device.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
- SAR tests are conducted using standard operating positions accepted by the FCC/ISED, with the device transmitting at its highest certified power level in all tested frequency bands. The SAR is determined at the highest certified power level. The actual SAR level of the device while operating can vary, but must not exceed the maximum value. In general, the closer you are to a wireless base station antenna, the lower the power output by the FCC/ISED.
- Before a new device is available for sale to the public, it must be tested and certified to the FCC/ISED that it does not exceed the exposure level established by the FCC/ISED. Tests for each device are performed in positions and locations as required by the FCC/ISED.
- For body worn operation, this device has been tested and meets the FCC/ISED RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal and that positions the handset a minimum of 5 mm from the body.
- Non-compliance with the above restrictions may result in violation of RF exposure guidelines.

- 11 -

  Manual Del Usuario	1. Información básica 1.1 Instrucción Gracias por elegir el nuestro teléfono móvil Maxwest. Las instrucciones sobre cómo hacer funcionar el teléfono se detallan en este manual del usuario. El teléfono MAXWEST es compatible con GSM y GPRS. El MAXWEST incluye todas las funciones básicas que se esperan de un teléfono con muchas más características, como Bluetooth, cambiador de voz, cámara, reproductor de música, y reproductor de vídeo, radio y muchos más. Estas funciones están diseñadas para la comodidad y mejorar la experiencia del usuario. 1.2 Para su seguridad Por favor revise estas sencillas instrucciones para su propia seguridad. No seguir estas instrucciones puede ser peligroso o ilegal. Lea la guía del usuario para obtener más información. Nota: La calidad de la llamada y la conexión depende de su proveedor de servicio local y de la señal. No nos hacemos responsables de cualquier daño físico o daños materiales debido a un uso inadecuado. 2. Apariencia 2.1 Descripción del teclado 2.1.1 Izquierda / Derecha tecla de navegación Mover el cursor a la izquierda o derecha durante la edición. Mientras que en reposo, oprima la tecla izquierda de navegación al menú (Bandeja de entrada), pulse la tecla de navegación hacia la derecha al menú (perfiles). Durante el uso de la aplicación de la cámara, pulse la tecla izquierda / pulse la tecla izquierda de navegación puede abrir el menú de opciones, pulse la tecla de retorno de navegación derecha al menú anterior.	- 1 -	2.1.2 Tecla arriba / abajo de navegación Ver el nombre, número de llamada, mensaje y todas las opciones del submenú. Mover el cursor a arriba o hacia abajo cuando edición. En estado de reposo, presione la tecla de navegación al menú [palma]. 2.1.3 Tecla suave izquierda Para realizar la función del indicador que aparece en la esquina inferior izquierda de la pantalla. 2.1.4 Tecla suave derecha Para realizar la función del indicador que aparece en la esquina inferior derecha de la pantalla. 2.1.5 Tecla de marcación Para marcar o extracto de un número de llamada entrante. En el modo de espera, presione la tecla de marcación para mostrar la llamada SIM1 archivos. 2.1.6 Tecla colgar Para finalizar una llamada o rechazar llamadas entrantes. Mantenga pulsado este botón para el encendido / apagado. Bajo la mayoría de circunstancias al pulsar esta tecla pondrá el teléfono móvil en modo de espera. 2.1.7 Número clave 0 ~ 9 tecla numérica número de entrada de Can y palabra, la velocidad para seleccionar el menú de opciones, llamada velocidad (la llamada debe ser almacenado en el directorio telefónico). 2.1.8 Tecla * Tiene función diferente en diferentes menús. 2.1.9 Tecla # Tiene función diferente en diferentes menús. 2.1.10 Medio clave En el modo de espera, presione la tecla para entrar en el menú principal. En otros submenús, que funciona igual	que la izquierda tecla de función. 2.1.11 EX1 En el modo de espera, llave EX1 presione para entrar en los registros de llamadas SIM2. 2.1.12 EX2 En el modo de espera, presione la tecla de cámara o EX2 FM u otro menú principal. Consejo: En este manual, la frase "pulse la tecla" se refiere a pulsar y soltar un tiempo clave "Mantenga pulsado una tecla" se refiere a pulsar una tecla y mantener pulsado durante 2 segundos o más. 2.2 Icono Descripción Icono Descripción ■ Cuantas más barras aparezcan, mayor será la intensidad de la señal ■ GPRS conectado ■ Bloqueo de teclado ■ Vibrar ■ Anillo y vibran ■ Anillo ■ Vibrador y después melodía ■ Auricular de entrada ■ Indicador de itinerancia ■ Indicador SMS ■ Indicador MMS ■ Mensaje de voz ■ Configuración y alarma abierta ■ SIM1 abierta Desvío ■ SIM2 abierta Desvío ■ La llamada de SIM1 ■ La llamada de SIM2 ■ Estado de la batería ■ Bluetooth abierto ■ Cronómetro de usos múltiples abierto	2.3 De la batería Para un uso óptimo por favor asegúrese de que el celular se carga a plena capacidad antes de usar. 2.4 Conectar Red 2.4.1 Tarjeta SIM Asegúrese de que se inserta una tarjeta SIM antes de utilizar su teléfono. La tarjeta SIM debe ser proporcionada a usted por su proveedor de servicios. Toda esta información es almacenada en la tarjeta SIM, tales como información de contacto, agenda, La música , etc se almacena en la tarjeta SIM. Para un uso óptimo de no tocar la parte metálica de la tarjeta SIM y mantenerlo alejado de los imanes y la electricidad. Si la tarjeta SIM se ha roto el teléfono el teléfono podría no ser capaz de completar todas sus funciones. Advertencia: Antes de insertar o extraer la tarjeta SIM, asegúrese de que el teléfono está apagado. Asegure que el teléfono no está conectado a una fuente de alimentación externa, ya que esto podría dañar potencialmente la tarjeta SIM. 2.5 Funciones características 2.6 Realización de llamadas En estado de reposo, pulse la tecla de número a número de llamada de entrada, pulse la tecla de función derecha para borrar la entrada error, mucho tiempo pulsar la tecla de función derecha para borrar todas las entradas. Pulse la tecla programable izquierda para guardar el número de llamada de teléfono o tarjeta SIM. Pulse la tecla de marcación para realizar una llamada. En estado de la llamada, puede dirigir tecla numérica de prensa para el número de entrada si es necesario. Para realizar llamadas internacionales se debe pulsar la tecla "0" hasta que aparezca el prefijo telefónico internacional "+4" en la pantalla ("4" en lugar de 00). 2.7 Las llamadas de emergencia	2.8 Responder a una llamada 2.9 Finalizar una llamada 2.10 Historial de llamadas 2.11 opción de llamada 3. Función 3.1 Teléfono libro Puede guardar campos de información ya sea a su tarjeta SIM o el teléfono, esta información incluye el nombre linkman, número de teléfono, número de casa, nombre de la empresa, correo electrónico, teléfono de la empresa, número de fax, cumpleaños, tono de llamada selecto, grupo de llamada. Mientras la prensa de inactividad la tecla derecha para "libreta de teléfonos", ver el registro de llamadas. NOTA: El auricular almacenar más 250 pcs registros telefónicos, base de la memoria de la tarjeta SIM en la misma capacidad. 3.2 Mensajes Mientras la tecla de navegación para seleccionar "Mensajes" para entrar en el submenú, incluyen SMS, MMS, Chat y mensajes de voz del servidor de difusión. 3.2.1 SMS Enviar un mensaje de texto por el Centro de Servicio. La ayuda del micro teléfono del MMS y se puede insertar la imagen, animación, melodía, tono de llamada en un mensaje. 3.2.2 MMS Acceda de MMS MMS o "servicio de mensajes multimedia", es la mejor manera de apoyar multimedia y es capaz de enviar mensajes de texto, imágenes, sonidos y otra información de formato multimedia.	MMS necesitan apoyo operador de red. Póngase en contacto con su proveedor de servicios para obtener más detalles sobre la facturación y los ajustes. 3.2.3 Chat Esta función se basa en SMS. 3.2.4 servidor de correo de voz Esto redireccionará automáticamente las llamadas entrantes al centro de correo de voz cuando no se puede aceptar una llamada para que la persona que llama puede dejar un mensaje en el sistema de correo de voz de la red de servicios. Marque la casilla de correo de voz número para acceder a un correo de voz. 3.2.5 Mensaje de difusión 3.3 El jugador Audio Entrar en el menú del reproductor de audio, presione hacia arriba de navegación / abajo - 8 - clave para controlar la música para reproducir / pausa y parada. Pulse la tecla izquierda de navegación / derecha para cambiar la música, presione "" y la tecla "H" para ajustar el volumen. Optimiza hacia la izquierda tecla de entrar en la lista de reproducción, pulse submenú "opción" pop-up como siguen 3.4 Marcación 3.5 Multimedia En el estado de menú principal, pulse la tecla de navegación para encontrar menú multimedia, pulse la tecla programable izquierda para entrar, o pulse icono de multimedia para acceder a este menú. 3.5.1 Cámara Utilizar esta función, tomar una foto o un video por sí mismo ama y guardar en el archivo de orden de la tarjeta de memoria o guardar en su teléfono. 3.5.2 Imagen espectador	- 5 -
Pulse la tecla programable izquierda para operar su foto seleccionada, se puede ver, buscar Estilo, Enviar, Renombrar, Eliminar, Eliminar todos los archivos de su foto, también se les puede cambiar la posición de almacenamiento. Ha separado imagen. Presione la tecla de navegación hacia arriba / abajo para navegar. 3.5.3 Video El auricular es compatible con función de grabación de vídeo. 3.5.4 Grabador de sonido Esta función muestra la lista actual de la grabadora que se almacenan en el teléfono, el apoyo grabadora de AMR y WAV archivo. Si su teléfono no tiene la grabadora, la pantalla le pedirá - 9 - (Vaciar carpeta). 3.5.5 Lista FMRecord Esta función de grabación del horario FM teléfono de soporte (también se puede utilizar en el estado de energía apagado). Puede configurar FMRecord horario múltiples. 3.5.6 Espectáculo de diapositivas Puede seleccionar una carpeta, que se almacena en la tarjeta de memoria o el teléfono, y reproducir imágenes de esta carpeta. 3.6 Gestor de archivos 3.7 Reproductor de video En este menú puede ver la lista de archivos de vídeo y oprima la tecla izquierda para jugar, enviar, renombrar, borrar, eliminar todos los archivos de ellos, también se les puede cambiar la posición de almacenamiento. Ordena, establece Bluetooth. 3.8 FM Radio El teléfono ha construido en función de radio, basta con insertar un auricular para abrir esta función. En el menú de	radio, pulse arriba / abajo de navegación para activar o desactivar la función de los canales de búsqueda, pulse la tecla de navegación izquierda / derecha para buscar canales automático hasta que buscó un canal. Cierre la función de búsqueda automática, puede buscar un canal por lo que quiere a mano. Pulse una vez la izquierda o la tecla de navegación derecha para añadir o 0.1 MHz minis. 3.9 Alarm 3.10 Calendario Pulse las flechas arriba / abajo y derecha / izquierda de la tecla de navegación - 10 - interruptor para editar la fecha, la hora. 3.11 Organizador 3.12 Centro de llamadas Pulse la tecla de navegación para esta función, a continuación, pulse submenú tecla izquierda de entrar en él, historial de llamadas 3.12.1 Las llamadas perdidas En esta función, se mostrará la lista de llamadas perdidas. Seleccione un registro de llamadas perdidas, presione la tecla programable izquierda para visualizarla detalle información, 3.12.2 Configuración general de llamada 3.13 Servicios 3.13.1 Cuenta de Datos 3.14 Configuración En opción, puede configurar el teléfono como su preferencia. 3.14.1 configuración Dual SIM Esta función incluye Dual SIM abierto, sólo SIM1 abierta, sólo el submenú de modo abierto y la fuga de SIM2. 3.14.2 calibración de la pantalla Tocar	- 2 -	Introduzca la calibración de tocar la pantalla para calibrar el lápiz para tocar más exacta. 3.14.3 Configuración del teléfono 1) El tiempo y la fecha 2) Ajuste Ciudad Ajustar la hora local de la ciudad como su tiempo de teléfono. 3) Ajuste de hora Se puede establecer una fecha y hora 2000-2030 4) Formato Establecer hora Puede establecer 12 horas o formato de 24 horas. 5) Energía del radio El teléfono tiene cuatro potencias On / Off/tiempo para editar. Nota: la función no se puede utilizar si el encendido / apagado de tiempo se estableció el mismo. 3.14.4 Configuración de la red 3.14.5 Configuración de seguridad Establecer la información de seguridad para proteger su tarjeta de teléfono y la tarjeta SIM contra el uso no autorizado. 3.14.6 Restaurar fábrica Introduzca la contraseña de inicio de teléfono (número predeterminado es - 12 - 0000. Esta característica se restablecerá el teléfono a la misma ajustes como los configurados en la fábrica. 3.15 Los perfiles de usuario Puede establecer perfiles de teléfono de acuerdo a su necesidad. Los perfiles de usuario incluyen en general, reunión, al aire libre, de interior, auriculares y Bluetooth. 3.16 botón de la luz de la antorcha Puede abrir la luz de la antorcha pulsando el botón OK durante mucho tiempo. Si la luz de la antorcha ha sido	se abre al pulsar el botón lateral, no hará ninguna diferencia pulsando el botón OK. 4. El modo de introducción de texto 4.1 Recapitulación definición 4.2 Teclado Tecla de función izquierda: confirman Tecla de función derecha: el retorno o clara Tecla de navegación: mover el cursor o seleccionar esperar carácter de entrada. 0 ~ 9: número de entrada o carta. Tecla #: cambiar el modo de entrada * Clave: En el estado de entrada, presiónelo cuadro de entrada de símbolos para abrir. EX1: pulse esta tecla para ver los registros de llamadas SIM2. EX2: pulse esta tecla para menú de la cámara. reemplazo de la batería tipo incorrecto causará una explosión peligrosa. Asegúrese de seguir las instrucciones para hacer frente a la batería terminada. Gracias por elegir nuestro teléfono Maxwest - Si necesita cualquier información adicional, por favor, póngase en contacto con nosotros en: www.maxwesttelecom.com	Advertencia ■ Cualquier cambio o modificación no aprobada expresamente por la parte responsable del cumplimiento podría anular la autoridad del usuario para operar el equipo. Este dispositivo cumple con la parte 15 de las normas de la FCC y los estándares RSS exentos de licencia de Industry Canada. El funcionamiento está sujeto a las siguientes dos condiciones: (1) Este dispositivo no puede causar interferencias. (2) Este dispositivo debe aceptar cualquier interferencia, incluidas las interferencias que puedan causar un funcionamiento no deseado del dispositivo. Nota: este equipo ha sido probado y cumple con los límites para un dispositivo digital de Clase B, de conformidad con la parte 15 de las normas de la FCC. Estos límites están diseñados para proporcionar una protección razonable contra interferencias perjudiciales en una instalación residencial. Este equipo genera, utiliza y puede emitir energía de radiofrecuencia y, si no se instala y utiliza de acuerdo con las instrucciones, puede causar interferencias perjudiciales en las comunicaciones de radio. Sin embargo, no hay garantía de que no se produzcan interferencias en una instalación en particular. Si este equipo causa interferencias perjudiciales en la recepción de radio o televisión, lo que puede determinarse encendiendo y apagando el equipo, se recomienda al usuario que intente corregir la interferencia por una o más de las siguientes medidas: • Reorientar o reubicar la antena receptora. • Aumentar la separación entre el equipo y el receptor. • Conecte el equipo a una toma de corriente y a un circuito diferente al que está conectado el receptor. • Consulte al distribuidor o a un técnico de radio / TV con experiencia para obtener ayuda. ■ Las pruebas de SAR se realizan utilizando posiciones de operación estándar aceptadas por la FCC / ISED con el dispositivo transmitiendo a su nivel de energía certificado más alto en todas las bandas de frecuencia probadas, aunque el SAR se determina al nivel de energía certificado más alto, el nivel SAR real del dispositivo mientras la operación puede estar muy por debajo del valor máximo, en general. ■ Antes de que un nuevo dispositivo esté disponible para la venta al público, debe probarse y certificarse ante la FCC / ISED que no excede el límite de exposición establecido por la FCC / ISED. Las pruebas para cada dispositivo se realizan en posiciones y ubicaciones como requerido por la FCC / ISED. ■ Para uso en el cuerpo, este dispositivo ha sido probado y cumple con las pautas de exposición a RF del FCC / ISED cuando se usa con un accesorio designado para este producto o cuando se usa con un accesorio que no contiene metal y que coloca el auricular a un mínimo de 5 mm del cuerpo. ■ El incumplimiento de las restricciones anteriores puede resultar en la violación de las pautas de exposición a RF.	- 4 -		
- 7 -	- 8 -	- 9 -	- 10 -	- 11 -	- 6 -			