

## Fast Lane

<b>Toys R Us</b>	<b>File Name:</b> US-10-FL-BLK-040-A-1
	<b>Mfr#:</b> KD0733 <b>Skn#:</b>
<b>Studio:</b> Design Design	<b>Vendor:</b> MAC DUE INT
<b>Product Description:</b> AJ-058	
<b>Flat Art Size:</b> A5 x 4 pages	<b>Coating:</b> PKG color <b>K</b>
<b>Packaging Dimension:</b>	<b>Insert color</b>
<b>Raster Effect:</b> 150 DPI	<b>Date:</b> 10-5-18
<b>(PDP) Primary Display Panel Size:</b>	
<b>Warning Size/Legal Panel:</b>	

\*REMINDER: Open space above UPC on packaging (and end of sewn-in-label if applicable) is the DATE CODE STAMP area. Please refer to TRU Shipping manual for date code requirements detail.

## English version



#KD0733

### CHARACTERISTICS

Functions: Forwards, Backwards Right, left and stop.

### BATTERY INSTALLATION

#### A-TRANSMITTER

1. Ensure that the ON/OFF switch is in the OFF position;
2. Open the battery compartment and insert 1 x 9V battery paying attention to the + and - indications;
3. Replace the battery compartment cover ensuring that it closed securely;
4. Attach the antenna to the top of the transmitter ensuring that is screwed until fully secure.

#### B-VEHICLE

1. Ensure that the ON/OFF switch is in the OFF position;
2. Open the battery compartment and insert the 3 x AAA batteries paying attention to the + and - indications;
3. Replace the battery compartment cover ensuring that it closed securely;

### BATTERY MAINTENANCE

Do not overcharge the battery. For best results ensure that the battery is completely used before charging. The battery will heat up during recharge and use, handle with care and allow cooling before recharging. Use only the recharger supplied to recharge the Battery.

### OPERATING FUNCTION

Move the ON/OFF switches of the transmitter and vehicle to the ON position.

- 1) To make the vehicle move forwards or backwards push on or pull back the trigger respectively;
  - 2) To make the car turn left or right, turn the wheel forward or backwards on the transmitter respectively;
  - 3) To stop the vehicle release the trigger
  - 4) For best performance ensure that the antenna is pointing towards the vehicle.
- When not in use, make sure the transmitter switch and vehicle switch are OFF

### WARNING!

Non-rechargeable batteries are not to be recharged. Different types of batteries are not to be mixed (transmitter only). Only batteries of the same or equivalent type as recommended are to be used. Batteries are to be inserted with correct polarity. Exhausted batteries are to be removed from the toy. Remove the batteries from the toy when not in use for an extended period of time. The supply terminals are not to be short-circuited. If there are leaks of liquid or signs of wear don't attempt to recharge the battery pack. The manufacturer is not responsible for the possible interferences from radio or TV owing to non-permitted modifications on this appliance.

### SAFETY FIRST

Read these instructions carefully before using this product and keep in a safe place for future reference.

Do not submerge this item in water. Use a damp cloth and dry before use. Do not leave this item in direct sunlight for a long period. We advise the use of this product while under the guidance of an adult. This toy is for children of 6 years and above. Do not use this toy on the road and keep away from animals and young children. Do not attempt to modify this product in any way or lift it from the ground while in movement. Keep moving parts of this product away from hair, clothes and hands. Handle with care at all times and only when the motor is off. Do not dispose of this product and accessories in a fire, as they may leak and explode, dispose of them in the appropriate container

### FCC Statements

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference, and
- 2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply within the limits of a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installation. This equipment generated, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harm to radio communications.

However, this is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- Consult the dealer or an experienced radio/TV technician for help.
- Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Please keep this packaging for future reference.

<b>6+</b>	<b>NOT INCLUDED</b> DXX1+ AAA3+	<b>Toys R Us</b>	<b>CONFORMS TO THE SAFETY REQUIREMENTS OF ASTM F963.</b>	Contents and colors may vary. Do not mix old and new batteries. Do not mix alkaline, standard carbon-zinc, or rechargeable batteries.	FAST LANE is a mark of Geoffrey, LLC, a subsidiary of Toys R Us, Inc. © 2010 Geoffrey, LLC Made in China Distributed in the United States by Toys R Us, Inc., Wayne, NJ 07470 Distributed in Australia by Toys R Us (Australia) Pty Ltd., Regents Park NSW 2143 <a href="http://www.toysrus.com">www.toysrus.com</a>
-----------	---------------------------------------	------------------	--	---	--

## Spanish version



#KD0733

### CARACTERÍSTICAS

Funciones: hacia adelante, hacia atrás, hacia la derecha, hacia la izquierda y parada.

### INSTALACIÓN DE LAS PILAS

#### A-CONTROL REMOTO

1. Asegúrese de que el interruptor ON/OFF esté en la posición OFF (apagado).
2. Abra el compartimento de las pilas e introduzca una de 9 V de tipo 6F22 respetando las indicaciones sobre polaridad.
3. Vuelva a colocar la tapa del compartimento de las pilas y asegúrese de esté bien cerrada.
4. Monte la antena en la parte superior del control remoto y asegúrese de atornillarla bien hasta que quede fija por completo.

#### B-VEHICULO

1. Asegúrese de que el interruptor ON/OFF esté en la posición OFF (apagado).
2. Abra el compartimento de la batería e inserte el paquete de la batería de 9,6 V y conecte los cables en el interior.
3. Vuelva a colocar la tapa del compartimento de la batería y asegúrese de que esté bien cerrada.

### MANTENIMIENTO DE LA BATERIA

No sobrecargue la batería. Para obtener los mejores resultados, asegúrese de que esta esté usada por completo antes de cargarla. La batería se calienta durante la recarga y el uso; manipúlela con cuidado y deje que se enfríe antes de recargarla. Use exclusivamente el cargador que se proporciona para recargar la batería.

### FUNCIONAMIENTO

Coloque el interruptor ON/OFF (encendido/apagado) tanto del control remoto como del vehículo en la posición ON (encendido).

- 1) Para hacer que el vehículo avance o retroceda, empuje hacia delante o tire hacia atrás del gatillo respectivamente.
- 2) Para hacer que el vehículo gire a la izquierda o hacia a la derecha, gire el volante del control remoto hacia delante o hacia atrás respectivamente.
- 3) Para detener el vehículo, suelte el gatillo.
- 4) Para obtener el mejor funcionamiento, asegúrese de dirigir la antena hacia el vehículo. Cuando no se usen, asegúrese de que el control remoto y el vehículo estén en la posición OFF (apagado).

### AVISOS

Las pilas no recargables no se deben recargar. No sumerja este artículo en agua. Use un trapo húmedo y séquelo tras su uso. No deje este artículo expuesto a la luz solar directa durante un largo período de tiempo. Las baterías recargables se deben retirar del juguete antes de cargarse (si se pueden cambiar). Las baterías recargables solo las debe cargar un adulto. No se deben mezclar distintos tipos de pilas o pilas nuevas y usadas (solo del control remoto). Se recomienda utilizar únicamente pilas iguales o del mismo tipo que las recomendadas. Las pilas deben instalarse siguiendo la polaridad correcta. Las pilas gastadas deben retirarse del juguete. Quite todas las pilas cuando no se utilice el juguete durante un largo período de tiempo. No se deben provocar cortocircuitos en los terminales de alimentación. Si existen fugas de líquidos o señales de desgaste, no intente recargar el paquete de la batería. El fabricante no se hace responsable de las posibles interferencias de radio o televisión causadas por las modificaciones no permitidas de este aparato. Se deben examinar con regularidad los transformadores o los cargadores de otras partes que se utilicen con el juguete para detectar daños en el cordón eléctrico, el enchufe, la caja o en otras partes. En su caso, no se deben usar hasta que el daño se haya reparado.

### LA SEGURIDAD ES SIEMPRE LO PRIMERO

Lea con detenimiento estas instrucciones antes de usar este producto y guárdelas en una lugar seguro para futuras consultas. No sumerja este artículo en agua. Use un trapo húmedo y séquelo tras su uso. Recomendamos que este producto se use con la orientación de un adulto. Este juguete es para niños a partir de 6 años de edad. No use este juguete en la carretera y manténgalo fuera del alcance de animales y niños pequeños. No intente modificar este producto de ninguna manera ni levantarlo del suelo mientras esté en movimiento. Mantenga las piezas móviles alejadas del pelo, ropa y manos. Manipúlelo siempre con cuidado y sólo cuando el motor esté apagado. No tire este producto ni sus accesorios al fuego ya que podrían derramar líquidos y explotar, tirelos al contenedor adecuado.

### Información de la FCC (Comisión Federal de Comunicaciones)

Este dispositivo cumple con la apartado 15 de las reglas de la FCC. El funcionamiento está sujeto a las siguientes condiciones:

- 1) Este dispositivo no debe causar interferencias dañinas.
- 2) Este dispositivo debe aceptar las interferencias recibidas, incluyendo interferencias que puedan causar un funcionamiento no deseado.

NOTA: Este equipo ha sido probado y se ha comprobado que cumple con los límites para un dispositivo digital Clase B, de conformidad con el apartado 15 de las normas de la CFC. Estos límites están diseñados para proporcionar una protección razonable contra interferencias dañinas en una instalación residencial. Este equipo genera, utiliza y puede irradiar energía de radiofrecuencia y, si no se instala y utiliza de acuerdo con las instrucciones, puede ocasionar interferencias dañinas para las radiocomunicaciones.

Sin embargo, no existe garantía de que no se produzcan interferencias en una instalación determinada. Si este equipo causara interferencias dañinas en la recepción de radio o televisión, lo que se puede determinar al apagarlo y encenderlo, intente corregirlo a través de las medidas siguientes:

- Reorientar o reubicar la antena receptora.
- Aumentar la separación entre el equipo y el receptor.
- Conectar el equipo a una toma en un circuito distinta a la del receptor.
- Consultar al distribuidor o a un técnico experimentado de radio/TV para obtener más información.
- Advertencia: los cambios o modificaciones que no hayan sido expresamente aprobados por la parte responsable y que no cumplan las normativas vigentes podrían anular la autoridad del usuario para utilizar el equipo.

Guarde este embalaje para futuras consultas.

<b>6+</b>	<b>NOT INCLUDED</b> DXX1+ AAA3+	<b>Toys R Us</b>	<b>CUMPLE CON LA NORMATIVA DE SEGURIDAD ASTM F963.</b>	El contenido y los colores pueden variar. No mezcle pilas nuevas con pilas usadas. No mezcle pilas alcalinas, estándar carbon-zinc o recargables.	FAST LANE is a mark of Geoffrey, LLC, a subsidiary of Toys R Us, Inc. © 2010 Geoffrey, LLC Made in China Distributed in the United States by Toys R Us, Inc., Wayne, NJ 07470 Distributed in Australia by Toys R Us (Australia) Pty Ltd., Regents Park NSW 2143 <a href="http://www.toysrus.com">www.toysrus.com</a>
-----------	---------------------------------------	------------------	--	---	--