The Manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the use's authority to operate the equipment

Car MP3 FM Transmitter (Full Frequency)

Description of goods, Specification, Manual Operation Instruction Guide

1 **Description of goods**

Built-in Fm transmitter

Read MP3 songs from the USB flash disk directly and broadcast through the car FM tuner.

Support USB Flash Disk, LINE-IN function enable you to enjoy music from the external audio device to your car radio by the earphone jack , such as CD,MD player.

Four functional keys: PLAY/PAUSE   PREV/V   NEXT/V

Digital LED display: present frequency, volume, serial number of songs.

Plays the last frequency and tracks number when it restarts

Repeat play all music and Auto run.

Frequency range:14 frequencies(88.1 ~ 89.1MHz and 106.7~107.9MHz)

Car cigar socket power supply (12V-24 DC power)

USB 2.0 interface with high transfer speed.

2 Specification

Specification	
Details	Technical Parameter
Model Name	Car USB MP3 Fm Transmitter
USB Port	USB2.0 and USB1.1
Audio Format:	MP3(MPEG Audio Layer3)
Power Supply:	DC 9　26V
Max USB port out current	1.2A
Bit Rate	32kbps　256kbps
FM Frequency	87.7 ~ 89.1MHz and 106.7~107.9MHz, More 0.2MHZ
Frequency setting	By function key and Remote controller
Signal/Noise SNR	45db
Harmonic Distortion	≤1%
Audio source:	USB Flash Disk,
Transmitting distance:	Up 3　5 miter
Frequency Channel	14 channels
Automatic remembrance in out of power station:　　　and remote control	With Remembrance of last running status (Frequency, song's sequence, etc.)and Remote controller

3 Operation Guide

Operation Guide	Car MP3 Player	6 Button Remote Controller
1　How to play and stop	Press "PLAY" Button : Play the music Second Press "PLAY" Button: Stop	Press Press/Stop Button
2　How to adjust the Volume	Long Press "NEXT/V　" button :Increase the Volume　press "PREV/V　" Button : decrease the Volume	Press "VOL+"" Increase the Volume　Press "VOL-"" reduce the Volume
3　How to change the Frequency	Press "+": increase the Frequency Press" –":decrease the frequency	Press "FREQ+" button:: Increase 0.1MHZ button: Press "FREQ-" button:: reduce 0.1MHZ First Press FREQ+ FREQ-　And then press NEXT/V button to increase 1MHZ　press PREV/V decrease 1MHZ
4　How to serial number of the song	Short Press NEXT/V　Button: Play the next song; Short Press PREV/V　Button: Play the previous song;	Press NEXT/V Button: Play the next song; Press PREV/V Button: Play the previous song;