



AC-UUD12 ACアダプター / AC Adaptor

デジタルペーパー (DPT-RP1 / DPT-S1) ・スタイラスペン(DPTA-RS1)専用ACアダプター / AC Adaptor for Digital Paper (DPT-RP1 / DPT-S1) and Stylus (DPTA-RS1)

取扱説明書 / User Guide

日本語

警告 安全のために

ソニー製品は安全に充分配慮して設計されています。しかし、電気製品はすべて、間違った使いかたをすると、火災や感電などにより人身事故になることがあり危険です。事故を防ぐために次のことを必ずお守りください。

安全のための注意事項を守る

この「安全のために」の注意事項をよくお読みください。

定期的に点検する

1年に1度は、ACアダプターとコンセントとの間にほこりがたまっていないか、故障したまま使用していないか、などを点検してください。

故障したら使わない

動作がおかしくなったり、ACアダプターが破損しているのに気づいたら、すぐにソニーの相談窓口にご相談ください。

万一、異常が起きたら

変な音・においがしたり、煙が出たときは・・・



- 1 ACアダプターをコンセントから抜く。
- 2 ソニーの相談窓口に修理を依頼する。

警告表示の意味

本書および製品では、次のような表示をしています。表示の内容をよく理解してから本文をお読みください。



この表示の注意事項を守らないと、火災・感電などにより死亡や大けがなど人身事故の原因となります。



この表示の注意事項を守らないと、感電やその他の事故によりけがをしたり周辺の家財に損害を与えたりすることがあります。



行為を指示する記号



プラグをコンセントから抜く



下記の注意事項を守らないと火災・感電により大けがの原因となります。



分解や改造をしない

火災や感電の原因となることがあります。内部の点検や修理はソニーの相談窓口にご相談ください。



内部に水や異物を入れない

水や異物が入ると火災や感電の原因となります。万一、水や異物が入ったときは、すぐにACアダプターをコンセントから抜いて、ソニーの相談窓口にご相談ください。



本機は対応機種以外では使わない

火災やけがの原因となることがあります。



湿気やほこり、油煙、湯気が多い場所、直射日光のあたる場所、水や薬品などがかかるおそれのある場所には置かない(特に風呂場では絶対に使用しない)



禁止

上記のような場所に置くと、火災や感電の原因となることがあります。また、本機の近くに水の入った容器などを置かないでください。

お手入れの際、電源プラグを抜く

電源プラグを差し込んだままお手入れすると、感電の原因となることがあります。



プラグをコンセントから抜く

雷が鳴りだしたら、電源プラグに触れない

感電の原因となります。



接触禁止

ぬれた手でACアダプターに触れない

感電の原因となることがあります。



ぬれ手禁止

ACアダプターを布団などでおおった状態で使わない

熱がこもってケースが変形したり、火災の原因となることがあります。



禁止



下記の注意事項を守らないと、けがをしたり周辺の家財に損害を与えたりすることがあります。

通電中のACアダプターや製品に長時間触れない

長時間皮膚が触れたままになっていると、低温やけどの原因となることがあります。



禁止

コード類は正しく配置する

コード類は足に引っかけたりして引っぱると製品の落下や転倒などによりけがの原因となることがあるため、充分注意して接続、配置してください。



禁止

長期間使わないときは電源プラグを抜く

長期間使用しないときは、安全のためACアダプターをコンセントから抜いてください。絶縁劣化、漏電などにより火災の原因となることがあります。



プラグをコンセントから抜く

可燃性ガスエアゾールやスプレーを使用しない

清掃用や潤滑用などの可燃性ガスを使用すると、モーターやスイッチの接点、静電気などの火花、高温部品が原因で引火し、爆発や火災が発生する恐れがあります。



禁止

はじめに

本機をご使用になる前に、本書をよくお読みのうえ、お読みになったあとは、いつでも見られるところに保管してください。

本機は、マイクロUSB端子を搭載したデジタルペーパーとデジタルペーパー専用スタイラスペン(DPTA-RS1)のACアダプターです。対象機種の最新情報は、デジタルペーパーの製品ページをご覧ください。

<http://www.sony.jp/digital-paper/>

使いかた

- 1 デジタルペーパーに付属のUSBケーブルを、デジタルペーパーまたはスタイラスペンのマイクロUSB端子とACアダプターのUSB端子に接続する。
- 2 ACアダプターの電源プラグをコンセントに差し込む。充電中はデジタルペーパーの充電ランプが赤色に点灯し、充電が完了すると消灯します。

充電時間はお使いのモデルによって異なります。DPT-RP1をお使いの場合はヘルプガイド(<http://www.sony.co.jp/dpt-rp1/help>)を、DPT-S1をお使いの場合はデジタルペーパー本体に収録の「ユーザーガイド」をご覧ください。

ご注意

- 充電は周囲の温度が5℃～35℃の環境で行ってください。
- USBハブやUSB延長ケーブルをご使用の場合の動作保証はいたしません。必ず、デジタルペーパーに付属のUSBケーブルをお使いください。

使用上のご注意

置いてはいけない場所

使用中、保管中にかかわらず、次のような場所に置かないでください。故障の原因になります。

- 異常に高温になる場所
炎天下や夏場の窓を閉め切った自動車内は特に高温になり、放置すると変形したり、故障したりすることがあります。
- 直射日光の当たる場所、熱器具の近く
変形したり、故障したりすることがあります。
- 激しい振動のある場所
- 本機を本棚や組み込み式キャビネットなどの狭い場所に設置しないでください。

使用について

- 本機を使用する前には、必ず接続する機器の定格電圧、定格電流を確認のうえ、ご使用ください。
- 本機の使用状態によって、定格電流より過大な電流が流れた場合は、安全のために本機の出力電圧が一時的に途切れ、使用されている機器の電源が切れる場合があります。
- 火災や感電の危険を避けるために、本機を水のかかる場所や湿気のある場所では使用しないでください。また、本機の上に花瓶などの水の入ったものを置かないでください。
- 本機は容易に手が届くようなコンセントに接続し、異常が生じた場合は速やかにコンセントから抜いてください。
- 強い衝撃を与えたり、落としたりしないでください。
- 使用後は必ず本機をコンセントから抜いておいてください。
- コンセントから抜くときは本機を持って抜いてください。
- 本機の接点部に他の金属類が触れないようにしてください。ショートすることがあります。
- 本機またはデジタルペーパーに付属のUSBケーブル以外の使用については、性能および安全性を保証いたしません。

温度上昇について

デジタルペーパーを充電中、または長時間お使いになると、本体の温度が上昇することがありますが、故障ではありません。

お手入れについて

- 汚れたときは、柔らかい布やティッシュペーパーなどで、きれいに拭き取ってください。
- 汚れがひどいときは、水でうすめた中性洗剤に柔らかい布をひたし、固くしぼってから汚れを拭き取り、乾いた布で仕上げてください。
- アルコール、シンナー、ベンジンなどは使わないでください。変質することがあります。
- 化学ぞうきんをご使用の際は、その注意書きに従ってください。
- 殺虫剤のような揮発性のものをかけたり、ゴムやビニール製品に長時間接触させると、変質することがあります。

主な仕様

定格出力電圧	DC 5 V
定格出力電流	1.5 A
動作温度／充電温度	5 °C ~ 35 °C
最大外形寸法	約31.6 × 59.3 × 23.0 mm (幅／高さ／奥行き)

質量	約34 g
付属品	ACアダプター (1) 取扱説明書 (本書) (1) 保証書 (一式)

本機の仕様および外観は、改良のため予告なく変更することがありますが、ご了承ください。

保証書とアフターサービス

保証書

- この製品には保証書が添付されていますので、所定事項の記入および記載内容をお確かめのうえ、大切に保管してください。
- 保証期間については、保証書をご確認ください。

アフターサービス

調子が悪いときはまずチェックを

この説明書をもう一度ご覧になってお調べください。

それでも具合の悪いときは

ソニーの相談窓口にご相談ください。

お問い合わせ先(日本専用)

よくあるお問い合わせ、窓口業務などはホームページをご利用ください。

<http://www.sony.jp/professional/support/>

業務用商品相談窓口

フリーダイヤル …………… **0120-788-333**

携帯電話・PHS一部のIP電話など

フリーダイヤルがご利用になれない場合 …… **050-3754-9550**

FAX **0120-884-707**

受付時間 9:00～18:00(土・日・祝日、および休業日は除く)

保証期間中の修理は

保証書の記載内容に基づいて修理させていただきます。

詳しくは保証書をご覧ください。

保証期間経過後の修理は

修理によって機能が維持できる場合は、ご要望により有料修理させていただきます。

保証期間中の修理など、アフターサービスについてご不明な点は、お買い上げ店、またはソニーの相談窓口にお問い合わせください。

English

WARNING

IMPORTANT SAFETY INSTRUCTIONS - SAVE THESE INSTRUCTIONS

DANGER - TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, CAREFULLY FOLLOW THESE INSTRUCTIONS

For connection to a supply not in the USA, use an attachment plug adaptor of the proper configuration for the power outlet, if needed.

For customers in the USA FCC Compliance Statement

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

– Reorient or relocate the receiving antenna.

– Increase the separation between the equipment and receiver.

– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

– Consult the dealer or an experienced radio/TV technician for help.

- You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.
- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Before use

This AC adaptor can be used to charge and operate the Digital Paper and the stylus (DPTA-RS1) for the Digital Paper with micro USB connectors. See the Digital Paper product page for the latest information on compatibility.

<https://www.sony.com/electronics/mobile-tablets>

Before using the AC adaptor, please read this manual thoroughly and retain it for future reference.

Specifications

Output: 5 V DC, 1.5 A

Operating/charging temperature:
5 °C to 35 °C (41 °F to 95 °F)

Dimensions: Approx. 31.6 x 59.3 x 23.0 mm
(w/h/d) (1¹/₄ x 2³/₈ x ²⁹/₃₂ in)

Mass: Approx. 34 g (1.2 oz)

Supplied items: AC adaptor × 1
User Guide × 1
Warranty × 1 set

Design and specifications are subject to change without notice.

How to use

- Connect the USB cable supplied with the Digital Paper to the micro USB connector of the device or stylus and the USB connector of the AC adaptor.
- Connect to an AC outlet.
The Charge indicator on the Digital Paper lights up in red while charging, and turns off when charging is completed.

Charging time varies depending on the model of the Digital Paper. For DPT-RP1 models, refer to the online Help Guide (<http://www.sony.net/dpt-rp1/help>). For DPT-S1 models, see the embedded User Guide in the Digital Paper.

Notes

- We do not guarantee performance when parts other than this AC adaptor and the USB cable supplied with the Digital Paper are used.
- Connect the AC adaptor to an easily accessible AC outlet. Should you notice an abnormality in the AC adaptor, disconnect it from the AC outlet.
- We do not guarantee use of a USB hub or USB extension cable.

Notes on use

- Do not place the device in locations that are:
 - Extremely hot or cold
 - Dusty or dirty
 - Very humid
 - Vibrating
 - Strong magnetic fields
 - Sandy
 - Exposed to direct sunlight
- Do not apply mechanical shock or drop the device.
- Disconnect the AC adaptor from the AC outlet when not in use for a long time. To disconnect the AC adaptor, pull it out by the plug. Never pull the USB cable itself.
- Be sure that nothing metallic comes into contact with the metal parts of this device. If this happens, a short circuit may occur and the device may be damaged.
- Do not operate the device with a damaged cord or if the device itself has been dropped or damaged.
- Always keep the metal contacts clean.
- Do not disassemble or convert the device.
- While the device is in use, it gets warm. This is normal.
- Keep the device away from TV or AM receivers, as it may disturb reception.
- To avoid the danger of fire or electric shock, do not use the Digital Paper in a wet or humid place.

On cleaning

- Clean the device with a soft dry cloth, or a soft cloth lightly moistened with a mild detergent solution. Do not use any type of solvent, such as alcohol or benzene, which may damage the finish.
- Do not use sprays or aerosols with flammable gas for cleaning and lubrication. Using these objects on the device may cause an explosion or fire due to sparks from contact with the switch or static electricity, or contact with hot parts.

Support for customers in the USA

Please refer to the PC support site for additional details.

<http://www.sony.com/digitalpapersupport>