FEDERAL COMMUNICATIONS COMMISSION

15.21

You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

15.105(b)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

Operation is subject to the following two conditions:

1) this device may not cause interference and

2) this device must accept any interference, including interference that may cause undesired operation of the device.

FCC RF Radiation Exposure Statement:
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Charging Music Angel (For with battery only)

Before using music angel who has the battery, you must charge the headset for approximately two hours. When fully charged, the battery provides up to 3 hours of talk time and up to 120 hours of standby time.

To charge the headset
1. Plug AC adapter into the AC jack on music angel, when the music angel is charging, the Amber LED on the music angel will light.
2. After charging finish the Amber LED will off, unplug the AC adapter from the AC jack.

Battery indication: The Amber LED on the ear hooker will remain on while music angel battery is in charging, and when battery is fully charged, Amber LED will be off. And the Amber LED will flash to indicate the battery low.

Powering Music Angel

With battery music angel
To turn on the Bluetooth on music angel
Press and hold the BT button for four seconds. The Blue LED will be flashed 3 times and you will hear ON tone. The music angel turns on, ready to make and receive calls.

To turn off the Bluetooth on music angel
When the music angel is on, press and hold the BT button for four seconds. The Blue LED will be flashed 3 times and you will hear ON tone. The music angle turns off.

Without battery music angle
To power on the music angel
Plug the music angel into remote control connecter on the MP3/CD/Workman, then the music angel will share power with MP3.

To turn on the Bluetooth on music angel
Press and hold the BT button for four seconds. The Blue LED will be flashed 3 times and you will hear ON tone. The music angel turns on, ready to make and receive calls.

To turn off the Bluetooth on music angel
When the music angel is on, press and hold the BT button for four seconds. The Blue LED will be flashed 3 times and you will hear ON tone. The music angle turns off.

Pairing OLED headset to your cell phone

Pairing is the process of linking the headset with your Bluetooth cell phone. Before you use Bluetooth function on music angel, you must pair the devices with you cell phones. After this process is completed, you can use the Bluetooth function on music angel only with its paired cell phone. If you wish to use the Bluetooth function with a different cell phone, you must repeat the pairing process with the new cell phone. In this case, the music angle will no longer work with the original cell phone. Before you pair the music angel, ensure that the music angel has full power supply.

To pair the device
1. With the Bluetooth on music angel turned off, press and hold the BT button for five seconds. The Amber LED and Blue LED switch flash per 0.1-0.5 seconds, and you will hear the PAIRING tone.
2. Release the BT button. The music angel is now in Pairing Mode.
3. Turn on the cell phone and place it within 10 feet of the music angel.
4. Initiate the device discovery feature on the cell phone. Refer to the cell phone user guide for instructions for initiating this feature.
5. When prompted by the cell phone, enter the music angel pin code "0000". When pairing is complete, the blue LED on the headset will flash at three-second intervals and the headset will be placed in standby mode, ready to make and receive calls.

To cancel pairing mode
While you are in pairing mode, you can cancel the pairing process and turn off the Bluetooth function on music angel headset.
Press and hold the BT button for three seconds. Both LEDs will turn off and you will hear the OFF tone.

Making calls

You can make calls from your cell phone, or directly from OLED headset using voice dialing and last number redial.

To make calls from your cell phone
Dial the call from the your cell phone, the call is automatically connected to your music angel.

To make calls using voice dialing (if supported by your cell phone)
1, Press the BT button on your music angel
2, Speak the name of the person you wish to call. The call is automatically connected to your cell phone.

To make calls using last number redial (if supported by your cell phone)
With standby mode, short press Volume down button and Skip previous button concurrently, and the call is automatically connected to your cell phone.

Receiving calls

You must configure your cell phone to answer calls directly on your music angel. Refer to the cell phone user guide for instruction for initiating this feature.

1, when your cell phones rings, press BT button on your music angel. The call is automatically connected to your headset.

Reject calls

When your cell phone rings, press and hold BT button on your music angel for 3 seconds.

Ending calls

When you have finished your call, press the BT button on your headset. The call will be disconnected.

Transfer calls

You can transfer the calls connected to your headset back to your cell phone, or from your cell phone to your headset

To transfer calls from your headset (phone dependent)

To transfer calls from you cell phone
With the call connected to your cell phone, Press BT button on your music angel.

Adjust the volume

To increase the volume
With talking mode, press (click) the Volume button + to increase volume by 1 step, repeat this procedure until you have reached the desired level.

To decrease the volume
With talking mode, press (click) the Volume button - to decrease volume by 1 step, repeat this procedure until you have reached the desired level.

Muting headset
You can mute and un-mute the microphone temporarily so that you cannot be heard by the connected party.

To mute the headset
With talking mode, press and hold the volume button + for 3 seconds.

To un-mute the headset
When microphone is muted, press and hold volume button + for 3 seconds.

Visual and audible indications
Visual indication
Two LEDs (blue and amber) indicate the status of the headset:

Status	Indication
Battery is full	Amber LED are off
Battery is low	Amber LED flash
Headset is off	Both LEDs are off
Headset is in standby mode, ready to make and receive calls	Blue LED flashes at three -second intervals
Headset is in pairing mode	Blue and amber LEDs flash alternately.

Audible Indicators
Tones heard through the headset provide an audible indication of a requested action:

Tone	Indicates

On	Headset has been turned on.
Off	Headset is about to turn off.
Pairing	Headset has been put into pairing mode.

Remote control functions

Play/Pause
With the MP3 paused, press play/pause button to play music.
With the MP3 played, press play/pause button to pause the played music.

Turn off the MP3
With the MP3 on, press and hold play/pause button to turn off the MP3.

Skip next
With the MP3 played, press skip next button to jump to the next music.

Skip previous
With the MP3 played, press skip previous button to jump to the previous music.

Fast forward
With the MP3 played, press and hold skip next button to fast forward current played music.

Fast backward
With the MP3 played, press and hold skip previous button to fast backward current played music.

Volume up/down
With MP3 played, press volume up/down to adjust the MP3 volume.