YAMAHA

⚠ Read this manual carefully before operating this vehicle.

OWNER'S MANUAL

XVZ13TFSB(C)

LIT-11626-25-41

1BM-28199-11

EAU10042

⚠ WARNING

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

YAMAHA LIT-CALIF-65-01

⚠ Read this manual carefully before operating this vehicle. This manual should stay with this vehicle if it is sold.

EAU10083

Congratulations on your purchase of the Yamaha Royal Star™ VENTURE®. This model is the result of Yamaha's vast experience in the production of fine sporting, touring, and pacesetting racing machines. It represents the high degree of craftsmanship and reliability that have made Yamaha a leader in these fields.
This manual will give you an understanding of the operation, inspection, and basic maintenance of this motorcycle. If you have any questions concerning the operation or maintenance of your motorcycle, please consult a Yamaha dealer.
The design and manufacture of this Yamaha motorcycle fully comply with the emissions standards for clean air applicable at the date of manufacture. Yamaha has met these standards without reducing the performance or economy of operation of the motorcycle. To maintain these high standards, it is important that you and your Yamaha dealer pay close attention to the recommended maintenance schedules and operating instructions contained within this manual.
Yamaha continually seeks advancements in product design and quality. Therefore, while this manual contains the most current product information available at the time of printing, there may be minor discrepancies between your motorcycle and this manual. If there is any question concerning this manual, please consult a Yamaha dealer.

EWA10011

⚠ WARNING

Please read this manual and the "YOU AND YOUR MOTORCYCLE: RIDING TIPS" booklet carefully before operating this motorcycle. Do not attempt to operate this motorcycle until you have attained adequate knowledge of its controls and operating features. Regular inspections and careful maintenance, along with good operating techniques, will help ensure that you safely enjoy the capabilities and reliability of this motorcycle.

IMPORTANT MANUAL INFORMATION

EAU10133

Particularly important information is distinguished in this manual by the following notations:

⚠	**This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.**
⚠ WARNING	**A WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.**
NOTICE	**A NOTICE indicates special precautions that must be taken to avoid damage to the vehicle or other property.**
TIP	A TIP provides key information to make procedures easier or clearer.

*Product and specifications are subject to change without notice.

IMPORTANT MANUAL INFORMATION

EAU10193

XVZ13TFSB(C)
OWNER'S MANUAL
©2011 by Yamaha Motor Corporation, U.S.A.
1st edition, July 2011
All rights reserved.
Any reprinting or unauthorized use
without the written permission of
Yamaha Motor Corporation, U.S.A.
is expressly prohibited.
Printed in Japan.
P/N LIT-11626-25-41

TABLE OF CONTENTS

LOCATION OF IMPORTANT LABELS 1-1

SAFETY INFORMATION 2-1

DESCRIPTION 3-1
- Left view 3-1
- Right view 3-2
- Controls and instruments 3-3

INSTRUMENT AND CONTROL FUNCTIONS 4-1
- Main switch/steering lock 4-1
- Indicator lights and warning lights 4-2
- Speedometer unit 4-4
- Cruise control system 4-5
- Self-diagnosis device 4-7
- Handlebar switches 4-7
- Clutch lever 4-9
- Shift pedal 4-9
- Brake lever 4-10
- Brake pedal 4-10
- Fuel tank cap 4-10
- Fuel 4-11
- Fuel tank breather/overflow hose 4-12
- Fuel cock 4-13
- Starter (choke) knob 4-14
- Locking the steering with a padlock 4-14
- Rider seat 4-14
- Helmet holders 4-15
- Sidecases and travel trunk 4-16
- Adjusting the front fork 4-18
- Adjusting the shock absorber assembly 4-19
- Sidestand 4-20
- Ignition circuit cut-off system 4-20
- Auxiliary DC jack and connector 4-22

AUDIO SYSTEM AND CB RADIO 5-1
- Location of parts 5-1
- Headsets (optional) 5-2
- Control unit 5-3
- Making basic settings 5-4
- Making mode settings 5-6
- Cassette deck operation 5-9
- Radio operation 5-11
- Optional CD changer operation 5-15
- CB radio operation 5-16
- Auxiliary audio source operation 5-20

FOR YOUR SAFETY – PRE-OPERATION CHECKS 6-1

OPERATION AND IMPORTANT RIDING POINTS 7-1
- Starting and warming up a cold engine 7-1
- Starting a warm engine 7-2
- Shifting 7-2
- Engine break-in 7-4
- Parking 7-4

PERIODIC MAINTENANCE AND ADJUSTMENT 8-1
- Owner's tool kit 8-2
- Periodic maintenance chart for the emission control system 8-3
- General maintenance and lubrication chart 8-5
- Removing and installing cowlings and panels 8-9
- Checking the spark plugs 8-12
- Canister (for California only) 8-13
- Engine oil and oil filter cartridge 8-14
- Final gear oil 8-16
- Coolant 8-18
- Cleaning the air filter elements 8-19
- Carburetors 8-21
- Checking the engine idling speed 8-21
- Checking the throttle grip free play 8-21
- Valve clearance 8-22
- Tires 8-22
- Cast wheels 8-24
- Clutch lever 8-24
- Adjusting the brake lever free play 8-25

Brake light switches 8-25
Checking the front and
rear brake pads 8-26
Checking the brake and
clutch fluid levels 8-26
Changing the brake and
clutch fluids 8-28
Checking and lubricating
the cables 8-28
Checking and lubricating
the throttle grip and cable 8-28
Checking and lubricating
the brake and shift pedals 8-29
Checking and lubricating
the brake and clutch levers 8-29
Checking and lubricating
the sidestand 8-30
Lubricating the swingarm pivots ...8-30
Lubricating the rear suspension ...8-30
Checking the front fork 8-31
Checking the steering 8-31
Checking the wheel bearings 8-32
Battery 8-32
Replacing the fuses 8-33
Replacing the headlight bulb 8-35
Replacing a turn signal light bulb
or the tail/brake light bulb 8-36
Supporting the motorcycle 8-36
Troubleshooting 8-37
Troubleshooting charts 8-38

MOTORCYCLE CARE AND STORAGE 9-1
Matte color caution 9-1
Cleaning 9-1
Storage 9-3

SPECIFICATIONS 10-1

CONSUMER INFORMATION..... 11-1
Identification numbers 11-1
Reporting safety defects 11-3
Motorcycle noise regulation 11-4
Maintenance record 11-5
YAMAHA MOTOR
CORPORATION, U.S.A.
ROYAL STAR™ VENTURE®
LIMITED WARRANTY 11-7

LOCATION OF IMPORTANT LABELS

EAU10384

1

Read and understand all of the labels on your vehicle. They contain important information for safe and proper operation of your vehicle. Never remove any labels from your vehicle. If a label becomes difficult to read or comes off, a replacement label is available from your Yamaha dealer.



1

NOTICE

- Cleaning with alkaline or acid cleaner, gasoline or solvent will damage windshield.
- Use neutral detergent.

4B5-2815K-00

2

⚠ WARNING

- BEFORE YOU OPERATE THIS VEHICLE, READ THE OWNER'S MANUAL AND ALL LABELS.
- ALWAYS WEAR AN APPROVED MOTORCYCLE HELMET, eye protection, and protective clothing.

5GK-2118K-00

3

⚠ WARNING

Improper loading can adversely affect handling.

- Do not exceed maximum load limit:
  9 kg (20 lb) each saddlebag /9 kg (20 lb) travel trunk /
  9 kg (20 lb) travel trunk bracket without travel trunk
- Distribute weight evenly from side to side.
- Read the Owner's manual for important loading and tire pressure information.
- Total weight of rider, passenger, accessories, and cargo must not exceed the motorcycle load capacity shown in the Owner's Manual.
- Never ride above 120 km/h(80 mph) with travel trunk and/or saddlebags because handling could be affected. This maximum speed may be reduced by such factors as improper loading, poor tire or overall motorcycle conditions, poor road surfaces, or adverse weather conditions.

4XY-28446-02

4 California only



5

TIRE INFORMATION

Cold tire normal pressure should be set as follows.

- Up to 90 kg (198 lbs) load

FRONT : 250 kPa, (2.50 kgf/cm²), 36 psi
REAR : 250 kPa, (2.50 kgf/cm²), 36 psi

- 90 kg (198 lbs) ~ maximum load

FRONT : 250 kPa, (2.50 kgf/cm²), 36 psi
REAR : 280 kPa, (2.80 kgf/cm²), 41 psi

4NK-21668-A0

EAU10289

Be a Responsible Owner

As the vehicle's owner, you are responsible for the safe and proper operation of your motorcycle.

Motorcycles are single-track vehicles. Their safe use and operation are dependent upon the use of proper riding techniques as well as the expertise of the operator. Every operator should know the following requirements before riding this motorcycle.

He or she should:

- Obtain thorough instructions from a competent source on all aspects of motorcycle operation.
- Observe the warnings and maintenance requirements in this Owner's Manual.
- Obtain qualified training in safe and proper riding techniques.
- Obtain professional technical service as indicated in this Owner's Manual and/or when made necessary by mechanical conditions.

Safe Riding

Perform the pre-operation checks each time you use the vehicle to make sure it is in safe operating condition. Failure to inspect or maintain the vehicle properly increases the possibility of an accident or equipment damage. See page 6-1 for a list of pre-operation checks.

- This motorcycle is designed to carry the operator and a passenger.
- The failure of motorists to detect and recognize motorcycles in traffic is the predominating cause of automobile/motorcycle accidents. Many accidents have been caused by an automobile driver who did not see the motorcycle. Making yourself conspicuous appears to be very effective in reducing the chance of this type of accident.

  Therefore:

  - Wear a brightly colored jacket.
  - Use extra caution when you are approaching and passing through intersections, since intersections are the most likely places for motorcycle accidents to occur.
  - Ride where other motorists can see you. Avoid riding in another motorist's blind spot.
- Many accidents involve inexperienced operators. In fact, many operators who have been involved in accidents do not even have a current motorcycle license.
  - Make sure that you are qualified and that you only lend your motorcycle to other qualified operators.
  - Know your skills and limits. Staying within your limits may help you to avoid an accident.
  - We recommend that you practice riding your motorcycle where there is no traffic until you have become thoroughly familiar with the motorcycle and all of its controls.
- Many accidents have been caused by error of the motorcycle operator. A typical error made by the operator is veering wide on a turn

due to excessive speed or undercornering (insufficient lean angle for the speed).
  - Always obey the speed limit and never travel faster than warranted by road and traffic conditions.
  - Always signal before turning or changing lanes. Make sure that other motorists can see you.
- The posture of the operator and passenger is important for proper control.
  - The operator should keep both hands on the handlebar and both feet on the operator footrests during operation to maintain control of the motorcycle.
  - The passenger should always hold onto the operator, the seat strap or grab bar, if equipped, with both hands and keep both feet on the passenger footrests. Never carry a passenger unless he or she can firmly place both feet on the passenger footrests.
- Never ride under the influence of alcohol or other drugs.
- This motorcycle is designed for on-road use only. It is not suitable for off-road use.

Protective Apparel

The majority of fatalities from motorcycle accidents are the result of head injuries. The use of a safety helmet is the single most critical factor in the prevention or reduction of head injuries.

- Always wear an approved helmet.
- Wear a face shield or goggles. Wind in your unprotected eyes could contribute to an impairment of vision that could delay seeing a hazard.
- The use of a jacket, heavy boots, trousers, gloves, etc., is effective in preventing or reducing abrasions or lacerations.
- Never wear loose-fitting clothes, otherwise they could catch on the control levers, footrests, or wheels and cause injury or an accident.
- Always wear protective clothing that covers your legs, ankles, and feet. The engine or exhaust system become very hot during or after operation and can cause burns.
- A passenger should also observe the above precautions.

Avoid Carbon Monoxide Poisoning

All engine exhaust contains carbon monoxide, a deadly gas. Breathing carbon monoxide can cause headaches, dizziness, drowsiness, nausea, confusion, and eventually death.

Carbon Monoxide is a colorless, odorless, tasteless gas which may be present even if you do not see or smell any engine exhaust. Deadly levels of carbon monoxide can collect rapidly and you can quickly be overcome and unable to save yourself. Also, deadly levels of carbon monoxide can linger for hours or days in enclosed or poorly ventilated areas. If you experience any symptoms of carbon monoxide poisoning, leave the area immediately, get fresh air, and SEEK MEDICAL TREATMENT.

- Do not run engine indoors. Even if you try to ventilate engine exhaust with fans or open windows and doors, carbon monoxide can rapidly reach dangerous levels.

- Do not run engine in poorly ventilated or partially enclosed areas such as barns, garages, or carports.
- Do not run engine outdoors where engine exhaust can be drawn into a building through openings such as windows and doors.

Loading

Adding accessories or cargo to your motorcycle can adversely affect stability and handling if the weight distribution of the motorcycle is changed. To avoid the possibility of an accident, use extreme caution when adding cargo or accessories to your motorcycle. Use extra care when riding a motorcycle that has added cargo or accessories. Here, along with the information about accessories below, are some general guidelines to follow if loading cargo to your motorcycle:

The total weight of the operator, passenger, accessories and cargo must not exceed the maximum load limit. **Operation of an overloaded vehicle could cause an accident.**

Maximum load:
190 kg (419 lb)

When loading within this weight limit, keep the following in mind:

- Cargo and accessory weight should be kept as low and close to the motorcycle as possible. Securely pack your heaviest items as close to the center of the vehicle as possible and make sure to distribute the weight as evenly as possible on both sides of the motorcycle to minimize imbalance or instability.
- Shifting weights can create a sudden imbalance. Make sure that accessories and cargo are securely attached to the motorcycle before riding. Check accessory mounts and cargo restraints frequently.
  - Properly adjust the suspension for your load (suspension-adjustable models only), and check the condition and pressure of your tires.
  - Never attach any large or heavy items to the handlebar, front fork, or front fender. These items, including such cargo as sleeping bags, duffel bags, or tents, can create unstable handling or a slow steering response.
- **This vehicle is not designed to pull a trailer or to be attached to a sidecar.**

Genuine Yamaha Accessories

Choosing accessories for your vehicle is an important decision. Genuine Yamaha accessories, which are available only from a Yamaha dealer, have been designed, tested, and approved by Yamaha for use on your vehicle.

Many companies with no connection to Yamaha manufacture parts and accessories or offer other modifications for Yamaha vehicles. Yamaha is not in a position to test the products that these aftermarket companies produce. Therefore, Yamaha can neither endorse nor recommend the use of accessories not sold by Yamaha or modifications not specifically recommended by Yamaha, even if sold and installed by a Yamaha dealer.

Aftermarket Parts, Accessories, and Modifications

While you may find aftermarket products similar in design and quality to genuine Yamaha accessories, recognize that some aftermarket accessories or modifications are not suitable because of potential safety hazards to you or others. Installing aftermarket products or having other modifications performed to your vehicle that change any of the vehicle's design or operation characteristics can put you and others at greater risk of serious injury or death. You are responsible for injuries related to changes in the vehicle.

Keep the following guidelines in mind, as well as those provided under "Loading" when mounting accessories.

- Never install accessories or carry cargo that would impair the performance of your motorcycle. Carefully inspect the accessory before using it to make sure that it does not in any way reduce ground clearance or cornering clearance, limit suspension travel, steering travel or control operation, or obscure lights or reflectors.
  - Accessories fitted to the handlebar or the front fork area can create instability due to improper weight distribution or aerodynamic changes. If accessories are added to the handlebar or front fork area, they must be as lightweight as possible and should be kept to a minimum.
  - Bulky or large accessories may seriously affect the stability of the motorcycle due to aerodynamic effects. Wind may attempt to lift the motorcycle, or the motorcycle may become unstable in cross winds. These accessories may also cause instability when passing or being passed by large vehicles.
  - Certain accessories can displace the operator from his or her normal riding position. This improper position limits the freedom of movement of the operator and may limit control ability, therefore, such accessories are not recommended.
- Use caution when adding electrical accessories. If electrical accessories exceed the capacity of the motorcycle's electrical system, an electric failure could result, which could cause a dangerous loss of lights or engine power.

Aftermarket Tires and Rims

The tires and rims that came with your motorcycle were designed to match the performance capabilities and to provide the best combination of handling, braking, and comfort. Other tires, rims, sizes, and combinations may not be appropriate. Refer to page 8-22 for tire specifications and more information on replacing your tires.

Transporting the Motorcycle

Be sure to observe following instructions before transporting the motorcycle in another vehicle.

- Remove all loose items from the motorcycle.

- Check that the fuel cock (if equipped) is in the “OFF” position and that there are no fuel leaks.
- Point the front wheel straight ahead on the trailer or in the truck bed, and choke it in a rail to prevent movement.
- Shift the transmission in gear (for models with a manual transmission).
- Secure the motorcycle with tiedowns or suitable straps that are attached to solid parts of the motorcycle, such as the frame or upper front fork triple clamp (and not, for example, to rubber-mounted handlebars or turn signals, or parts that could break). Choose the location for the straps carefully so the straps will not rub against painted surfaces during transport.
- The suspension should be compressed somewhat by the tiedowns, if possible, so that the motorcycle will not bounce excessively during transport.

EAU10410

Left view



1. Shift pedal (page 4-9)
2. Starter (choke) knob (page 4-14)
3. Fuel tank cap (page 4-10)
4. Fuel cock (page 4-13)
5. Battery (page 8-32)
6. Fuse box 2 (page 8-33)
7. Main fuse (page 8-33)
8. Sidecase (page 4-16)
9. Helmet holder (page 4-15)
10. Tail/brake light (page 8-36)
11. Rear turn signal light (page 8-36)

EAU10420

Right view



1. Muffler
2. Owner's tool kit (page 8-2)
3. Helmet holder (page 4-15)
4. Travel trunk (page 4-16)
5. Passenger seat (page 4-14)
6. Shock absorber assembly air valve (page 4-19)
7. Coolant reservoir (page 8-18)
8. Rider seat (page 4-14)
9. Fuel tank (page 4-10)
10. Front fork air valve (page 4-18)
11. Headlight (page 8-35)
12. Front turn signal/position lights (page 8-36)
13. Fuse box 1 (page 8-33)
14. Brake pedal (page 4-10)
15. Rider footrest
16. Passenger footrest

EAU10430

Controls and instruments



1. Clutch lever (page 4-9)
2. Audio system/CB radio control unit (page 5-3)
3. Left handlebar switches (page 4-7)
4. Rider headset jack (page 5-2)
5. Speedometer unit (page 4-4)
6. Main switch/steering lock (page 4-1)
7. Right handlebar switches (page 4-7)
8. Throttle grip (page 8-21)
9. Brake lever (page 4-10)

EAU10460

Main switch/steering lock

The main switch/steering lock controls the ignition and lighting systems, and is used to lock the steering. The various positions are described below.

EAU10510

ON

All electrical systems are supplied with power, and the headlight, meter lighting, taillight and position lights come on, and the engine can be started. The key cannot be removed.

EAU10661

OFF

All electrical systems are off. The key can be removed.

EWA10061

⚠ WARNING

Never turn the key to "OFF" or "LOCK" while the vehicle is moving. Otherwise the electrical systems will be switched off, which may result in loss of control or an accident.

EAU10691

LOCK

The steering is locked, and all electrical systems are off. The key can be removed.

To lock the steering



1. Push.
2. Turn.

1. Turn the handlebars all the way to the left or right.
2. Push the key in from the "OFF" position, and then turn it to "LOCK" while still pushing it.
3. Remove the key.

To unlock the steering



1. Push.
2. Turn.

Push the key into the main switch, and then turn it to "OFF" while still pushing it.

EAU10951

ACC (Accessory)

The audio system and the auxiliary DC jack and connector can be used in this position. Do not use the accessory position for an extended period of time, otherwise the battery may discharge.

The key cannot be removed.

EAU49391

Indicator lights and warning lights



1. Left turn signal indicator light "⇦"
2. High beam indicator light "≣○"
3. Oil level warning light "🛢"
4. Overdrive indicator light "O/D"
5. Engine trouble warning light "🔧"
6. Fuel level warning light "⛽"



1. Cruise control indicator lights
2. Right turn signal indicator light "⇨"
3. Neutral indicator light "N"
4. Coolant temperature warning light "🌡"

EAU11030

Turn signal indicator lights "⇦" and "⇨"

The corresponding indicator light flashes when the turn signal switch is pushed to the left or right.

EAU11060

Neutral indicator light "N"

This indicator light comes on when the transmission is in the neutral position.

EAU11080

High beam indicator light “ ”

This indicator light comes on when the high beam of the headlight is switched on.

EAU11141

Oil level warning light “ ”

This warning light comes on if the engine oil level is low.

The electrical circuit of the warning light can be checked according to the following procedure.

1. Set the engine stop switch to “ ” and turn the key to “ON”.
2. Shift the transmission into the neutral position or pull the clutch lever.
3. Push the start switch. If the warning light does not come on while pushing the start switch, have a Yamaha dealer check the electrical circuit.

TIP

Even if the oil level is sufficient, the warning light may flicker when riding on a slope or during sudden acceleration or deceleration, but this is not a malfunction.

EAU11270

Fuel level warning light “ ”

This warning light comes on when the fuel level drops below approximately 3.5 L (0.92 US gal, 0.77 Imp.gal). When this occurs, turn the fuel cock lever to the “RES” position and refuel as soon as possible.

EAU11380

Cruise control indicator lights

See page 4-5 for an explanation of these indicator lights.

EAU11413

Coolant temperature warning light “ ”

This warning light comes on if the engine overheats. If this occurs, stop the engine immediately and allow the engine to cool.

The electrical circuit of the warning light can be checked according to the following procedure.

1. Set the engine stop switch to “ ” and turn the key to “ON”.
2. Shift the transmission into the neutral position or pull the clutch lever.
3. Push the start switch. If the warning light does not come on while pushing the start switch, have a Yamaha dealer check the electrical circuit.

ECA10021

NOTICE

Do not continue to operate the engine if it is overheating.

TIP

- For radiator-fan-equipped vehicles, the radiator fan(s) automatically switch on or off according to the coolant temperature in the radiator.
- If the engine overheats, see page 8-39 for further instructions.

EAU11450

Overdrive indicator light “O/D”

This indicator light comes on when the transmission is in overdrive (5th gear).

EAU11505

Engine trouble warning light “ ”

This warning light comes on or flashes if a problem is detected in the electrical circuit monitoring the engine. If this occurs, have a Yamaha dealer check the

self-diagnosis system. (See page 4-7 for an explanation of the self-diagnosis device.)
The electrical circuit of the warning light can be checked by turning the key to "ON". The warning light should come on for a few seconds, and then go off.
If the warning light does not come on initially when the key is turned to "ON", or if the warning light remains on, have a Yamaha dealer check the electrical circuit.

EAU36403

Speedometer unit



1. Speedometer
2. Odometer/tripmeter/fuel reserve tripmeter/clock
3. "RESET" button
4. "SELECT" button
5. Fuel meter

The speedometer unit is equipped with the following:

- a digital speedometer
- an odometer
- two tripmeters (which show the distance traveled since they were last set to zero)
- a fuel reserve tripmeter (which shows the distance traveled on the fuel reserve)
- a clock
- a fuel meter

Odometer and tripmeter modes
Pushing the "SELECT" button switches the display between the odometer mode "ODO" and the tripmeter modes "TRIP 1" and "TRIP 2" in the following order:
ODO → TRIP 1 → TRIP 2 → ODO
If the fuel level warning light comes on (see page 4-2), the odometer display will automatically change to the fuel reserve tripmeter mode "TRIP F" and start counting the distance traveled from that point. In that case, pushing the "SELECT" button switches the display between the various tripmeter and odometer modes in the following order:
TRIP F → TRIP 1 → TRIP 2 → ODO → TRIP F
To reset a tripmeter, select it by pushing the "SELECT" button, and then push the "RESET" button. If you do not reset the fuel reserve tripmeter manually, it will reset itself automatically and the display will return to "TRIP 1" after refueling and traveling 5 km (3 mi).

TIP

After resetting the fuel reserve tripmeter, the display will return to the prior mode.

Clock mode

To change the display to the clock mode, push the "SELECT" button for at least two seconds.

To change the display back to the odometer and tripmeter modes, push the "SELECT" button.

To set the clock

1. Push both the "SELECT" and "RESET" buttons for at least two seconds.
2. When the hour digits start flashing, push the "RESET" button to set the hours.
3. Push the "SELECT" button, and the minute digits will start flashing.
4. Push the "RESET" button to set the minutes.
5. Push the "SELECT" button to start the clock.

TIP

After setting the clock, be sure to push the "SELECT" button before turning the key to "OFF", otherwise the clock will not be set.

Fuel meter

The fuel meter indicates the amount of fuel in the fuel tank. The display segments of the fuel meter disappear towards "E" (Empty) as the fuel level decreases. When only one segment is left near "E" (Empty), refuel as soon as possible. When the key is turned to "ON", all of the display segments of the fuel meter will appear one after the other and then disappear in order to test the electrical circuit.

TIP

This fuel meter is equipped with a self-diagnosis system. If a problem is detected in the electrical circuit, all the display segments will start flashing. If this occurs, have a Yamaha dealer check the electrical circuit.

EAU11843

Cruise control system

1. "CRUISE" switch

This model is equipped with a cruise control system designed to maintain a set traveling speed.

Activating and setting the cruise control system

The cruise control system can only be activated when riding in 4th or 5th gear at speeds between 50 km/h (31 mi/h) and 130 km/h (81 mi/h).

To activate and set the cruise control system

1. Push the "CRUISE" switch to the left. The "ON" indicator light will come on.



1. Cruise control switch
2. "CANCEL" switch

2. Press the "SET/DEC" (set/decelerate) side of the cruise control switch to activate the cruise control system. The "SET" indicator light comes on.
3. Set the desired traveling speed as follows. Press the "RES/ACC" (resume/accelerate) side of the cruise control switch to increase the set speed or the "SET/DEC" side to decrease the speed.



1. "SET" indicator light
2. "RES" indicator light
3. "ON" indicator light

TIP

Pressing the cruise control switch once will change the speed in increments of 1.6 km/h (1 mi/h). Holding the cruise control switch down will increase or decrease the speed continuously until the switch is released.

The traveling speed can be set to a maximum of 130 km/h (81 mi/h) and a minimum of 50 km/h (31 mi/h).
When the cruise control system is activated and the throttle grip is turned to increase the speed by up to 8 km/h (5 mi/h), the cruise control system will return to the set speed after the throttle grip is released. However, if the speed is increased by more than 8 km/h (5 mi/h), the cruise control system will be deactivated until the traveling speed is within 8 km/h (5 mi/h) of the set speed.

Deactivating the cruise control system

Applying the front or rear brake or disengaging the clutch will automatically deactivate the cruise control system.
Push the "CANCEL" switch to manually deactivate the cruise control.

TIP

- When the cruise control system is deactivated, the "RES" (resume) indicator light will come on.
- Traveling speed decreases as soon as the cruise control system is deactivated; unless the throttle grip is turned.

Push the "RES/ACC" side of the cruise control switch to reactivate the system. The traveling speed will return to the previously set speed. The "RES" indicator light will flash during this time and

then go off. Once the cruise control system is reactivated, the “SET” indicator light will come on.
Push the “CRUISE” switch to the right to turn the cruise control system off completely.

EWA11071

⚠ WARNING

If the cruise control system is not working correctly, the “SET” and “RES” indicator lights will flash simultaneously. If this occurs, turn the cruise control system off and have a Yamaha dealer check it.

EAU12092

Self-diagnosis device

This model is equipped with a self-diagnosis device for various electrical circuits.
If a problem is detected in any of those circuits, the engine trouble warning light will come on or flash. If this occurs, have a Yamaha dealer check the vehicle.

ECA11170

NOTICE

To prevent engine damage, be sure to consult a Yamaha dealer as soon as possible if this occurs.

EAU12349

Handlebar switches

Left



1. “TALK” switch
2. Dimmer switch “≣○/≣○”
3. Turn signal switch “⇦/⇨”
4. Horn switch “📯”

Right



1. Engine stop switch "○/⊗"
2. Hazard switch "⚠"
3. Cruise control switch
4. Start switch "Ⓢ"

EAU12390

"TALK" switch

See page 5-16 for an explanation of the CB radio.

EAU12400

Dimmer switch "≡D/≡D"

Set this switch to "≡D" for the high beam and to "≡D" for the low beam.

EAU12430

Turn signal switch "⇦/⇨"

To signal a right-hand turn, push this switch to "⇨". To signal a left-hand turn, push this switch to "⇦". When released, the switch returns to the center position.

Since this model is equipped with a self-canceling system, the turn signal lights will self-cancel after the vehicle has traveled both about 150 m (490 ft) and for approximately 15 seconds. However, the turn signal lights can also be canceled manually by pushing the switch in after it has returned to the center position.

TIP

The self-canceling system only operates when the vehicle is moving, so that the turn signal lights will not self-cancel while you are stopped at an intersection.

EAU12500

Horn switch "📯"

Press this switch to sound the horn.

EAU12660

Engine stop switch "○/⊗"

Set this switch to "○" before starting the engine. Set this switch to "⊗" to stop the engine in case of an emergency, such as when the vehicle overturns or when the throttle cable is stuck.

EAU12711

Start switch "Ⓢ"

Push this switch to crank the engine with the starter. See page 7-1 for starting instructions prior to starting the engine.

EAU42390

The oil level warning light and coolant temperature warning light will come on when the key is turned to "ON" and the start switch is pushed, but this does not indicate a malfunction.

EAU12765

Hazard switch "⚠"

With the key in the "ON" position, use this switch to turn on the hazard lights (simultaneous flashing of all turn signal lights).

The hazard lights are used in case of an emergency or to warn other drivers when your vehicle is stopped where it might be a traffic hazard.

ECA10061

NOTICE

Do not use the hazard lights for an extended length of time with the engine not running, otherwise the battery may discharge.

EAU12780

Cruise control switches

See page 4-5 for an explanation of the cruise control system.

EAU12820

Clutch lever



1. Clutch lever

The clutch lever is located at the left handlebar grip. To disengage the clutch, pull the lever toward the handlebar grip. To engage the clutch, release the lever. The lever should be pulled rapidly and released slowly for smooth clutch operation.

The clutch lever is equipped with a clutch switch, which is part of the ignition circuit cut-off system. (See page 4-20.)

EAU12881

Shift pedal



1. Shift pedal
2. Neutral position

The shift pedal is located on the left side of the motorcycle and is used in combination with the clutch lever when shifting the gears of the 5-speed constant-mesh transmission equipped on this motorcycle.

TIP

Use your toes or heel to shift up and your toes to shift down.

EAU12890

Brake lever



1. Brake lever

The brake lever is located at the right handlebar grip. To apply the front brake, pull the lever toward the handlebar grip.

EAU12941

Brake pedal



1. Brake pedal

The brake pedal is on the right side of the motorcycle. To apply the rear brake, press down on the brake pedal.

EAU13122

Fuel tank cap



1. Fuel tank cap lock cover
2. Unlock.

To remove the fuel tank cap

Slide the fuel tank cap lock cover open, insert the key into the lock, and then turn it 1/4 turn clockwise. The lock will be released and the fuel tank cap can be removed.

To install the fuel tank cap

1. Insert the fuel tank cap into the tank opening with the key inserted in the lock and with the "△" mark facing forward.
2. Turn the key counterclockwise to the original position, remove it, and then close the lock cover.

TIP

The fuel tank cap cannot be installed unless the key is in the lock. In addition, the key cannot be removed if the cap is not properly installed and locked.

EWA10131

⚠ WARNING

Make sure that the fuel tank cap is properly installed before riding. Leaking fuel is a fire hazard.

EAU13212

Fuel

Make sure there is sufficient gasoline in the tank.

EWA10881

⚠ WARNING

Gasoline and gasoline vapors are extremely flammable. To avoid fires and explosions and to reduce the risk of injury when refueling, follow these instructions.

1. Before refueling, turn off the engine and be sure that no one is sitting on the vehicle. Never refuel while smoking, or while in the vicinity of sparks, open flames, or other sources of ignition such as the pilot lights of water heaters and clothes dryers.
2. Do not overfill the fuel tank. Stop filling when the fuel reaches the bottom of the filler tube. Because fuel expands when it heats up, heat from the engine or the sun can cause fuel to spill out of the fuel tank.



1. Fuel tank filler tube
2. Maximum fuel level

3. Wipe up any spilled fuel immediately. ***NOTICE:*** **Immediately wipe off spilled fuel with a clean, dry, soft cloth, since fuel may deteriorate painted surfaces or plastic parts.** [ECA10071]
4. Be sure to securely close the fuel tank cap.

EWA15151

⚠ WARNING

Gasoline is poisonous and can cause injury or death. Handle gasoline with care. Never siphon gasoline by mouth. If you should swallow some gasoline or inhale a lot of gasoline vapor, or get some gasoline in your eyes, see your doctor immedi-

ately. If gasoline spills on your skin, wash with soap and water. If gasoline spills on your clothing, change your clothes.

EAU13373

Recommended fuel:
Unleaded gasoline only
Fuel tank capacity:
22.5 L (5.94 US gal, 4.95 Imp.gal)
Fuel reserve amount (when the fuel level warning light comes on):
3.5 L (0.92 US gal, 0.77 Imp.gal)

ECA11400

NOTICE

Use only unleaded gasoline. The use of leaded gasoline will cause severe damage to internal engine parts, such as the valves and piston rings, as well as to the exhaust system.

Your Yamaha engine has been designed to use regular unleaded gasoline with a pump octane number [(R+M)/2] of 86 or higher, or a research octane number of 91 or higher. If knocking (or pinging) occurs, use a gasoline of a different brand or premium unleaded fuel. Use of unleaded fuel will extend spark plug life and reduce maintenance costs.

Gasohol

There are two types of gasohol: gasohol containing ethanol and that containing methanol. Gasohol containing ethanol can be used if the ethanol content does not exceed 10% (E10). Gasohol containing methanol is not recommended by Yamaha because it can cause damage to the fuel system or vehicle performance problems.

EAU48760

Fuel tank breather/overflow hose



1. Fuel tank breather/overflow hose

TIP

For California: See page 8-13 for breather hose information.

Before operating the motorcycle:

- Check the fuel tank breather/overflow hose connection.
- Check the fuel tank breather/overflow hose for cracks or damage, and replace it if damaged.
- Make sure that the end of the fuel tank breather/overflow hose is not blocked, and clean it if necessary.

EAU13550

Fuel cock

The fuel cock supplies fuel from the tank to the carburetors while also filtering it.
The fuel cock lever positions are explained as follows and shown in the illustrations.

OFF



1. Pointed end positioned over “OFF”

With the fuel cock lever in this position, fuel will not flow. Always turn the fuel cock lever to this position when the engine is not running.

ON



1. Pointed end positioned over “ON”

With the fuel cock lever in this position, fuel flows to the carburetors. Turn the fuel cock lever to this position when starting the engine and riding.

RES

1. Pointed end positioned over “RES”

This indicates reserve. With the fuel cock lever in this position, the fuel reserve is made available. Turn the fuel cock lever to this position if you run out of fuel while riding. When this occurs, refuel as soon as possible and be sure to turn the fuel cock lever back to “ON”!

EAU13600

Starter (choke) knob " |↘| "



1. Starter (choke) knob " |↘| "

Starting a cold engine requires a richer air-fuel mixture, which is supplied by the starter (choke).
Move the knob in direction (a) to turn on the starter (choke).
Move the knob in direction (b) to turn off the starter (choke).

EAU13780

Locking the steering with a padlock



In addition to the main switch/steering lock, there are brackets on the right side of the steering head pipe for locking the steering with a padlock. To do so, turn the handlebar until the holes in the two brackets are aligned, and then lock the steering with a suitable padlock.

EAU14240

Rider seat

To remove the rider seat

Remove the nuts, and then pull the rider seat up.



1. Nut

To install the rider seat

Insert the projection on the rear of the rider seat into the seat holder as shown, place the seat in the original position, and then tighten the nuts.



1. Projection
2. Seat holder

TIP

Make sure that the rider seat is properly secured before riding.

EAU50730

Helmet holders

There is a helmet holder on each side of the travel trunk.

To open a helmet holder

Insert the key into the helmet holder lock, and then turn it as shown.



1. Helmet holder (right)
2. Unlock.



1. Helmet holder (left)
2. Unlock.

To close a helmet holder

Place the helmet holder in the original position, and then remove the key. **WARNING! Never ride with a helmet attached to a helmet holder, since the helmet may hit objects, causing loss of control and possibly an accident.** [EWA11041]

EAU14635

Sidecases and travel trunk

EWA11083

⚠ WARNING

Improper loading or overloading can cause loss of control and possibly an accident or personal injury. See pages 2-3 and 8-22 for important loading and tire pressure information.

- **Always securely close the sidecases and travel trunk before riding.**
- **Distribute weight evenly on each side of the motorcycle.**
- **Do not exceed the load limit of 9 kg (20 lb) for each sidecase and the travel trunk.**
- **Do not exceed the maximum load of 190 kg (419 lb) for the vehicle.**
- **Do not exceed 120 km/h (80 mi/h) when riding with the travel trunk, sidecases or both installed, otherwise handling could be affected. Improper loading, poor tire or overall motorcycle conditions, poor road surfaces or adverse weather conditions may make it necessary to further reduce the riding speed.**

Sidecases

To open a sidecase

1. Insert the key into the sidecase lock, turn it counterclockwise, and then push it in.



1. Sidecase lock
2. Unlock.

2. Fold the sidecase lid up.



1. Storage compartment
2. Storage pouch

To close a sidecase

1. Fold the sidecase lid down.
2. Turn the key clockwise, and then remove it.

TIP

Push both sides of the lid down so that both latches snap into place.

Travel trunk

To open the travel trunk

1. Insert the key into the travel trunk lock, turn it counterclockwise, and then push it in.



1. Travel trunk lock
2. Unlock.

2. Fold the travel trunk lid up, and then release it so that it will rest in place as shown. ***NOTICE:*** **Do not apply excessive pressure on the travel trunk lid when it is open.**

[ECA10911]



1. Travel trunk lid resting in opened position
2. Storage pouch

To close the travel trunk

1. Fold the travel trunk lid up completely, and then fold it down.



TIP

Push both sides of the lid down so that both latches snap into place.

2. Turn the key clockwise, and then remove it.

ECA10921

NOTICE

To avoid locking the key in, never lock either sidecase or the travel trunk and remove the key from the lock before closing the lid.

EAU14655

Adjusting the front fork

EWA10180

⚠ WARNING

Always adjust both fork legs equally, otherwise poor handling and loss of stability may result.

This front fork is equipped with air valves for adjusting the spring rate.

ECA10091

NOTICE

To avoid damaging the front fork oil seals, do not exceed the maximum air pressure.

Adjust the spring rate as follows.

1. Place the vehicle on the sidestand.

TIP

- When checking and adjusting the air pressure, there should be no weight on the vehicle.
- A low-pressure air gauge and an air pump are required to adjust the spring rate. These items are available at a Yamaha dealer.

2. Remove the front fork air valve cap from each fork leg.



1. Front fork air valve cap

3. Check the air pressure in each fork leg using a low-pressure air gauge.
4. To increase the spring rate and thereby harden the suspension, increase the air pressure with an air pump. To decrease the spring rate and thereby soften the suspension, decrease the air pressure by pushing each valve stem down.

Spring rate:
Minimum (soft):
Air pressure = 0 kPa (0 kgf/cm², 0 psi)
Standard:
Air pressure = 0 kPa (0 kgf/cm², 0 psi)
Maximum (hard):
Air pressure = 50 kPa (0.5 kgf/cm², 7.1 psi)

5. Securely install the air valve caps.

EAU14803

Adjusting the shock absorber assembly

This shock absorber assembly is equipped with an air valve for adjusting the spring rate.

ECA11090

NOTICE

Never exceed the maximum air pressure, otherwise the oil seal may become damaged.

Adjust the spring rate as follows.

1. Place the vehicle on the sidestand.

TIP

- When checking and adjusting the air pressure, there should be no weight on the vehicle.
- An air pump is required to adjust the spring rate. This item is available at a Yamaha dealer.

2. Remove the shock absorber assembly air valve cap.



1. Shock absorber assembly air valve cap

3. Check the air pressure with the air pressure gauge included in the owner's tool kit.
4. To increase the spring rate and thereby harden the suspension, increase the air pressure with an air pump. To decrease the spring rate and thereby soften the suspension, decrease the air pressure by pushing the valve stem down.

Spring rate:
Minimum (soft):
Air pressure = 0 kPa (0 kgf/cm², 0 psi)
Standard:
Air pressure = 0 kPa (0 kgf/cm², 0 psi)
Maximum (hard):
Air pressure = 400 kPa (4.0 kgf/cm², 57 psi)

5. Securely install the air valve cap.

EAU15305

Sidestand

The sidestand is located on the left side of the frame. Raise the sidestand or lower it with your foot while holding the vehicle upright.

TIP

The built-in sidestand switch is part of the ignition circuit cut-off system, which cuts the ignition in certain situations. (See the following section for an explanation of the ignition circuit cut-off system.)

EWA10241

⚠ WARNING

The vehicle must not be ridden with the sidestand down, or if the sidestand cannot be properly moved up (or does not stay up), otherwise the sidestand could contact the ground and distract the operator, resulting in a possible loss of control. Yamaha's ignition circuit cut-off system has been designed to assist the operator in fulfilling the responsibility of raising the sidestand before starting off. Therefore, check this system regularly and have a Yamaha dealer repair it if it does not function properly.

EAU15314

Ignition circuit cut-off system

The ignition circuit cut-off system (comprising the sidestand switch, clutch switch and neutral switch) has the following functions.

- It prevents starting when the transmission is in gear and the sidestand is up, but the clutch lever is not pulled.
- It prevents starting when the transmission is in gear and the clutch lever is pulled, but the sidestand is still down.
- It cuts the running engine when the transmission is in gear and the sidestand is moved down.

Periodically check the operation of the ignition circuit cut-off system according to the following procedure.

TIP

This check is most reliable if performed with a warmed-up engine.

With the engine turned off:
1. Move the sidestand down.
2. Make sure that the engine stop switch is set to "○".
3. Turn the key on.
4. Shift the transmission into the neutral position.
5. Push the start switch.

Does the engine start?

YES **NO** → The neutral switch may not be working correctly. **The motorcycle should not be ridden** until checked by a Yamaha dealer.

With the engine still running:
6. Move the sidestand up.
7. Keep the clutch lever pulled.
8. Shift the transmission into gear.
9. Move the sidestand down.

Does the engine stall?

YES **NO** → The sidestand switch may not be working correctly. **The motorcycle should not be ridden** until checked by a Yamaha dealer.

After the engine has stalled:
10. Move the sidestand up.
11. Keep the clutch lever pulled.
12. Push the start switch.

Does the engine start?

YES **NO** → The clutch switch may not be working correctly. **The motorcycle should not be ridden** until checked by a Yamaha dealer.

The system is OK. **The motorcycle can be ridden.**

⚠ WARNING

If a malfunction is noted, have a Yamaha dealer check the system before riding.

EAU15417

Auxiliary DC jack and connector

EWA11051

⚠ WARNING

To prevent electrical shock or short-circuiting, make sure that the caps are installed when the auxiliary DC jack and connector are not being used.

ECA11032

NOTICE

The accessories connected to the auxiliary DC jack and connector should not be used with the engine turned off, and their combined load must never exceed 5 A or 60 W, otherwise the fuse may blow or the battery may discharge.

Auxiliary DC jack

A 12-V accessory connected to the auxiliary DC jack at the front of the vehicle can be used when the key is in the "ACC" or "ON" position.

To use the auxiliary DC jack

1. Turn the key to "OFF".
2. Open the auxiliary DC jack cap.



1. Auxiliary DC jack
2. Auxiliary DC jack cap

3. Turn the accessory off.
4. Insert the accessory plug into the auxiliary DC jack.
5. Turn the key to "ACC" or "ON".
6. Turn the accessory on.

Auxiliary DC connector

A 12-V accessory connected to the auxiliary DC connector under the rider seat can be used when the key is in the "ACC" or "ON" position.



1. Auxiliary DC connector
2. Auxiliary DC connector cap

AUDIO SYSTEM AND CB RADIO

EAU15440

Location of parts



1. Audio system/CB radio control unit
2. Front speaker
3. Rider headset jack
4. Cassette deck lid
5. Main switch/steering lock
6. Eject (“ ⏏ ”) button
7. Cassette deck compartment
8. Auxiliary audio input jack
9. Rear speaker
10. Passenger volume control knob
11. Passenger “TALK” button
12. Passenger headset jack

EWA11370

⚠ WARNING

- **It is dangerous to operate the audio system controls while riding. Never take your hands off the handlebars while riding.**
- **Keep the volume at a low enough level to be aware of traffic conditions and ensure safety.**

ECA11750

NOTICE

- **Do not use the audio system or CB radio for a long period of time when the engine is not running as the battery may discharge.**
- **The control unit, cassette deck and speakers are water-resistant; however, it is good practice to cover them with a plastic bag when washing the motorcycle.**
- **When cleaning the control unit display, use a neutral detergent. Never use strong abrasive cleaning products, fuel (gasoline), thinner, etc.**

EAU15450

Headsets (optional)



1. Rider headset jack



1. Passenger headset jack

For CB (Citizens Band) radio transmission, a headset is necessary; however, CB reception is possible without a headset. For intercom use, two headsets are necessary. Consult a Yamaha dealer if you wish to obtain headsets. Connect the headsets to the jacks shown in the illustrations and make sure that the headsets are selected as the output. (See page 5-6.)

Control unit

EAU15462



1. Volume control knob
2. Up/down (“⧋”) switch
3. Audio system button “AUDIO”
4. Selection button “SELECT”
5. CB radio button “CB”

Volume control knob
This knob adjusts the audio system volume, the CB radio reception volume, and the CB squelch level.

Up/down (“⧋”) switch
This switch is used to perform the following operations.
Short push (less than one second)
- Skipping songs on the cassette tape
- Selecting a preset radio station
- Selecting a track on the optional CD changer
- Selecting a CB channel
- Adjusting the CB squelch level
- Tuning in a radio station manually
- Adjusting the intercom volume
- Changing the settings in a mode

Long push (one second or more)
- Changing the cassette deck play direction
- Tuning in a radio station automatically
- Selecting a CD in the optional CD changer

Audio system button “AUDIO”
This button is used to perform the following operations.
Short push (less than one second)
- Turning on the audio system
- Changing the audio source in the following sequence



* The CD mode appears in the display only when the optional CD changer is installed.

Long push (one second or more)
- Turning off the audio system

Selection button “SELECT”
This button is used to perform the following operations.
Short push (less than two seconds)
- Changing modes in the following sequence

Audio system



[1] This mode does not appear in the display when the headsets are selected as the output.

[2] This mode appears in the display only when one of the radio frequency bands is selected as the audio source.

CB Radio



- Programming preset radio stations

Long push (two seconds or more)

- Selecting the preset radio station programming mode

CB radio button “CB”

This button is used to perform the following operations.

Short push (less than one second)

- Turning on the CB radio
- Selecting the squelch level mode

Long push (one second or more)

- Turning off the CB radio

EAU15480

Making basic settings

Turning on/off the audio system



To turn the power on

1. Make sure that the key is in the “ACC” or “ON” position.
2. Push the “AUDIO” button once for less than one second.

To turn the power off

Push the “AUDIO” button once for one second or more.

5

Adjusting the audio system volume



Turn the volume control knob until the desired audio system volume is displayed (e.g., “Vo:10”). The audio system volume can be set between “0” and “30”. After the adjustment is made, the audio system returns to normal operation and the current audio mode appears in the display.

Turning on/off the CB radio



1. CB radio indicator light

To turn the power on

1. Make sure that the key is in the “ACC” or “ON” position.
2. Push the “CB” button once for less than one second. The current CB channel appears in the display.

To turn the power off

Push the “CB” button once for one second or more. The CB indicator light will go off.

Adjusting the CB reception volume

Turn the control knob until the desired CB reception volume is displayed (e.g., “Vo:10”). The CB reception volume can be set between “0” and “20”. After the adjustment is made, the CB radio returns to normal operation and the CB channel appears in the display.

EAU15502

Making mode settings

General procedure

The following setting procedure applies to the audio system, CB radio, and optional CD changer.

TIP

- In order to make settings in any of the audio system modes, make sure that the audio system is selected. If necessary, push the "AUDIO" button for less than one second.
- In order to make settings in the CB radio modes, make sure that the CB radio is selected. If necessary, push the "CB" button for less than one second.

1. Repeatedly push the "SELECT" button for less than one second until the desired mode appears in the display. With each press of the button, the mode changes in the following sequence.

Audio system



[1] This mode does not appear in the display when the headsets are selected as the output.

[2] This mode appears in the display only when one of the radio frequency bands is selected as the audio source.

CB Radio



2. While the selected mode is displayed (for about five seconds), repeatedly push either side of the up/down switch for less than one second until the desired setting is displayed.

Selecting the output (speakers or headsets)



1. Repeatedly push the "SELECT" button for less than one second until either "SP" (speakers) or "HS" and "🎧" (headsets) appears in the display.
2. Push either side of the up/down switch for less than one second to change the setting.

TIP

The speakers and headsets cannot be used at the same time.

5

Adjusting the bass level



1. Repeatedly push the “SELECT” button for less than one second until “BASS” appears at the bottom of the display.
2. Repeatedly push either side of the up/down switch for less than one second until the desired level is displayed. The bass level can be set between “-6” and “+6”.

Adjusting the treble level



1. Repeatedly push the “SELECT” button for less than one second until “TREB” appears at the bottom of the display.
2. Repeatedly push either side of the up/down switch for less than one second until the desired level is displayed. The treble level can be set between “-6” and “+6”.

Adjusting the fade level (balance between front and rear speakers)



1. Make sure that the speakers are selected as the output source. (See the “Selecting the output” section.)
2. Repeatedly push the “SELECT” button for less than one second until “FAD” appears at the bottom of the display.
3. Repeatedly push either side of the up/down switch for less than one second until the desired level is displayed. The fade level can be set between “F9” (front speakers only) and “R9” (rear speakers only).

TIP

When the fade level is set to “0”, the front and rear speaker levels are the same.

Adjusting the intercom volume



1. Repeatedly push the “SELECT” button for less than one second until the intercom volume (e.g., “IC:10”) appears in the display.
2. Repeatedly push either side of the up/down switch for less than one second until the desired volume is displayed. The intercom volume can be set between “0” and “20”.

Adjusting the auto volume



When riding the vehicle, external noise may override the audio system output volume. The audio system features an automatic volume control function which compensates for external noise.

1. Repeatedly push the “SELECT” button for less than one second until the auto volume (e.g., “AV: 3”) appears in the display.
2. Repeatedly push either side of the up/down switch for less than one second until the desired volume is displayed. The auto volume can be set between “0” and “5”.

Turning on/off the CB roger beep



1. Repeatedly push the “SELECT” button for less than one second until either “RB:on” (roger beep on) or “RB:oF” (roger beep off) appears in the display.
2. Repeatedly push either side of the up/down switch for less than one second to change the setting.

Intercom operation

Provided both the rider and passenger are wearing headsets, they can talk to each other through the intercom at any time. (See the “Adjusting the intercom volume” section.)

Cassette deck operation

EAU15520



1. Cassette deck compartment
2. Eject (“ ⏏ ”) button
3. Cassette deck lid



EWA11380

⚠ WARNING

- **It is dangerous to operate the cassette deck while riding. Never take your hands off the handlebars while riding.**
- **Keep the volume at a low enough level to be aware of traffic conditions and ensure safety.**

ECA11760

NOTICE

- **Keep the cassette deck lid closed at all times, except when inserting or removing a cassette.**
- **Do not leave cassette tapes in direct sunlight for a long period of time.**
- **Do not allow the inside of the cassette deck to get wet. If this happens, keep the cassette deck lid open and dry out the deck in the shade.**
- **To clean the tape head, use a de-magnetizing cleaning cassette, but be sure to turn the volume all the way down to avoid speaker damage.**

Playing a cassette tape



1. Make sure that the audio system is turned on. (See page 5-3.)
2. Insert a cassette tape into the cassette compartment as shown. “LOAD”, then “PLAY” appears in the display. (If a cassette is already inserted, push the “AUDIO” button until “PLAY” appears in the display.) The tape starts playing.

Skipping songs



While a cassette tape is playing, push either side of the up/down switch once for less than one second for each song to be skipped. Pushing "▽" skips songs in the forward direction. Pushing "△" skips songs in the reverse direction. "APC" (auto program control) and the number of songs to be skipped (e.g., "3") appear in the display. When skipping songs in reverse, a minus sign appears in front of the number of songs to be skipped (e.g., "-2"). ("-1" indicates that the current song will be played again.)

TIP

- The maximum number of songs that can be skipped in either direction is 9.
- To stop skipping songs, push the up/down switch in the opposite direction that songs are being skipped.

Skipping a blank



When there is a long blank portion of tape on the cassette, "BLS" appears in the display and the cassette deck automatically fast-forwards the tape to the next song.

Changing the tape play direction



While the cassette tape is playing, push either side of the up/down switch for more than one second to reverse the play direction. "F" appears in the display when the tape is played in the forward direction. "R" appears in the display when the tape is played in the reverse direction.

5

Turning on/off the Dolby noise reduction system



While the cassette tape is playing, push the eject (“⏏”) button for more than two seconds to turn the Dolby B noise reduction system on or off. “B NR” appears in the display when the noise reduction system is turned on.

TIP

- The Dolby noise reduction system has been manufactured under license from Dolby Laboratories Licensing Corporation.
- Dolby and the double “D” symbol are registered trademarks of Dolby Laboratories Licensing Corporation.

Ejecting the cassette tape



1. Eject (“⏏”) button

Push the eject (“⏏”) button to eject the tape from the cassette deck. “EJCT” appears in the display, and then “CASS” starts flashing.

EAU15533

Radio operation

1. Radio antenna



1. Antenna sleeve

EWA11390

⚠ WARNING

- **It is dangerous to operate the radio while riding. Never take your hands off the handlebars while riding.**
- **Keep the volume at a low enough level to be aware of traffic conditions and ensure safety.**
- **Never ride the motorcycle with the radio antenna folded down.**

TIP

- The antenna can be folded down after lifting the sleeve.
- Be sure to tighten the antenna nut securely when putting the antenna back to the original position.

Selecting a frequency band



1. Frequency band

This radio offers three FM bands and one AM band. Since all three FM bands cover the whole FM frequency range, any one of them can be selected for tuning in an FM station. These three FM bands are useful for categorizing FM preset stations. Repeatedly push the “AUDIO” button for less than one second until the desired frequency band appears in the display.



* The CD mode appears in the display only when the optional CD changer is installed.

Tuning in a radio station automatically



1. Select a frequency band. (See the “Selecting a frequency band” section.)
2. Push either side of the up/down switch once for one second or more. The radio automatically

5

tunes in the first station that has a strong enough signal to be received.

Tuning in a radio station manually



In order to tune in a particular radio station (e.g., when the signal is too weak for automatic tuning), the radio frequency can be selected manually as follows.

1. Select a frequency band. (See the "Selecting a frequency band" section.)
2. Repeatedly push the "SELECT" button for less than one second until the currently selected radio frequency appears in the display.
3. Push either side of the up/down switch for less than one second until the desired frequency is displayed. The frequency changes in 0.2-MHz steps for FM and in 10-kHz steps for AM.

Tuning in a preset radio station



1. Preset station number

1. Select a frequency band. (See the "Selecting a frequency band" section.)
2. Repeatedly push either side of the up/down switch for less than one second until the desired preset station number is displayed.

TIP

To be able to tune in a preset radio station, you must have previously programmed at least one. (See the following sections.)

Programming preset radio stations manually



Up to six stations can be programmed for each frequency band (FM1, FM2, FM3, and AM) using either manual or automatic tuning.

Using manual tuning

1. Manually tune in a radio station that you wish to preset. (See the "Tuning in a preset radio station" section.)
2. Push the "SELECT" button once for two seconds or more. The radio frequency and preset station number "1" (to the right of "CH.") start flashing.

3. Repeatedly push either side of the up/down switch for less than one second until the desired preset number (“1” through “6”) is displayed.

TIP

Selecting “A” will automatically program the preset stations. See the following section.

4. Push the “SELECT” button once for less than one second to store the radio station selected in step 1 under the preset number selected in step 3.
5. Repeat this procedure to preset other radio stations.

Using automatic tuning

1. Select a frequency band. (See the “Selecting a frequency band” section.)
2. Push the “SELECT” button once for two seconds or more. The radio frequency and preset station number “1” (to the right of “CH.”) start flashing.
3. Push either side of the up/down switch once for one second or more to tune in a station automatically.
4. Repeatedly push either side of the up/down switch for less than one second until the desired preset number (“1” through “6”) is displayed.
5. Push the “SELECT” button once for less than one second to store the radio station selected in step 3 under the preset number selected in step 4.
6. Repeat this procedure to preset other radio stations.

Programming preset radio stations automatically



Up to six stations can be programmed automatically for each frequency band (FM1, FM2, FM3, and AM) as follows.

TIP

This function works best in areas with strong radio signals.

1. Select a frequency band. (See the “Selecting a frequency band” section.)
2. Push the “SELECT” button once for two seconds or more. The radio frequency and preset station number “1” (to the right of “CH.”) start flashing.



3. Repeatedly push either side of the up/down switch for less than one second until “A” (automatic) appears in the display.

4. Push the “SELECT” button once for less than one second to program preset radio stations automatically.

EAU15540

Optional CD changer operation

EWA11400

⚠ WARNING

- **It is dangerous to operate the CD changer while riding. Never take your hands off the handlebars while riding.**
- **Keep the volume at a low enough level to be aware of traffic conditions and ensure safety.**

An optional six-disc CD changer can be mounted in the travel trunk. Ask a Yamaha dealer to install the genuine Clarion CDC635 model.

Playing a CD



1. Insert up to six CDs into the CD changer. Follow the manufacturer’s directions.
2. Push the “AUDIO” button until “ ” as well as the CD number and track number (e.g., “6-3”) appear in the display. The CD starts playing.

TIP

“6-3” indicates track no. 3 on CD no. 6.

Selecting a CD



Repeatedly push either side of the up/down switch for one second or more until the number for the desired CD appears in the display.

Selecting a CD track
Repeatedly push either side of the up/down switch for less than one second until the number for the desired CD track appears in the display.

CB radio operation

EAU15551



1. CB antenna



1. Antenna sleeve

EWA11410

⚠ WARNING

- **It is dangerous to change CB radio channels or adjust the volume while riding. Never take your hands off the handlebars while riding.**
- **Keep the volume at a low enough level to be aware of traffic conditions and ensure safety.**
- **Never ride the motorcycle with the CB antenna folded down.**

TIP

Lift the sleeve to fold down the antenna.

This CB radio will operate on any of the 40 frequencies designated as Citizens band channels by the Federal Communications Commission (F.C.C.). This model features a frequency-synthesizing circuit with PHASE LOCK LOOP technology to assure ultra-precise frequency control. This radio has been Type-Accepted and Type-Certified by the F.C.C.

The Citizens Band Radio Service is under the jurisdiction of the Federal Communications Commission (F.C.C.). Any adjustments or modifications which would alter the performance of the transceiver's original F.C.C. Type Acceptance or which would change the frequency-determining method are strictly prohibited. Replacement or substitution of Crystals, Transistors, IC, Regulator Diodes or any other part of unique nature with parts other than those recommended may cause violation of the technical regulation of Part 95 of the F.C.C. Rules or Violation of Type Acceptance requirements of Part 2 of the Rules.

Elimination of licensing

The Federal Communications Commission (F.C.C.) has ruled that Citizens Band Radio Service Operators no longer are required to obtain an F.C.C. license to operate their CB equipment. In doing so, the F.C.C. also decided to permit CB station operation without station identification. Elimination of individual station license results in no lessening of the operating privileges or responsibilities of CB users. An operator of a CB radio station is still required to comply with the Communications Act and with the rules of CB Radio Service.

CB radio functions

The CB radio is capable of the following functions, which are further explained in the following sections:

- Selecting a CB channel for transmitting or receiving
- Adjusting the squelch level
- Adjusting the receiving volume level
- Transmitting and receiving

Selecting a CB channel



1. CB radio indicator light

1. Make sure that the CB radio is turned on and is selected. (See page 5-6.)
2. Repeatedly push either side of the up/down switch for less than one second until the desired CB channel ("Ch:01" through "Ch:40") is displayed.

TIP

All channels, except channel 9, may be used for communications between stations operating under different licenses. Channel 9 has been reserved by the F.C.C. for emergency communications involving the immediate safety of individuals or immediate protection of property. Channel 9 may also be used to render assistance to a motorist. This is an F.C.C. rule and applies to all operators of CB radios.

Adjusting the squelch level

The squelch is a noise suppresser designed to reduce or eliminate background noise in the absence of an incoming signal. The squelch level can be adjusted as follows.

1. Push the “CB” button once for less than one second. The squelch level appears in the display (e.g., “SQ:10”).
2. Repeatedly push either side of the up/down switch for less than one second or turn the control knob until the desired squelch level is displayed. The squelch level can be set between “1” and “20”. After the adjustment is made, the CB radio returns to normal operation and the CB channel appears in the display.

For maximum reception sensitivity, the squelch level should be set by turning the control knob fully counterclockwise, and then slowly turning it clockwise until the background noise has been sufficiently reduced. In order for an incoming CB signal to be heard, it must be stronger than the noise received. Turning the control further clockwise will increase the threshold level that a signal must overcome in order to be heard. Only strong signals will be heard at the maximum setting.



Adjusting the receiving volume



Turn the volume control knob to change the receiving volume level of the CB radio. After setting the level, the display will automatically change back to the “CB” mode and the channel will appear. The volume level can be set between “0” and “20”.

5

Channel information

Channel	Channel Frequency in MHz	Channel	Channel Frequency in MHz
1	26.965	21	27.215
2	26.975	22	27.225
3	36.985	23	27.235
4	27.005	24	27.245
5	27.015	25	27.255
6	27.025	26	27.265
7	27.035	27	27.275
8	27.055	28	27.285
9	27.065	29	27.295
10	27.075	30	27.305
11	27.085	31	27.315
12	27.105	32	27.325
13	27.115	33	27.335
14	27.125	34	27.345
15	27.135	35	27.355
16	27.155	36	27.365
17	27.165	37	27.375
18	27.175	38	27.385
19	27.185	39	27.395
20	27.205	40	27.405

TIP

This radio has been designed for operation in the 11-meter Citizens Band Radio Service. It uses a frequency-synthesizing circuit with Phase-Locked Loop (PLL) technology to provide crystal-controlled transmit and receive operation on all 40 channels. The PLL circuitry assures ultra-precise frequency control and is designed to meet the Federal Communications Commission requirements applicable to equipment operating in the Citizens Radio Service; it is not to be used for any other purpose.

Transmitting and receiving

Transmission

Push the rider "TALK" switch or the passenger "TALK" button to transmit. "TX" appears in the display.



1. "TALK" switch



1. Passenger "TALK" button



Reception

"RX" appears in the display when the CB radio is receiving a signal.



EAU15570

Auxiliary audio source operation

Auxiliary audio equipment can be connected to, and played through, the audio system.

1. Insert the output plug of the auxiliary equipment into the jack located at the right of the cassette deck.

1. Auxiliary audio input jack

2. Repeatedly push the "AUDIO" button for less than one second until "AUX" appears in the display. The auxiliary equipment can now be played through the audio system.

5


AUX
AUDIO
SELECT
CB

EAU15596

Inspect your vehicle each time you use it to make sure the vehicle is in safe operating condition. Always follow the inspection and maintenance procedures and schedules described in the Owner's Manual.

EWA11151

⚠ WARNING

Failure to inspect or maintain the vehicle properly increases the possibility of an accident or equipment damage. Do not operate the vehicle if you find any problem. If a problem cannot be corrected by the procedures provided in this manual, have the vehicle inspected by a Yamaha dealer.

Before using this vehicle, check the following points:

ITEM	CHECKS	PAGE
Fuel	• Check fuel level in fuel tank. • Refuel if necessary. • Check fuel line for leakage. • Check fuel tank breather/overflow hose for obstructions, cracks or damage, and check hose connection.	4-11, 4-12
Engine oil	• Check oil level in engine. • If necessary, add recommended oil to specified level. • Check vehicle for oil leakage.	8-14
Final gear oil	• Check vehicle for oil leakage.	8-16
Coolant	• Check coolant level in reservoir. • If necessary, add recommended coolant to specified level. • Check cooling system for leakage.	8-18

FOR YOUR SAFETY – PRE-OPERATION CHECKS

ITEM	CHECKS	PAGE
Front brake	• Check operation. • If soft or spongy, have Yamaha dealer bleed hydraulic system. • Check lever free play. • Adjust if necessary. • Check brake pads for wear. • Replace if necessary. • Check fluid level in reservoir. • If necessary, add specified brake fluid to specified level. • Check hydraulic system for leakage.	8-25, 8-26, 8-26
Rear brake	• Check operation. • If soft or spongy, have Yamaha dealer bleed hydraulic system. • Check brake pads for wear. • Replace if necessary. • Check fluid level in reservoir. • If necessary, add specified brake fluid to specified level. • Check hydraulic system for leakage.	8-26, 8-26
Clutch	• Check operation. • If soft or spongy, have Yamaha dealer bleed hydraulic system. • Check fluid level in reservoir. • If necessary, add recommended fluid to specified level. • Check hydraulic system for leakage.	8-24, 8-26
Throttle grip	• Make sure that operation is smooth. • Check throttle grip free play. • If necessary, have Yamaha dealer adjust throttle grip free play and lubricate cable and grip housing.	8-21, 8-28
Control cables	• Make sure that operation is smooth. • Lubricate if necessary.	8-28
Wheels and tires	• Check for damage. • Check tire condition and tread depth. • Check air pressure. • Correct if necessary.	8-22, 8-24
Brake and shift pedals	• Make sure that operation is smooth. • Lubricate pedal pivoting points if necessary.	8-29

ITEM	CHECKS	PAGE
Brake and clutch levers	• Make sure that operation is smooth. • Lubricate lever pivoting points if necessary.	8-29
Sidestand	• Make sure that operation is smooth. • Lubricate pivot if necessary.	8-30
Chassis fasteners	• Make sure that all nuts, bolts and screws are properly tightened. • Tighten if necessary.	—
Instruments, lights, signals and switches	• Check operation. • Correct if necessary.	—
Sidestand switch	• Check operation of ignition circuit cut-off system. • If system is not working correctly, have Yamaha dealer check vehicle.	4-20

EAU15951

Read the Owner's Manual carefully to become familiar with all controls. If there is a control or function you do not understand, ask your Yamaha dealer.

EWA10271

⚠ WARNING

Failure to familiarize yourself with the controls can lead to loss of control, which could cause an accident or injury.

EAU44746

Starting and warming up a cold engine

In order for the ignition circuit cut-off system to enable starting, one of the following conditions must be met:

- The transmission is in the neutral position.
- The transmission is in gear with the clutch lever pulled and the sidestand up.
  See page 4-20 for more information.

1. Turn the fuel cock lever to "ON".
2. Turn the key to "ON" and make sure that the engine stop switch is set to "○".
   The engine trouble warning light should come on for a few seconds, then go off.

ECA16711

NOTICE

If the warning light does not come on initially when the key is turned to "ON", or if the warning light remains on, see page 4-2 for the warning light circuit check.

3. Shift the transmission into the neutral position. The neutral indicator light should come on. If not, ask a Yamaha dealer to check the electrical circuit.
4. Turn the starter (choke) on and completely close the throttle. (See page 4-14.)
5. Start the engine by pushing the start switch.
   If the engine fails to start, release the start switch, wait a few seconds, and then try again. Each starting attempt should be as short as possible to preserve the battery. Do not crank the engine more than 10 seconds on any one attempt.
6. After starting the engine, move the starter (choke) back halfway.
7. When the engine is warm, turn the starter (choke) off.

TIP

The engine is warm when it responds quickly to the throttle with the starter (choke) turned off. To avoid the possibility of excessive exhaust emissions, never leave the starter (choke) on long-

er than necessary. The time necessary for starter (choke) use depends upon the ambient temperature. Temperatures above 10 °C (50 °F) require about 7 seconds of starter (choke) use and temperatures below 10 °C (50 °F) require about 35 seconds with the starter (choke) turned on, then about 2.5 minutes with the starter (choke) in the halfway position.

ECA11042

NOTICE

For maximum engine life, never accelerate hard when the engine is cold!

EAU16640

Starting a warm engine

Follow the same procedure as for starting a cold engine with the exception that the starter (choke) is not required when the engine is warm.

EAU16671

Shifting



1. Shift pedal
2. Neutral position

Shifting gears lets you control the amount of engine power available for starting off, accelerating, climbing hills, etc.
The gear positions are shown in the illustration.

TIP

To shift the transmission into the neutral position, press the shift pedal down repeatedly until it reaches the end of its travel, and then slightly raise it.

ECA10260

NOTICE

- **Even with the transmission in the neutral position, do not coast for long periods of time with the engine off, and do not tow the motorcycle for long distances. The transmission is properly lubricated only when the engine is running. Inadequate lubrication may damage the transmission.**
- **Always use the clutch while changing gears to avoid damaging the engine, transmission, and drive train, which are not designed to withstand the shock of forced shifting.**

EAU16681

To start out and accelerate

1. Pull the clutch lever to disengage the clutch.
2. Shift the transmission into first gear. The neutral indicator light should go out.
3. Open the throttle gradually, and at the same time, release the clutch lever slowly.
4. At the recommended shift points shown in the following table, close the throttle, and at the same time, quickly pull the clutch lever in.
5. Shift the transmission into second gear. (Make sure not to shift the transmission into the neutral position.)
6. Open the throttle part way and gradually release the clutch lever.
7. Follow the same procedure when shifting to the next higher gear.

TIP

When shifting gears in normal operating conditions, use the recommended shift points.

EAU16700

To decelerate

1. Apply both the front and the rear brakes to slow the motorcycle.
2. Shift the transmission into first gear when the motorcycle reaches 25 km/h (16 mi/h). If the engine is about to stall or runs very roughly, pull the clutch lever in and use the brakes to stop the motorcycle.
3. Shift the transmission into the neutral position when the motorcycle is almost completely stopped. The neutral indicator light should come on.

EAU16720

Recommended shift points

The recommended shift points during acceleration and deceleration are shown in the table below.

Shift up points:	
1st → 2nd:	20 km/h (12 mi/h)
2nd → 3rd:	30 km/h (19 mi/h)
3rd → 4th:	40 km/h (25 mi/h)
4th → 5th:	50 km/h (31 mi/h)
Shift down points:	
5th → 4th:	25 km/h (16 mi/h)
4th → 3rd:	25 km/h (16 mi/h)
3rd → 2nd:	25 km/h (16 mi/h)
2nd → 1st:	25 km/h (16 mi/h)

EAU16841

Engine break-in

There is never a more important period in the life of your engine than the period between 0 and 1600 km (1000 mi). For this reason, you should read the following material carefully.

Since the engine is brand new, do not put an excessive load on it for the first 1600 km (1000 mi). The various parts in the engine wear and polish themselves to the correct operating clearances. During this period, prolonged full-throttle operation or any condition that might result in engine overheating must be avoided.

EAU17043

0–1000 km (0–600 mi)

Avoid prolonged operation above 1/3 throttle. ***NOTICE:*** **After 1000 km (600 mi) of operation, the engine oil and final gear oil must be changed, and the oil filter cartridge or element replaced.** [ECA10332]

1000–1600 km (600–1000 mi)

Avoid prolonged operation above 1/2 throttle.

1600 km (1000 mi) and beyond

The vehicle can now be operated normally.

ECA10270

NOTICE

If any engine trouble should occur during the engine break-in period, immediately have a Yamaha dealer check the vehicle.

EAU17171

Parking

When parking, stop the engine, remove the key from the main switch, and then turn the fuel cock lever to “OFF”.

EWA10311

⚠ WARNING

- **Since the engine and exhaust system can become very hot, park in a place where pedestrians or children are not likely to touch them and be burned.**
- **Do not park on a slope or on soft ground, otherwise the vehicle may overturn, increasing the risk of a fuel leak and fire.**
- **Do not park near grass or other flammable materials which might catch fire.**

7

PERIODIC MAINTENANCE AND ADJUSTMENT

EAU17244

Periodic inspection, adjustment, and lubrication will keep your vehicle in the safest and most efficient condition possible. Safety is an obligation of the vehicle owner/operator. The most important points of vehicle inspection, adjustment, and lubrication are explained on the following pages.

The intervals given in the periodic maintenance charts should be simply considered as a general guide under normal riding conditions. However, depending on the weather, terrain, geographical location, and individual use, the maintenance intervals may need to be shortened.

EWA10321

⚠ WARNING

Failure to properly maintain the vehicle or performing maintenance activities incorrectly may increase your risk of injury or death during service or while using the vehicle. If you are not familiar with vehicle service, have a Yamaha dealer perform service.

EWA15122

⚠ WARNING

Turn off the engine when performing maintenance unless otherwise specified.

- **A running engine has moving parts that can catch on body parts or clothing and electrical parts that can cause shocks or fires.**
- **Running the engine while servicing can lead to eye injury, burns, fire, or carbon monoxide poisoning – possibly leading to death. See page 2-2 for more information about carbon monoxide.**

EWA15460

⚠ WARNING

Brake discs, calipers, drums, and linings can become very hot during use. To avoid possible burns, let brake components cool before touching them.

EAU17302

Emission controls not only function to ensure cleaner air, but are also vital to proper engine operation and maximum performance. In the following periodic maintenance charts, the services related to emissions control are grouped separately. These services require specialized data, knowledge, and equipment. Maintenance, replacement, or repair of the emission control devices and systems may be performed by any repair establishment or individual that is certified (if applicable). Yamaha dealers are trained and equipped to perform these particular services.

EAU17412

Owner's tool kit



1. Owner's tool kit

The owner's tool kit is located inside the right sidecase. (See page 4-16.)
The service information included in this manual and the tools provided in the owner's tool kit are intended to assist you in the performance of preventive maintenance and minor repairs. However, additional tools such as a torque wrench may be necessary to perform certain maintenance work correctly.

TIP

If you do not have the tools or experience required for a particular job, have a Yamaha dealer perform it for you.

EAU48490

TIP

- From 24000 mi (37000 km) or 36 months, repeat the maintenance intervals starting from 8000 mi (13000 km) or 12 months.
- Items marked with an asterisk require special tools, data and technical skills, have a Yamaha dealer perform the service.

EAU17601

Periodic maintenance chart for the emission control system

No.		ITEM	ROUTINE	INITIAL	ODOMETER READINGS				
				600 mi (1000 km) or 1 month	4000 mi (7000 km) or 6 months	8000 mi (13000 km) or 12 months	12000 mi (19000 km) or 18 months	16000 mi (25000 km) or 24 months	20000 mi (31000 km) or 30 months
1	*	**Fuel line**	• Check fuel hoses for cracks or damage. • Replace if necessary.		√	√	√	√	√
2	*	**Fuel filter**	• Replace.						Replace.
3		**Spark plugs**	• Check condition. • Adjust gap and clean. • Replace every 8000 mi (13000 km) or 12 months.		√	Replace.	√	Replace.	√
4	*	**Valve clearance**	• Check and adjust valve clearance when engine is cold.	Every 26600 mi (42000 km)					
5	*	**Crankcase breather system**	• Check breather hose for cracks or damage. • Replace if necessary.		√	√	√	√	√
6	*	**Carburetor synchronization**	• Adjust synchronization of carburetors.	√	√	√	√	√	√

No.		ITEM	ROUTINE	INITIAL	ODOMETER READINGS				
				600 mi (1000 km) or 1 month	4000 mi (7000 km) or 6 months	8000 mi (13000 km) or 12 months	12000 mi (19000 km) or 18 months	16000 mi (25000 km) or 24 months	20000 mi (31000 km) or 30 months
7	*	**Idle speed**	• Check and adjust engine idle speed.	√	√	√	√	√	√
8	*	**Exhaust system**	• Check for leakage. • Tighten if necessary. • Replace gasket(s) if necessary.		√	√	√	√	√
9	*	**Evaporative emission control system (for California only)**	• Check control system for damage. • Replace if necessary.				√		√

EAU32186

General maintenance and lubrication chart

No.		ITEM	ROUTINE	INITIAL	ODOMETER READINGS				
				600 mi (1000 km) or 1 month	4000 mi (7000 km) or 6 months	8000 mi (13000 km) or 12 months	12000 mi (19000 km) or 18 months	16000 mi (25000 km) or 24 months	20000 mi (31000 km) or 30 months
1		**Air filter elements**	• Clean with compressed air. • Replace if necessary.		√	√	√	√	√
2	*	**Clutch**	• Check operation and fluid leakage. • Correct if necessary.	√	√	√	√	√	√
3	*	**Front brake**	• Check operation, fluid level, and for fluid leakage. • Adjust brake lever free play and replace brake pads if necessary.	√	√	√	√	√	√
4	*	**Rear brake**	• Check operation, fluid level, and for fluid leakage. • Replace brake pads if necessary.	√	√	√	√	√	√
5	*	**Brake hoses**	• Check for cracks or damage. • Check for correct routing and clamping.		√	√	√	√	√
			• Replace.	Every 4 years					
6	*	**Wheels**	• Check runout and for damage. • Replace if necessary.		√	√	√	√	√
7	*	**Tires**	• Check tread depth and for damage. • Replace if necessary. • Check air pressure. • Correct if necessary.		√	√	√	√	√

No.		ITEM	ROUTINE	INITIAL	ODOMETER READINGS				
				600 mi (1000 km) or 1 month	4000 mi (7000 km) or 6 months	8000 mi (13000 km) or 12 months	12000 mi (19000 km) or 18 months	16000 mi (25000 km) or 24 months	20000 mi (31000 km) or 30 months
8	*	**Wheel bearings**	• Check bearings for smooth operation. • Replace if necessary.		√	√	√	√	√
9	*	**Swingarm pivot bearings**	• Check bearing assemblies for looseness. • Moderately repack with lithium-soap-based grease.			√		Repack.	
10	*	**Steering bearings**	• Check bearing assemblies for looseness.	√	√	√	√	√	√
			• Moderately repack with lithium-soap-based grease.	Every 16000 mi (25000 km)					
11	*	**Chassis fasteners**	• Check all chassis fitting and fasteners. • Correct if necessary.		√	√	√	√	√
12		**Brake lever pivot shaft**	• Apply silicone grease lightly.		√	√	√	√	√
13		**Brake pedal pivot shaft**	• Apply lithium-soap-based grease lightly.		√	√	√	√	√
14		**Clutch lever pivot shaft**	• Apply silicone grease lightly.		√	√	√	√	√
15		**Shift pedal pivot shaft**	• Apply lithium-soap-based grease lightly.		√	√	√	√	√
16		**Sidestand pivot**	• Check operation. • Apply lithium-soap-based grease lightly.		√	√	√	√	√

No.		ITEM	ROUTINE	INITIAL	ODOMETER READINGS				
				600 mi (1000 km) or 1 month	4000 mi (7000 km) or 6 months	8000 mi (13000 km) or 12 months	12000 mi (19000 km) or 18 months	16000 mi (25000 km) or 24 months	20000 mi (31000 km) or 30 months
17	*	**Sidestand switch**	• Check operation and replace if necessary.	√	√	√	√	√	√
18	*	**Front fork**	• Check operation and for oil leakage. • Replace if necessary.		√	√	√	√	√
19	*	**Shock absorber assembly**	• Check operation and for oil leakage. • Replace if necessary.		√	√	√	√	√
20	*	**Rear suspension link pivots**	• Apply lithium-soap-based grease lightly.					√	
21		**Engine oil**	• Change (warm engine before draining).	√	√	√	√	√	√
22	*	**Engine oil filter cartridge**	• Replace.	√		√		√	
23	*	**Cooling system**	• Check hoses for cracks or damage. • Replace if necessary.		√	√	√	√	√
			• Change with ethylene glycol antifreeze coolant every 24 months.					Change.	
24		**Final gear oil**	• Check oil level and for oil leakage. • Change at initial 600 mi (1000 km) or 1 month, and thereafter every 16000 mi (25000 km) or 24 months.	Change.	√	√	√	Change.	√
25	*	**Front and rear brake switches**	• Check operation.	√	√	√	√	√	√

No.		ITEM	ROUTINE	INITIAL	ODOMETER READINGS				
				600 mi (1000 km) or 1 month	4000 mi (7000 km) or 6 months	8000 mi (13000 km) or 12 months	12000 mi (19000 km) or 18 months	16000 mi (25000 km) or 24 months	20000 mi (31000 km) or 30 months
26	*	**Control cables**	• Apply Yamaha chain and cable lube or engine oil thoroughly.	√	√	√	√	√	√
27	*	**Throttle grip**	• Check operation. • Check throttle grip free play, and adjust if necessary. • Lubricate cable and grip housing.		√	√	√	√	√
28	*	**Lights, signals and switches**	• Check operation. • Adjust headlight beam.	√	√	√	√	√	√

EAU17660

TIP

- The air filter needs more frequent service if you are riding in unusually wet or dusty areas.
- Hydraulic brake and clutch systems
  - After disassembling the brake or clutch master cylinders, caliper cylinders or clutch release cylinder, always change the fluid. Regularly check the brake and clutch fluid levels and fill the reservoirs as required.
  - Replace the oil seals on the inner parts of the brake or clutch master cylinders, caliper cylinders and clutch release cylinder every two years.
  - Replace the brake and clutch hoses every four years or if cracked or damaged.

EAU18712

Removing and installing cowlings and panels

The cowlings and panels shown need to be removed to perform some of the maintenance jobs described in this chapter. Refer to this section each time a cowling or panel needs to be removed and installed.



1. Cowling A
2. Panel A



1. Cowling B
2. Panel B
3. Panel C

EAU35841

Cowling A

To remove the cowling

1. Remove the bolts.
2. Remove the quick fastener screw by turning it 1/4 turn counterclockwise, and then take the cowling off.



1. Cowling A
2. Bolt
3. Quick fastener screw

1. Bolt

To install the cowling

Place the cowling in the original position, and then install the quick fastener screw and the bolts.



1. Grommet
2. Projection
3. Cowling A

TIP

Make sure that the projection fits into the grommet.

EAU35850

Cowling B

To remove the cowling

1. Remove cowling A.
2. Remove the bolts, and then pull the cowling off as shown.



1. Cowling B
2. Bolt

1. Bolt

To install the cowling

1. Place the cowling in the original position, and then install the bolts.

TIP

Make sure that the projection fits into the grommet.

2. Install cowling A.

EAU35861

Panels A and B

To remove a panel

Remove the bolt, and then pull the panel off as shown.



1. Panel A
2. Bolt

8



1. Panel B
2. Bolt

To install a panel

Place the panel in the original position, and then install the bolt.





EAU19333

Panel C

To remove the panel

1. Remove panel B.
2. Remove the left passenger footrest by removing the bolts.
3. Remove the screw, and then pull the panel off as shown.



1. Panel C
2. Screw
3. Bolt
4. Passenger footrest

To install the panel

1. Place the panel in the original position, and then install the screw.



2. Install the passenger footrest by installing the bolts.

3. Install panel B.

EAU19545

Checking the spark plugs

The spark plugs are important engine components, which are easy to check. Since heat and deposits will cause any spark plug to slowly erode, the spark plugs should be removed and checked in accordance with the periodic maintenance and lubrication chart. In addition, the condition of the spark plugs can reveal the condition of the engine.

To remove a spark plug

1. Remove the spark plug cap.



1. Spark plug cap

2. Remove the spark plug as shown, with the spark plug wrench included in the owner's tool kit.



1. Spark plug wrench

To check the spark plugs

1. Check that the porcelain insulator around the center electrode on each spark plug is a medium-to-light tan (the ideal color when the vehicle is ridden normally).
2. Check that all spark plugs installed in the engine have the same color.

TIP

If any spark plug shows a distinctly different color, the engine could be operating improperly. Do not attempt to diagnose such problems yourself. Instead, have a Yamaha dealer check the vehicle.

8

3. Check each spark plug for electrode erosion and excessive carbon or other deposits, and replace it if necessary.

Specified spark plug:
NGK/DPR8EA-9
DENSO/X24EPR-U9

4. Measure the spark plug gap with a wire thickness gauge and, if necessary, adjust the gap to specification.



1. Spark plug gap

Spark plug gap:
0.8–0.9 mm (0.031–0.035 in)

To install a spark plug

1. Clean the surface of the spark plug gasket and its mating surface, and then wipe off any grime from the spark plug threads.
2. Install the spark plug with the spark plug wrench, and then tighten it to the specified torque.

Tightening torque:
Spark plug:
18 Nm (1.8 m·kgf, 13 ft·lbf)

TIP

If a torque wrench is not available when installing a spark plug, a good estimate of the correct torque is 1/4–1/2 turn past finger tight. However, the spark plug should be tightened to the specified torque as soon as possible.

3. Install the spark plug cap.

EAU19681

Canister (for California only)



This model is equipped with a canister to prevent the discharging of fuel vapor into the atmosphere. Before operating this vehicle, make sure to check the following:

- Check each hose connection.
- Check each hose and canister for cracks or damage. Replace if damaged.
- Make sure that the canister breather is not blocked, and if necessary, clean it.

EAU19908

Engine oil and oil filter cartridge

The engine oil level should be checked before each ride. In addition, the oil must be changed and the oil filter cartridge replaced at the intervals specified in the periodic maintenance and lubrication chart.

To check the engine oil level

1. Place the vehicle on a level surface and hold it in an upright position. A slight tilt to the side can result in a false reading.
2. Start the engine, warm it up for several minutes, and then turn it off.
3. Wait a few minutes until the oil settles, and then check the oil level through the check window located at the bottom-right side of the crankcase.

TIP

The engine oil should be between the minimum and maximum level marks.



1. Engine oil level check window
2. Maximum level mark
3. Minimum level mark

4. If the engine oil is below the minimum level mark, add sufficient oil of the recommended type to raise it to the correct level.

To change the engine oil (with or without oil filter cartridge replacement)

1. Place the vehicle on a level surface.
2. Start the engine, warm it up for several minutes, and then turn it off.
3. Place an oil pan under the engine to collect the used oil.
4. Remove the engine oil filler cap, the engine oil drain bolt and its gasket to drain the oil from the crankcase.



1. Engine oil filler cap



1. Engine oil drain bolt
2. Gasket

TIP

Skip steps 5–7 if the oil filter cartridge is not being replaced.

5. Remove the oil filter cartridge with an oil filter wrench.

1. Oil filter cartridge
2. Oil filter wrench

TIP

An oil filter wrench is available at a Yamaha dealer.

6. Apply a thin coat of clean engine oil to the O-ring of the new oil filter cartridge.



1. O-ring

TIP

Make sure that the O-ring is properly seated.

7. Install the new oil filter cartridge with an oil filter wrench, and then tighten it to the specified torque with a torque wrench.



1. Torque wrench
2. Oil filter wrench

Tightening torque:
Oil filter cartridge:
17 Nm (1.7 m·kgf, 12 ft·lbf)

8. Install the engine oil drain bolt and its new gasket, and then tighten the bolt to the specified torque.

Tightening torque:
Engine oil drain bolt:
43 Nm (4.3 m·kgf, 31 ft·lbf)

9. Refill with the specified amount of the recommended engine oil, and then install and tighten the oil filler cap.

Recommended engine oil:
See page 10-1.
Oil quantity:
Without oil filter cartridge replacement:
3.50 L (3.70 US qt, 3.08 Imp.qt)
With oil filter cartridge replacement:
3.70 L (3.91 US qt, 3.26 Imp.qt)

TIP

Be sure to wipe off spilled oil on any parts after the engine and exhaust system have cooled down.

ECA11620

NOTICE

- **In order to prevent clutch slippage (since the engine oil also lubricates the clutch), do not mix any chemical additives. Do not use oils with a diesel specification of "CD" or oils of a higher quality than specified. In addition, do not use oils labeled "ENERGY CONSERVING II" or higher.**
- **Make sure that no foreign material enters the crankcase.**

10. Start the engine, and then let it idle for several minutes while checking it for oil leakage. If oil is leaking, immediately turn the engine off and check for the cause.

TIP

After the engine is started, the engine oil level warning light should go off if the oil level is sufficient.

ECA10401

NOTICE

If the oil level warning light flickers or remains on even if the oil level is correct, immediately turn the engine off and have a Yamaha dealer check the vehicle.

11. Turn the engine off, wait a few minutes until the oil settles, and then check the oil level and correct it if necessary.

EAU20026

Final gear oil

The final gear case must be checked for oil leakage before each ride. If any leakage is found, have a Yamaha dealer check and repair the vehicle. In addition, the final gear oil level must be checked and the oil changed as follows at the intervals specified in the periodic maintenance and lubrication chart.

EWA10370

⚠ WARNING

- **Make sure that no foreign material enters the final gear case.**
- **Make sure that no oil gets on the tire or wheel.**

To check the final gear oil level

1. Place the vehicle on a level surface and hold it in an upright position.

TIP

Make sure that the vehicle is positioned straight up when checking the oil level. A slight tilt to the side can result in a false reading.

2. Remove the final gear oil filler bolt and its gasket, and then check the oil level in the final gear case.

TIP

The oil level should be at the brim of the filler hole.



1. Final gear oil filler bolt
2. Gasket
3. Correct oil level

3. If the oil is below the brim of the filler hole, add sufficient oil of the recommended type to raise it to the correct level.
4. Check the gasket for damage, and replace it if necessary.
5. Install the final gear oil filler bolt and its gasket, and then tighten the bolt to the specified torque.

Tightening torque:
Final gear oil filler bolt:
23 Nm (2.3 m·kgf, 17 ft·lbf)

To change the final gear oil

1. Place an oil pan under the final gear case to collect the used oil.
2. Remove the final gear oil filler bolt, the final gear oil drain bolt and their gasket to drain the oil from the final gear case.



1. Final gear oil drain bolt
2. Gasket

3. Install the final gear oil drain bolt and its new gasket, and then tighten the bolt to the specified torque.

Tightening torque:
Final gear oil drain bolt:
23 Nm (2.3 m·kgf, 17 ft·lbf)

4. Refill with the recommended final gear oil to the brim of the filler hole.

Recommended final gear oil:
SAE80 API GL-4 Hypoid gear oil
Oil quantity:
0.20 L (0.21 US qt, 0.18 Imp.qt)

TIP

GL4 is a quality rating. Hypoid gear oils rated GL5 or GL6 may also be used.

5. Check the oil filler bolt gasket for damage, and replace it if necessary.
6. Install the oil filler bolt and its gasket, and then tighten the bolt to the specified torque.

Tightening torque:
Final gear oil filler bolt:
23 Nm (2.3 m·kgf, 17 ft·lbf)

7. Check the final gear case for oil leakage. If oil is leaking, check for the cause.

EAU20070

Coolant

The coolant level should be checked before each ride. In addition, the coolant must be changed at the intervals specified in the periodic maintenance and lubrication chart.

EAU20214

To check the coolant level

1. Place the vehicle on a level surface.
2. Remove panel A. (See page 8-9.)
3. Hold the vehicle in an upright position.

TIP

- The coolant level must be checked on a cold engine since the level varies with engine temperature.
- Make sure that the vehicle is positioned straight up when checking the coolant level. A slight tilt to the side can result in a false reading.

4. Check the coolant level in the coolant reservoir.

TIP

The coolant should be between the minimum and maximum level marks.



1. Coolant reservoir
2. Maximum level mark
3. Minimum level mark

5. If the coolant is at or below the minimum level mark, remove the rider seat (See page 4-14.), open the reservoir cap, add coolant to the maximum level mark, and then close the reservoir cap and install the rider seat. **WARNING! Remove only the coolant reservoir cap. Never attempt to remove the radiator cap when the engine is hot.** [EWA15161] ***NOTICE:*** **If coolant is not available, use distilled water or soft tap water instead. Do not use hard water or salt water since it is harmful to the engine. If water has been used instead of coolant, replace it with coolant as soon as possible, otherwise the cooling system will not be protected against frost and corrosion. If water has been added to the coolant, have a Yamaha dealer check the antifreeze content of the coolant as soon as possible, otherwise the effectiveness of the coolant will be reduced.** [ECA10472]



1. Coolant reservoir cap

Coolant reservoir capacity (up to the maximum level mark):
0.35 L (0.37 US qt, 0.31 Imp.qt)

6. Install the panel.

EAU33031

Changing the coolant

The coolant must be changed at the intervals specified in the periodic maintenance and lubrication chart. Have a Yamaha dealer change the coolant. **WARNING! Never attempt to remove the radiator cap when the engine is hot.** [EWA10381]

EAU35196

Cleaning the air filter elements

The air filter elements should be cleaned at the intervals specified in the periodic maintenance and lubrication chart. Clean or, if necessary, replace the air filter elements more frequently if you are riding in unusually wet or dusty areas.

1. Remove cowlings A and B. (See page 8-9.)

TIP

Continue as follows for each air filter element.

2. Remove the air filter case bolts.



1. Air filter case
2. Bolt

3. Loosen the air filter case joint clamp screw, and then pull the air filter case off.



1. Air filter case joint clamp screw

4. Remove the air filter case cover by removing the screws.



1. Screw

5. Remove the air filter element by removing the screws.



1. Air filter element
2. Screw

6. Lightly tap the air filter element to remove most of the dust and dirt, and then blow the remaining dirt out with compressed air as shown. If the air filter element is damaged, replace it.



1. Air filter element

7. Install the air filter element by fitting the projection on the air filter element into the holder in the air filter case, then tightening the screws. ***NOTICE:*** **Make sure that the air filter element is properly seated in the air filter case. The engine should never be operated without the air filter element installed, otherwise the piston(s) and/or cylinder(s) may become excessively worn.**
   [ECA10481]
8. Install the air filter case cover by installing the screws.
9. Push the air filter case onto the air filter case joint, and then tighten the clamp screw.
10. Install the air filter case bolts.
11. Install the cowlings.
12. Route the carburetor air vent hose as shown.



1. Carburetor air vent hose

EAU21271

Carburetors

The carburetors are important parts of the engine and emission control system, which require very sophisticated adjustment. Therefore, all carburetor adjustments should be left to a Yamaha dealer, who has the necessary professional knowledge and experience.

EAU44734

Checking the engine idling speed

Check the engine idling speed and, if necessary, have it corrected by a Yamaha dealer.

Engine idling speed:
950–1050 r/min

EAU21384

Checking the throttle grip free play



1. Throttle grip free play

The throttle grip free play should measure 4.0–6.0 mm (0.16–0.24 in) at the inner edge of the throttle grip. Periodically check the throttle grip free play and, if necessary, have a Yamaha dealer adjust it.

EAU21401

Valve clearance

The valve clearance changes with use, resulting in improper air-fuel mixture and/or engine noise. To prevent this from occurring, the valve clearance must be adjusted by a Yamaha dealer at the intervals specified in the periodic maintenance and lubrication chart.

EAU32545

Tires

To maximize the performance, durability, and safe operation of your motorcycle, note the following points regarding the specified tires.

Tire air pressure

The tire air pressure should be checked and, if necessary, adjusted before each ride.

EWA10503

⚠ WARNING

Operation of this vehicle with improper tire pressure may cause severe injury or death from loss of control.

- **The tire air pressure must be checked and adjusted on cold tires (i.e., when the temperature of the tires equals the ambient temperature).**
- **The tire air pressure must be adjusted in accordance with the riding speed and with the total weight of rider, passenger, cargo, and accessories approved for this model.**

Tire air pressure (measured on cold tires):

0–90 kg (0–198 lb):

Front:
250 kPa (2.50 kgf/cm², 36 psi)

Rear:
250 kPa (2.50 kgf/cm², 36 psi)

90–190 kg (198–419 lb):

Front:
250 kPa (2.50 kgf/cm², 36 psi)

Rear:
280 kPa (2.80 kgf/cm², 41 psi)

Maximum load*:

190 kg (419 lb)

* Total weight of rider, passenger, cargo and accessories

EWA10511

⚠ WARNING

Never overload your vehicle. Operation of an overloaded vehicle could cause an accident.

8

Tire inspection



1. Tire sidewall
2. Tire wear indicator
3. Tire tread depth

Always check the tires before operating the motorcycle. If a tire tread shows crosswise lines (minimum tread depth), if the tire has a nail or glass fragments in it, or if the sidewall is cracked, contact a Yamaha dealer immediately and have the tire replaced.

Minimum tire tread depth (front and rear):
1.0 mm (0.04 in)

EWA10521

⚠ WARNING

- **It is dangerous to ride with a worn-out tire. When a tire tread begins to show lines, have a Yamaha dealer replace the tire immediately. Brakes, tires and related wheel parts replacement should also be left to a Yamaha dealer.**
- **Ride at moderate speeds after changing a tire since the tire surface must first be "broken in" for it to develop its optimal characteristics.**

Tire information

This motorcycle is equipped with tubeless tires, tire air valves and cast wheels.

EWA10461

⚠ WARNING

The front and rear tires should be of the same make and design, otherwise the handling characteristics of the vehicle may be different, which could lead to an accident.

After extensive tests, only the tires listed below have been approved for this model by Yamaha Motor Co., Ltd.

Front tire:
Size:
150/80-16M/C 71H
Manufacturer/model:
DUNLOP/D404F
BRIDGESTONE/G705G
Rear tire:
Size:
150/90B15M/C 74H
Manufacturer/model:
DUNLOP/D404
BRIDGESTONE/G702G

EAU21994

Cast wheels

To maximize the performance, durability, and safe operation of your vehicle, note the following points regarding the specified wheels.

- The wheel rims should be checked for cracks, bends, warpage or other damage before each ride. If any damage is found, have a Yamaha dealer replace the wheel. Do not attempt even the smallest repair to the wheel. A deformed or cracked wheel must be replaced.
- The wheel should be balanced whenever either the tire or wheel has been changed or replaced. An unbalanced wheel can result in poor performance, adverse handling characteristics, and a shortened tire life.
- After repairing or replacing the rear tire, tighten the valve stem nut and locknut to the specified torques.



1. Valve stem nut
2. Valve stem locknut

Tightening torques:
Valve stem nut:
1.6 Nm (0.16 m·kgf, 1.2 ft·lbf)
Valve stem locknut:
1.6 Nm (0.16 m·kgf, 1.2 ft·lbf)

EAU22073

Clutch lever



1. No clutch lever free play

Since this model is equipped with a hydraulic clutch, adjusting the clutch lever free play is not needed. However, it is necessary to check the clutch fluid level and check the hydraulic system for leakage before each ride. (See page 8-26.) If the clutch lever free play does become excessive, and shifting becomes rough or clutch slippage occurs, causing poor acceleration, there may be air in the clutch system. If there is air in the hydraulic system, have a Yamaha dealer bleed the system before operating the motorcycle.

EAU22093

Adjusting the brake lever free play



1. Locknut
2. Brake lever free play adjusting screw
3. Brake lever free play

The brake lever free play should measure 2.0–5.0 mm (0.08–0.20 in) as shown. Periodically check the brake lever free play and, if necessary, adjust it as follows.

1. Loosen the locknut at the brake lever.
2. To increase the brake lever free play, turn the brake lever free play adjusting screw in direction (a). To decrease the brake lever free play, turn the adjusting screw in direction (b).
3. Tighten the locknut.

EWA10630

⚠ WARNING

- **After adjusting the brake lever free play, check the free play and make sure that the brake is working properly.**
- **A soft or spongy feeling in the brake lever can indicate the presence of air in the hydraulic system. If there is air in the hydraulic system, have a Yamaha dealer bleed the system before operating the motorcycle. Air in the hydraulic system will diminish the braking performance, which may result in loss of control and an accident.**

EAU22282

Brake light switches

The brake light, which is activated by the brake pedal and brake lever, should come on just before braking takes effect. Since the brake light switches are components of the cruise control system, they must be adjusted by a Yamaha dealer, who has the necessary professional knowledge and experience.

EAU22392

Checking the front and rear brake pads

The front and rear brake pads must be checked for wear at the intervals specified in the periodic maintenance and lubrication chart.

EAU22430

Front brake pads



1. Brake pad wear indicator groove

Each front brake pad is provided with wear indicator grooves, which allow you to check the brake pad wear without having to disassemble the brake. To check the brake pad wear, check the wear indicator grooves. If a brake pad has worn to the point that the wear indicator grooves have almost disappeared, have a Yamaha dealer replace the brake pads as a set.

EAU22470

Rear brake pads



1. Brake pad wear indicator groove

Each rear brake pad is provided with a wear indicator groove, which allows you to check the brake pad wear without having to disassemble the brake. To check the brake pad wear, check the wear indicator groove. If a brake pad has worn to the point that the wear indicator groove has almost disappeared, have a Yamaha dealer replace the brake pads as a set.

EAU22661

Checking the brake and clutch fluid levels

Before riding, check that the brake and clutch fluids are above the minimum level marks. Check the brake and clutch fluid levels with the tops of the reservoirs level. Replenish the brake and clutch fluids if necessary.

Front brake



1. Minimum level mark

8

Rear brake



1. Minimum level mark

Clutch

1. Minimum level mark

Specified brake and clutch fluid:
DOT 4 brake fluid

EWA16000

⚠ WARNING

Improper maintenance can result in loss of braking ability or clutch operation. Observe these precautions:

- **Insufficient brake or clutch fluid may allow air to enter the brake or clutch system, reducing braking or clutch performance.**
- **Clean the filler caps before removing. Use only DOT 4 brake fluid from a sealed container.**
- **Use only the specified brake fluid; otherwise, the rubber seals may deteriorate, causing leakage.**
- **Refill with the same type of brake fluid. Adding a brake fluid other than DOT 4 may result in a harmful chemical reaction.**
- **Be careful that water does not enter the brake or clutch fluid reservoir when refilling. Water will significantly lower the boiling point of the fluid and may result in vapor lock.**

ECA17640

NOTICE

Brake fluid may damage painted surfaces or plastic parts. Always clean up spilled fluid immediately.

As the brake pads wear, it is normal for the brake fluid level to gradually go down. A low brake fluid level may indicate worn brake pads and/or brake system leakage; therefore, be sure to check the brake pads for wear and the brake system for leakage. A low clutch fluid level may indicate clutch system leakage; therefore, be sure to check the clutch system for leakage. If the brake or clutch fluid level goes down suddenly, have a Yamaha dealer check the cause before further riding.

EAU22751

Changing the brake and clutch fluids

Have a Yamaha dealer change the brake and clutch fluids at the intervals specified in the TIP after the periodic maintenance and lubrication chart. In addition, have the oil seals of the brake and clutch master cylinders and calipers as well as the brake and clutch hoses replaced at the intervals listed below or whenever they are damaged or leaking.

- Oil seals: Replace every two years.
- Brake and clutch hoses: Replace every four years.

EAU23095

Checking and lubricating the cables

The operation of all control cables and the condition of the cables should be checked before each ride, and the cables and cable ends should be lubricated if necessary. If a cable is damaged or does not move smoothly, have a Yamaha dealer check or replace it. **WARNING! Damage to the outer housing of cables may result in internal rusting and cause interference with cable movement. Replace damaged cables as soon as possible to prevent unsafe conditions.**

[EWA10711]

Recommended lubricant:
Yamaha Chain and Cable Lube or engine oil

EAU49920

Checking and lubricating the throttle grip and cable

The operation of the throttle grip should be checked before each ride. In addition, the cable should be lubricated by a Yamaha dealer at the intervals specified in the periodic maintenance chart.

8

EAU44272

Checking and lubricating the brake and shift pedals

Brake pedal



Shift pedal



The operation of the brake and shift pedals should be checked before each ride, and the pedal pivots should be lubricated if necessary.

Recommended lubricant:
Lithium-soap-based grease

EAU43600

Checking and lubricating the brake and clutch levers



The operation of the brake and clutch levers should be checked before each ride, and the lever pivots should be lubricated if necessary.

Recommended lubricant:
Silicone grease

EAU23202

Checking and lubricating the sidestand



The operation of the sidestand should be checked before each ride, and the sidestand pivot and metal-to-metal contact surfaces should be lubricated if necessary.

EWA10731

⚠ WARNING

If the sidestand does not move up and down smoothly, have a Yamaha dealer check or repair it. Otherwise, the sidestand could contact the ground and distract the operator, resulting in a possible loss of control.

Recommended lubricant:
Lithium-soap-based grease

EAUM1652

Lubricating the swingarm pivots

The swingarm pivots must be lubricated by a Yamaha dealer at the intervals specified in the periodic maintenance and lubrication chart.

Recommended lubricant:
Lithium-soap-based grease

EAU23251

Lubricating the rear suspension

The pivoting points of the rear suspension must be lubricated by a Yamaha dealer at the intervals specified in the periodic maintenance and lubrication chart.

Recommended lubricant:
Lithium-soap-based grease

EAU51950

Checking the front fork

The condition and operation of the front fork must be checked as follows at the intervals specified in the periodic maintenance and lubrication chart.

To check the condition

Check the front fork for damage and excessive oil leakage.

To check the operation

1. Place the vehicle on a level surface and hold it in an upright position. **WARNING! To avoid injury, securely support the vehicle so there is no danger of it falling over.** [EWA10751]
2. While applying the front brake, push down hard on the handlebars several times to check if the front fork compresses and rebounds smoothly.



ECA10590

NOTICE

If any damage is found or the front fork does not operate smoothly, have a Yamaha dealer check or repair it.

EAU23283

Checking the steering

Worn or loose steering bearings may cause danger. Therefore, the operation of the steering must be checked as follows at the intervals specified in the periodic maintenance and lubrication chart.

1. Place a stand under the engine to raise the front wheel off the ground. (See page 8-36 for more information.) **WARNING! To avoid injury, securely support the vehicle so there is no danger of it falling over.** [EWA10751]
2. Hold the lower ends of the front fork legs and try to move them forward and backward. If any free play can be felt, have a Yamaha dealer check or repair the steering.

EAU23291

Checking the wheel bearings



The front and rear wheel bearings must be checked at the intervals specified in the periodic maintenance and lubrication chart. If there is play in the wheel hub or if the wheel does not turn smoothly, have a Yamaha dealer check the wheel bearings.

EAU50581

Battery



1. Battery
2. Negative battery lead (black)
3. Positive battery lead (red)

The battery is located under the rider seat. (See page 4-14.)
This model is equipped with a VRLA (Valve Regulated Lead Acid) battery. There is no need to check the electrolyte or to add distilled water. However, the battery lead connections need to be checked and, if necessary, tightened.

EWA10760

⚠ WARNING

- **Electrolyte is poisonous and dangerous since it contains sulfuric acid, which causes severe burns. Avoid any contact with skin, eyes or clothing and always shield your eyes when working near batteries. In case of contact, administer the following FIRST AID.**
  - **EXTERNAL: Flush with plenty of water.**
  - **INTERNAL: Drink large quantities of water or milk and immediately call a physician.**
  - **EYES: Flush with water for 15 minutes and seek prompt medical attention.**
- **Batteries produce explosive hydrogen gas. Therefore, keep sparks, flames, cigarettes, etc., away from the battery and provide sufficient ventilation when charging it in an enclosed space.**
- **KEEP THIS AND ALL BATTERIES OUT OF THE REACH OF CHILDREN.**

ECA10620

NOTICE

Never attempt to remove the battery cell seals, as this would permanently damage the battery.

8

To charge the battery

Have a Yamaha dealer charge the battery as soon as possible if it seems to have discharged. Keep in mind that the battery tends to discharge more quickly if the vehicle is equipped with optional electrical accessories.

ECA16521

NOTICE

To charge a VRLA (Valve Regulated Lead Acid) battery, a special (constant-voltage) battery charger is required. Using a conventional battery charger will damage the battery.

To store the battery

1. If the vehicle will not be used for more than one month, remove the battery, fully charge it, and then place it in a cool, dry place. ***NOTICE:*** **When removing the battery, be sure the key is turned to "OFF", then disconnect the negative lead before disconnecting the positive lead.**

   [ECA16302]
2. If the battery will be stored for more than two months, check it at least once a month and fully charge it if necessary.
3. Fully charge the battery before installation. ***NOTICE:*** **When installing the battery, be sure the key is turned to "OFF", then connect the positive lead before connecting the negative lead.**

   [ECA16840]
4. After installation, make sure that the battery leads are properly connected to the battery terminals.

ECA16530

NOTICE

Always keep the battery charged. Storing a discharged battery can cause permanent battery damage.

EAU23664

Replacing the fuses

The main fuse is located behind panel C. (See page 8-9.)



1. Main fuse
2. Spare main fuse

Fuse box 1 is located behind cowling A. (See page 8-9.)



1. Cruise control fuse
2. Carburetor heater fuse
3. Auxiliary DC connector fuse
4. Auxiliary DC jack fuse
5. Audio system fuse
6. Spare fuse

Fuse box 2 is located behind panel B. (See page 8-9.)



1. Backup fuse (for clock and audio system)
2. Radiator fan fuse
3. Headlight fuse
4. Signaling system fuse
5. Ignition fuse
6. Spare fuse

If a fuse is blown, replace it as follows.

1. Turn the key to “OFF” and turn off the electrical circuit in question.
2. Remove the blown fuse, and then install a new fuse of the specified amperage. **WARNING! Do not use a fuse of a higher amperage rating than recommended to avoid causing extensive damage to the electrical system and possibly a fire.** [EWA15131]

Specified fuses:
Main fuse:
30.0 A
Cruise control fuse:
10.0 A
Carburetor heater fuse:
10.0 A
Auxiliary DC connector fuse:
5.0 A
Auxiliary DC jack fuse:
5.0 A
Audio system fuse:
10.0 A
Ignition fuse:
10.0 A
Signaling system fuse:
15.0 A
Headlight fuse:
15.0 A
Radiator fan fuse:
10.0 A
Backup fuse:
10.0 A

3. Turn the key to “ON” and turn on the electrical circuit in question to check if the device operates.
4. If the fuse immediately blows again, have a Yamaha dealer check the electrical system.

EAU23764

Replacing the headlight bulb

This model is equipped with a halogen bulb headlight. If the headlight bulb burns out, replace it as follows.

ECA10650

NOTICE

Take care not to damage the following parts:

- **Headlight bulb**
  Do not touch the glass part of the headlight bulb to keep it free from oil, otherwise the transparency of the glass, the luminosity of the bulb, and the bulb life will be adversely affected. Thoroughly clean off any dirt and fingerprints on the headlight bulb using a cloth moistened with alcohol or thinner.
- **Headlight lens**
  Do not affix any type of tinted film or stickers to the headlight lens.
  Do not use a headlight bulb of a wattage higher than specified.



1. Do not touch the glass part of the bulb.

1. Disconnect the headlight coupler, and then remove the headlight bulb cover.



1. Headlight bulb cover
2. Headlight coupler

2. Unhook the headlight bulb holder, and then remove the burnt-out bulb.



1. Headlight bulb holder

3. Place a new headlight bulb into position, and then secure it with the bulb holder.
4. Install the headlight bulb cover, and then connect the coupler.
5. Have a Yamaha dealer adjust the headlight beam if necessary.

EAU24283

Replacing a turn signal light bulb or the tail/brake light bulb

1. Remove the lens by removing the screws.



1. Screw



1. Screw

2. Remove the burnt-out bulb by pushing it in and turning it counterclockwise.
3. Insert a new bulb into the socket, push it in, and then turn it clockwise until it stops.
4. Install the lens by installing the screws. ***NOTICE:*** **Do not overtighten the screws, otherwise the lens may break.** [ECA10681]

EAU24350

Supporting the motorcycle

Since this model is not equipped with a centerstand, follow these precautions when removing the front and rear wheel or performing other maintenance requiring the motorcycle to stand upright. Check that the motorcycle is in a stable and level position before starting any maintenance. A strong wooden box can be placed under the engine for added stability.

To service the front wheel

1. Stabilize the rear of the motorcycle by using a motorcycle stand or, if an additional motorcycle stand is not available, by placing a jack under the frame in front of the rear wheel.
2. Raise the front wheel off the ground by using a motorcycle stand.

To service the rear wheel

Raise the rear wheel off the ground by using a motorcycle stand or, if a motorcycle stand is not available, by placing

a jack either under each side of the frame in front of the rear wheel or under each side of the swingarm.

EAU25871

Troubleshooting

Although Yamaha motorcycles receive a thorough inspection before shipment from the factory, trouble may occur during operation. Any problem in the fuel, compression, or ignition systems, for example, can cause poor starting and loss of power.

The following troubleshooting charts represent quick and easy procedures for checking these vital systems yourself. However, should your motorcycle require any repair, take it to a Yamaha dealer, whose skilled technicians have the necessary tools, experience, and know-how to service the motorcycle properly.

Use only genuine Yamaha replacement parts. Imitation parts may look like Yamaha parts, but they are often inferior, have a shorter service life and can lead to expensive repair bills.

EWA15141

⚠ WARNING

When checking the fuel system, do not smoke, and make sure there are no open flames or sparks in the area, including pilot lights from water heaters or furnaces. Gasoline or gasoline vapors can ignite or explode, causing severe injury or property damage.

EAU42313

Troubleshooting charts

Starting problems or poor engine performance



Engine overheating

EWAT1040

⚠ WARNING

- **Do not remove the radiator cap when the engine and radiator are hot. Scalding hot fluid and steam may be blown out under pressure, which could cause serious injury. Be sure to wait until the engine has cooled.**
- **Place a thick rag, like a towel, over the radiator cap, and then slowly rotate the cap counterclockwise to the detent to allow any residual pressure to escape. When the hissing sound has stopped, press down on the cap while turning it counterclockwise, and then remove the cap.**



8

TIP

If coolant is not available, tap water can be temporarily used instead, provided that it is changed to the recommended coolant as soon as possible.

EAU37833

Matte color caution

ECA15192

NOTICE

Some models are equipped with matte colored finished parts. Be sure to consult a Yamaha dealer for advice on what products to use before cleaning the vehicle. Using a brush, harsh chemical products or cleaning compounds when cleaning these parts will scratch or damage their surface. Wax also should not be applied to any matte colored finished parts.

EAU26123

Cleaning

Frequent, thorough cleaning of your motorcycle not only enhances its appearance, but also improves its performance and extends its life.

ECA10732

NOTICE

- **Improper cleaning can damage plastic parts (such as cowlings, panels, windshields, headlight lenses, meter lenses, etc.) and the mufflers. Use only a soft, clean cloth or sponge with water to clean plastic. However, if the plastic parts cannot be thoroughly cleaned with water, diluted mild detergent with water may be used. Be sure to rinse off any detergent residue using plenty of water, as it is harmful to plastic parts. If the windshield is scratched, use a quality plastic polishing compound after washing.**
- **Do not use any harsh chemical products on plastic parts. Make sure to avoid using cloths or sponges which have been in contact with strong or abrasive cleaning products, solvent or thinner, fuel (gasoline), rust removers or inhibitors, brake fluid, antifreeze or electrolyte.**

Before cleaning the motorcycle

1. Cover the muffler outlets, to prevent water entry, with plastic bags and strong rubber bands.
2. Make sure that the spark plugs and all caps and covers are properly installed.
3. Apply Yamaha Mud and Grease Release or another high-quality degreaser to the crankcase, to remove any excessive grease, with a paintbrush. Do not apply degreaser to the wheel axles.

Cleaning the motorcycle

ECA10940

NOTICE

- **Do not use high-pressure washers, since excessive high pressure may cause water seepage and deterioration of wheel bearings, the front fork, brakes,**

transmission seals, audio system, speakers, saddlebags, travel trunk and electrical parts.

- **Many expensive repair bills have resulted from improper high-pressure washer applications, such as those available at coin-operated car washers.**

1. Rinse any dirt and degreaser off with a garden hose, using only enough pressure to do the job.
2. Once the majority of the dirt has been hosed off, wash all surfaces with warm water and a mild detergent. Use a toothbrush or bottlebrush to get into those hard-to-reach places.
3. Rinse the motorcycle off immediately with clean water and dry all surfaces with a chamois, clean towel, or soft absorbent cloth.
4. Clean the seat with Yamaha Protectant or another high-quality vinyl upholstery cleaner to keep the cover pliable and glossy.

Cleaning the windshield

Avoid using any alkaline or strong acid cleaner, gasoline, brake fluid, or any other solvent. Clean the windshield with a cloth or sponge dampened with a mild detergent, and then wash it off thoroughly with water. For additional cleaning, use Yamaha Windshield Cleaner or another high-quality windshield cleaner. Some cleaning compounds for plastics may leave scratches on the windshield. Before using such cleaners, test an area of the windshield which does not affect your visibility and which cannot be easily recognized.

After cleaning the motorcycle

Apply Yamaha Silicone Wax or another high-quality automotive-type wax on all painted and chrome-plated surfaces. Avoid combination cleaner-waxes, since many contain abrasives that may mar the paint or protective finish. When finished, start the engine and let it idle for several minutes.

TIP

Washing, rainy weather or humid climates can cause the headlight lens to fog. Turning the headlight on for a short period of time will help remove the moisture from the lens.

Storage

EAU26252

Short-term

Always store your motorcycle in a cool, dry place and, if necessary, protect it against dust with a porous cover. Be sure the engine and the exhaust system are cool before covering the motorcycle.

ECA10810

NOTICE

- **Storing the motorcycle in a poorly ventilated room or covering it with a tarp, while it is still wet, will allow water and humidity to seep in and cause rust.**
- **To prevent corrosion, avoid damp cellars, stables (because of the presence of ammonia) and areas where strong chemicals are stored.**

Long-term

Before storing your motorcycle for several months:

1. Follow all the instructions in the "Care" section of this chapter.
2. For motorcycles equipped with a fuel cock that has an "OFF" position: Turn the fuel cock lever to "OFF".
3. Drain the carburetor float chamber by loosening the drain bolt; this will prevent fuel deposits from building up. Pour the drained fuel into the fuel tank.
4. Fill up the fuel tank and add fuel stabilizer (if available) to prevent the fuel tank from rusting and the fuel from deteriorating.
5. Perform the following steps to protect the cylinders, piston rings, etc. from corrosion.
   a. Remove the spark plug caps and spark plugs.
   b. Pour a teaspoonful of engine oil into each spark plug bore.
   c. Install the spark plug caps onto the spark plugs, and then place the spark plugs on the cylinder head so that the electrodes are grounded. (This will limit sparking during the next step.)
   d. Turn the engine over several times with the starter. (This will coat the cylinder walls with oil.)

      WARNING! To prevent damage or injury from sparking, make sure to ground the spark plug electrodes while turning the engine over.

      [EWA10951]

   e. Remove the spark plug caps from the spark plugs, and then install the spark plugs and the spark plug caps.
6. Lubricate all control cables and the pivoting points of all levers and pedals as well as of the sidestand/centerstand.
7. Check and, if necessary, correct the tire air pressure, and then lift the motorcycle so that both of its wheels are off the ground. Alternatively, turn the wheels a little every month in order to prevent the tires from becoming degraded in one spot.
8. Cover the muffler outlets with plastic bags to prevent moisture from entering them.
9. Remove the battery and fully charge it. Store it in a cool, dry place and charge it once a month. Do not store the battery in an ex-

cessively cold or warm place [less than 0 °C (30 °F) or more than 30 °C (90 °F)]. For more information on storing the battery, see page 8-32.

TIP

Make any necessary repairs before storing the motorcycle.

Dimensions:
Overall length:
2655 mm (104.5 in)
Overall width:
900 mm (35.4 in)
Overall height:
1565 mm (61.6 in)
Seat height:
750 mm (29.5 in)
Wheelbase:
1705 mm (67.1 in)
Ground clearance:
155 mm (6.10 in)
Minimum turning radius:
3500 mm (137.8 in)

Weight:
Curb weight:
394 kg (869 lb)

Engine:
Engine type:
Liquid cooled 4-stroke, DOHC
Cylinder arrangement:
V-type 4-cylinder
Displacement:
1294 cm³
Bore × stroke:
79.0 × 66.0 mm (3.11 × 2.60 in)
Compression ratio:
10.00 : 1
Starting system:
Electric starter
Lubrication system:
Wet sump

Engine oil:
Recommended brand:
YAMALUBE
Type:
SAE 10W-30, 10W-40, 10W-50, 15W-40, 20W-40 or 20W-50



Recommended engine oil grade:
API service SG type or higher, JASO standard MA
Engine oil quantity:
Without oil filter cartridge replacement:
3.50 L (3.70 US qt, 3.08 Imp.qt)
With oil filter cartridge replacement:
3.70 L (3.91 US qt, 3.26 Imp.qt)

Final gear oil:
Type:
SAE 80 API GL-4 Hypoid gear oil
Quantity:
0.20 L (0.21 US qt, 0.18 Imp.qt)

Cooling system:
Coolant reservoir capacity (up to the maximum level mark):
0.35 L (0.37 US qt, 0.31 Imp.qt)
Radiator capacity (including all routes):
3.50 L (3.70 US qt, 3.08 Imp.qt)

Air filter:
Air filter element:
Dry element

Fuel:
Recommended fuel:
Unleaded gasoline only
Fuel tank capacity:
22.5 L (5.94 US gal, 4.95 Imp.gal)
Fuel reserve amount:
3.5 L (0.92 US gal, 0.77 Imp.gal)

Carburetor:
Type × quantity:
BDSR32 x 4

Spark plug(s):
Manufacturer/model:
NGK/DPR8EA-9
Manufacturer/model:
DENSO/X24EPR-U9
Spark plug gap:
0.8–0.9 mm (0.031–0.035 in)

Clutch:
Clutch type:
Wet, multiple-disc

Transmission:
Primary reduction ratio:
1.776 (87/49)
Final drive:
Shaft
Secondary reduction ratio:
2.567 (21/27 x 33/10)
Transmission type:
Constant mesh 5-speed

Operation:
Left foot operation
Gear ratio:
1st:
2.529 (43/17)
2nd:
1.632 (31/19)
3rd:
1.200 (30/25)
4th:
0.960 (24/25)
5th:
0.786 (22/28)

Chassis:
Frame type:
Double cradle
Caster angle:
29.17 °
Trail:
152 mm (6.0 in)

Front tire:
Type:
Tubeless
Size:
150/80-16M/C 71H
Manufacturer/model:
DUNLOP/D404F
Manufacturer/model:
BRIDGESTONE/G705G

Rear tire:
Type:
Tubeless
Size:
150/90B15M/C 74H
Manufacturer/model:
DUNLOP/D404
Manufacturer/model:
BRIDGESTONE/G702G

Loading:
Maximum load:
190 kg (419 lb)
(Total weight of rider, passenger, cargo and accessories)

Tire air pressure (measured on cold tires):
Loading condition:
0–90 kg (0–198 lb)
Front:
250 kPa (2.50 kgf/cm², 36 psi)
Rear:
250 kPa (2.50 kgf/cm², 36 psi)
Loading condition:
90–190 kg (198–419 lb)
Front:
250 kPa (2.50 kgf/cm², 36 psi)
Rear:
280 kPa (2.80 kgf/cm², 41 psi)

Front wheel:
Wheel type:
Cast wheel
Rim size:
16M/C x MT3.50

Rear wheel:
Wheel type:
Cast wheel
Rim size:
15M/C x MT4.00

Front brake:
Type:
Dual disc brake
Operation:
Right hand operation
Specified brake fluid:
DOT 4

Rear brake:
Type:
Single disc brake
Operation:
Right foot operation
Specified brake fluid:
DOT 4

Front suspension:
Type:
Telescopic fork
Spring/shock absorber type:
Coil-air spring/oil damper
Wheel travel:
140.0 mm (5.51 in)

Rear suspension:
Type:
Swingarm (link suspension)
Spring/shock absorber type:
Coil-air spring/oil damper
Wheel travel:
105.0 mm (4.13 in)

Electrical system:
Ignition system:
TCI
Charging system:
AC magneto

Battery:
Model:
YTX20L-BS
Voltage, capacity:
12 V, 18.0 Ah

Headlight:
Bulb type:
Halogen bulb

Bulb voltage, wattage × quantity:
Headlight:
12 V, 60 W/55 W × 1
Tail/brake light:
12 V, 8.0 W/27.0 W × 1
Front turn signal/position light:
12 V, 23 W/8.0 W × 2
Rear turn signal light:
12 V, 21.0 W × 2
Neutral indicator light:
12 V, 1.7 W × 1
High beam indicator light:
12 V, 1.7 W × 1
Oil level warning light:
12 V, 1.7 W × 1
Turn signal indicator light:
12 V, 1.7 W × 2
Fuel level warning light:
14 V, 3.0 W × 1
Coolant temperature warning light:
12 V, 1.7 W × 1
Engine trouble warning light:
12 V, 1.7 W × 1
Overdrive indicator light:
12 V, 1.7 W × 1
Cruise control "SET" indicator light:
12 V, 1.7 W × 1
Cruise control "RES" indicator light:
12 V, 1.7 W × 1
Cruise control "ON" indicator light:
12 V, 1.7 W × 1

Audio system amplifier:
Speaker output:
14 W × 4
Headset output:
1 W × 2
Auto volume range:
5 steps
Speaker impedance:
4 Ω
Headset impedance:
8-16 Ω

Fuses:
Main fuse:
30.0 A
Headlight fuse:
15.0 A
Signaling system fuse:
15.0 A
Ignition fuse:
10.0 A
Radiator fan fuse:
10.0 A
Carburetor heater fuse:
10.0 A
Cruise control fuse:
10.0 A
Audio system fuse:
10.0 A
Auxiliary DC connector fuse:
5.0 A
Auxiliary DC jack fuse:
5.0 A
Backup fuse:
10.0 A

EAU26353

Identification numbers

Record the key identification number, vehicle identification number and model label information in the spaces provided below for assistance when ordering spare parts from a Yamaha dealer or for reference in case the vehicle is stolen.

KEY IDENTIFICATION NUMBER:

VEHICLE IDENTIFICATION NUMBER:

MODEL LABEL INFORMATION:

EAU26381

Key identification number



1. Key identification number

The key identification number is stamped into the key tag. Record this number in the space provided and use it for reference when ordering a new key.

EAU26400

Vehicle identification number



1. Vehicle identification number

The vehicle identification number is stamped into the steering head pipe. Record this number in the space provided.

TIP

The vehicle identification number is used to identify your motorcycle and may be used to register your motorcycle with the licensing authority in your area.

EAU26470

Model label



1. Model label

The model label is affixed to the frame under the rider seat. (See page 4-14.) Record the information on this label in the space provided. This information will be needed when ordering spare parts from a Yamaha dealer.

EAU48270

Vehicle Emission Control Information label



1. Vehicle Emission Control Information label

The Vehicle Emission Control Information label is affixed at the location in the illustration. This label shows specifications related to exhaust emissions as required by federal law, state law and Environment Canada.

EAU26551

Reporting safety defects

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Yamaha Motor Corporation, U.S.A. If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Yamaha Motor Corporation, U.S.A.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to http://www.safercar.gov; or write to: Administrator, NHTSA, 400 Seventh Street, SW., Washington, DC 20590. You can also obtain other information about motor vehicle safety from http://www.safercar.gov.

EAU26560

Motorcycle noise regulation

TAMPERING WITH NOISE CONTROL SYSTEM PROHIBITED:

Federal law prohibits the following acts or the causing thereof: (1) The removal or rendering inoperative by any person other than for purposes of maintenance, repair, or replacement of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use or (2) the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

“AMONG THOSE ACTS PRESUMED TO CONSTITUTE TAMPERING ARE THE ACTS LISTED BELOW”.

These acts include tampering with the following systems; i.e., modification, removal, etc.

Exhaust system
- Muffler
- Exhaust pipe
- Silencer

Intake system
- Air cleaner case
- Air cleaner element
- Intake duct

EAU26632

Maintenance record

Copies of work orders and/or receipts for parts purchased and installed on your vehicle will be required to document that maintenance has been completed in accordance with the emissions warranty. The chart below is printed only as a reminder that maintenance work is required. It is not acceptable proof of maintenance work.

Maintenance interval	Date of service	Mileage	Servicing dealer name and address	Remarks
600 mi (1000 km) or 1 month				
4000 mi (7000 km) or 6 months				
8000 mi (13000 km) or 12 months				
12000 mi (19000 km) or 18 months				
16000 mi (25000 km) or 24 months				
20000 mi (31000 km) or 30 months				
24000 mi (37000 km) or 36 months				
28000 mi (43000 km) or 42 months				
32000 mi (49000 km) or 48 months				

Maintenance interval	Date of service	Mileage	Servicing dealer name and address	Remarks
36000 mi (55000 km) or 54 months				
40000 mi (61000 km) or 60 months				

EAU26703

YAMAHA MOTOR CORPORATION, U.S.A. ROYAL STAR™ VENTURE® LIMITED WARRANTY

Yamaha Motor Corporation, U.S.A. hereby warrants that each new Yamaha Royal Star Venture motorcycle purchased from an authorized Yamaha motorcycle dealer in the continental United States will be free from defects in material or workmanship for the period of time stated herein, subject to certain stated limitations.

THE PERIOD OF WARRANTY for the Yamaha Royal Star Venture, including windshield, saddlebags, and mounting hardware installed as original equipment, shall be five (5) years from the date of purchase, regardless of mileage.

MODELS EXCLUDED FROM WARRANTY include those used for non-Yamaha-authorized renting, leasing, or other commercial purposes.

DURING THE PERIOD OF WARRANTY any authorized Yamaha motorcycle dealer will, free of charge, repair or replace any part adjudged defective by Yamaha due to faulty workmanship or material from the factory. Parts used in warranty repairs will be warranted for the balance of the product's warranty period. All parts replaced under warranty become property of Yamaha Motor Corporation, U.S.A..

GENERAL EXCLUSIONS from this warranty shall include any failures caused by:

a. Competition or racing use.
b. Installation of parts or accessories that are not qualitatively equivalent to genuine Yamaha parts.
c. Abnormal strain, neglect, or abuse.
d. Lack of proper maintenance or storage.
e. Accident or collision damage.
f. Modification to original parts.
g. Damage due to improper transportation.

SPECIFIC EXCLUSIONS from this warranty shall include:

1. The cost of parts and labor for routine maintenance or normal wear and tear. Examples include periodic oil changes and lubrication, filter cleaning and replacement, spark plugs, tune-ups, coolant, and brake and clutch adjustments.
2. Battery deterioration caused by improper maintenance and/or storage.

THE CUSTOMER'S RESPONSIBILITY under this warranty shall be to:
Operate and maintain the Royal Star Venture as specified in the appropriate Owner's Manual, and Give notice to an authorized Yamaha motorcycle dealer of any and all apparent defects within ten (10) days after discovery, and make the machine available at that time for inspection and repairs at such dealer's place of business.

WARRANTY TRANSFER

To transfer the warranty from the original purchaser to any subsequent purchaser, it is imperative that the machine be inspected and registered for warranty by an authorized Yamaha motorcycle dealer. In order for this warranty to remain in effect, this inspection and registration must take place within ten (10) days after transfer of ownership to the subsequent purchaser. A reasonable dealer-imposed fee may be charged for the inspection.

AUDIO WARRANTY

Yamaha Motor Corporation, U.S.A. warrants that factory-installed audio components which prove defective due to improper workmanship or material will be repaired or replaced, at Yamaha's option, without charge for parts or labor for a period of five (5) years from the date of purchase of the motorcycle, subject to certain stated limitations.

This warranty excludes audio components damaged or affected by:

1. Accident or collision.
2. Misuse or neglect.
3. Alteration, improper installation or connection.
4. Unauthorized adjustment or repairs.
5. Use in an application for which the audio component was not designed.

In addition, any audio component which has had the serial number in any way tampered with or removed will be excluded from warranty.

This warranty does not cover the elimination of static or other electrical interference.
Audio components and parts repaired or replaced under this warranty will be warranted for the balance of the audio warranty period. All defective components or parts replaced under the warranty become the property of Yamaha Motor Corporation, U.S.A.

EMISSIONS CONTROL SYSTEM WARRANTY

Yamaha Motor Corporation, U.S.A. also warrants to the ultimate purchaser and each subsequent purchaser of each Royal Star Venture that the vehicle is designed, built, and equipped so as to conform at the time of sale with all U.S. emissions standards applicable at the time of manufacture, and that it is free from defects in materials and workmanship which would cause it not to meet these standards for 18, 642 miles (30,000 km) or five years, whichever occurs first. Failures other than those resulting from defects in material or workmanship which arise solely as a result of owner abuse and/or lack of proper maintenance are not covered by this warranty.

YAMAHA MOTOR CORPORATION, U.S.A. MAKES NO OTHER WARRANTY OF ANY KIND, EXPRESSED OR IMPLIED. ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE WHICH EXCEED THE OBLIGATIONS AND TIME LIMITS STATED IN THIS WARRANTY ARE HEREBY DISCLAIMED BY YAMAHA MOTOR CORPORATION, U.S.A. AND EXCLUDED FROM THIS WARRANTY.

SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. ALSO EXCLUDED FROM THIS WARRANTY ARE ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES INCLUDING LOSS OF USE. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE EXCLUSIONS MAY NOT APPLY TO YOU.

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

YAMAHA MOTOR CORPORATION, U.S.A.
Post Office Box 6555
Cypress, CA 90630

WARRANTY QUESTIONS AND ANSWERS

Q. What costs are my responsibility during the warranty period?
A. The customer's responsibility includes all costs of normal maintenance services, non-warranty repairs, accident and collision damage, and oil, oil filters, air filters, spark plugs, and brake shoes or pads.

Q. What are some examples of "abnormal" strain, neglect, or abuse?
A. These terms are general and overlap each other in areas. Specific examples include: Running the machine out of oil, sustained high-rpm, full-throttle use; operating the machine with a broken or damaged part which causes another part to fail; damage or failure due to improper or careless transportation and or tie down; and so on. If you have any specific questions on operation or maintenance, please contact your dealer for advice.

Q. Does the warranty cover incidental costs such as towing or transportation due to a failure?
A. No. The warranty is limited to repair of the machine itself.

Q. May I perform any or all of the recommended maintenance shown in the Owner's Manual instead of having the dealer do them?
A. Yes, if you are a qualified mechanic and follow the procedures specified in the Owner's and Service Manual. We do recommend, however, that items requiring special tools or equipment be done by Yamaha motorcycle dealer.

Q. Will the warranty be void or cancelled if I do not operate or maintain my new motorcycle exactly as specified in the Owner's Manual?
A. No. The warranty on a new motorcycle cannot be "voided" or "cancelled." **However, if a particular failure is caused by operation or maintenance other than as shown in the Owner's Manual, that failure may not be covered under warranty.**

Q. What responsibility does my dealer have under this warranty?
A. Each Yamaha Motorcycle dealer is expected to:
1. Completely set up every new machine before sale.
2. Explain the operation, maintenance, and warranty requirements to your satisfaction at the time of sale, and upon your request at any later date.

In addition, each Yamaha motorcycle dealer is held responsible for his setup, service and warrnaty repair work.

Q. Is the warranty transferable to second owners?

A. Yes. The remainder of the existing warranty can be transferred upon request. The unit has to be inspected and re-registered by an authorized Yamaha motorcycle dealer for the warranty coverage to remain effective.

CUSTOMER SERVICE

If your machine requires warranty service, you must take it to any authorized Yamaha motorcycle dealer within the continental United States. Be sure to bring your warranty registration identification or other valid proof of the original date of purchase. If a question or problem arises regarding warranty, first contact the owner of the dealership. Since all warranty matters are handled at the dealer level, this person is in the best position to help you. If you are still not satisfied and require additional assistance, please write:

YAMAHA MOTOR CORPORATION U.S.A.
CUSTOMER RELATIONS DEPARTMENT
P.O. Box 6555
Cypress, California 90630

When contacting Yamaha Motor Corporation, U.S.A. don't forget to include any important information such as names, addresses, model, V.I.N. (frame number), dates, and receipts.

CHANGE OF ADDRESS

The federal government requires each manufacturer of a motor vehicle to maintain a complete, up-to-date list of all first purchasers against the possibility of a safety-related defect and recall. This list is compiled from the purchase registrations sent to Yamaha Motor Corporation, U.S.A. by the selling dealer at the time of your purchase.

If you should move after you have purchased your new motorcycle, please advise us of your new address by sending a postcard listing your motorcycle model name, V.I.N. (frame number), dealer number (or dealer's name) as it is shown on your warranty identification, your name and new mailing address. Mail to:

YAMAHA MOTOR CORPORATION, U.S.A.
P.O. Box 6555
Cypress, California 90630
Attention: Warranty Department

This will ensure that Yamaha Motor Corporation, U.S.A. has an up-to-date registration record in accordance with federal law.

INDEX

A

Air filter elements, cleaning 8-19
Audio settings (basic) 5-4
Audio settings (modes) 5-6
Audio system 5-1
Auxiliary audio source 5-20
Auxiliary DC jack and connector 4-22

B

Battery 8-32
Brake and clutch fluid levels, checking 8-26
Brake and clutch fluids, changing 8-28
Brake and clutch levers, checking and lubricating 8-29
Brake and shift pedals, checking and lubricating 8-29
Brake lever 4-10
Brake lever free play, adjusting 8-25
Brake light switches 8-25
Brake pedal 4-10

C

Cables, checking and lubricating 8-28
Canister (for California only) 8-13
Carburetors 8-21
Cassette deck operation 5-9
CB radio operation 5-16
CD changer operation 5-15
Cleaning 9-1
Clutch lever 4-9, 8-24
Coolant 8-18
Coolant temperature warning light 4-3
Cowlings and panels, removing and installing 8-9
Cruise control indicator lights 4-3
Cruise control switches 4-9
Cruise control system 4-5

D

Dimmer switch 4-8

E

Engine break-in 7-4
Engine idling speed, checking 8-21
Engine oil and oil filter cartridge 8-14
Engine, starting a warm 7-2
Engine stop switch 4-8
Engine trouble warning light 4-3

F

Final gear oil 8-16
Front and rear brake pads, checking 8-26
Front fork, adjusting 4-18
Front fork, checking 8-31
Fuel 4-11
Fuel cock 4-13
Fuel level warning light 4-3
Fuel tank breather/overflow hose 4-12
Fuel tank cap 4-10
Fuses, replacing 8-33

H

Handlebar switches 4-7
Hazard switch 4-8
Headlight bulb, replacing 8-35
Headsets 5-2
Helmet holders 4-15
High beam indicator light 4-3
Horn switch 4-8

I

Identification numbers 11-1
Ignition circuit cut-off system 4-20
Indicator lights and warning lights 4-2

K

Key identification number 11-1

L

Labels, location 1-1

M

Main switch/steering lock 4-1
Maintenance and lubrication, periodic 8-5
Maintenance, emission control system 8-3
Maintenance record 11-5
Matte color, caution 9-1
Model label 11-2

N

Neutral indicator light 4-2
Noise regulation 11-4

O

Oil level warning light 4-3
Overdrive indicator light 4-3

P

Parking 7-4
Part locations 3-1
Parts, location of 5-1

R

Radio operation 5-11
Rear suspension, lubricating 8-30
Rider seat 4-14

S

Safety defects, reporting 11-3
Safety information 2-1
Self-diagnosis device 4-7
Shifting 7-2
Shift pedal 4-9
Shock absorber assembly, adjusting 4-19
Sidecases and travel trunk 4-16
Sidestand 4-20

INDEX

Sidestand, checking and lubricating 8-30
Sound control unit 5-3
Spark plugs, checking 8-12
Specifications 10-1
Speedometer unit 4-4
Starter (choke) knob 4-14
Starting and warming up a cold engine 7-1
Start switch 4-8
Steering, checking 8-31
Steering, locking with a padlock 4-14
Storage 9-3
Supporting the motorcycle 8-36
Swingarm pivots, lubricating 8-30

T

TALK switch 4-8
Throttle grip and cable, checking and lubricating 8-28
Throttle grip free play, checking 8-21
Tires 8-22
Tool kit 8-2
Troubleshooting 8-37
Troubleshooting charts 8-38
Turn signal indicator lights 4-2
Turn signal light bulb or tail/brake light bulb, replacing 8-36
Turn signal switch 4-8

V

Valve clearance 8-22
Vehicle Emission Control Information label 11-2
Vehicle identification number 11-1

W

Warranty, limited 11-7
Wheel bearings, checking 8-32
Wheels 8-24

For your best ownership experience, think **Genuine Yamaha!**

Genuine Yamaha Parts – Genuine Yamaha replacement parts are the exact same parts as the ones originally equipped on your vehicle, providing you with the performance and durability you have come to expect. Why settle for aftermarket parts that may not provide full confidence and satisfaction?

Genuine Yamaha Accessories – Yamaha only offers accessories that meet our high standards for quality and performance. Buy with confidence, knowing your Genuine Yamaha Accessories will fit right and perform right – right out of the box.

Yamalube – Take care of your Yamaha with legendary Yamalube oils, lubricants, and care products. They're formulated and approved by the toughest judges we know: the Yamaha engineering teams that know your Yamaha from the inside out.

Genuine Yamaha Service Manuals – Get the same factory manual for your vehicle that the technicians at your authorized Yamaha dealer use. Service manuals are available through your Yamaha dealer or you can order them directly through yamahapubs.com.

Genuine Yamaha products are available only from your Yamaha dealer.

Find out more at yamaha-motor.com

PRINTED ON RECYCLED PAPER

PRINTED IN JAPAN
2011.08-0.3×1 CR
(E)