

PROSCAN

PLT7064

User Manual



Introduction

Thank you for your choosing the Intel QuadCore 7” Window Tablet PC.

This guide serves to enable users to get to know and familiar with our product as soon as possible. Here we have made a brief introduction to the key layout and definitions in figures and words.

Contents


I . Precautions before Use	02
II . Key Layout and Definitions	03
III. Introduction to Desktop.....	04
Windows8.1 Start Screen	04
Image Slide Application	04
Introduction to apps Introduction.....	05
Charm Menu Column	06
Double Screen Application	08
IV. Basic Operations	09
Dormancy, Restart, and Power off	09
Security Management	09
V. Media Function	10
Camera	10
Browser.....	10
Xbox Music	11
VI. Specification	12

I . Precautions before Use

This production is suitable for use in non-tropic areas below 2,000 meters, and the mark  in the nameplate indicates the product is suitable for use in non-tropic areas.

2. Prevent the Tablet PC from falling to the ground or being strongly impacted otherwise.
1. Do not use it in the long term in any environment where the air is too cold, too hot (<35 °C), too humid or with too much dust. Do not expose the Tablet PC to sunlight.
4. Avoid using it in the strong magnetic and strong static environment as much as possible.
5. Once any water or other liquid splashes onto the Tablet PC, close it immediately and do not use it until it dries out.
1. Do not clean the Tablet PC with any detergent containing chemical element or other liquid to avoid causing damage due to corrosion and becoming damp. If cleaning is really necessary, clean it with dry soft cloth tissue paper.
7. Our company shall not bear any and all responsibilities for loss or deletion of material inside the machine caused due to abnormal software and hardware operation, maintenance or any other accident.
8. Please back up your important material at any time to avoid loss.
9. Please do not disassemble the Tablet PC by yourself; otherwise you will lose the right to warranty.
10. Quick Use Guide and the relevant software shall be updated at any time. For updated software version, visit <http://www.proscanvideo.com> for downloading by yourself, and no notice shall be given otherwise. If any anything is found to be inconsistent with the Quick Use Guide, the material object shall prevail.
11. Replacement with incorrect type batteries may cause explosion. Make sure to use original batteries.

II .Key Layout and Definitions



- ① Front Camera: take photos, and record pictures
- ② Loudspeaker: The built-in loudspeaker enables you to hear the sound without having to linking additional device.
- ③ Socket for earphone: This socket can transmit the audio signals of Tablet PC to earphone.
- ④ Micro USB Interface: You can read the data through USB or Recharge the device.
- ⑤ Rear Camera: take photos, and record pictures
- ⑥ Power Key: Press it down to start or close the touch screen panel. You can also let the computer to enter dormancy through this button or wake from the dormancy mode.
- ⑦、⑧ Volume +/- : adjustment volume
- ⑨ MicroSD& MicroSDHC Format Micro SD card slot: The built-in storage card reader slot supports MicroSD and MicroSDHC format.
- ⑩ Microphone connector outlet

III. Introduction to Desktop

1. Windows 8.1 start image: On the start screen, you can see many programs fixed in the image.

These application programs are displayed in the form of “magnet”. As long as you click them, you can easily visit them.

You need to log on your Microsoft account before the application program completely runs.



2. Image slide applications

Slide to right



Slide to the right from the left side of the screen to start the application program in running.

Slide to left



Slide to the left from the right side of the screen to start Charm menu column

Reduce



On the touch screen, narrow two fingers to reduce the image.

Slide with finger



In start screen, slide finger right and left to move the image.

Enlarge



On the touch screen, widen two fingers to enlarge the image.


Slide upward




In the start screen, slide upward from the bottom of the screen to visit all application program(APPS) interfaces.

3.Introduction to app Interface


Besides the application programs already fixed on the start screen, you can also start other application programs in all application programs, such as other software application programs attached to the Tablet PC.



If you want to fix more application programs on the start interface, see the operation in the figure below, (1) lightly touch, press and hold the application program magnet for about one second and then let go, and select (2) to fix to the start screen.




Conversely, if you want to cancel or delete a certain application in the start screen, (1) lightly touch, press and hold the application program magnet for about one second and then let it go and run, and select (2) attribute column to cancel the programs such as fixation and deletion and then it can be completed.



4. Charm menu column

Slide it to the left from the right side of the screen to start Charm menu column, including: Start, Device, Setup, Share, and Search Program.



Slide it to the left from the right side of the screen to start Charm menu column, including: Start, Device, Setup, Share, and Search Program.



Can let you search the files and application programs in the Tablet PC.



Can let you share the program through social exchange website or e-mail.



Can return to the start screen. From the start screen, you can also use this function to return the application program that is opened in the latest.



Can let you read, write and share files, connect external screen or printer with the device connected to the Tablet PC.




Can let you set up the Table PC.

Search menu



Device Menu

Share menu



Set up Menu




5. Dual-Screen Application

On my computer in (Figure 1), slide it inward from the left side of the screen, drag it and hold. Let go when seeing double interfaces appear.

In (Figure 2), press the partition button on the middle partition line and drag right and left to partition the display proportion of the double screens.




(Figure 1)



(Figure 2)


IV. Basic Operations

1. Dormancy, restart and power off



2. Security Management

User and password setup



Method for quick setup:

Click the “Setup” button in “Charm” setup, and select “Change computer setup”. Select “User” on the left and click “Create local account” in “Your account” on the right side. After inputting the password of Complete Windows Live Id Account, input username, password, confirm password and password prompt.

V. Media Function



1. In the star screen, click camera application procedure , enter into camera
Operation of camera




Operation of camera

- ①. Camera Roll: to check the photo or video you are shoot
- ②. Change camera: change front and back camera
- ③. Timer: you can choose 3 second, 10 second, or off. Its support to take photo by time-lapse
- ④. Exposure: adjustment exposure
- ⑤. Video shooting
- ⑥. Click it to take photo


2. Browser

In case of Wi-Fi internet is connected well click IE browser

Type the website you want to visit then you can enjoy the internet browser



3, Xbox Music



①Collection: Add songs to any folder on the PC

②Radio: Connect to the Internet, listen to Radio

③Explore: Connect to the Internet, download and listen to music

④New playlist: Add new playlist

⑤Import playlists: The system of importing music files

VI. Specification

Specifications:	
Product	7" Intel Quad Core Table With Windows 8.1
Processor	Intel Baytrail-T 1.8Ghz(Quad Core)(Z3735G)
Operating System	Windows 8.1 Preloaded
Memory	16 GB Built-In Memory
Expansion	microSD Card Slot Built-in(Support Max Upto 64GB)
Display Size	7" 1024×600 Screen
Resolution	Display 1024×600 dpi(High Resolution)
RAM Memory	1GB DDR3 Built-in(eMMC Fast Memory)For Faster Apps Run
Screen	7" Capacitive Multi-Touch Super Sensitive Screen
WiFi	IEEE 802.11 b/g/n
USB	Micro USB 2.0 Port For USB Drives&Charging
Bluetooth	Built-in Latest Bluetooth V4.0 EDR
Office	MS Office 365 Personal(Word,Excel,PowerPoint,OneNote&Outlook for 1 Year
Audio Output Jack	3.5mm Headphone Jack
Dual Camera	Back 2.0M Pixels&Front 0.3M Pixels
Speaker/Mic	Built-in Stereo Speaker&Microphone
G-Sensor	360°Gravity Induction For All side Easy View
Flash Player/Language	Support Flash Player 10.2&Above/Support Multiple Language
Power Adapter	Power Adapter AC100-240V(DC 5V,2A),USB Charge Capable
Battery	Rechargeable Li-ion Polymer Big Capacity Battery 2800 mAh/3.7V mah
Playback/Standby	Music:Up to 8 Hrs(Depends On Vol Select)
	Video:Up to 4 Hrs(Depends On Brightness Select)
	Web Browsing:Up To 5Hrs(Depends On Wi-Fi Signals)
Audio Files	WAV,MP3,MP2,AAC,AMR-NB,AMR-WB,MIDI,Vorbis,APE)
Video Files	Support 1080P,MEPG 1/2/4 H.263/H.264,RMVB,WMV/VC-1,MVC,AVS,MJPEG
Photo Files	JPEG,BMP,GIF,PNG(Support Upto 2592×1944 dpi pics size

FCC STATEMENT

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

P R O S C A N

PLT7064

Manuel de l'utilisateur



Introduction

Remerci de vous choisir l'Intel QuadCore 7" Window Tablet PC.

Cet manuel sert à faire les utilisateurs comprendre et connaître notre produit le plus vite possible. Voici c'est une introduction sommaire de la disposition importante et les définitions avec des chiffres et des mots.


CONTENUS

I .	Avertissements Préalables.....	02
II .	Dispositions importantes et Définitions.....	03
III.	Introduction de Desktop.....	04
	Écran Commence par Windows8.1.....	04
	Applicat d'image et de diapositive.....	04
	Introduction des Introductions des.....	05
	Colonne de Menu Charmant.....	06
	Applications à Double Écran.....	08
IV.	Opérations Basiques.....	09
	Sommeil, Redémarrer, et Éteindre l'équipement.....	09
	Gestion de la Sécurité.....	09
V.	Caractéristiques des Médias.....	10
	Appareil photographique.....	10
	Burineur.....	10
	Musique de Xbox.....	11
VI.	Spécification.....	12

I . Avertissement Préalable

1. Cet produit est adaptable que les utilisateurs l'utilise dans les régions non tropicales ci-dessous une altitude de 2,000 mètres,et la signe  sur le nom de marque indique que le produit est convenable d'utiliser dans les régions non tropicales.
2. Empêcher le Tablet PC tomber au sol ou avoir un fort impact.
3. Ne l'utilisez pas pendant une longue période dans les endroits froids,trop chaud(<35 °C), trop humide ou trop poussiéreux.Ne laissez pas le produit dans le soleil.
4. Évitez de l'utiliser dans un fort champ magnétique et un endroit avec une électricité statique très forte autant que possible.
5. Si l'eau ou d'autres liquides mouillent le Tablet PC,mettez-le immédiatement,ne pas l'utiliser jusqu'à ce qu'il sèche.
6. Ne pas utiliser n'importe quel liquide ou produit chimiques pour éviter la corrosion et l'humidité du produit. Si vous avez vraiment besoin de nettoyer le produit,utilisez la serviette en papier ou le chiffon doux sèche.
7. Notre entreprise ne assume pas aucune responsabilité causée par un mauvais fonctionnement (du hard et du soft) de la machine,l'entretien ou tout autre accident.
8. Sauvegarder vos matériaux importants pour éviter la perte à tout moment ,s'il vous plaît.
9. Ne dégrippez pas votre Tablet PC par vos propres moyens,autrement vous perdrez vos droits de garantie.
10. Le manuel et les logiciels connexes renouvellent constamment.Pour les renouveler,visitez <http://www.proscanvideo.com> pour télécharger par vous-même,et nous ne remarquerons pas par ailleurs.Basez sur le vrais produit si il y a des divergence avec le manuel.
11. Piles de type incompatibles peuvent provoquer une explosion.Assurez-vous d'utiliser la batterie d'origine.

II. Dispositions importante et Definitions



- ① Caméra frontale: photographier et enregistrer des images.
- ② Haut-parleur: Vous pouvez entendre le son par le haut-parleur encastré sans connecter des équipements supplémentaires.
- ③ Jack d'écouteurs: Cet jack peut transmettre le signal audio du produit vers les écouteurs.
- ④ Interface de Micro USB: Vous pouvez lire les datas via USB ou port de charge.
- ⑤ Caméra dorsale: Photographier et enregistrer des images.

⑥ Bouton d'alimentation: Pressez le bouton d'alimentation, vous pouvez démarrer ou désamorcer l'écran tactile. Vous pouvez faire cet ordinateur entrer l'hibernation ou le réveiller par ce bouton.

⑦、⑧ Volume + /- : Réglez le volume

⑨ Slot de Micro SD de Format de MicroSD& MicroSDHC: Le slot de Micro SD supporte les formats de Micro SD& Micro SDHC.

⑩ Jack de connecteur de microphone

III. Introduction de Desktop

1. Interface de démarrage de Windows 8.1 : Au début de l'interface, vous pouvez regarder beaucoup d'images des programmes.

Ces programmes déroulent par une forme d'aimant. Tant que vous cliquez sur eux, vous pouvez les visiter facilement.

Avant d'utiliser les applications, vous devez vous connecter à votre compte de Microsoft.



2. Applications d'images et de diapositive

Glissez à droite



Glissez de gauche à droite sur l'écran démarrer les application.
Colonne de Menu Charmant.

Glissez à gauche



Glissez de droite à gauche peut sur l'écran peut démarrer la.

Réduction



Sur l'écran tactile,contracter deuxdoigts pour réduire une image.

Glissez avec un doigts

Dilatation



Sur l'écran tactile,élargir la distance de deux doigts pour agrandir une image.

Glissez vers le haut




Sur l'écran de démarrage,glissez un doigt entre gauche et droite pour déplacer une image.




Sur l'écran de démarrage,glissez vers vers le haut de le bas d'écran pour visiter toutes les Interfaces de programmes des applications(APPS).

3. Introduction d'Interface d'app

Sauf les applications qui sont fixée sur l'écran de démarrage, vous pouvez démarrer autres applications dans toutes applications, par exemple les autres applications qui connectent à le Tablet PC.



Si vous voulez fixer plus de programmes des application sur l'écran de démarrage, regarder l'opération dans l'image au-dessous, (1) touchez doucement, pressez et maintenez l'aimant de programme d'application pour un second, puis l'éloignez et choisissez (2) le fixe sur l'écran de démarrage.




Par contre, si vous voulez démonter une application sur l'écran de démarrage, (1) touchez doucement, pressez et maintenez l'aimant de programme d'application pour un second puis l'éloignez, et choisissez (2) classifiez des programmes comme une colonne, par exemple, fixation et déléation, et puis il peut être accompli.



4. Colonne de Menu Charmant

Glissez à gauche de droite sur l'écran de démarrage pour démarrer la Colonne de Menu Charmant, inclut: commencer, installation, programme d'installer, partager, programme de recherche.





Vous permettez de rechercher des fichiers et des applications sur le Tablet PC.



Vous permettez de partager les programmes via les sites ou par e-mail.



Vous permettez retourner à l'écran de démarrage. A partir d'écran de démarrage, vous pouvez utiliser cette fonction pour rentrer les programmes récemment ouverts.



Vous permettez lire, écrire et partager des fichiers, connecter un écran externe ou une imprimante connectée au Tablet PC.




Vous permettez installer le Tablet PC.

Menu de rechercher



Menu de partager



Menu périphérique



Menu d'installer




5. Application à double-écran

Sur mon ordinateur dans (Dessin 1), le glissez de gauche d'écran, le tirez et le maintenez. L'éloignez quand vous regardez double interfaces.

Dans (Dessin 2), pressez le bouton de partition au milieu ligne de partition et tirez à droite et à gauche pour montrer la proportion de double écrans.




(Dessin 1)



(Dessin 2)


IV. Opérations élémentaires

1. Sommeil, Redémarrer, et Éteindre l'équipement



2. Gestion de la Sécurité

Installation du nom d'utilisateur et du code secret



Méthod d'installation facile:

Cliquez le bouton <Installer> dans les installations <Charmant>, et choisissez <Changer l'installation d'ordinateur>. Choisissez <utilisateur> à gauche et clique <Établir les comptes locaux> dans <Votre comptes> à droite. Après entrez les codes secrets de Compte Complet de Windows Live ID, le nom d'utilisateur, les codes secrets, les codes secrets pour confirmer, et la remarque du code secret.

V. Caractéristiques des Midias

1. Sur l'écran de démarrage, cliquez l'application de caméra,  démarrez l'Opération de caméra.




Opération de caméra

- ① Pellicule de Caméra: pour vérifier les photos ou les vidéos que vous avez photographié.
- ② Changer caméra: changer la camera frontale et dorsale
- ③ Minuteur: vous pouvez choisir 3 seconds, 10 seconds, ou éteindre. Il soutiens le passage du temps quand vous photographiez.
- ④ Exposition à la lumière: réglage d'exposition
- ⑤ Réalisation de vidéos
- ⑥ Cliquer pour photographier


2. Burineur

Dans l'environnement de wifi, l'Internet est connecté, cliquez Burineur IE.

Vous pouvez visiter les sites internet via le burineur.



3. Musique de Xbox



- ① Collection: Ajouter des chansons dans les dossiers sur votre ordinateur à plaisir.
- ② Radio: Connecter à Internet, écouter la radio
- ③ Exploration: Connecter à Internet, télécharger et écouter de la musique
- ④ Nouvel list d'émettre: Ajouter un nouvel list d'émettre
- ⑤ Conduire un list d'émettre: Le système de conduire les fichiers de la musique.

VI. Spécification

Specifications:	
Product	7" Intel Quad Core Table With Windows 8.1
Processor	Intel Baytrail-T 1.8Ghz(Quad Core)(Z3735G)
Operating System	Windows 8.1 Preloaded
Memory	16 GB Built-In Memory
Expansion	microSD Card Slot Built-in(Support Max Upto 64GB)
Display Size	7" 1024×600 Screen
Resolution	Display 1024×600 dpi(High Resolution)
RAM Memory	1GB DDR3 Built-in(eMMC Fast Memory)For Faster Apps Run
Screen	7" Capacitive Multi-Touch Super Sensitive Screen
WiFi	IEEE 802.11 b/g/n
USB	Micro USB 2.0 Port For USB Drives&Charging
Bluetooth	Built-in Latest Bluetooth V4.0 EDR
Office	MS Office 365 Personal(Word,Excel,PowerPoint,OneNote&Outlook for 1 Year
Audio Output Jack	3.5mm Headphone Jack
Dual Camera	Back 2.0M Pixels&Front 0.3M Pixels
Speaker/Mic	Built-in Stereo Speaker&Microphone
G-Sensor	360°Gravity Induction For All side Easy View
Flash Player/Language	Support Flash Player 10.2&Above/Support Multiple Language
Power Adapter	Power Adapter AC100-240V(DC 5V,2A),USB Charge Capable
Battery	Rechargeable Li-ion Polymer Big Capacity Battery 2800 mAh/3.7V mah
Playback/Standby	Music:Up to 8 Hrs(Depends On Vol Select)
	Video:Up to 4 Hrs(Depends On Brightness Select)
	Web Browsing:Up To 5Hrs(Depends On Wi-Fi Signals)
Audio Files	WAV,MP3,MP2,AAC,AMR-NB,AMR-WB,MIDI,Vorbis,APE)
Video Files	Support 1080P,MEPG 1/2/4 H.263/H.264,RMVB,WMV/VC-1,MVC,AVS,MJPEG
Photo Files	JPEG,BMP,GIF,PNG(Support Upto 2592×1944 dpi pics size

Déclarations FCC

Toute modification non expressément approuvées par la partie responsable de la conformité pourrait annuler l'autorisation de l'utilisateur d'utiliser cet appareil.

Remarque : Cet équipement a été testé et déclaré conforme aux limites d'un appareil de classe Bdigital, en vertu de la partie 15 des règles FCC.Ces limites sont conçues pour fournir une protection raisonnable contre les interférences nuisibles dans une installation résidentielle.Cet équipement génère l'utilise et peut émettre de l'énergie de fréquence radio et, si pas installé et utilisé conformément aux instructions, peut causer des interférences nuisibles aux communications de la radio.Cependant, il n'y a aucune garantie que l'interférence ne se produira pas dans une installation particulière. Si cet équipement provoque des interférences nuisibles à la radio ou la réception de la télévision, qui peut être déterminée en éteignant et rallumant l'équipement, l'utilisateur est encouragé à essayer de corriger l'interférence par une ou plusieurs des mesures suivantes :

Réorienter ou déplacer l'antenne réceptrice.

Augmenter la distance séparant l'équipement et le récepteur.

Branchez l'appareil dans une prise sur un circuit différent de celui auquel le récepteur est branché.

Consultez le revendeur ou un technicien radio/TV.