AKRAM

Bluetooth speaker

USER MANUAL
MANUEL D'UTILISATION

IN THE BOX

Wireless Tower Speaker

3.5mm Auxiliary Cable

AC Adapter

4 Screws

Tower Base

Remote Control

PLAYING MUSIC

Playing wireless music

To enjoy wireless music on your Wireless Tower Speaker, make sure you are connected to a Bluetooth enabled device. Once connected press PLAY on your Bluetooth device. When playback has begun, you can control the music with your connected device or the buttons of the Bluetooth speaker (with devices that have the AVRCP Bluetooth profile).

Play/Pause

- Quick press the **[SCAN/ ▶‖]** button on the speaker or the remote control to pause the music.
- To resume music playback, quick press the **[SCAN/ ▶‖]** button again.

Skipping Songs

- Quick press the **[VOL-/◀◀]** button on the speaker or the remote control to skip to the previous song.
- Quick press the **[VOL+/▶▶]** button to on the speaker or the remote control to skip to the next song.

LOCATION OF CONTROLS

TOP PANEL

1. **[⏻] button:** Power ON/OFF
2. **[MODE/LIGHT] button:**
   - Quick press **–** Bluetooth, AUX IN, FM radio
   - Long press **–** activate light
3. **[VOL-/◀◀] button:**
   - Quick press **–** skip to previous song/ tune FM radio down
   - Long press **–** decrease volume
4. **[SCAN/▶‖] button:**
   - Quick press **–** play/pause
   - Long press **–** scan FM radio
5. **[VOL+/▶▶] button:**
   - Quick press **–** skip to next song/ tune FM radio up
   - Long press **–** increase volume

PLAYING MUSIC (cont'd)

Adjusting the volume

- Long press the **[VOL+/▶▶]** button on the speaker or the **[+]** button on the remote control to gradually increase the volume.
- Long press the **[VOL-/◀◀]** button on the speaker or the **[–]** button on the remote control to gradually decrease the volume.
- Press the **[🔇]** button on the remote control to mute the sound. Press again to turn the sound back on.

You may also adjust the volume from your connected device's volume control

Equalizer

Press the **[EQ]** button on the remote control to adjust equalizer settings.

LOCATION OF CONTROLS (cont'd)



FRONT PANEL

9. LED Power indicator light
8. LED Bluetooth indicator light
10. LED AUX indicator light
11. LED FM radio indicator light
12. Infrared sensor
13. AUX IN port
14. ANT
15. DC IN

BACK PANEL

FM RADIO MODE

Listening to the radio by scanning

1. Press the **[MODE/LIGHT]** button on the speaker or the **[MODE]** button on the remote control repeatedly until the LED FM radio indicator light turns GREEN.
2. Press and hold the **[SCAN/ ▶‖]** button on the speaker for a second and then release, or press the **[▶‖ /SCAN]** button on the remote control. All available stations will be searched and then stored into the memory automatically.
3. After scanning, press the numeric buttons to select 1-20 preset stations. (Ex: pressing 1 means preset station 1, pressing 2 and 0 means preset station 20, etc.)

NOTE: After scanning and saving stations, if the Wireless Tower Speaker is turned OFF and then back ON, be sure to select your preset stations with the numeric buttons, if you press **[SCAN/ ▶‖]** again, the scanning process will start over.

Listening to the radio by manual search

Quick press the **[VOL-/◀◀]** and **[VOL+/▶▶]** buttons on the speaker or the remote control to go to the next radio station.

To enhance radio reception please, fully unwind and adjust the FM antenna wire located on the back of the speaker.

LOCATION OF CONTROLS (cont'd)

1. **[MODE] button:** Bluetooth, AUX IN, FM radio
2. **[⏻] button:** Power ON/OFF
3. **[TUNE-/◀◀] button:**
   - BT Mode **–** skip to previous song
   - FM Radio **–** Long press: tune FM radio up Quick press: scan down to next station
4. **[TUNE+/▶▶] button:**
   - BT Mode **–** skip to next song
   - FM Radio **–** Long press: tune FM radio down. Quick press: scan down to next station
5. **[–] button:** Decrease volume
6. **[+] button:** Increase volume
7. **[LIGHT] button:** Turn on lights
8. **[🔇] button:** Mute
9. **[▶‖] button:**
   - Quick press **–** play/pause
   - Long press **–** scan FM radio
10. **[RESET] button:** Volume reset
    - Resets volume to 60%
11. **[EQ] button:** Equalizer

USING AS A MIXED SPEAKER

1. Quick press the **[MODE/LIGHT]** button on the speaker or the **[MODE]** button on the remote control repeatedly until the LED AUX indicator light turns GREEN.
2. Connect one end of the 3.5mm auxiliary cable to the AUX-IN port on the side of this speaker, and the other end of the cable to an external device's audio output port (smartphone, tablet, MP3 player,).
3. Use the controls on your connected device to control music playback and volume.

When a device is plugged into the AUX IN jack, only the volume can be controlled by the buttons on the speaker and remote control. You must use your connected device to control music playback.

INSTALLING THE BATTERY

NOTE: The battery for the remote control (1 CR2025 lithium battery) is included. To replace the battery, push and slide out the battery door in the remote control. Replace the battery with a new CR2025 battery with the polarity "+" facing up. Slide the door back.

CHARGING DEVICES

The Wireless Tower Speaker has a USB input located on the front. This can be used as a charging port for charging external devices such as MP3 players, smartphones or tablets.

1. Attach your device to the speaker's USB port using your device's USB charging cord.
2. The device will start charging automatically.
3. Check your device's charging indicator for charging status.

SETTING UP THE SPEAKER



1. Connect the wooden tower base to the speaker using the supplied screws.
2. Connect the AC plug on the back of the unit into an outlet.

TROUBLESHOOTING

I cannot get the Wireless Tower Speaker into my Bluetooth device, but I cannot hear any music.

1. Make sure your Bluetooth device supports A2DP profile.
2. Turn up the volume on your Bluetooth device.
3. You may have to unpair the speaker, then reseat to your device.
4. Use your connected device to increase the volume.

My Bluetooth device is not able to pair with the Wireless Tower Speaker.

1. Make sure the Wireless Tower Speaker is turned ON before beginning the pairing process.
2. Keep the Wireless Tower Speaker and Bluetooth enabled device within 3 feet of each other during the pairing process.
3. Press the **[MODE/LIGHT]** button on the speaker or the **[MODE]** button on the remote control repeatedly until the LED Bluetooth indicator light flashes GREEN and a tone is heard.
4. Check that YOUR device's Bluetooth feature is turned ON.
5. Try repeating the pairing process, see "Pairing the Speaker".

PAIRING THE SPEAKER

1. Plug the speaker into a power source.
2. Turn the speaker ON by pressing the Main Power switch on the back of the unit, then the **[⏻]** button on the top panel or the remote control.
3. Press the **[MODE/LIGHT]** button on the speaker or the **[MODE]** button on the remote control repeatedly, until the LED Bluetooth indicator light flashes GREEN and a tone is heard.
4. Keep the speaker and Bluetooth enabled device within 3 feet of each other during the pairing process.
5. Set your mobile phone or other Bluetooth enabled device to search for Bluetooth devices.

If a paired device is in range, the speaker will connect to it automatically when Bluetooth mode is enabled.

On an iPhone

- Go to SETTINGS > BLUETOOTH (Make sure Bluetooth is turned ON)

TROUBLESHOOTING (cont'd)

I cannot pair the Wireless Tower Speaker into pairing mode.

1. Make sure the Wireless Tower Speaker is turned ON before beginning the pairing process.
2. Press the **[MODE/LIGHT]** button on the speaker or the **[MODE]** button on the remote control repeatedly until the LED Bluetooth indicator light flashes GREEN and a tone is heard.
3. The turntable is now in pairing mode.

PAIRING THE SPEAKER (cont'd)

On a Blackberry

- Go to SETTINGS > BLUETOOTH
- Enable BLUETOOTH

On an Android Phone

- Go to SETTINGS > BLUETOOTH > MENU > Search for devices (Make sure Bluetooth is turned ON)

SAFETY INSTRUCTIONS

PAIRING THE SPEAKER (cont'd)

On other Cell Phones/Devices

- Review the instruction manual that came with your phone/device.

5. When the Bluetooth enabled device finds the speaker, select "AKRAM MUSIC TOWER" from the list of devices.
6. If required, enter the password 0000. Select OK or Yes to pair the two units.
7. After a successful pairing, the LED Bluetooth indicator light will steadily flash GREEN.

NOTE: It is possible for the speaker to remember multiple devices. If you want to connect the speaker to another device, you must disconnect from the currently paired device first. In your device's Bluetooth settings, select "AKRAM MUSIC TOWER" then select "Unpair". When the speaker has been unpaired, it automatically goes into pairing mode again.

To connect to the speaker via Auto Connect feature, the last device connected to the speaker must be turned on and within range of the speaker. If you want to connect to a different device, you must first disconnect with the speaker and pair it to the new device.

ADDITIONAL WARNINGS & PRECAUTIONS

USING THE SPEAKER

Powering ON/OFF

Turn the speaker ON by pressing the Main Power switch on the back of the unit, then the **[⏻]** button on the top panel or the remote control. Press again to turn OFF.

Adjusting the volume

- Long press the **[VOL+/▶▶]** button on the speaker or the **[+]** button on the remote control to gradually increase the volume.
- Long press the **[VOL-/◀◀]** button on the speaker or the **[–]** button on the remote control to gradually decrease the volume.
- Press the **[🔇]** button on the remote control to mute the sound. Press again to turn the sound back on.

To enhance radio reception please, fully unwind and adjust the FM antenna wire located on the back of the speaker.

Switching modes

Press the **[MODE/LIGHT]** button on the speaker or the **[MODE]** button on the remote control repeatedly to switch between modes. The LED indicator light will light up accordingly: Bluetooth, AUX, and FM radio.

Disco light

To activate the Disco light, long press the **[MODE/LIGHT]** button on the speaker or the **[LIGHT]** button on the remote control. Long press again to turn OFF.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.
This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
o Reorient or relocate the receiving antenna.
o Increase the separation between the equipment and receiver.
o Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
o Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.