THIS ARTWORK IS SOLELY TO BE USED FOR THE SUPPLY OF GOODS TO THE COTTON ON GROUP AND MUST NOT BE USED FOR ANY OTHER PURPOSE

* ARTWORK IS SHOWN AT ACTUAL SIZE PLEASE USE ACTUAL ARTWORK AS SHOWN BELOW

MOCK UP

DIMENSIONS

75MM W x 85MM H

BASE STOCK

WHITE (MATTE)
80GSM

PRINT COLOUR

TRUE BLACK

KEY

CUT
(DO NOT PRINT-
USE AS GUIDES ONLY)

FRONT

Typo

TWS Earbuds

[Instruction Manual]



1. Earbuds Button
2. LED Indicator
3. Battery Indicator
4. Charging box cover
5. Left earbuds cap
6. Charging port
7. Earbuds
8. Magnetic compartment of the charging box
9. Charging box bottom cover

Charging for charging box

The battery must be full charged before the first use!

1. Connect the cord of the charging cable to the charging port (part 6) of the charging box.

2. Plug the other end of the charging cable into the power USB port and start charging.

3. When charging, the battery indicator light (part 3) will flash, and keep light when full charged.

4. Remove the charging cable.

Charging for Earbuds

The battery must be full charged before the first use!

1. Put the earbuds (part 7) into the charging box, the earbuds will be charged automatically.

2. When charging, the LED indicator (part 2) will light red.

3. When full charged, the LED indicator (part 2) will go out.

Earbuds switch and wireless connection

1. Power on: Take the earbuds (part7) out of the charging box, the earbuds (part7) will automatically turn on, the prompt tone "Power on" and the LED indicator (part2) flash red and blue light.

2. Pairing: When using for the first time, double-click one of the earbuds buttons (part1) to pair and it will have tone for "Pairing".

3. Open the wireless device, searching for the wireless name TWS-TWS, click the connection if the connection is successful, it will have prompt tone "Connected".

4. After successful connection, you can press the earbuds button(part 1) to answer/end the call or play/pause the music in Wireless mode.

5. For low battery, it has the prompt tone for "Low battery", please charge.

6. Disconnect, it has the prompt tone for "disconnected".

7. Power off: Press and hold the earbuds button (part1), the tone is "Power off".

Specifications

Wireless version: 5.0

Play time: 4-5 hours

Transmission distance: 10m

Battery capacity for charging box: 300mah

Battery capacity for earbuds: 50mah

Speaker: 10mm moving coil

Impedance: 32 Ohms

Sensitivity: 105dB+-3dB

Frequency response range: 20Hz-20KHz

Product use manual

Please read and keep these instructions for future use.

Warning

When using do not have volume too high.
Do not use while driving.
Ensure cord hangs loosely.
Keep out of reach of children.
Do not expose device to high temperatures, humidity, water, direct heat or high dust areas as these may damage the device.
Any repairs need to be carried out by a professional.

Care instruction.

Ensure ear piece is regularly cleaned/free of dust.
Clean with damp cloth only.
Do not use alcohol or any other harsh chemicals to clean this product.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occurin a particular installation. If this equipment does cause harmful interference to radio or television
reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.
Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to
operate this equipment.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) the device must accept any interference received, including interference that may cause undesired operation.