2.3 Operating summary

- TRANSMITTER's button is pushed
- TRANSMITTER sends appropriate CODE by RF frequency.
- RECEIVER gets the code and decodes it.
- When Rx proves it to be the right code, Rx drive the actuator or carry out the alarm function.

2.3.1 LOCK & UNLOCK

If LOCK or UNLOCK button is pushed for less than 1 sec, then TRANSMITTER sends the LOCK or UNLOCK DATA.

2.3.2 PANIC

If PANIC button is pushed, then transmitter sends the PANIC data.

2.4 Caution

- Danger of explosion if battery is incorrectly replaced.
- Replace only with the same or equivalent type recommended by the manufacture
- Dispose of used batteries according to the manufacturer's instructions.

2		