D-7129

DRONE MISSION

For ages 14+
Ab 14 Jahren
A partir de 14 ans
A partir van/af 14 jaar
A partir de 14 años
Età: 14 anni in su

MFR No. 84772

Hereby, Silverlit Toys Manufactory Ltd declares that the radio equipment 84772 is in compliance with Directive 2014/53/EU.
The full text of the EU declaration of conformity is available at the following internet address: www.silverlit.com/certificate

Delivery Contents



Precautions and Warnings

The crossed-out dustbin symbol indicates that batteries, rechargeable batteries, button cells, electrical equipment and electronic equipment must not be disposed of with household waste. Observe the environment. Please help to protect the environment from harmful risks. If the toy is out of use, please use common household but to break the product for both or rechargeable battery operated toys. Remove batteries and rechargeable batteries from the toy before disposing of the toy. Dispose of battery in accordance with your local battery recycling or disposal laws.

Waste Electrical and Electronic Equipment (WEEE)
Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being. When replacing old appliances with new ones, the retailer is legally obligated to take back your old appliance for disposal at least for free of charge.

Safety precautions:
Warning: Unknown or modified use to this product not expressly approved by the party responsible for compliance could void the user's authority to operate the product.
- The USB cable is also made for the LiPo rechargeable battery used in Drone. Do not use it to charge any battery other than the LiPo one.

Care and Maintenance:
- Always remove batteries from the product when it is not being used for a long period of time, as battery leakage can occur.
- Regularly examine for damage to the plug, enclosure and other parts. In the event of any damage, the product must not be used with the transmitter charger until the damage has been repaired.
- Wipe the product gently with a clean cloth.
- Keep the product away from direct heat.
- Do not submerge the product into water that can damage the electronic assemblies.

Special notes:
- This product is designed to be used in domestic area (house and garden) only.
- Do not change or modify anything on the Drone.

Notes:
- New alkaline batteries are recommended to use in this product to obtain best and maximum performance of transmitter and Drone.
- This product must only be used with the recommended charger.

Battery warnings:
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed before being charged. (Transmitter and Truck)
- Rechargeable batteries are only to be charged under adult supervision.
- Different types of batteries or new and used batteries are not to be mixed. (Transmitter and Truck)
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the product. (Transmitter and Truck)
- The supply terminals are not to be short-circuited.
- Do not dispose of batteries in a fire. (Transmitter and Truck)
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries. (Transmitter and Truck)

This Drone is equipped with a LiPo rechargeable battery, please pay attention to the following cautions for safety use:
- Do not dispose the battery in the or trash.
- Do not expose the battery to heat or flame and keep away from source such as fire or heater.
- Do not throw or throw the battery against hard surfaces.
- Do not immerse the battery in water, and keep the battery in a cool dry environment.
- Do not use damaged battery or battery charger specifically for that purpose.
- Do not over-discharge the battery.
- Do not connect the battery to an electrical outlet.
- Do not pierce the battery with sharp objects or crush the battery with a nail or other sharp object.
- Do not disassemble or alter the battery.
- Charge the battery every 6 months.

Battery requirements transmitter:

Power supply	: ammo
Battery voltage	: DC 4.5 V, 0.27 W
Batteries	: 3 x 1.5 V 'AA'/LR6/AM3 (not included)

Part Identification

Drone



Transmitter



Truck



The normal function of the product may be disturbed by Strong Electro Magnetic Interference. If so, simply reset the product to resume normal operation by following the instruction manual.
In case the function could not resume, please use the product in other location.

Battery requirement for Truck:

Power Supply	: DC3V
Charger	: DC 5V, 0.3W
Batteries	: 2 x 1.2 V 'AA'/LR6/AM3 (not included)

Battery requirements Drone:

Power supply	: ammo
Charging ratings	: DC 5 V, 7.77 W
Batteries	: 1 x 3.7 V LiPo Rechargeable Battery Pack (included)
Capacity	: 180 mAh

Silverlit SAS, 80 rue Barthelemy Danjou, 92100 Boulogne-Billancourt / France.
© 2016 Silverlit. All rights reserved.

Battery Installation and Charging

Transmitter Battery Installation (*Make sure the power switch is on "OFF" position.)



Warning !
Remove these batteries from the unit by pulling up on one end of the battery positive by hand.
DO NOT attempt to install batteries using sharp or metal tools.

Truck Battery Installation (*Make sure the power switch is on "OFF" position.)



Charging Drone on the Truck

Charging Drone with USB Cable



Note: 1. The Drone can operate for about 4- 5 minutes per every 28-40 minutes charging.
2. Before recharging the battery, wait 10 - 15 minutes for it to cool down.

Flying the Drone

Tip! ***Piloting hints***
- For controlling the sticks on transmitter, try not to push the sticks immediately to any extreme positions. It should be like steering a bicycle rather than pressing computer game sticks.
- For the novice pilot (after the trimming procedure is completed), it is highly recommended to focus exclusively on learning to control the throttle stick first. If the Drone turns around by itself there is no need to keep it straight. For the first flight, it is important to learn to keep the Drone at a constant altitude of around 1 meter with very gentle inputs on the throttle stick. Once the pilot masters this, he may start learning to take control with the direction stick.

1. Procedure for PAIR / SYNC the Drone, Truck and Transmitter
2.4 GHz technology allows Drone and Truck to be controlled by one Transmitter without signal interference. A connection, PAIR / SYNC, must be made between the Drone, Truck and the Transmitter to function. Follow these steps to PAIR/SYNC the Drone, Truck and the Transmitter.

- Place the Drone on the Truck with the back point towards you and the head pointing away. Make sure the throttle stick is at the minimum position.
- Turn the Power Switch button to 'ON' position on the Drone, Truck and Transmitter. The LEDs of the Drone and Truck will gradually flash in and out (fig 1).
- When the LEDs become flash and the power indicator on Transmitter light up. Push the throttle stick to top then pull down to bottom (fig 2). The pair procedure is completed.



2. Flight environment
Choose the place which meets the following condition:
1. Indoor environment with calm air. Beware of the air circulation from the air-conditioner.
2. Caution: There must not be any dangerous objects (electric fan, air-conditioner, reading lamp, etc) on the flight path.

3. Trimming the Drone:
- Make sure the transmitter is in Drone mode.
- Gently push the throttle up or press the "Auto Takeoff / Landing" button to raise your Drone about 0.5 to 1 meter high.



4. Flight control: The Drone
(i) Auto take-off & landing :

Press "Auto take off / landing" button, Drone flies up to a standard level and hover in the air.

Press again "Auto take off / landing" button, Drone will land automatically.

Press & hold over 2 seconds for emergency stop.

(ii) Auto to Manual control :

When Drone is hovering, slowly push the throttle stick up to certain level and the Drone will change to manual control automatically.

Note: The hovering level may vary at different ground color and material reflection. When ground color is dark and hovering low, press the throttle stick a bit more to raise the hovering level.

5. General Control:



6. Lift-off Procedures (After Trimming Procedure):
- Slowly increase the throttle.
- Do not look at the transmitter but focus on the Drone.
- As soon as the Drone leaves the track / floor, reduce the throttle slightly. (In the worst case, the Drone will go back to the floor, but that is better than crashing against the ceiling)
- Very gently increase the throttle if the Drone descends.
- Very gently reduce the throttle if the Drone ascends.
- For turning, give short and small inputs to the direction stick. (Most beginners will easily over control the Drone)
- For moving forward, turn the Drone pointing to more open space before pushing the stick forward.

7. Flying mode:

Beginner Mode:	Vertically press one time the throttle stick, you will hear a "BEEP" sound to indicating **Beginner Mode**.	**Beginner mode** (slow&soft) : Lower speed (for beginners).
Advanced mode:	Vertically press the throttle stick twice to enter **Advanced Mode** after hearn a "BEEP BEEP" sound.	**Advanced mode** : Higher speed.
Headless mode:	Enter the **Headless Mode** after you vertically press three time the throttle and hear "BEEP BEEP BEEP" sound.	**Headless mode**: The four directions of the Drone will keep the same right after enter Headless mode.
	(i) The four directions (front, left, right, back) will be set, after the Drone entered the Headless mode	(ii) After rotating the Drone, the 4 directions will be kept the same.

Truck Mode:	- Switch Mode selector to 'TRUCK' to enter Truck Mode (fig. 3)	
Drone Mode:	- Switch Mode selector to 'DRONE' to enter Drone Mode (fig. 4)	
Follow Mode:	Press the "Follow mode" button on transmitter to enable following mode, a blue LED on the Drone will light up. (i) Takeoff the Drone and hovering above the Truck (ii) Switch to Truck mode on the transmitter and drive the Truck. (iii) The Drone will hover above the Truck and start following	

Tip! ***DRONE FOLLOWING THE TRUCK***
- Keep Drone fly too far away from the Truck, it will hovering in the air
- Drive the Truck towards the Drone and stop close, the Drone will continue following the Truck
- Press the "Follow mode" button once more to disable following mode, the LED on the Drone will turn off

8. Driving Control: The Truck
- Set the power switch on transmitter and truck to ON.
- Get the mode selector on transmitter to "Truck" mode.
- Steer the truck by adjusting the control stick of transmitter in different combinations to perform different action.

Direction stick	Action (Direction stick only)	Action (Throttle stick)
	Forward *(Low Speed)*	**Forward** *(Speed Up)*
	Backward *(Low Speed)*	**Backward** *(Speed Up)*
	Forward left *(Low Speed)*	**Forward left** *(Speed Up)*
	Forward right *(Low Speed)*	**Forward right** *(Speed Up)*
	Backward left *(Low Speed)*	**Backward left** *(Speed Up)*
	Backward right *(Low Speed)*	**Backward right***(Speed Up)*

Tip! ***DRIVING THE TRUCK***
- Stop acceleration varies at different stick position.
- Operate the truck on flat, smooth /not slippery and dry surfaces and low pile carpet. Hair, carpet or dirt can affect the truck's operation.
- Don't drive the truck on sand or through water or snow, if it gets wet, wipe it with a towel and allow it to dry completely.

Troubleshooting

Symptom	Cause	Correction
The Drone does not response.	- The Drone and/ or the transmitter is switch off ('OFF'). - The battery of the Drone is weak.	- Set the power switch to "ON" - Recharge the battery of the Drone.
The Drone does not hover, or road quickly to one direction when flying. The Drone is not response. The transmitter generate a long "BEEP" sound.	- PAIRING / SYNCD Procedure is not yet completed or done. - The truck and/or the transmitter is switched off.	- Repeat the PAIRS/SYNCD procedure again. - Set the power switch to "on".
The Drone suddenly stops and drops down when flying.	- The battery of the Drone is weak.	- Recharge the battery of the Drone
Loss of control (Truck / Drone).	- Another radio control device using the same frequency and channel is operated near your Truck / Drone. - Out of the control distance.	- Move to another place where without radio frequency interference from another device. - The control range for the Drone and the Truck is up to 20 meters.

Drone Mission™

Become our fan on facebook
facebook.com/SilverlitToys

Visit us at
www.Silverlit.com