5B249BT

Bluetooth Speaker

INSTRUCTION MANUAL
PLEASE READ ALL INSTRUCTIONS CAREFULLY
& RETAIN FOR FUTURE USE

Getting Started

Remove the unit from the box.
Remove any packaging from the product.
Please retain all packaging until you have checked and counted all the parts and the contents against the parts list.

Package Contents

Bluetooth Resound Speaker
USB Charging cable
3.2mm auxiliary cord
Instruction manual

Features

1. Stream music wirelessly from Bluetooth enabled audio devices
2. Works with iPad, iPhone, iPod Touch, Android devices, tablets, computers and more
3. Built-in controls support play, pause, forward/backward track and volume
4. Integrated microphone for hands free calling capability
5. Rechargeable battery for up to 8 hours of continuous music
6. Built-in subwoofer for powerful bass
7. Play music through Bluetooth, Auxiliary, Micro SD (TF) Card & USB
8. Built-in FM radio
9. Folding handles for portability
10. Perfect for use indoors & outdoors

DESCRIPTION OF PARTS

1. Skip Backward / Decrease Volume
2. Play / Pause / Mode button
3. Skip Forward / Increase Volume
4. ON/OFF button
5. Auxiliary Port
6. Micro SD (TF) Card Slot
7. USB Port
8. LED Light Indicator
9. USB Charging Port

Instructions for use

Charging the speaker
For best results, fully charge the speaker before use.

1. Connect the USB cord (included) to the charging port of the speaker and insert the other end into a port on your computer or similar suitable power source.
2. The Red LED turns on, indicating that the battery is being charged. Once it is full, charged, the Red LED will turn off. It takes 5 to 7 hours to charge the speaker fully.

Turn On/Off the Speaker

1. To Turn "ON", slide the "ON/OFF" switch to the ON Position.
2. To Turn "OFF", slide the "ON/OFF" switch to the OFF Position.

Switch the speaker to Bluetooth pairing mode -

1. Turn ON the speaker.
2. You will hear the indication tone and the LED Light blinks rapidly. The speaker is now in pairing mode.

(Note: Speaker will automatically pair with previously paired devices)

Pairing your device with Bluetooth Speaker –

Your Bluetooth Speaker can wirelessly stream audio from any Bluetooth enabled device within 27-33 Feet. Simply follow the below steps.

1. Turn ON the speaker.
2. You will hear the indication tone and the LED Light blinks rapidly. The speaker is now in pairing mode.
3. Turn on the Bluetooth on your Mobile Phone or Tablet or Computer.
4. It will search for various devices.
5. The pairing name of our Bluetooth Speaker is " 17-243SU ", pair it with this device.
6. If required, enter the password "0000" to confirm the pairing.
7. Once paired successfully, the Blue LED will blink slowly.
8. It will only need to pair for the first time or you want to pair it with a new device (please follow the steps above).

Select your favorite song at the Bluetooth device and music would now stream through Bluetooth speaker.

Listening to Music Wirelessly

Please ensure that your device (Phone, Tablet or Other Smart Phone) is paired with the Bluetooth Speaker to stream music wirelessly. Once it is paired, play music from your device.

Function	Operation	Button
Increase Volume	Hold to press	Hold to press on the + button once will increase the volume
Decrease Volume	Hold to press	Hold to press on the - button once will decrease the volume
Pause	Hold to press	Press ⏯ once to pause the music
Play	Pause	Press ⏯ once to pause the music
Previous track	Hold to press	Short press the ⏮ button to the previous track
Next track	Hold to press	Short press the ⏭ button to the next track

Note: An indication tone will alert you when the volume is adjusted to the maximum level.

Aux function of the Speaker (to play music from non-Bluetooth devices)

1. Turn on the speaker.
2. Plug the 3.2 mm auxiliary cord (included) in to the auxiliary port of the speaker. And, connect the other end of the cable to the audio device (such as MP3 Player / computer / tablet etc.).
3. Select your favorite song at the source device.

Note: Once AUX cable is connected to the Speaker, music through the Bluetooth will be stopped. Functions except increase/decrease volume, Skip Backward, Skip Forward etc can be only controlled through source devices, while playing music in Auxiliary mode.

Listening to Music using USB / Micro SD (TF) Card Slot

1. Turn on the speaker.
2. Insert Micro SD (TF) card or USB flash drive into the Micro SD (TF) Card Slot or USB Slot. Music would be automatically streamed.
3. Press Skip Forward or Skip Backward to move forward or backward on your playlist.
4. Press Play/Pause to Play or Pause a track.

Note: While using Bluetooth, if you insert Micro SD (TF) Card or USB Flash drive, speaker would disconnect the Bluetooth connection and switch to Micro SD (TF) card or USB card function. You can long press MODE button each time until it goes back Bluetooth mode.
Micro SD (TF) Card/USB Flash Drive not included.

FM Radio

1. Turn ON the Speaker.
2. Insert the auxiliary cord (included) into the auxiliary port. Leave the other end of the cord open. Auxiliary cord serves as FM Antenna while in FM Radio mode.
3. Long press "MODE" button each time until FM mode is selected.
4. Short press "MODE" button again and the device would automatically search and store all the FM Radio stations.
5. Press "SKIP FORWARD" or "SKIP BACKWARD" to change the FM Radio stations.

Tips!!

1. Long press the "MODE" button each time to switch different functions of the speaker, The modes appear in the following sequence
   → Bluetooth / USB/Micro SD (TF) / FM Radio / AUX →
2. When the unit is not in use, turn OFF the device to save the battery power.

Specification

Bluetooth version	2.1 + EDR
Speaker Output	2 x 3Watts + 1 x 10Watts Sub-Woofer
FM Frequency	87.5 – 108MHz
Unit Size	~10" x 6.6" x 6.6"
Unit Weight	~4.8lbs (2.2 kg)
Play time	Up to 12 hours (max. volume), and 8 hours (moderate volume)
Charge Voltage	DC5V (USB)
Bluetooth Range	27 – 33 Feet
Built-in Rechargeable Battery	3.7V / 1800mA

(Note: Battery life & charging time may vary based on usage & types of devices used.)

Troubleshooting

Problem	Possible Cause	Solution
Low sound (only)	Source/Target, Mobile Phone, Laptop etc. is set to mute. Battery low.	Adjust source volume. Charge Battery.
Sound distorted	Battery low or dead.	Charge Battery.
No sound at all	Source/Target, Mobile Phone, Laptop etc. turned off. Speaker turned off. Volume turned down source. Media paused on source.	Turn the source on. Turn the speaker on. Adjust volume source. Play media from source.

Care and Maintenance

Clean the unit with a soft, damp cloth. Never use chemicals or hard abrasives.
Keep this unit away from wet or damp surroundings.

The crossed out wheelie bin symbol on this item indicates that this product needs to be disposed of in an environmentally friendly way when it becomes of no further use or has worn out. Contact your local authorities for details of where to take the item for recycling.

Note: iPod and iPhone are trademarks of Apple Inc. registered in the US, and other countries.

Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provid reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio* communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
– Reorient or relocate the receiving antenna.
– Increase the separation between the equipment and receiver.
– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
– Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction

5B249BT

RESUENAN BLUETOOTH ALTAVOZ INALÁMBRICO

MANUAL DE INSTRUCCIONES
POR FAVOR LEA TODAS LAS INSTRUCCIONES CUIDADOSAMENTE
& RETENER PARA USO FUTURO

Getting Started

Remove the unit from the box.
Remove any packaging from the product.
Please retain all packaging until you have checked and counted all the parts and the contents against the parts list.

El contenido del paquete

Resuenan Bluetooth Altavoz.
Cable de carga USB.
Cable auxiliar de 3.2mm.
Manual de instrucciones.

Características

1. Transmita música de forma inalámbrica desde dispositivos de audio habilitados.
2. Funciona con iPad, iPhone, iPod Touch, dispositivos Android, tabletas, ordenadores y mucho más.
3. Los controles integrados admiten reproducción, pausa, avance/retroceso de pista y volumen.
4. Transmita música de forma inalámbrica con dispositivos habilitados para Bluetooth.
5. Batería recargable de hasta 8 horas de música continua.
6. Subwoofer integrado para una potente reproducción de bajos.
7. Reproducir música a través de Bluetooth, Auxiliar Micro SD (TF) Tarjeta &Amp; USB.
8. Radio FM incorporada.
9. Asas plegables para portabilidad.
10. Perfecto para uso en interiores & afuera.

Designación de las Piezas

1. Saltar hacia atrás Disminuir el volumen.
2. Reproducir/Pausa Modo Botón.
3. Avanzar hacia adelante / Aumentar el volumen.
4. Encender en ENCENDIDO/APAGADO.
5. Puerto auxiliar.
6. Micro SD (TF) Ranura para tarjeta.
7. Puerto USB.
8. Indicador luz LED.
9. Puerto de carga USB.

Instrucciones de uso

Carga del Altavoz
Para obtener los mejores resultados, cargue completamente antes de usar el Altavoz.

1. Conecte el cable USB (incluido) al puerto de carga del Altavoz e inserte el otro extremo a un puerto del ordenador o similar fuente de alimentación adecuada.
2. El LED rojo se encenderá, lo que indica que la batería se está cargando. Una vez que está completamente cargado, el LED rojo se apagará. Se tarda de 5 a 7 horas para cargar completamente el altavoz.

Activar/desactivar el altavoz

1. Pase "Activar" deslice el interruptor "ON/OFF" a la posición "ON".
2. Desactivar la opción de "apagado", deslice el interruptor "ON/OFF" a la posición "OFF".

Cambiar el altavoz a modo de emparejamiento Bluetooth -

1. Encienda el altavoz.
2. Oirá el tono de indicación y el LED azul parpadeará rápidamente. El altavoz se encuentra ahora en modo de emparejamiento.

(Nota: El altavoz se empareja automáticamente con dispositivos emparejados previamente)

Emparejar el dispositivo con Bluetooth Altavoz -

El altavoz Bluetooth puede transmitir audio de forma inalámbrica desde cualquier dispositivo Bluetooth dentro de los 27-33 pies. Simplemente siga los pasos que se indican a continuación.

1. Encienda el altavoz.
2. Oirá el tono de indicación y el LED azul parpadeará rápidamente. El altavoz se encuentra ahora en modo de emparejamiento.
3. Encienda el Bluetooth en su Teléfono Móvil o Tablet o el ordenador.
4. Se buscará para diversos dispositivos.
5. El emparejamiento nombre de nuestro altavoz Bluetooth es " 17-243U " renombrar, emparejarlo con este dispositivo.
6. Si es necesario, introduzca la contraseña "0000" para confirmar para finalizar el emparejamiento.
7. Una vez emparejado correctamente, el LED azul parpadeará lentamente.
8. Si no emparejado dentro del marco de tiempo o desea emparejar con un dispositivo nuevo por favor, siga los pasos descritos anteriormente.

Seleccione su canción favorita en el dispositivo Bluetooth y música será ahora transmitir desde el altavoz Bluetooth.

Escuchar música de forma Inalámbrica

Asegúrese de que el dispositivo (iPhone, Tablet u otros teléfonos inteligentes) está emparejado con el altavoz Bluetooth para transmitir música de forma inalámbrica. Una vez emparejado, reproducir música desde su dispositivo.

Función	La operación	Botón
Aumentar el volumen	Longpulsación de mantener	Longpulsación mantener + en el botón aumentar el volumen.
Disminuir el volumen	Longpulsación de mantener	Longpulsación mantener - en el botón disminuir el volumen.
Pausa	Longpulsación de mantener	Presione ⏯ una vez para pausar la música.
Reproducir	Pausa	Pulse ⏯ una vez para reanudar la música.
Pista anterior	Longpulsación de mantener	Pulse brevemente el botón ⏮ a la pista anterior.
La siguiente pista	Longpulsación de mantener	Pulse brevemente el botón ⏭ para la siguiente pista.

(Nota: Una indicación de tono le avisará cuando el volumen está ajustado al máximo nivel.)
La función Aux del altavoz (para reproducir música desde dispositivos que no disponen de Bluetooth).

1. Encienda el altavoz.
2. Enchufe el cable auxiliar 3.2 mm (incluido) en el puerto auxiliar del altavoz. Y, conecte el otro extremo del cable al dispositivo de audio (como, por ejemplo, reproductores MP3 / PC / tablet, etc.).
3. Seleccione su canción favorita en el dispositivo de origen.

Note: Una vez cable AUX está conectado a los altavoces, a través de Bluetooth a la música se detendrá. Las funciones excepto para aumentar/disminuir el volumen como Retroceder, Avanzar, etc puede ser controlado únicamente a través de dispositivos de origen, mientras que la reproducción de música en modo auxiliar.

Escuchar música mediante USB / Micro SD (TF) Ranura para tarjeta.

1. Encienda el altavoz.
2. Inserte el micro SD (TF) tarjeta o unidad flash USB en la tarjeta Micro SD (TF) ranura de tarjeta o ranura USB. Música será enviada automáticamente.
3. Pulse Avanzar o Retroceder para avanzar o retroceder en la lista de reproducción.
4. Pulse Play/Pause para reproducir o pausar una pista.

Note: Si utiliza Bluetooth, al insertar Micro SD (TF) tarjeta o unidad Flash USB, altavoces será desconectar la conexión Bluetooth y cambiar a Micro SD (TF) tarjeta USB o tarjeta de función. Siempre puede pulsar el botón de modo cada vez hasta que vuelva al modo Bluetooth.
Micro SD (TF) Tarjeta/unidad flash USB no incluida.

Radio FM

1. Encienda el altavoz.
2. Inserte el cable auxiliar (incluido) en el puerto auxiliar. Deje el otro extremo del cable abierto. Cable auxiliar sirve como antena de FM, mientras que en el modo de radio FM.
3. Pulse por largo tiempo el botón "MODE" cada vez, hasta que se seleccione el modo FM.
4. Pulse brevemente el botón "MODE" de nuevo y el dispositivo debería buscar y almacenar automáticamente todas las emisoras de radio FM.
5. Pulse el botón "AVANZAR" o "RETROCEDER" para cambiar las emisoras de radio FM.

Tips!!

1. Pulse por largo tiempo el botón "MODE" cada vez para alternar diferentes funciones del altavoz, los modos aparecen en el siguiente orden: Bluetooth / USB/Micro SD (TF) / Radio FM / AUX →.
2. Cuando la unidad no está en uso, apagar el dispositivo para ahorrar energía de la batería.