LFH7470

PHILIPS

REMOTE DEVICE MANAGEMENT 3.8

Technical Documentation
Advanced Configuration

For Certified MDC Partners and Support technicians

PHILIPS

This page is intentionally left blank

Introduction **8**

1. System Reguirements **9**

1.1. Hardware 9
1.2. Software 9

2. System Architecture **10**

3. Installation process Windows 10 ..... **12**

3.1. Installation Internet Information Services 12
3.2. Installation MSSQL Server 2012 SP1 17
3.2.1. Unattended MSSQL installation 17
3.2.2. Customizable MSSQL installation 19
3.3. Installation IIS Web Service 25
3.4. Installation Management Console 27
3.5. Installation Updater Client on client computer 29
3.6. Related System Files and Registry Keys 32

4. Installation process Windows Server 2012 R2 ..... **37**

4.1. Installation Internet Information Services 38
4.2. Installation MSSQL Server 2012 SP1 46
4.2.1. Unattended MSSQL installation 46
4.2.2. Customizable MSSQL installation 48
4.3. Installation IIS Web Service 53
4.4. Installation Management Console 56
4.5. Installation Client Updater on client computer 58
4.6. Related System Files and Registry Keys 60

5. Upgrade from previous version **62**

5.1. Backup SQL Database 62
5.2. Uninstall previous PRDM Server 63
5.3. Install and configure IIS 63
5.4. Install PRDM IIS Web Service 63
5.5. Install PRDM Management Console 63

6. Management Console **64**

6.1. Database settings for unattended MSSQL installation 64
6.2. Database settings for custom defined MSSQL installation 65
6.3. Toolbar 66
6.3.1. Toolbar Menu - Server 66
6.3.2. Toolbar Menu – Author-PIN link 70
6.3.3. Toolbar Menu Keyword distribution 72
6.3.4. Toolbar menu - Refresh 73
6.3.5. Toolbar Menu - Exit 73
6.4. Configuration tree 74
6.4.1. Configuration tree - New Devices 74
6.4.2. Configuration tree - Unassigned Devices 74
6.4.3. Configuration tree – Organizational Units 75
6.4.4. Configuration tree – Device Group Configuration 75
6.4.5. Configuration tree – Device Configuration 76
6.5. Configuration list 76
6.6. Configuration editor 78

7. Updater Client 79

7.1. Log Files 80

8. Management Console - Custom filter 81

9. Management Console – Templates 81

9.1. Template creation 82
9.2. Template editing 82
9.3. Template deletion 83

10. Management Console - Firmware files 84

10.1. Add New Firmware 85

11. Management Console – Images 86

11.1. Add new image files 86
11.2. Delete selected images 87
11.3. Set to all configuration 87

12. Management Console SpeechAir Settings. 88

12.1. PRDM server URL 88
12.2. Refresh interval 88
12.3. WLAN enabled 88
12.4. User networks enabled 88
12.5. Bluetooth 88
12.6. VPN 88
12.7. Wallpaper 88
12.8. Autorotate screen 88
12.9. Uninstall apps 89
12.10. Install apps 89
12.11. Allow user to uninstall apps 89
12.12. Start app with smart button 89
12.13. Allow apps to access the location information 89
12.14. Show owner info on lockscreen 89
12.15. Owner info 89
12.16. Make password visible 89
12.17. Allow unknown sources 89
12.18. Camera 89
12.19. Select language 90
12.20. Spell checker 90
12.21. Automatic date and time 90
12.22. NTP server address 90
12.23. Time zone 90
12.24. Use 24-hour format 90
12.25. Date format 90
12.26. Firmware 90
12.27. Developer options 91

13. SpeechAir settings for Philips Dictation Recorder APK 92

13.1. PRDM server URL 92
13.2. Refresh interval 92
13.3. Data list URL 92

13.4. Data list refresh interval 92
13.5. Data list visible column 92
13.6. Data list author column 92
13.7. Slider configuration 92
13.8. Function button 92
13.9. Recording screen text 93
13.10. Purge dictation 93
13.11. Automatically send EOL dictations 93
13.12. Voice activation 93
13.13. Edit mode 94
13.14. Microphone sensitivity 94
13.15. Microphone directivity 94
13.16. Record notification beep 94
13.17. Jump back 94
13.18. Audio format 94
13.19. Email sending 94
13.20. Use dictation hub 94
13.21. Use SpeechLive 94
13.22. Author 95
13.23. Default author 95
13.24. Worktype 95
13.25. Default worktype 95
13.26. Category 95
13.27. Default category 95
13.28. Delivery 95
13.29. Default delivery 95
13.30. Mandatory author 95
13.31. Mandatory worktype 95
13.32. Mandatory category 95
13.33. Mandatory barcode 96
13.34. Mandatory data list 96
13.35. Mandatory delivery 96
13.36. Use encryption 96

14. Management Console - DPM Settings 97

14.1. 4-position Switch 97
14.1.1. Philips classic switch 97
14.1.2. Philips slide switch 97
14.1.3. International slide switch 97
14.1.4. Grundig slide switch 97
14.2. Active recording profile 97
14.3. Additional function key 98
14.4. Additional user defined labels 98
14.5. Append mode 98
14.6. Appearance 98
14.7. Audible scan 99
14.8. Background illumination time 99
14.9. Barcode scan button 99
14.10. Barcode scan mode 100
14.11. Delete files on the DPM after download 100
14.12. Device beep 100
14.13. Display a low area 100
14.14. Download file Keyword1 filter 101
14.15. Download file type 101
14.16. DSS mode 101

14.17. Edit mode ... 101
14.18. Enable noise reduction ... 102
14.19. Enable USB audio device ... 102
14.20. EOL button enabled ... 102
14.21. File name mode ... 102
14.22. File name prefix ... 103
14.23. Firmware version ... 103
14.24. Foot controlled operation ... 103
14.25. Index/Spoken instructions ... 103
14.26. Keyword area string ... 103
14.27. Keyword options ... 104
14.28. Lock timeout ... 104
14.29. Mandatory user input options ... 105
14.30. Mass storage write protection ... 105
14.31. Microphone directivity in hand/on desk ... 105
14.32. Microphone sensitivity ... 105
14.33. Plus/Minus button enabled ... 106
14.34. Protect device configuration ... 106
14.35. Record into one file only ... 107
14.36. Record notification beep ... 107
14.37. Recording format ... 107
14.38. Slider jump back time ... 108
14.39. Smart button configuration ... 108
14.40. Time format ... 109
14.41. Update DPM time ... 109
14.42. Welcome screen ... 109
14.43. Usage of keyword ... 110
14.44. Obligatory keyword selection ... 110
14.45. USB High Power Mode ... 111
14.46. Voice-activated recording ... 111

15. Management Console - SpeechMike Settings ... 112

15.1. Disconnect when OOR ... 112
15.2. Enable acoustical warning ... 112
15.3. Enable button blick buppression ... 112
15.4. Enable haptic warning ... 112
15.5. Enable ScrollWheel ... 113
15.6. Enable ScrollWheel Volume Control ... 113
15.7. Enable Trackball ... 113
15.8. Enable Trackball Volume Control ... 113
15.9. Enable wheel functions on Function-Keys ... 114
15.10. Lock Device Settings ... 114
15.11. Motion Control ... 114
15.12. Pick and Drop delay ... 115
15.13. Power Mode ... 115
15.14. Power off timer ... 115
15.15. Sleep mode timer ... 116
15.16. Trackball speed ... 116
15.17. USB gap detection mode ... 116

16. Management Console - Foot Control Settings ... 117

17. Version Changes and History ... 118

17.1. Version 3.7.370. ... 118

17.1.1. Changes and Improvements 119
17.2. Version 3.6.360.34 120
17.2.1. Changes and Improvements 120
17.3. Version 3.3.331.06 121
17.3.1. Changes and Improvements 122
17.4. Version 3.2.320.46 122
17.4.1. Changes and Improvements 123
17.5. Version 3.2.320.12 124
17.5.1. Changes und Improvements 125
17.6. Version 3.0.300.15 125
17.6.1. Changes und Improvements 126
17.7. Version 2.9.271.16 127

18. Known Issues 128

19. Purchase Unlimited Edition 129

Introduction

This document describes the installation, configuration and functionality of the Philips Remote Device Manager.

With Philips Remote Device Manager you can centrally manage your Philips Dictation devices. You can assign device configurations to users, device types and devices. Device configurations are regularly downloaded and cached by the Updater Client applications on the users' machines to allow fast configuration update of the connected devices.

The following models are supported:
SpeechAir 1100

Digital Pocket Memo 4th Generation
DPM8000, DPM8200*, DPM8500

SpeechMike Premium Touch
LFH3700, LFH3710, LFH3720, LFH3800, LFH3810, LFH3820

SpeechMike Premium
LFH3500, LFH3510, LFH3520*, LFH3600, LFH3610

SpeechMike 3rd Generation
LFH3200, LFH3210, LFH3220*, LFH3300, LFH3310

SpeechMike Air
LFH3000, LFH3010, LFH3020*

Foot Control
ACC2310, ACC2320 and ACC2330
Note:
The 2310, 2320 type Foot Controls have three pedals, and they are called 3-Pedal FootControl.
The four-pedal Foot Controls are called the 4-Pedal FootControl.

*Product not available in North America

1. System Requirements

1.1. Hardware

Minimum requirement: Pentium with 1GHz and 1GB RAM.
Recommended requirement: Pentium I3/I5/I7 or similar with 2 GHz and 2 GB RAM.
Harddisk - 50 GB free hard disk space for installing the Software is required.
.NET - Microsoft .NET Framework requires 250 MB of free disk space.

1.2. Software

Microsoft Windows 7 Service Pack 1 (32 and 64-bit)
Microsoft Windows 8.1 (32 and 64-bit)
Microsoft Windows 10 (64-bit)

Microsoft Windows Server 2008 R2 Service Pack 1
Microsoft Windows Server 2012 R2
Microsoft Windows Server 2016

Internet Information Services 7.0

The remote device management server needs one of the following SQL servers:
Windows SQL Server 2012 Service Pack 3
Microsoft SQL Server 2014 Service Pack 1
Microsoft SQL Server 2016

It is strongly recommended to have the latest Service Packs and hotfixes installed. Make sure that you have all the necessary operating system updates installed. For more information, see the Microsoft Windows Update website.

2. System Architecture



Figure 1 - Server, Console and Database installed on dedicated system



Figure 2 – Different systems for Database and for RDM Server and Console

SpeechExec Remote Device Manager is a client-server application with an SQL database and web service. The Remote Device Server runs as a Windows service and the following types of clients can be connected to it: the Management Console and the Updater Client. Most of the topics in this help file refer to the Management Console application.

- **MS IIS Server**

Provides a wireless interface for mobile devices.

- **MSSQL Server**

Stores the device configurations in an SQL database and serves the two kinds of clients (Management Console and Update Client) with data.

- **Management Console**

Allows the administrator to assign configurations to users, device types and devices. It can be installed on the same computer as the server using the server setup or on a separate computer.

- **Updater Client**

It is a small application that starts when the system starts on the user's machine. The Updater Client runs under the user's account and has an icon on the system tray. It checks, if a device is connected and asks the latest configuration from the server based on the device and user information. If the server is not available, it uses a cached configuration, if there is any. If the server is available, it is polled for new configurations regularly. However, the update takes place only when the application starts or a device is connected in order to avoid disturbing the user during work.

3. Installation process Windows 10

For a typical installation of the Philips Remote Device Manager environment the following components have to be installed:
Step 1 - Microsoft Internet Information Services (Web Server)
Step 2 - Microsoft SQL Express on a Computer
Step 3 - Philips Remote Device Management Web Service on IIS
Step 4 - Management Console on the Computer
Step 5 - Updater Client on Computer

In follows chapters we describe step-by-step the installation and configuration process.

Software and drivers Download the *.zip file from http://bit.ly/prdm38

Remote Device Manager
3.8.380.12

Unzip this and doublecklick on Autorun.exe



Autorun.bmp	05.12.2016 14:32	Bitmap-Bild	503 KB
Autorun.exe	05.12.2016 15:02	Anwendung	2.343 KB
Autorun.ini	05.12.2016 15:10	Konfigurationsein...	3 KB
Philips Remote Device Manager.chm	05.12.2016 14:32	Kompilierte HTML...	251 KB
PRDMIISWebServiceSetup.exe	05.12.2016 15:08	Anwendung	75.366 KB
PRDMManagementConsoleSetup.exe	05.12.2016 15:10	Anwendung	74.541 KB
PRDMUpdaterSetup.exe	05.12.2016 15:09	Anwendung	73.366 KB
readme.txt	20.12.2016 16:44	TXT-Datei	4 KB
SQLEXPR_x64_ENU.exe	25.07.2014 15:43	Anwendung	151.642 KB
SQLEXPR32_x86_ENU.exe	25.07.2014 15:44	Anwendung	131.026 KB

3.1. Installation Internet Information Services

Before you start with the installation of Philips Remote Device Manager components you must activated IIS on your PC.

Start the Control Panel – type WIN+R


Run
Type the name of a program, folder, document, or Internet resource, and Windows will open it for you.
Open:
control
OK
Cancel
Browse...

Other option - go to Start, select Windows System and select Control Panel.



Click on Programs category



Click on Turn Windows features on or off option



Scroll down and click on Internet Information Services – this is our webserver installation - Click on OK



Next step – select World Wide Web Services and activate Windows Authentication and click on OK.



Check and activate Application Development Features for ASP.NET 4.6 and click on OK



Check the Installation by opening a Web browser and verifying that the following default Web page is displayed when you use the http://localhost/ address. You can use also the computer name or the IP address as the URL see the screenshots below.



3.2. Installation MSSQL Server 2012 SP1

You can select between two installation options – unattended and customizable.

You can start unattended and customizable setup for the MSSQL Server



We describe both options; the first and easy one is the unattended option

3.2.1. Unattended MSSQL installation

Click on red marked field, wait a short time until the installation process is completed



The unattended Installation process is running.



Setup files are downloaded



Once the installation windows are closed, you can open the Windows Task Manager (Keyboard shortcut STRG+SHIFT+ESC), and check, if the new Service MSSQL$PRDM is up and running.



Now, you can start with the next step – Installation IIS Web Service

3.2.2. Customizable MSSQL installation

Depending on the operating system select the 64bit or 32bit Installer.



Click on *New installation or add features…*



Click Next



Select the Perform a new installation of SQL Server 2012 and click on NEXT.
Our previous, unattended installation, is also recognized with the instance name PRDM and the ID MSSQL11.PRDM



Accept the licence terms and click on NEXT



Check the Instance and Features for installation – Database Engine Services, SQL Server Replication and click on NEXT



Define the instance name - our test installation uses the PRDMPRI name.
If you have other installed MSSQL Instances, you see this as installed instances, in our example named PRDM.
Enter the information, then click NEXT.



Check the startup type is automatic and click on Next



Select the SQL Server Administrator name



Click on Next



The installation process will continue automatically, then click on Close.



Once the installation windows are closed, you can open the Windows Task Manager (Keyboard shortcut STRG+SHIFT+ESC), and check, if the new Service MSSQL$PRDMPRI is up and running.



3.3. Installation IIS Web Service

Click on Install Philips Remote Device Manager IIS Web Service.

Click on Next. Files are prepared for installation process.



Click on Install



The installer create new virtual PRDM directory for the installation



Installation is completed,



Now we can start with the next step – installation Management Console.

3.4. Installation Management Console

Management Console allows the administrator to assign configurations to users, device groups and single devices. It can be installed on the same computer as the server using the server setup or on a separate computer.

Click on the 3rd option – Install Philips Remote Device Manager Management Console

Click on Next



Click on Install



The installation wizard is running, finaly activate the Launch Management Console and click on Finish



The installer creates a new icon on the PC Desktop

3.5. Installation Updater Client on client computer

Select the 4th option – Install Philips Remote Device Manager Updater client

Select one of the available languages – English or German and click on OK



The Installation wizard prepares all files for the installation process.
Click on Next



For the connection to the previous installed Management Console you need the URL to the PRDM service installed on the IIS server.



Click on Install and the installation process will continue automatically.



The installation process is completed, tick the box Launch Remote Device Manager Updater Client and click on Finish



The Updater Client is running



Verify the installation, open Windows Task Manager, select Processes and check if the Process named Philips Remote Device Manager – Updater Client (32 bit) is running.



3.6. Related System Files and Registry Keys

Installation path:
C:\Program Files (x86)\Philips Speech\Remote Device Manager\IIS Web Service
C:\Program Files (x86)\Philips Speech\Remote Device Manager\ManagementConsole
C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient

Log files:
C:\Users\USERNAME\AppData\Local\Philips Remote Device Manager\ManagementConsole\log
C:\Users\USERNAME\AppData\Local\Philips Remote Device Manager\UpdaterClient\log

Local configuration files:
C:\Users\USERNAME\AppData\Local\Philips Remote Device Manager\UpdaterClient\

The Application Data folder, also called AppData, is one of many hidden system folders containing important files and documents that help run Windows operating systems. By default, the folder is hidden.
Open the Microsoft Windows Explorer and go to the user folder C:\Users\USERNAME\, in this example SPSTest, click View and activate Hidden items in the tab Show/hide.



Registry

Computer\HKEY_CURRENT_USER\Software\Microsoft\Windows NT\CurrentVersion\
AppCompatFlags\Compatibility Assistant\Persisted



Computer\HKEY_CURRENT_USER\Software\Philips Speech\RemoteDevice Manager\





Computer\HKEY_LOCAL_MACHINE\SOFTWARE\Classes\Installer\Features\



Computer\HKEY_LOCAL_MACHINE\SOFTWARE\Microsoft\Windows\CurrentVersion\
Installer\Folders



Computer\HKEY_LOCAL_MACHINE\SOFTWARE\Microsoft\Windows\CurrentVersion\
Installer\UserData\S-1-5-18\Components\068B724715B43FD429779B2ACDBE675D



Computer\HKEY_LOCAL_MACHINE\SOFTWARE\Microsoft\Windows\CurrentVersion\
Installer\UserData\S-1-5-18\Products\C8DB0CC6395766A4786296A9C710667F\InstallProperties

Name	Type	Data
(Default)	REG_SZ	(value not set)
AuthorizedCDFPrefix	REG_SZ	
Comments	REG_SZ	
Contact	REG_SZ	
DisplayName	REG_SZ	Philips Remote Device Manager Updater Client
DisplayVersion	REG_SZ	3.2.320.18
EstimatedSize	REG_...	0x00003ee3 (16099)
HelpLink	REG_SZ	
HelpTelephone	REG_SZ	
InstallDate	REG_SZ	20130614
InstallLocation	REG_SZ	C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\
InstallSource	REG_SZ	C:\Users\peter\AppData\Local\Downloaded Installations\{26E2C538-C418-4980-956D-43B1D812FF7B}\
Language	REG_...	0x00000000 (0)
LocalPackage	REG_SZ	C:\Windows\Installer\a25162.msi
ModifyPath	REG_...	MsiExec.exe /X{6CC0BD8C-7593-4A66-8726-699A7C0166F7}
NoModify	REG_...	0x00000001 (1)
ProductID	REG_SZ	none
Publisher	REG_SZ	Speech Processing Solutions GmbH
Readme	REG_SZ	
RegCompany	REG_SZ	
RegOwner	REG_SZ	peter
Size	REG_SZ	
UninstallString	REG_...	MsiExec.exe /X{6CC0BD8C-7593-4A66-8726-699A7C0166F7}
URLInfoAbout	REG_SZ	http://www.philips.com/dictation
URLUpdateInfo	REG_SZ	
Version	REG_...	0x03020140 (50463040)
VersionMajor	REG_...	0x00000003 (3)
VersionMinor	REG_...	0x00000002 (2)
WindowsInstaller	REG_...	0x00000001 (1)

Computer\HKEY_LOCAL_MACHINE\SOFTWARE\Wow6432Node\Microsoft\Windows\
CurrentVersion\SharedDLLs

Name	Type	Data
C:\Program Files (x86)\Philips Speech\Remote Device Manager\ManagementConsole\Infragistics2.Shared.v10.1.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\ManagementConsole\Infragistics2.Win.Misc.v10.1.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\ManagementConsole\Infragistics2.Win.UltraWinDataSource.v10.1.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\ManagementConsole\Infragistics2.Win.UltraWinEditors.v10.1.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\ManagementConsole\Infragistics2.Win.UltraWinGrid.v10.1.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\ManagementConsole\Infragistics2.Win.UltraWinStatusBar.v10.1.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\ManagementConsole\Infragistics2.Win.UltraWinTabControl.v10.1.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\ManagementConsole\Infragistics2.Win.UltraWinToolbars.v10.1.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\ManagementConsole\Infragistics2.Win.v10.1.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\ManagementConsole\log4net.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\ManagementConsole\Philips Remote Device Manager.chm	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\ManagementConsole\PIA.SpMikeCtrl.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\ManagementConsole\PSP.Common.Logger.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\ManagementConsole\PSP.RemoteDeviceManager.Common.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\ManagementConsole\PSP.RemoteDeviceManager.ManagementConsole.exe	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\Server\log4net.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\Server\Philips Remote Device Manager.chm	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\Server\PSP.Common.Logger.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\Server\PSP.RemoteDeviceManager.Common.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\Server\PSP.RemoteDeviceManager.Server.exe	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\Server\PSP.RemoteDeviceManager.ServerLib.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\de\PSP.RemoteDeviceManager.Common.resources.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\Infragistics2.Shared.v10.1.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\Infragistics2.Win.Misc.v10.1.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\Infragistics2.Win.UltraWinDataSource.v10.1.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\Infragistics2.Win.UltraWinEditors.v10.1.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\Infragistics2.Win.UltraWinGrid.v10.1.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\Infragistics2.Win.UltraWinStatusBar.v10.1.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\Infragistics2.Win.UltraWinTabControl.v10.1.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\Infragistics2.Win.UltraWinToolbars.v10.1.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\Infragistics2.Win.v10.1.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\log4net.dll	REG_DWORD	0x00000001 (1)

Computer\HKEY_LOCAL_MACHINE\SOFTWARE\Wow6432Node\Microsoft\Windows\
CurrentVersion\Uninstall\{6CC0BD8C-7593-4A66-8726-699A7C0166F7}

Name	Type	Data
(Default)	REG_SZ	(value not set)
AuthorizedCDFPrefix	REG_SZ	
Comments	REG_SZ	
Contact	REG_SZ	
DisplayName	REG_SZ	Philips Remote Device Manager Updater Client
DisplayVersion	REG_SZ	3.2.320.18
EstimatedSize	REG_DWORD	0x00003ee3 (16099)
HelpLink	REG_SZ	
HelpTelephone	REG_SZ	
InstallDate	REG_SZ	20130614
InstallLocation	REG_SZ	C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\
InstallSource	REG_SZ	C:\Users\peter\AppData\Local\Downloaded Installations\{26E2C538-C418-4980-956D-43B1D812FF7B}\
Language	REG_DWORD	0x00000000 (0)
ModifyPath	REG_EXPAND_SZ	MsiExec.exe /X{6CC0BD8C-7593-4A66-8726-699A7C0166F7}
NoModify	REG_DWORD	0x00000001 (1)
Publisher	REG_SZ	Speech Processing Solutions GmbH
Readme	REG_SZ	
Size	REG_SZ	
UninstallString	REG_EXPAND_SZ	MsiExec.exe /X{6CC0BD8C-7593-4A66-8726-699A7C0166F7}
URLInfoAbout	REG_SZ	http://www.philips.com/dictation
URLUpdateInfo	REG_SZ	
Version	REG_DWORD	0x03020140 (50463040)
VersionMajor	REG_DWORD	0x00000003 (3)
VersionMinor	REG_DWORD	0x00000002 (2)
WindowsInstaller	REG_DWORD	0x00000001 (1)

Computer\HKEY_LOCAL_MACHINE\SOFTWARE\Wow6432Node\Philips Speech\
Remote Device Manager\ManagementConsole\Setup

Name	Type	Data
(Default)	REG_SZ	(value not set)
InstallDir	REG_SZ	C:\Program Files (x86)\Philips Speech\Remote Device Manager\ManagementConsole\

Computer\HKEY_LOCAL_MACHINE\SOFTWARE\Wow6432Node\Philips Speech\
Remote Device Manager\Server\Setup

Name	Type	Data
(Default)	REG_SZ	(value not set)
InstallDir	REG_SZ	C:\Program Files (x86)\Philips Speech\Remote Device Manager\Server\

Computer\HKEY_LOCAL_MACHINE\SOFTWARE\Wow6432Node\Philips Speech\
Remote Device Manager\UpdaterClient\Setup

Name	Type	Data
(Default)	REG_SZ	(value not set)
Language	REG_SZ	en
ManagementServe...	REG_SZ	127.0.0.1
ManagementServe...	REG_DWORD	0x000035cf (13775)

Computer\HKEY_LOCAL_MACHINE\SOFTWARE\Wow6432Node\Philips Speech\
Remote Device Manager\UpdaterClient\Setup

Name	Type	Data
(Default)	REG_SZ	(value not set)
InstallDir	REG_SZ	C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\

Computer\HKEY_USERS\S-1-5-21-870713966-423158035-1578731419-1000\Software\
Microsoft\Windows NT\CurrentVersion\AppCompatFlags\Compatibility Assistant\Persisted

Name	Type	Data
C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\PSP.RemoteDeviceManager.UpdaterClient.exe	REG_DWORD	0x00000001 (1)

Computer\HKEY_USERS\S-1-5-21-870713966-423158035-1578731419-1000\Software\
Philips Speech\Remote Device Manager\ManagementConsole\

Name	Type	Data
(Default)	REG_SZ	(value not set)
FirmwareFileFilterIndex	REG_DWORD	0x00000002 (2)
LastSelectedFirmwareType	REG_DWORD	0x00000004 (4)
ManagementServerAddress	REG_SZ	127.0.0.1
ManagementServerPort	REG_DWORD	0x000035cf (13775)
SelectedPageIndex	REG_DWORD	0x00000000 (0)

Computer\HKEY_USERS\S-1-5-21-870713966-423158035-1578731419-1000\Software\
Philips Speech\Remote Device Manager\UpdaterClient\

Name	Type	Data
(Default)	REG_SZ	(value not set)
SupressConnectionMessages	REG_DWORD	0x00000001 (1)

4. Installation process Windows Server 2012 R2

For a typical installation of the Philips Remote Device Manager environment the following components have to be installed:

Step 1 - Microsoft Internet Information Services
Step 2 - Microsoft SQL Express on a Server Computer
Step 3 - Philips Remote Device Management Web Service on IIS
Step 4 - Management Console on the Server Computer
Step 5 - Updater Client on Client Computer.

In follows chapter we describe step-by-step the installation and configuration process.

Software and drivers Download the *.zip file from http://bit.ly/prdm38

Remote Device Manager
3.8.380.12

Unzip this and doublecklick on Autorun.exe



Autorun.bmp	05.12.2016 14:32	Bitmap-Bild	503 KB
Autorun.exe	05.12.2016 15:02	Anwendung	2.343 KB
Autorun.ini	05.12.2016 15:10	Konfigurationsein...	3 KB
Philips Remote Device Manager.chm	05.12.2016 14:32	Kompilierte HTML...	251 KB
PRDMIISWebServiceSetup.exe	05.12.2016 15:08	Anwendung	75.366 KB
PRDMManagementConsoleSetup.exe	05.12.2016 15:10	Anwendung	74.541 KB
PRDMUpdaterSetup.exe	05.12.2016 15:09	Anwendung	73.366 KB
readme.txt	20.12.2016 16:44	TXT-Datei	4 KB
SQLEXPR_x64_ENU.exe	25.07.2014 15:43	Anwendung	151.642 KB
SQLEXPR32_x86_ENU.exe	25.07.2014 15:44	Anwendung	131.026 KB

4.1. Installation Internet Information Services

Before you start with the installation of Philips Remote Device Manager components you must activated IIS on your PC.

Server Manager

Here we describe the full installation process from the Server Manager.

Copyright © 2013 Microsoft Corporation. All rights reserved.

In the Server Manager window, with the Dashboard and Quick Start selected, click Add roles and futures, or click the Manager menu, and then click Add Roles and Features.



The Add Roles and Features Wizard will start with a Before You Begin page. On the page click on Next



On the installation Type page, select Role-based or future-based installation to configure a single server. Click Next button.



On the Server Selection page, activate Select a server from the server pool, and then select a server.



On the Server Roles page select Web Server (IIS)



In the Add Roles and Features wizard, click Add Features if you want to install the IIS Management Console. If you do not want to install the Management Console, uncheck Include management tools (if applicable), and then click Continue. Our recommendation – activate Add Features.



On the Server Roles page click on Next.



Click again on Next



On the Web Server Role (IIS) page click on Next.



On the Role Services page select Windows Authentication



Also activate the ASP.NET 4.5 for Application Development and click on Next



On the Confirmation page, verify the role services and features that are selected. Select Restart the destination server automatically if required to restart the destination server if the settings need to take immediate effect.



To save the configuration information to an XML-based file that you can use for unattended installations with Windows PowerShell, select Export configuration settings, move to the appropriate path in the Save As dialog box, enter a file name, and then click Save.
When you are ready to start the installation process on the Confirmation page, click Install.

The installation progress page is displayed.



On the Results page verify that the installation succeeds and click on Close



Check the Instalaltion by opening a Web browser and verifying thet the following default Web page is displayed when you use the http://localhost/ address. You can use also the computer name or the IP address as the URL see the screenshots below.



4.2. Installation MSSQL Server 2012 SP1

You can select between two installation options – unattended and customizable.
We describe both options; the first and easy is the unattended

4.2.1. Unattended MSSQL installation

Select the first option for Microsoft SQL Server 20012 R2 Express Edition installation. Click on red marked field, wait a short time until the installation process is completed



Unattended Installation process is running



Once the installation windows are closed, you can open the Windows Task Manager, and check the new service MSSQL$PRDM is up and running.



Other check – from the commandline

sqlcmd /S servername\instancename –U sa –P PRDMSQL#1



4.2.2. Customizable MSSQL installation

Depending on the operating system select the 64bit or 32bit Installer.



Click on New SQL Server stand-alone installation or add features…



Accept the license terms and click on Next



Click Next



On the Feature Selection page, the SQL Server features are separated into two main sections: Instance Features and Shared Features. Check the preconfigured settings and click on Next



Use the Instance Configuration page of the SQL Server Installation Wizard to specify whether to create a default instance or a named instance of SQL Server. If an instance of SQL Server is not already installed, a default instance will be created unless you specify a named instance.



Define different authentification methods, depending on your network configuration or keep the preconfigured settings and click on Next



Use this page to set the SQL Server security mode, and to add Windows users or groups as administrators of the SQL Server Database Engine.



Use the Error Reporting page of the SQL Server Installation Wizard to enable feature error reporting functionality for SQL Server. Click Next.



Installation is running and completed. Click on Close and the installation is ready



Check the installation - open the Windows Task Manager (Keyboard shortcut STRG+SHIFT+ESC) and check if a new instance MSSQL$SQLEXPRESS is running.



4.3. Installation IIS Web Service

Select second option to install Philips Remote Device Manager IIS Web Service.

Click on Next



Click Install to start with the installation prozess.



Click Finish to close the installation.






Internet Information Services (IIS) Manager
2K12PRDMPRI ▸ Sites ▸ Default Web Site ▸ PRDM ▸
File View Help
Connections
Start Page
2K12PRDMPRI (2K12PRDMPRI
Application Pools
Sites
Default Web Site
PRDM
/PRDM Home
Filter:
Go
Show All
Group by: Area
ASP.NET
.NET Authorizat...
.NET Compilation
.NET Error Pages
.NET Globalization
.NET Profile
.NET Roles
.NET Trust Levels
.NET Users
Application Settings
Connection Strings
Machine Key
Pages and Controls
Providers
Session State
SMTP E-mail
IIS
Authentication
Compression
Default Document
Directory Browsing
Error Pages
Handler Mappings
HTTP Respon...
Logging
MIME Types
Modules
Output Caching
Request Filtering
SSL Settings
Management
Configurat... Editor
Features View
Content View
Actions
Open Feature
Explore
Edit Permissions...
Basic Settings...
View Virtual Directories
Manage Application
Browse Application
Browse *:80 (http)
Advanced Settings...
Help
Ready


Internet Information Services (IIS) Manager
2K12PRDMPRI ▸ Sites ▸ Default Web Site ▸ PRDM ▸
File View Help
Connections
Start Page
2K12PRDMPRI (2K12PRDMPRI
Application Pools
Sites
Default Web Site
PRDM
Authentication
Group by: No Grouping
Name
Status
Response Type
Anonymous Authentication
Enabled
ASP.NET Impersonation
Disabled
Windows Authentication
Enabled
HTTP 401 Challenge
Features View
Content View
Alerts
Click here to learn how to configure Extended Protection.
Actions
Disable
Providers...
Help
Configuration: 'localhost' applicationHost.config , <location path="Default Web Site/PRDM">

4.4. Installation Management Console

Management Console allows the administrator to assign configurations to users, device types and devices. It can be installed on the same computer as the IIS web service or on a separate computer.



The installation wizard prepares all files for the installation process.
Click on Next



Click on Install



The installer running through the installation setup, finally click on Finish.



Check the installation - open the Windows Task Manager (Keyboard shortcut STRG+SHIFT+ESC) and check, if the PSP.RemoteDeviceManager.ManagementConsole.exe process is running.



Installation is completed, and we can proceed to the next installation step.

The Installer create also new Icon on the PC Desktop

4.5. Installation Client Updater on client computer

Select the 4th option – Install Philips Remote Device Manager Updater client

Select one of the available languages – English or German and click on OK



The Installation wizard prepares all files for the installation process.
Click on Next



For the connection to the previous installed Management Console you need the URL to the PRDM service installed on the IIS server.



In our example we connected to the 2k12prdmpri computer placed in the testnet.at domain.

http://2k12prdmpri.testnet.at/PRDM

Click on Install and the installation process will continue automatically.



The installation process is completed, tick the box Launch Remote Device Manager Updater Client and click on Finish



Check the installation - open the Windows Task Manager (Keyboard shortcut STRG+SHIFT+ESC) and check, if the PSP.RemoteDeviceManager.UpdaterClient.exe process is running



4.6. Related System Files and Registry Keys

Installation path:
C:\Program Files (x86)\Philips Speech\Remote Device Manager\IIS Web Service

C:\Program Files (x86)\Philips Speech\Remote Device Manager\ManagementConsole

C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient

Log files:
C:\Users\USERNAME\AppData\Local\Philips Remote Device Manager\ManagementConsole\log

C:\Users\USERNAME\AppData\Local\Philips Remote Device Manager\UpdaterClient\log
File name structure:
UpdaterClient_YYYYMMDD_HHMMSS.log – UpdaterClient_20130614_131053.log

Local configuration files:
C:\Users\USERNAME\AppData\Local\Philips Remote Device Manager\UpdaterClient\
File name:
Remote Device Manager.32.local – xml file

File name structure:
UpdaterClient_YYYYMMDD_HHMMSS.log – UpdaterClient_20130614_131053.log

Registry

Computer\HKEY_LOCAL_MACHINE\SOFTWARE\Wow6432Node\Microsoft\Windows\
CurrentVersion\SharedDLLs\

C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\de\PSP.RemoteDeviceManager.Common.resources.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\Infragistics2.Shared.v10.1.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\Infragistics2.Win.Misc.v10.1.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\Infragistics2.Win.UltraWinDataSource.v10.1.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\Infragistics2.Win.UltraWinEditors.v10.1.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\Infragistics2.Win.UltraWinGrid.v10.1.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\Infragistics2.Win.UltraWinStatusBar.v10.1.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\Infragistics2.Win.UltraWinTabControl.v10.1.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\Infragistics2.Win.UltraWinToolbars.v10.1.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\Infragistics2.Win.v10.1.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\log4net.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\Philips Remote Device Manager.chm	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\PIA.DpmCtrlLib.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\PIA.SpMikeCtrl.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\PSP.Common.Logger.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\PSP.RemoteDeviceManager.Common.dll	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\PSP.RemoteDeviceManager.UpdaterClient.exe	REG_DWORD	0x00000001 (1)
C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\PSP.RemoteDeviceManager.UpdaterClientLib.dll	REG_DWORD	0x00000001 (1)

Computer\HKEY_LOCAL_MACHINE\SOFTWARE\Wow6432Node\Microsoft\Windows\
CurrentVersion\Uninstall\

(Default)	REG_SZ	(value not set)
AuthorizedCDFPrefix	REG_SZ	
Comments	REG_SZ	
Contact	REG_SZ	
DisplayName	REG_SZ	Philips Remote Device Manager Updater Client
DisplayVersion	REG_SZ	3.2.320.18
EstimatedSize	REG_DWORD	0x0000424a (16970)
HelpLink	REG_SZ	
HelpTelephone	REG_SZ	
InstallDate	REG_SZ	20130628
InstallLocation	REG_SZ	C:\Program Files (x86)\Philips Speech\Remote Device Manager\UpdaterClient\
InstallSource	REG_SZ	C:\Users\Administrator\AppData\Local\Downloaded Installations\{26E2C538-C418-4980-956D-43B1D812FF7B}\
Language	REG_DWORD	0x00000000 (0)
ModifyPath	REG_EXPA...	MsiExec.exe /X{6CC0BD8C-7593-4A66-8726-699A7C0166F7}
NoModify	REG_DWORD	0x00000001 (1)
Publisher	REG_SZ	Speech Processing Solutions GmbH
Readme	REG_SZ	
Size	REG_SZ	
UninstallString	REG_EXPA...	MsiExec.exe /X{6CC0BD8C-7593-4A66-8726-699A7C0166F7}
URLInfoAbout	REG_SZ	http://www.philips.com/dictation
URLUpdateInfo	REG_SZ	
Version	REG_DWORD	0x03020140 (50463040)
VersionMajor	REG_DWORD	0x00000003 (3)
VersionMinor	REG_DWORD	0x00000002 (2)
WindowsInstaller	REG_DWORD	0x00000001 (1)

5. Upgrade from previous version

The following steps are the suggested and supported upgrade process

5.1. Backup SQL Database

The most important part of a SQL Server maintenance plan is backing up your database. To backup a database, you cannot simply copy the respective MDF and LDF files of the database as SQL Server has a lock on these. Instead, you need to create a true backup file through SQL Server.

While this can be done by developing a Maintenance Plan inside of SQL Management Studio, the free, delivery with Philips Remote Device Manager, Express editions of SQL Server do not offer this interface. To work around this, you can easily backup your databases by running the command below while logged in as a Windows Administrator.

We create a new Folder for the backup's e.g PRDMDBBACKUP.

Start the command line interpreter with WIN+R and type cmd, klick OK type Enter.



Type the command:

```
sqlcmd –U sa –P PRDMSQL#1 –S MS2012R2PRI\PRDM –Q "BACKUP DATABASE [PRDMDB] TO DISK='C:\PRDMDBBACKUP\DBBACKUP.bak'"
```

Description for the command
-U sa – is the user login for the Database
-P PRDMSQL#1– is a user-specified password. Passwords are case sensitive. If the –U option is used and the –P option is not used, sqlcmd prompts the user for a password.
-S MS2012R2PRI\PRDM – specifies the server\instance of SQL Server to which to connect, in our example this is **MS2012R2PRI** for Server and **PRDM** for instance.
-Q "cmdline query" execute a query when sqlcmd starts and then immediately exits sqlcmd.

Source:
https://msdn.microsoft.com/en-us/library/ms180944.aspx

5.2. Uninstall previous PRDM Server

Go to Control panel, click Programs, and select Uninstall a program.
Search for the Philips Remote Device Manager components.



5.3. Install and configure IIS

See chapter 3.1 for Windows 10 or chapter 4.1 for Windows Server 2012 R2

5.4. Install PRDM IIS Web Service

See chapter 3.3 for Windows 10 and chapter 4.3 for Windows Server 2012 R2

5.5. Install PRDM Management Console

- Specify new URL for accessing PRDM IIS Web Service
- Configure SQL connection string
- Open PRDM Console and add the previous string for the connection to the database. This automatically triggers an PRDM IIS Web Service restart which causes the database upgrade.
- Old PRDM Server cannot connect to the upgraded database anymore
- Install or upgrade all PRDM Updater Clients – during the installation you must specify new URL for accessing PRDM IIS Web Service during upgrade.

There is no data loss during the upgrade, all existing group, device and template configurations are kept in the database.

Rollback to previous version is possible after restoring the previous SQL database from backup, uninstalling all new PRDM components and reinstalling previous PRDM components

6. Management Console

The Management Console allows the administrator to assign configurations to users, device types and devices. It can be installed on the same computer as the IIS web server using the server setup or on a separate computer. Management Console is the GUI for the Remote Device Server.



6.1. Database settings for unattended MSSQL installation

The unattended installer uses the following parameters:

/INSTANCENAME=PRDM
/FEATURES=SQLEngine,Tools
/SECURITYMODE=SQL
/SAPWD=PRDMSQL#1
/ADDCURRENTUSERASSQLADMIN
/SQLSVCACCOUNT="NT AUTHORITY\SYSTEM

The hardcoded SA password is **PRDMSQL#1**



Click on Server and select

Database settings

Fill the Server name with .\PRDM
The Database name –define a preferred name, in our example we use PRDM2013
Login user name – use *sa* and for Password use PRDMSQL#1
Finally click on NEXT



Management Console checks the settings and if all parameters are correct, a confirmation window will appear. Click on Finish and the SpeechExec Remote Device Server is connected with a MSSQL Database ready to setup all the devices and parameters.



6.2. Database settings for custom defined MSSQL installation



Click on Server and select

Database settings

Fill the Server name with NB101\PRDM
The Database name –define a preferred name, in our example we use PRDM32320
Login user name – use the Windows integrated authentification
Finally click on NEXT Click on Finish – you are connected with the PRDM32320 Database



6.3. Toolbar

SpeechExec Remote Device Manager has the following toolbar.



6.3.1. Toolbar Menu - Server

Server – shows the server menu, where server-related tasks are available



Database settings
Options
Check number of device configurations
Enter registration key
Connect to server
LAN Adapter settings
Assignment mode

Database settings (Keyboard shortcut - CTRL+F1). Create a new database or specify an existing one for using the application. Configuration settings and firmware files will be uploaded to and stored in the database. The Updater Client will upload the necessary settings and firmware files to the connected device from this database.



Create new database and tables – connectto the server (2k12prdmpri\prdm) and create new database: my_database.





Options (Keyboard shortcut - CTRL+F2)



Application mode
Define the operation mode of the application.

Distributed mode – this mode is the recommended use of Philips Remote Device Manager. In distributed mode, the updater clients download the related configurations from the server in the background. The Updater Client will use only the already downloaded configuration at the device connection, changes made in the configuration since the last download will not take effect. The download period can be specified between 1-60 minutes. This mode offers the maximum performance and the minimum impact on other applications.

Local mode: In this mode the updater clients refresh the cached configuration on each device connection. The time of the refresh is unpredictable as it depends on several external factors. This mode can be used to simulate the operation of the system, but not suggested in production environment.

Secure mode – you can enable secure mode or disable secure mode.
The secure mode in the Remote Device Management Tool means that only Windows users of the **RDMAdmin** Active Directory group can use the Management Console and connect to the IIS Web Service.
In secure operation mode, the Updater Client does not save configurations in cache, which means that you cannot use PRDM in offline mode and a constant connection is required to PRDM IIS web service.
Additionally, if connection to the IIS web service is lost when the Updater Client is running, then the last known configuration will also be lost when you close the Updater Client.

There are certain files and settings that are still cached in secure operation mode:

- SpeechMike and Foot Control configurations
- Binary files, such as firmware files, images and APK files

You can create the "RDMAdmin" group in the Active Directory and assign the users to the group in the administration tool manually.

To use central login, choose Options from the Server toolbar item in the Remote Device Management Tool and select the Enable secure operation mode checkbox. In this case, the Management Console can be accessed by RDMAdmin group members only.

The local administrator must configure IIS to enable the PRDM IIS Web Service. The following settings ensure that only those requests can reach the PRDM IIS Web Service where the calling user can be successfully validated in the Windows domain or Active Directory.

1. Enable Windows Authentication and disable all other authentication methods for the PRDM IIS Web Service Virtual Application in IIS.
2. Enable NTLM authentication provider.
3. Enable HTTPS binding and disable all HTTP bindings for the web site containing PRDM IIS Web Service Virtual Application in IIS.

After successful configuration, the web service checks the user's AD membership. A user must be the member of the following AD groups:

- Management Console users: **RDMAdmin**
- Updater Client users: **RDMAdmin, RDMUser, SEEAllowedAuth, SEEAllowedTrans**

Check number of device configurations (Keyboard shortcut - CTRL+F3)



It indicates the maximum number of possible device configurations and the current number of the device configurations.
When installing the application, a limited edition is available, where maximum 10 device configurations can be created.
If the number of the configurations reaches the limit, you can create further configurations only by deleting existing configurations or by upgrading to the Enterprise edition. To upgrade the application to Enterprise edition, contact your local Philips Certified Partner.

Enter registration key (Keyboard shortcut - CTRL+F4)

Enter the registration key at first use of the application. The key is validated by the Server at start-up and upon entering a new key (for example, when upgrading the application). If the registry key is deleted and the Server is restarted, no more device configurations are allowed, but the previously created configurations will not be lost. The registry key is also required if the Server is installed on another computer or in a clean Windows environment.



Connect to server (Keyboard shortcut - CTRL+F5)

Enter the name or the IP address of the Remote Device Manager IIS Web Service. The port can be set additionally after the IIS Web Service name with a colon if not the default (port 80) is used.





LAN Adapter settings (Keyboard shortcut - CTRL+F6)

You can export DPM configurations into specific folders in specific format to supported devices through w ACC8160 WLAN adapter.





Export the configuration files to the LAN adapter as follow:

- Select the LAN Adapter options from the toolbar (Server/LAN Adapter settings)
- In the LAN Adapter dialog, define the root folder for the configuration files.
  The root folder must be an existing folder and must be reachable.
- Click on Export now button.
  All configurations under the organization units are exported.

Select the Organisation Group or Products Group.



Click on Server, select LAN Adapter settings (CTRL+F6) and click on Export now





Folder Structure **before** Export



Folder Structure **after** Export – you can see the new folder named with the device serial number.



Inside the folder you can see device config file, named serial number.cfg.xml



Assignment mode (Keyboard shortcut - CTRL+F7)

Select whether you want to assign SpeechMike and Foot Control device configurations to Windows logins (DOMAIN\USERNAME) or workstations (COMPUTERNAME).



If you assign Windows login to device configurations then the same user will have separate device configurations on each computer they log in.

Important: If you change the assignment mode, all your SpeechMike and Foot Control device configurations are removed from the database.

6.3.2. Toolbar Menu – Author-PIN link

Author-PIN link



Displays the Link author name with PIN code window, where the author-PIN code linking can be managed.

This option applies to Digital Pocket Memo 8000 series only.

Here you can define whether to link authors with unique PIN code:

Set author-PIN link: Select this option to link author and PIN code on all connected Digital Pocket Memo 8000 series devices within the selected organizational unit. If the organizational unit belonging to the connected device has an author name and a PIN list specified, the Updater Client sets the link with the specified list. Keyword 1 values for the selected organizational unit cannot be configured, if author-PIN code linking is set. The author-PIN code links must be set separately for the organizational units in the configuration tree.



Note:
Author-PIN code linking is not available for devices in the Unassigned group.

Clear author-PIN link on devices:
Select this option to disable linking between author name and PIN code on all connected Digital Pocket Memo 8000 series devices. Keyword 1 values are available for configuration.

Do not change author-PIN link settings:
Select this option to leave linking between author name and PIN code unchanged on all connected Digital Pocket Memo 8000 series devices. In this case, no linking is made or cleared by the Updater Client. Keyword 1 values defined in the configuration editor will be ignored by devices with author-PIN code linking.This is the default value.

Set author-PIN code linking, as follows:



Go to the configuration tree.

Select an organizational unit.
Right-click on the selected Organizational unit, and choose –

Set author-PIN link - from the context menu.

The Link author name with PIN code window is displayed.



Set the author-PIN code links by defining the author name (maximum 30 characters) in the Author name column and the PIN code (digital numeric values allowed) in the PIN code column.

Notes:
Maximum 40 author-PIN code links can be set.The PIN code must be unique for each author.

6.3.3. Toolbar Menu Keyword distribution

Keyword distribution



Displays the Keyword list management window, where keyword distribution is managed.

This option applies to Digital Pocket Memo 8000 series only.

Define to set the keywords on devices to pre-defined values:



Distribute keyword list to devices:
Select this option to set the keywords on Digital Pocket Memo 8000 series devices based on the CSV files in the specified network share.If the organizational unit belonging to the connected device has a CSV file with a matching name in the network share, the Updater Client copies that CSV file to the device, which will import the file automatically and use the specified keyword values. Keyword 2-4 values for the selected organizational unit cannot be configured, if keyword distribution is set. When selecting this option, define the network share in the **Network share for the CSV files** textbox.

Note:
All Updater Clients must have read access to the specified network share.

Note:
Keyword distribution is not available for devices in the unassigned group.

Clear keyword distribution on devices



Select this option to disable keyword distribution to all connected Digital Pocket Memo 8000 series devices.Keyword 2-4 values are available for configuration.

Do not change keyword distribution settings:



Select this option to leave keyword list distribution unchanged on all connected Digital Pocket Memo 8000 series devices. In this case, no keyword list is distributed or cleared by the Updater Client.

Keyword 2-4 values defined in the configuration editor will be ignored by devices with keyword distribution.

This is the default value.

6.3.4. Toolbar menu - Refresh

Reloads the configuration database and refreshes the device configuration and firmware files list in the Management Console.

6.3.5. Toolbar Menu - Exit

Shut down the Management Console.

6.4. Configuration tree

On the left side of the Management Console, the device configurations are categorized in a configuration tree. All new, unassigned, and assigned device configurations are contained by the *All configurations* root item. The configuration list of this item displays all the device configurations with information on device identification, with the organizational unit to which the devices belong, and other necessary information.



Under the All configurations root item,
the NEW DEVICES unit,
the Unassigned unit,
and the organizational units can be found.

6.4.1. Configuration tree - New Devices



New device configurations are displayed under the **NEW DEVICES** unit. New devices are devices connected by the user to the Updater Client for first time and not created by the administrator in the Management Console. From this time on, the administrator manages the configuration.

6.4.2. Configuration tree - Unassigned Devices



Device configurations not assigned yet to any organizational unit are displayed under the **Unassigned** unit. Device groups in this unit are only virtual, and do not contain device settings. Configurations can be made only on a device level here.

6.4.3. Configuration tree – Organizational Units



The organizational units contain the group configurations with the device configurations. The name of this unit is displayed the way it was named during creation. The configuration list of the organizational units displays the device configurations belonging to the organization.

6.4.4. Configuration tree – Device Group Configuration



Group configurations under the organizational units can be created for the device types of Digital Pocket Memos, SpeechMikes, and Foot Controls. For different types of devices (devices with different LFH or DPM numbers) different groups must be created. When editing a group configuration, the defined settings will be used by all device configurations belonging to that group. These settings will be automatically updated in the device configurations and they will be read-only. When a device configuration is moved to another group, all settings that have been defined and locked in the group configuration will be cleared in the device configuration. The configuration list of the groups displays the device configurations belonging to the group.

6.4.5. Configuration tree – Device Configuration



Device configurations can be found under groups. They are named by serial number (Digital Pocket Memos) or by Windows user name with domain name (SpeechMikes and Foot Controls). The device configuration settings can be edited in the Configuration editor window by double-clicking on the device configuration or on the settings list or with the Edit toolbar button.

6.5. Configuration list



Configurations can be created and edited. The Updater Client will use these configurations to update the connected devices at the user's PC. The configuration list enumerates the device configurations belonging to the organization or group, which is selected in the configuration tree.
The configuration list displays the following information on the device configurations:

- Device type
  This column displays the devices for which configurations are created, the device can be a Digital Pocket Memo, SpeechMike or Foot Control.
- LFH
  This column displays the LFH or DPM number of the device
- Serial number
  This column displays the serial number of the Digital Pocket Memos Devices
- User name
  This column contains the user name with the domain name specified. Whenever a user connects a device, the Updater Client application will send the user´s name and the identifiers of the device to the server. If a configuration exists for the user and for the device, the existing configuration will be used, otherwise a new entry will be created in the list with the user´s name. This user name identification is used in the case of SpeechMikes and Foot Controls.
- Status
  This column displays the status of the configuration.

New –
The device was connected by the user and recognized by the system, but no user configuration has been done yet. The system creates a configuration by downloading the actual configuration from the device, but the administrator has not yet taken care of it. The Updater Client will not perform any updates, if the device has only a new configuration.
Recognized –
The administrator opened and confirmed the configuration by either moving it to an organizational unit or to the Unassigned special unit.

- Update status
  This column displays the success – Updated – or failure – Failed – of the update of the settings on the device.
- Last modified
  This column displays date and time of the last modification of the device configuration.
- Organizational unit
  This column displays the organization which the device configuration belongs to.
- Comment
  This column displays additional information on the device configuration.

The following actions are available in the configuration list:



- Add
  Add a new configuration. The configuration can be modified before saving. This button is only active in the configuration list of groups.
- Edit
  Edit the selected device configuration in the Configuration editor window. This button is only active if a device configuration is selected.
- Delete
  Delete the selected device configuration. When a configuration is deleted, and the device is connected to the Updater client, no device update will take place and a configuration will be created in the list with the **New** status.
- Move to organizational unit
  Move device configurations to another organizational unit or to the Unassigned group. The target organizational unit must be defined. The drag and drop functionality is also available for this operation. In this case, the device configurations to be moved can be selected both from the configuration list and from the configuration tree.
  Note:
  When a device configuration is moved to an organizational unit without group configuration for the LFH, an empty group configuration is created. The overwrite value of the settings in the empty group configuration is not enabled, and the comment is left empty. If another administrator creates the same group configuration at the same time (either manually or automatically), one of the operations may fail.
- Export
  Export the current configuration list in *.CSV file format and save to the PC.

6.6. Configuration editor

In the Configuration editor window device configuration settings can be edited. This editor may be opened from the configuration list or from the View configuration page.



- LFH
  The device type of the currently edited configuration.
- Serial
  The serial number of the currently selected Digital Pocket Memo configuration. This field is only visible when editing Digital Pocket Memo configurations. Not visible in group configurations.
- User name
  The Domain\User name of the currently edited configuration. This field is only visible when editing SpeechMike and Foot Control configurations. Not visible in group configurations.
- Organizational unit
  The organizational unit which the currently selected configuration belongs to.
- Comment
  Additional information on the device configuration given by the administrator.
- Setting name
  Each configuration setting is represented by a row in the table. The settings are independent; the only exception is DSS Mode, because if Classic mode is selected then QualityPlay is not a selectable option for recording format. The settings are grouped into sections.
- Last known setting
  The value that was given for the setting when the device was last connected to the Updater Client. This field is only visible when editing device configurations.

- Overwrite
  If checked, the current setting (in the New setting column) is applied on the device by the Updater Client application. If unchecked, the setting on the device will not be changed.
  Note:
  When a setting is defined on group level, it will apply for all device configurations in that group and cannot be changed on device level.
- New setting
  The setting that will be uploaded to the device. This field can be edited only if Overwrite is enabled. Values can be selectable options or just plain text fields. The only special setting is the Keyword input options that brings up a special dialog.
  Note:
  When a setting is defined on group level, it will apply for all device configurations in that group and cannot be changed on device level.

For a description on the relevant device configuration settings, see DPM settings, SpeechMike settings, and Foot Control settings.

7. Updater Client



The Updater Client application browses for a configuration for the user's device according to the following rules:

- The Updater Client application starts running and checks the device that has been connected.
- The application reads the LFH and serial number (DPM) or user name (SpeechMike and Foot Control) of the device and looks for a configuration that can be uploaded onto the device.
- When the application finds the configuration, it uploads the configuration onto the connected device. Only those settings will be changed on the device, where **Overwrite** is checked in either in the group configuration or in the device configuration.
- The Updater Client reads the actual setting values of the connected device and uploads them to the Server. These values will be visible in the **Last known setting** column in the Management Console.
- If the connected device is a Digital Pocket Memo and a firmware version is defined in the configuration, the specified firmware file will be copied to the device if the version numbers do not match.
  Note:
  The actual firmware upgrade process will be done after the device is disconnected from the PC.

After the process the following message appears.

The client caches the configurations and the firmware files in the current user's file system (no additional rights required). If the client cannot connect to the server, the cached configurations and firmware files of the client are used.
The location path to the files on Windows 7 is:
C:\Users\USERNAME\AppData\Local\Philips Remote Device Manager\UpdaterClient

Warning:
The Application Data folder, also called /AppData/ is one of many hidden system folders containing important files and documents that help run Windows operating systems. By default, the folder is hidden so that it remains unchanged for the benefit of the computer.

The Updater Client downloads and maintains the list of all device configurations on a per-user basis. At startup it downloads all the necessary configurations. The list of configurations is stored for work in offline mode. This means that when a user connects a device with configuration to the client PC, no network traffic is needed and the configuration can be uploaded immediately.

The system tray icon of Updater Client displays the following options:



Update now
Forces a download from the Server and then updates all the connected devices. This function is used for immediate upload of the modified settings.

Reset device
Resets the settings of all connected dictation devices to their factory defaults.

Suppress connection messages
When checked, prevents displaying a notification which informs you whether the connection to the server was successful.

About...
Displays the **About** dialog with general version and copyright information.

Exit
Removes the icon of Updater Client from the system tray.
Remarks:
If more than one Digital Pocket Memo is connected to the client PC, only one of them will be updated.All devices are updated when they are connected to the PC or when the Updater Client application is started.

7.1. Log Files

Log Files are saved on Windows 7 on:
C:\Users\USERNAME\AppData\Local\Philips Remote Device Manager\UpdaterClient\log

8. Management Console - Custom filter

The Custom filter window enables displaying only specific information in the Device list.



The **Device list** can be filtered by using the following attributes:



Device type / LFH
Select the type or the LFH of the device configuration. The device can be a DPM, a FootControl, or a SpeechMike.

Serial
Enter the serial number of the selected Digital Pocket Memo configuration. This field is only visible when editing Digital Pocket Memo configurations.

Login
Enter the login of the selected FootControl or SpeechMike configuration. This field is only visible when editing FootControl or SpeechMike configurations.

Organization Unit
Select the NEW DEVICES unit, the Unassigned unit or an organizational unit which the currently selected configuration belongs to.

Comment
Enter text that you want to search for.

For **Serial**, **Login** and **Comment** Field wildcard is used automatically and the filtering is case-sensitive. To apply the filter and refresh the configuration list, click the **Filter** button.

9. Management Console – Templates

Configuration templates can be used to manage group configurations at once instead of the individual configurations that must be handled one by one.



The Templates tree displays the templates of the devices in a hierarchical structure.
The template list displays the following information:

- the templates of a device (if a device is selected in the Templates tree)
- the templates of all devices of a category (if a category is selected in the Templates tree)
- all templates (if the All templates category is selected in the Templates tree)

The template configuration page displays the configuration settings of the template selected in the Templates tree.

9.1. Template creation

To create new configuration templates, select a device in the tree and click the Add toolbar button on the Template list page or choose Add template from the context menu in the Configuration tree. New configuration templates are created in the Configuration editor window.



Configuration templates can also be created from existing source group configurations. In this case, all settings with enabled Overwrite option are copied from the source group configuration into the new template. To create a configuration template from an existing source group configuration, select a group configuration from the Configuration tree and choose Create template from the context menu.

9.2. Template editing

To edit existing configuration templates, select a device in the tree and click the Edit toolbar button on the Template list page or choose Edit from the context menu in the Configuration tree. Editing the settings of a template is done in the Configuration editor window.



Applying template to group configuration



The new or edited template of a device can be applied to a group configuration with the Apply template button [2] in the Configuration editor window, opened from the group configuration in the Configuration tree [1]. Select the appropriate template from the list [3] displayed in the Select template window (more templates can be applied one by one).
All settings with enabled Overwrite option are copied to the group configuration, overwriting the existing settings.

Note:
The Apply template function is only available when creating or editing a template from the group configuration.

9.3. Template deletion

To delete existing configuration templates, select a device in the Templates tree and click the Delete toolbar button on the Template list page or choose Delete from the context menu in the Templates tree.



10. Management Console - Firmware files

Warning: If write protection is enabled on a Digital Pocket Memo, the Updater Client has to temporarily disable it when copying the firmware file to the device. If the firmware is specified in a DPM configuration and firmware upgrade is needed, the Updater Client will re-enable the write protection after finishing the upgrade process. However, if the Digital Pocket Memo device is disconnected before the end of the process, the device will remain writable.

If you do not want the write protection to be removed, make sure that the device configurations do not specify a firmware file. The specified firmware will be set to all Digital Pocket Memo devices by clicking the Set to all configurations option, regardless of their write protection setting.



This page lists the available firmware files which can be uploaded to the connected Digital Pocket Memo 9600 and 9500 series, Digital Pocket Memo 8000 series, SpeechMike 3rd Generation, SpeechMike Air, or SpeechMike Premium devices. The list displays the version and the name of the file.

The firmware files are classified in categories that correspond to the device categories. Firmware files for Digital Pocket Memo 8000 series are only selectable in Digital Pocket Memo 8000 series device configurations.

Firmware versions in this list can be associated to individual device configurations in the Configuration editor window.



The following actions are available on the Firmware files page:

- **Add**
  Add new firmware files to the list.
- **Delete**
  Delete the selected firmware file from the list.
  Files can only be deleted, if they are not associated to any of the configurations.
- **Set to all configurations**
  Assign the selected firmware version to all configurations under Unassigned and to all group configurations under the organizational units. The selected firmware version will be applicable to all device configurations under these units, without the ability to change it in the individual device configurations.

10.1. Add New Firmware

Click on Add button and select the Firmware for upload to the server. The file can be chosen from the common open file dialog. Firmware version information is read from the file.



Open the folder with related Firmware; you can select Firmware files for SpeechMike and for Digital Pocket Memo. Firmware with *.bin file extension is predefined for SpeechMike. Firmware with file extension *.dpm is applicable for Digital Pocket Memo.



Select the file extension for Digital Pocket Memo or SpeechMike.



Each row in the table represents a firmware file stored on the server. *Version* displays the recognized firmware version. Major, minor and build numbers are provided. These values are filed automatically when uploading the Firmware file to the server. The file name containing the firmware data is also saved.



11. Management Console – Images

This page lists the available image files which can be uploaded to the connected DPM8000 series devices to be displayed on the welcome screen of the devices. The list displays an automatically generated ID, the name of the file and the picture of the image.



The following actions are available on the Images page – Add, Delete and Set to all configurations

11.1. Add new image files

Click on Add button



The welcome screen must be a .bmp file with 200x50px in 24 bit color for DPM devices and a .jpg or .png file with 800x480px resolution for SpeechAir device. It is also recommended to use black background color for good visibility purposes, as the surrounding display area on the Digital Pocket Memo is black as well.

Select a prepared bitmap and click on OPEN



The new image picture for welcome-screen is available. You can prepare and add lot of picture.



11.2. Delete selected images

Delete the selected bitmap file from the list. Files can be deleted only if they are **not** associated to any of the configurations.



11.3. Set to all configuration

Assign the selected image file to all configurations under **Unassigned** and to all group configurations under the organizational units. The selected image file will be applicable to all device configurations under these units, without the ability to change it in the individual device configuration.



12. Management Console SpeechAir Settings.

Settings related to Operating System

12.1. PRDM server URL

This property defines the PRDM IIS Web Service's URL.
Starting with http.
This feature is supported only for SpeechAir running with firmware 4.4.2.034 or higher.

12.2. Refresh interval

This property defines how frequently the OS queries the configuration from the PRDM IIS Web Service.

Available values:
1 hour, 8 hours
1 day, 3 days,
1 week.
This feature is supported only for SpeechAir running with firmware 4.4.2.034 or higher.

12.3. WLAN enabled

This property defines whether WLAN is enabled on the SpeechAir device.
Available values – yes/no

12.4. User networks enabled

This property defines whether a user can add new networks.
Available values – yes/no

12.5. Bluetooth

This is a standard Android setting.
Available values – yes/no

12.6. VPN

This is a standard Android setting.
Available values – yes/no

12.7. Wallpaper

This is a standard Android setting.

12.8. Autorotate screen

This is a standard Android setting.
Available values – yes/no

12.9. Uninstall apps

This property defines a list of packages to uninstall from the SpeechAir device. Package names can only contain lower case letters and dots (.).

12.10. Install apps

This property defines a list of apps that you want to install on the SpeechAir device.

12.11. Allow user to uninstall apps

This property defines whether the user is allowed to modify/uninstall the installed apps, and also to remove applications by moving the app icons to the bin by drag and drop.

12.12. Start app with smart button

This property defines the package name of the installed app.

12.13. Allow apps to access the location information

This is a standard Android setting.
Available values – yes/no

12.14. Show owner info on lockscreen

This is a standard Android setting.
Available values – yes/no

12.15. Owner info

This is a standard Android setting.

12.16. Make password visible

This is a standard Android setting.
Available values – yes/no

12.17. Allow unknown sources

This is a standard Android setting.
Available values – yes/no

12.18. Camera

This is a standard Android setting.
Available values – yes/no

12.19. Select language

This is a standard Android setting.
Available values:

Chinese simplified
Chinese traditional

Deutsch (Deutschland
Deutsch (Liechtenstein)
Deutsch (Österreich)
Deutsch (Schweiz)

English (Australia)
English (Canada)
English (New Zealand)
English (United Kingdom)
English (United States)

Español (España)
Español (Estados Unidos)

Française (Belgique)
Française (Canada)
Française (France)
Française (Suisse)

Nederlands (België)
Nederlands (Nederland)

12.20. Spell checker

This is a standard Android setting.
Available values – yes/no

12.21. Automatic date and time

This is a standard Android setting.
Available values – yes/no

12.22. NTP server address

This is a standard Android setting. NTP Server address

12.23. Time zone

This is a standard Android setting, select time zones.

12.24. Use 24-hour format

This property defines whether to use 24-hour time format on the device.
Available values – yes/no

12.25. Date format

This property defines the date format of dictations.
Available values – mm/dd/yyyy, dd/mm/yyyy, yyyy/mm/dd

12.26. Firmware

This property selects the firmware version that you want to upload to the SpeechAir device.

12.27. Developer options

This property defines whether developer options are enabled on the SpeechAir device.
Available values – yes/no

13. SpeechAir settings for Philips Dictation Recorder APK

13.1. PRDM server URL

This property defines the PRDM IIS Web Service's URL.



13.2. Refresh interval

This property defines how frequently PDR queries the configuration from the PRDM IIS Web Service.
Available values – 5, 15, 30 minutes
1, 3, 6, 12 hours
1, 3 days
1 week

13.3. Data list URL

This property defines the data-list URL.

13.4. Data list refresh interval

This property defines the data-list refresh interval between 5 minutes and 1 week.
Available values – 5, 15, 30 minutes
1, 3, 6, 12 hours
1, 3 days
1 week

13.5. Data list visible column

These properties define which column (from 1 to 10) is displayed first in the data-list overview.

13.6. Data list author column

This property defines which data list column contains the Author property of a dictation.

13.7. Slider configuration

This property defines the slide switch configuration of a SpeechAir device.
Available values – International, Philips, German

13.8. Function button

This property defines what action the device takes when the user presses the function button.
Available values – End of letter (EOL), New dictation, Fast forward, None

13.9. Recording screen text

These properties define the list of strings, which are displayed in the configurable textfield on the recording screen of the Philips dictation recorder.
Available values:

Text 1 - Author	Text 2 - Worktype	Text 3 - Category	Text 4 - Barcode
Author	Author	Author	Author
Worktype	Worktype	Worktype	Worktype
Category	Category	Category	Category
Custom1	Custom1	Custom1	Custom1
Custom2	Custom2	Custom2	Custom2
Custom3	Custom3	Custom3	Custom3
Custom4	Custom4	Custom4	Custom4
Custom5	Custom5	Custom5	Custom5
Barcode	Barcode	Barcode	Barcode
Comment	Comment	Comment	Comment
ListColumn1	ListColumn1	ListColumn1	ListColumn1
ListColumn2	ListColumn2	ListColumn2	ListColumn2
ListColumn3	ListColumn3	ListColumn3	ListColumn3
ListColumn4	ListColumn4	ListColumn4	ListColumn4
ListColumn5	ListColumn5	ListColumn5	ListColumn5
ListColumn6	ListColumn6	ListColumn6	ListColumn6
ListColumn7	ListColumn7	ListColumn7	ListColumn7
ListColumn8	ListColumn8	ListColumn8	ListColumn8
ListColumn9	ListColumn9	ListColumn9	ListColumn9
ListColumn10	ListColumn10	ListColumn10	ListColumn10
Delivery	Delivery	Delivery	Delivery
None	None	None	None

13.10. Purge dictation

This property defines the purge interval for dictations on the SpeechAir device.
Available values – 1, 3, 10, 15, 30 days and never.

13.11. Automatically send EOL dictations

This property defines whether the Send dialog is automatically opened after the user presses the EOL button.
Available values – yes or no.

13.12. Voice activation

This property defines whether voice-activated recording is enabled on the SpeechAir device.
Available values – yes or no.

13.13. Edit mode

This property defines the editing mode (Insert, Overwrite or Append) of the dictation files.
Available values – Insert, Overwrite, Append.

13.14. Microphone sensitivity

This property defines the microphone sensitivity setting for both microphones.
Available values – low, medium and high.

13.15. Microphone directivity

This property defines which microphone will be used for recording when the device is in hand.
Available values – directional or 360° meeting.
This property defines which microphone will be used for recording when the device is placed on a desk.
Available values – directional or 360° meeting.

13.16. Record notification beep

This property defines whether the record notification beep is turned on.
Available values – yes, no.

13.17. Jump back

This property defines the number of seconds to rewind a dictation when the user presses the FRWD button on the device.
Available values – 1, 2, 3 or 4 second.

13.18. Audio format

This property defines the audio format of dictations.
Available values – WAV (ADPCM) or DS2 (DSS Pro).

13.19. Email sending

This property defines whether the email sending feature is enabled.
Available values – yes, no.

13.20. Use dictation hub

This property defines whether dictation the hub configuration is enabled.
Available values – yes, no.

13.21. Use SpeechLive

This property defines whether SpeechLive can be used to transcribe dictations.
Available values – yes, no.

13.22. Author

Here you can define up to 20 Authors names.

13.23. Default author

This property defines the default Author string.

13.24. Worktype

Here you can define up to 20 Worktypes.

13.25. Default worktype

This property defines the default Worktype string.

13.26. Category

Here you can define up to 20 Categories.

13.27. Default category

This property defines the default Category string.

13.28. Delivery

This property defines a list of Delivery keyword strings to be used in Philips dictation recorder.

13.29. Default delivery

This property defines the default Delivery string.

13.30. Mandatory author

This property defines whether an Author must be selected when creating a dictation.
Available values – yes, no.

13.31. Mandatory worktype

This property defines whether a Worktype must be selected when creating a dictation.
Available values – yes, no.

13.32. Mandatory category

This property defines whether a Category must be selected when creating a dictation.
Available values – yes, no.

13.33. Mandatory barcode

This property defines whether a barcode must be scanned when creating a dictation.
Available values – yes, no.

13.34. Mandatory data list

This property defines whether DataList must be used.
Available values – yes, no.

13.35. Mandatory delivery

This property defines whether Delivery must be selected when creating a dictation.
Available values – yes, no.

13.36. Use encryption

This property specifies whether MobileServer and DictationHub use encryption.
Available values – yes, no.

14. Management Console - DPM Settings

14.1. 4-position Switch

Only available for Digital Pocket Memo 8000 series.



This property specifies the slide switch behavior of the device.
The following slide switch configurations are available:

14.1.1. Philips classic switch

14.1.2. Philips slide switch

Only available for Digital Pocket Memo 8200

14.1.3. International slide switch

Only available for Digital Pocket Memo 8000 and 8500

14.1.4. Grundig slide switch

14.2. Active recording profile

Only available for Digital Pocket Memo 8000 series.



This property specifies the active recording profile of the recorder. The following recording profiles are available:

- Dictate
- Meeting
- Speech recognition
- Personal

The settings of the profiles can be defined under microphone directivity in hand/on desk, recording format and microphone sensitivity.

14.3. Additional function key

Only available for Digital Pocket Memo 8000 series.



This property specifies the function that the user can access directly by pressing the function key. The setting defined here will be performed when pressing the function key of the Digital Pocket Memo.

14.4. Additional user defined labels

Only available for Digital Pocket Memo 8000 series.



This property specifies the number of user strings for a dictation on a DPM. By default, the value of this property is set to 0. For more information about assigning keywords, recording special instructions and entering user-defined labels – please see the user manual of the related Digital Pocket Memo.

14.5. Append mode

Only available for Digital Pocket Memo 8000 series.



This property specifies that newly recorded voice is added at the end of the existing dictation file, in order to avoid accidental overwriting regardless where the cursor is at the moment of a new recording

14.6. Appearance

This property specifies the appearance of the display mode on the Digital Pocket Memo.



- Standard display – this option uses larger symbols and shows less detailed information about the current dictation file.
- Advanced display – this option uses smaller symbols and shows more detailed information about the current dictation file.

The following display modes are only available for Digital Pocket Memo 8000 series.



- Classic display – this option shows an animated analog cassette tape and analog recorder functionalities
- Advanced display – this option uses smaller symbols and shows more detailed information about the current dictation file

14.7. Audible scan

This property specifies whether listening to the dictation file is enabled while forwarding or rewinding a recording on the Digital Pocket Memo.



When this option is activated the winding speed is slower.

14.8. Background illumination time

Only available for Digital Pocket Memo 8000 series.



This property specifies the switch-off time of the display of the DPM. The following options are available:

- Auto
- Switch off after 8 seconds
- Switch off after 20 seconds
- On – always on

14.9. Barcode scan button

This property specifies which button triggers barcode scanning in online mode. If the DPM device is connected to your PC, you can use any button for scanning. However, if the device is not connected to the PC, only the smart button can be used for scanning.



14.10. Barcode scan mode

Only available for Digital Pocket Memo 8000 series.



This property specifies the mode of barcode scanning.
The following settings are available:

Scan to application focus – keyboard mode.
The barcode will be scanned to the current place of the Windows cursor.

Barcode event mode – the application automatically processes the scanned barcode and initiates the associated action, such as starting a new recording. In this mode, the application must be prepared for handling the barcode read event.

14.11. Delete files on the DPM after download

This value is used by the download software to store and adjust the setting that specifies whether the dictation files on the DPM should be deleted after they have been transferred to the PC.



14.12. Device beep

This property specifies whether the device beep is enabled. The DPM gives an audio signal – beep – when certain tasks have been completed, for example, after a dictation has been played back. If the device beep is disabled, the DPM gives an audio signal only as a warning, for example, when the Memory Card is full.



14.13. Display a low area

Only available for Digital Pocket Memo 8000 series.



This property defines the content shown at the bottom of the Digital Pocket Memo display. Select the Author name option to display the user name which the dictation file was created. For Digital Pocket Memo files, this is the Author keyword

14.14. Download file Keyword1 filter



This setting applies when the Download file type is set to Files with Keyword 1.

14.15. Download file type



This property specifies the settings for the download. Using a download application, the following settings may apply during file transfer:

- All files –all files on the DPM are transferred to the PC.
- EOL files – only files with the EOL indication are transferred from the DPM to the PC
- File selection – the download application displays a file selection dialog. This dialog lists all files on the DPM. Only those files are transferred from the DPM to the PC which are selected in this dialog.
- Files with Keyword1 – all files with a specific keyword assignment are downloaded. This assignment matches the defined content string for Keyword1, which can be given in the field.

14.16. DSS mode

Only available for Digital Pocket Memo 8000 series



This property specifies whether the user can record .ds2 files on the DPM device. Recording .ds2 files has the following advantages:

- The user can protect the files with the enhanced DSS Pro encryption.
- Creation of dictations in Quality Play mode is possible, which ensures recordings with the highest quality.

14.17. Edit mode

Only available for Digital Pocket Memo 8000 series



This property specifies the place where the newly recorded voice is inserted in the dictation file. The following options are available:

- Insert mode – the newly recorded voice is inserted at the current position in the sound file. Any existing recording is preserved.
- Overwrite mode – the newly recorded voice replaces existing recordings at that position in the sound file. The default setting is Overwrite.
- Append mode – the newly recorded voice is added to the end of the sound file. Any existing recording is preserved.

14.18. Enable noise reduction

This property specifies whether noise reduction is enabled on the DPM. This feature reduces background noise during recording.



The following settings are available:
Yes – Noise reduction is enabled on the device.
No – Noise reduction is disabled on the device.

14.19. Enable USB audio device

This property specifies whether USB audio device is enabled on the DPM. If this option is disabled, recording and playback will not function on the DPM device. In this case, the default Windows recording and playback device will not be changed automatically when the DPM is connected to the computer.



14.20. EOL button enabled



This property specifies whether the EOL (End of Letter) button is enabled on a DPM.

14.21. File name mode

This setting defines how DPM file names are created.



- Keyword1 – the file name creation is based on the predefined Keyword1.
  Example: Keyword1 is Author that has been defined as the Keyword1 usage. For more information, see Keyword Definition in the SpeechExec Dictate online help. The entries for the keyword usage are a selection of the authors names: James, Peter, John.
  Author Peter selects the respective author name on the DPM. The DPM generates the Pete001.dss file name, the first four characters of the author name are used for the file name.
- Custom string – the file name creation is based on the predefined prefix string. The prefix string may not have more than four characters.
  Example: Author Peter defines the prefix string Memo. The DPM generates the Memo001.dss file name.

14.22. File name prefix

This setting applies when the File name mode is set to prefix.



In case of Digital Pocket Memo 9600, the prefix string may not have more than four characters. In case of Digital Pocket Memo 8000 series, the prefix string may not have more than thirty characters.

14.23. Firmware version



This property specifies the firmware version to be uploaded onto the devices.

14.24. Foot controlled operation

Only available for Digital Pocket Memo 8000 series. This property specifies the Foot Control operation on dictation and transcription functions to keep hands free for work.



The following ooptions are available:
Hands-free dictation
Hands-free transcription.

14.25. Index/Spoken instructions



Depending on the DPM which is used, this setting defines whether creating an index or a spoken instruction is enabled on the device during recording.

14.26. Keyword area string

Only available for Digital Pocket Memo 8000 series. This property specifies what is displayed in the keyword area on the DPM screen. The following options are available:



Empty – the keyword area remains empty
Keyword1 – the keyword area shows the Keyword1 value
Keyword2 – the keyword area shows the Keyword2 value
Keyword3 – the keyword area shows the Keyword3 value
Keyword4 – the keyword area shows the Keyword4 value

Keyword5 – the keyword area shows the Keyword5 value
Barcode – the keyword area shows the value of the barcode scanning.

14.27. Keyword options

Only available for Digital Pocket Memo 8000 series



This property specifies the options for keywords on the DPM.

• Keywords – each keyword is represented by a column in the table. This property is only available for Digital Pocket Memo 9600/9500 series.

• Barcode – the keyword is set by the user with the barcode scanner. If more than one keyword is set in Barcode, all the keywords are mandatory, and the user has to scan them in order.

• Voice command – the keyword is set by the user with a voice command. If more than one keyword is set in Voice command, all the keywords are mandatory, and the user has to say them one after another, in the order of the keywords.
This property is available only for Digital Pocket Memo 8000 series.

- Mandatory – the keyword has to be set by the user before dictation.
- Type of voice command – the user can either say a keyword value or say the alphanumeric characters to set the keyword. This property is available only for the Digital Pocket Memo 8000 series.
- Linked keywords – Specifies whether the keywords are linked to each other. For example, if the user selects the second keyword value from Keyword1, all other keywords have their second value. This way you can assign, for example, work types or transcriptionists to authors. For Digital Pocket Memo 8000 serieskeyword values can be set to pre-defined values with the Keyword distribution toolbar button.

14.28. Lock timeout



This property determines the time after which the device ask a PIN code. The timeout interval can be set to 5, 15, 30, 60 or 90 minutes. Select – Never – to turn off the timeout.

14.29. Mandatory user input options

Only available for Digital Pocket Memo 8000 series.



This setting applies when the value of the user-defined label property is set to at least 1. Select the type of mandatory information that DPM users have to provide when making recordings:

- None – disables the mandatory user input feature.
- User-defined label – the specified number of the user-defined label property must be entered when a new recording is started.

14.30. Mass storage write protection

Only available for Digital Pocket Memo 9600/9500 series with firmware version 3.90 or newer.



This property specifies whether the mass storage device of the Digital Pocket Memo device is read-only.

14.31. Microphone directivity in hand/on desk

Only available for Digital Pocket Memo 8000 series. This property specifies how the DPM uses its microphone while it is held in hand or put on a desk. The following options are available:



- Directional – this option is used for focused recording.
- 360° meeting – this option is used for recording overall ambient sound equally with two active microphones.

14.32. Microphone sensitivity

The sensitivity of the microphone can be set to the following options:

- Low (Private) – this setting is recommended when recording dictations in a noisy environment. To get a good quality recording it is important to speak close to the microphone.
- Medium (Dictate) – this is the default setting and recommended when recording dictations in a normal environment.
- High (Conference) – this setting is recommended when,recording at a conference, lecture or meeting.

DPM8000 series Settings



DPM9600/9500 series Settings



14.33. Plus/Minus button enabled

Only available for Digital Pocket Memo 8000 series



This property specifies whether the +/- button is enabled on the device.

14.34. Protect device configuration

This property specifies whether the settings saved on the DPM can be changed remotely. If this property is enabled, the configuration of the DPM can only be done through a PC and not on the device itself.



The following DPM menu entries cannot be accessed and changed:

- setting the date and time.
- setting the Standard Play, Long Play mobile or Quality Play recording format.
- enabling and disabling the device beep.
- setting the microphone sensitivity.
- enabling and disabling the backlit display function.
- changing the contrast setting
- showing and hiding the remaining time.
- reformatting the memory card.

14.35. Record into one file only

This property specifies whether all recordings made with the DPM should be stored in one file. By default, each new dictation is recorded in a separate file.



When this property is set, pressing the EOL button has no effect. This behavior is similar to recording on a tape with an analog device.

14.36. Record notification beep

This property specifies whether the DPM beeps when recording is possible.



Activating this option means that you must wait until you hear a beep before you start recording. This behavior is similar to the behavior of standard voice mail machines.

14.37. Recording format

This property specifies the recording format in which dictation files are recorded on the Digital Pocket Memo.



The DPM can create dictation files with the following formats:

- Standard Play – 12kHz in DSS mode without silence compression.
- Quality Play – 16kHz in DSS Pro mode
- MP3 Stereo – MP3.
- PCM Stereo – WAV Format
- PCM Mono – WAV Format

14.38. Slider jump back time

This is only available for Digital Pocket Memo 8000 series and Digital Pocket Memo 9600 series with firmware version 3.90 or higher



This property specifies the number of seconds (between 0 and 4 seconds) to rewind a file when restarting playback.

14.39. Smart button configuration

Available only for Digital Pocket Memo 8000 series. This property specifies the role and behavior of the Smart buttons 1-3 on the selected recorder to meet your personal requirements in STOP NEW, STOP, RECORD, RECORD STANDBY and PLAY mode.



The following configurations are available:

- Stop New – show Keyword1-4 values, Toggle priority, File information, Recording profile, Scan barcode (only for DPM8500), Disabled, Main menu (only for Smart button2).
- Stop – Set index, Change edit mode, ShowKeyword1-4 values, Toggle priority, File information, Delete file, Scan barcode – only for DPM 8500, Toggle EOL, Create new file, Disabled, Main menu – only for Smart button 2.
- Record – Set index, Set instruction, Disabled
- Record Standby – Show Keyword1-4 values, File information, Set index, Create new file, Disabled
  NOTE: In case of international slide switch configuration, the smart buttons cannot be customized in Record Standby mode.
- Play – Mute speaker, Playback speed, Set index, Disabled

14.40. Time format

This property specifies the date and time format to be used on the Digital Pocket Memo. The date and time can be shown in US format (AM/PM) and international 24 hour format.



If the US format is used, the date is shown in the YYYY-DD-MM format, the time is shown using the 12-hour clock with AM/PM symbols. If the international format is used, the date is shown in this format: YYYY-MM-DD, the time is shown using the 24 hour clock.

14.41. Update DPM time

This property specifies the time and date on the Digital Pocket Memo so that it is synchronous with the time and date on the PC.



14.42. Welcome screen

Available only for Digital Pocket Memo 8000 series

The property specifies the bitmap file to be displayed on the welcome screen of the Digital Pocket Memo. You can select the appropriate bitmap file from the combo-box. The combo-box displays only the ID of the bitmap files. The picture can be previewed in the tooltip. To add new bitmap files, go to the Bitmaps page and click Add. The welcome screen must be a *.bmp file with 200x50px in 24 bit color. It is also recommended to use black background color for good visibility purpose, as the surrounding display area on the Digital Pocket Memo is black as well.



14.43. Usage of keyword

Specify keywords that can be selected on the Digital Pocket Memo. Keywords enable authors to personalize their dictations through selecting their personal keyword on the Digital Pocket Memo. Keywords can also be used for workflow purposes and as a destination path, if the automatic download functionality is enabled. The DPM Download/Configuration programs are usually delivered with the following default keywords defined:

Keyword1
Usage string: Author
Content string: John

Keyword 2		
Usage of Keyword 2	☑	Subject
Value 1 of Keyword 2	☑	Radiology
Value 2 of Keyword 2	☑	Surgery
Value 3 of Keyword 2	☑	Patient

Example:
Defining usage strings with three content strings each, for Keyword2 and Keyword3
For the Usage of Keyword2, type Subject
For the Value1 of Keyword2, type Radiology

The maximum number of characters for each usage and content string is 30 for the Digital Pocket Memo 8000 series and 15 for the Digital Pocket Memo 9600 series. Each keyword can have one usage entry and twenty or forty content entries, depending on the device type.

This information is transferred to the Digital Pocket Memo where the author selects the subject names and actions for each dictation. Allowed characters:

A a	B b	C c	D d	E e	F f	G g	H h	I i	J j
K k	L l	M m	N n	O o	P p	Q q	R r	S s	T t
U u	V v	W w	X x	Y y	Z z				
0	1	2	3	4	5	6	7	8	9
-	_	/	#	*	+	@	&	'	ç
à	â	è	é	ê	î	ô	û	ß	
Ä ä	Ö ö	Ü ü	Å å	Æ æ					

14.44. Obligatory keyword selection

Only available for Digital Pocket Memo 9600 and 9500 series with firmware version 3.90 or higher and for Digital Pocket Memo 8000 series
This property specifies whether keyword selection is mandatory for a new dictation.

Advanced		
Audible scan	☐	
Enable USB audio device	☐	
USB High Power Mode	☐	
Jump back	☐	
Obligatory keyword selection	☑	No ▾
Foot controlled operation	☐	Yes No

14.45. USB High Power Mode



This property specifies whether USB High Power mode is enabled. If this option is disabled, the battery of the Digital Pocket Memo is not charged when connected via USB cable.

14.46. Voice-activated recording

This property specifies whether voice-activated recording is enabled.



When voice-activated recording is enabled, the Digital Pocket Memo is in Record Standby mode. Recording starts automatically when the input level exceeds a certain threshold, which happens usually when the author starts dictating. Recording stops automatically a few seconds after the author stops speaking, and restarts automatically when the author starts speaking into the microphone again.

15. Management Console - SpeechMike Settings

15.1. Disconnect when OOR

Only available for SpeechMike Air



This property specifies the timeout when the SpeechMike AirBridge disconnects from the USB host after the SpeechMike Air is outside the Bluetooth range.

15.2. Enable acoustical warning

Only available for SpeechMike Air



This property specifies whether the acoustical warning is enabled on the SpeechMike Air.

15.3. Enable button blick buppression

This property specifies whether the button click suppression functionality is enabled or not.



If enabled, the Button Click Suppression filter will be used during recording. This feature removes the clicking noise of buttons when pressing them.

15.4. Enable haptic warning

Only available for SpeechMike Air



This property specifies whether the vibration warning is enabled on the SpeechMike Air. The SpeechMike Air then vibrates when it is out of the Bluetooth range.

15.5. Enable ScrollWheel

Only available for SpeechMike 2



This property specifies whether the scroll wheel functionality is enabled or not.
If enabled, the scroll wheel of the SpeechMike works like a standard Microsoft mouse scroll wheel.

15.6. Enable ScrollWheel Volume Control

Only available for SpeechMike 2

This property specifies whether the volume can be adjusted with the scroll wheel.



If enabled, users can adjust playback volume using the scroll wheel on the SpeechMike device.

15.7. Enable Trackball

This property specifies whether the track ball functionality is enabled or not.



If enabled, users can use the trackball on the SpeechMike like a regular trackball to guide the mouse pointer on the screen.

15.8. Enable Trackball Volume Control

This property specifies whether the volume can be adjusted by pressing and scrolling the trackball.



If enabled, users can adjust playback volume using the trackball on the SpeechMike device.

15.9. Enable wheel functions on Function-Keys

Only available for SpeechMike Premium



This property specifies whether the scroll wheel functions are enabled on the function keys of the SpeechMike Premium.

15.10. Lock Device Settings

The value of this property can be used by 3rd party integrators.



15.11. Motion Control

Only available for SpeechMike Premium



This property specifies defines how the microphone adjusts the input level. The value specifies whether the input level of the microphone is changed when put on desk.

Disable - this function is disabled, the input level of the microphone is not changed.
Reduce input level - the input level of the microphone is reduced by 20 dB when put on desk.
Mute microphone - the input level of the microphone is muted when put on desk.

15.12. Pick and Drop delay

Only available for SpeechMike Air



This property controls the Pick and Drop functionality of the SpeechMike Air. If Pick and Drop is turned on, the user can drag and drop without holding the mouse button. If the user holds the left mouse button for the specified Pick and Drop time, the object is dragged. The object can be dropped with a simple mouse-click.
The value specifies the time needed for starting the drag operation.

Available value – 100ms up to 2500ms.

15.13. Power Mode

This property specifies whether the power mode functionality is enabled or not.



Standard Power Mode
Switches the SpeechMike to standard power management mode. In standard power mode the SpeechMike device uses approximately 300mA (milliapms) of power from the USB port. However some PC providers limit the output power of USB ports to 100mA (so called "bus-powered USB ports"). Such ports do not provide enough power for the SpeechMike to function properly. In this case, you can switch the device to low power mode.

Low Power Mode
Switches the SpeechMike to low energy consumption mode. In low power mode the SpeechMike uses only about 100mA (milliamps) of power from the USB port (as opposed to 300mA in standard power mode). This is useful when the PC has "bus-powered USB ports". It may also be useful when using the SpeechMike with a notebook computer running off batteries.

Important:
When in low power mode, the playback volume may be noticeably lower.
For power mode settings to take effect, the device must be unplugged from the computer then plugged back in.

15.14. Power off timer

Only available for SpeechMike Air



This property specifies the time after the SpeechMike Air is turned off.

Available time between 5, 10, 30 minutes, 1, 2, 5, 10, 20 hours and never.

15.15. Sleep mode timer

Only available for SpeechMike Air This property specifies the time after the SpeechMike Air goes into sleep mode.



15.16. Trackball speed

This property specifies the trackball speed from 0 (slow) to 3 (fast).



This setting is similar to, but works independently of, the Cursor Speed and Acceleration setting on the standard Windows Mouse control panel. Adjusting this value does not affect the speed of the screen pointer when using a mouse. It only affects pointer speed when using the SpeechMike trackball.

15.17. USB gap detection mode

Only available for SpeechMike Air



This property specifies the USB gap detection mode on SpeechMike Air
USB gaps occur when Microsoft Windows does not read the audio data from the device when it should.
If this setting is turned on, the application is prepared for handling the USB gap event.

16. Management Console - Foot Control Settings

When pressing a Foot Control button, first a Stop released event is sent and then the pressed event of the specified setting. When releasing the Foot Control button, the released event of the specified setting is sent, followed by a Stop pressed event.

Example:
Specified setting = Play

When pressing Play, first a Stop released event is sent and then the Play pressed event. When releasing the Play button, first a Play released event is sent and then the Stop pressed event.

Important:

- The only exception to this is when the specified event is the Play Stop Toggle. In this case, a Play Stop Toggle pressed event is sent without the Stop release and Stop pressed event. This way, users do not have to keep the "Play" button pressed during playback, but they can stop playback by pressing the Play Stop Toggle button again.

- Foot Control settings are read by the applications only at start-up. If settings are modified by the Updater Client after the start-up of the application using the Foot Control, the settings will not take effect until the application is restarted.

For every button you can assign following function:
Disabled
Stop
Play
Record
Insert
EOL
Rewind
Forward
Priority
Command
Play/Stop Toggle
Trigger
Instruction
Function key 1
Function key 2
Function key 3
Function key 4

17. Version Changes and History

17.1. Version 3.8.380

Release Date: December 2016

The following models are supported:

Device Category	Device Type
Digital Pocket Memo 4	DPM8000 DPM8200 DPM8500
SpeechMike Premium	LFH3610 LFH3600 LFH3520 LFH3510 LFH3500
SpeechMike Premium Touch	LFH3820 LFH3810 LFH3800 LFH3720 LFH3710 LFH3700
SpeechMike 3	LFH3310 LFH3300 LFH3220 LFH3210 LFH3200
SpeechMike Air	LFH3020 LFH3010 LFH3000
SpeechAir	1100
Smartphones	With Android
Foot Control	ACC2330 ACC2320 ACC2310

17.1.1. Changes and Improvements

Support for Microsoft Windows Server 2016 has been added.

Active Directory import is now possible in PRDM.

The Bitmaps page has been renamed to Images to better reflect the type of images that can be uploaded to devices.

17.2. Version 3.7.370.

Release Date: September 2016

The following models are supported:

Device Category	Device Type
Digital Pocket Memo 4	DPM8000 DPM8200 DPM8500
SpeechMike Premium	LFH3610 LFH3600 LFH3520 LFH3510 LFH3500
SpeechMike Premium Touch	LFH3820 LFH3810 LFH3800 LFH3720 LFH3710 LFH3700
SpeechMike 3	LFH3310 LFH3300 LFH3220 LFH3210 LFH3200
SpeechMike Air	LFH3020 LFH3010 LFH3000
SpeechAir	1100
Foot Control	LFH2330 LFH2320 LFH2310

17.2.1. Changes and Improvements

The architecture of PRDM has been updated: the local server installation has been replaced by an IIS web service solution.

Support for the following devices has been added:
SpeechAir
SpeechMike Premium Touch 3700
SpeechMike Premium Touch 3710
SpeechMike Premium Touch 3720
SpeechMike Premium Touch Barcode 3800
SpeechMike Premium Touch Barcode 3810
SpeechMike Premium Touch Barcode 3820

SpeechMike II and DPM 3 devices are no longer supported.

The central login feature has been replaced by secure operation mode.

The Bitmaps page has been renamed to Images to better reflect the type of images that can be uploaded to devices.

17.3. Version 3.6.360.34

Release Date: March 2016

The following models are supported:

Device Category	Device Type
Digital Pocket Memo 4	DPM8000 DPM8200 DPM8500
SpeechMike Premium	LFH3610 LFH3600 LFH3520 LFH3510 LFH3500
SpeechMike 3	LFH3310 LFH3300 LFH3220 LFH3210 LFH3200
SpeechMike Air	LFH3020 LFH3010 LFH3000
Foot Control	LFH2330 LFH2320 LFH2310

17.3.1. Changes and Improvements

Assignment modes have been introduced to select whether you want to assign SpeechMike and FootControl device configurations to Windows logins (DOMAIN\USERNAME) or workstations (COMPUTERNAME).

17.4. Version 3.3.331.06

Release Date: September 2014

The following models are supported:

Device Category	Device Type
Digital Pocket Memo 4	DPM8000 DPM8200 DPM8500
Digital Pocket Memo 3	LFH9620 LFH9600 LFH9520 LFH9500
SpeechMike Premium	LFH3610 LFH3600 LFH3520 LFH3510 LFH3500
SpeechMike 3	LFH3310 LFH3300 LFH3220 LFH3210 LFH3200
SpeechMike Air	LFH3020 LFH3010 LFH3000
SpeechMike 2	LFH5284 LFH5282 LFH5276 LFH5274 LFH5272 LFH5270 LFH5262 LFH5260
Foot Control	LFH2330 LFH2320 LFH2310 LFH6220 LFH6212 LFH210/90

Software requirements:

- Microsoft Windows 7 Service Pack 1
- Windows 8.1
- Microsoft Windows Server 2008 R2 Service Pack 1
- Microsoft Windows Server 2012 R2

The remote device management server needs one of the following SQL servers:

- Microsoft SQL Server 2012 Service Pack 1 R2
- Microsoft SQL Server 2014

17.4.1. Changes and Improvements

New silent installation option added to be able to run Philips Remote Device Manager Updater Client automatically after successful silent installation.

17.5. Version 3.2.320.46

Release Date: September 2013

The following models are supported:

Device Category	Device Type
Digital Pocket Memo 4	DPM8000 DPM8200 DPM8500
Digital Pocket Memo 3	LFH9620 LFH9600 LFH9520 LFH9500
SpeechMike Premium	LFH3610 LFH3600 LFH3520 LFH3510 LFH3500
SpeechMike 3	LFH3310 LFH3300 LFH3220 LFH3210 LFH3200
SpeechMike Air	LFH3020 LFH3010 LFH3000
SpeechMike 2	LFH5284 LFH5282 LFH5276 LFH5274 LFH5272 LFH5270 LFH5262 LFH5260
Foot Control	LFH2330 LFH2320 LFH2310 LFH6220 LFH6212 LFH210/90

The LFH 210/90, 6212, 6220, 2310, 2320 type Foot Controls have three pedals.
The four-pedal Foot Controls are called the 4-Pedal FootControl.

Software requirements:

- Microsoft Windows XP (32 bit) Service Pack 3 (Supported till mid April 2014)
- Microsoft Windows 7 Service Pack 1
- Windows 8
- Microsoft Windows Server 2008 R2 Service Pack 1
- Microsoft Windows Server 2012 Standard

The remote device management server needs one of the following SQL servers:

- Windows Server 2008 R2 Service Pack 1
- Microsoft SQL Server 2008 R2
- Microsoft SQL Server 2008 R2 Express

17.5.1. Changes and Improvements

New features:

- Export through ACC8160 WLAN Adapter – You can export DPM configurations into specific folders in specific format to supported devices through a WLAN Docking Station
- Bitmaps – You can upload bitmap files to the connected DPM 8000series devices to be displayes on the welcome screen of the devices.
- PIN/Encryption settings only with DPM8000 series.

New DPM settings:

- Encryption key – this property specifies the encryption key used for the Digital Pocket Memo 8000series
- PIN – this property specifies the PIN code used for the Digital Pocket Memo 8000series.
- Welcome screen – this property specifies the bitmap file to be displayed on the welcome screen of the DPM8000series.

17.6. Version 3.2.320.12

Release Date: February 2013

The following models are supported:

Device Category	Device Type
Digital Pocket Memo 3	LFH9620 LFH9600 LFH6520 LFH9500
SpeechMike Premium	LFH3610 LFH3600 LFH3520 LFH3510 LFH3500
SpeechMike 3	LFH3310 LFH3300 LFH3220 LFH3210 LFH3200
SpeechMike Air	LFH3020 LFH3010 LFH3000
SpeechMike 2	LFH5284 LFH5282 LFH5276 LFH5274 LFH5272 LFH5270 LFH5262 LFH5260
Foot Control	LFH2330 LFH2320 LFH2310 LFH6220 LFH6212 LFH210/90

The LFH 210/90, 6212, 6220, 2310, 2320 type Foot Controls have three pedals.

Software requirements:

- Microsoft Windows Server 2008 R2 Service Pack 1
- Microsoft Windows 7 Service Pack 1
- Microsoft Windows XP (32 bit) Service Pack 3

The remote device management server needs one of the following SQL servers:

- Windows Server 2008 R2 Service Pack 1
- Microsoft SQL Server 2008 R2
- Microsoft SQL Server 2008 R2 Express

17.6.1. Changes und Improvements

- SpeechMike Premium
- New Settings are added with the following possible values:
  Motion Control
  Enable wheel function on Function Keys
  For the barcode device the default values of barcode trigger settings are “OFF”, except for back button 1 wher it is “ON”
- New Category is added to the firmware file category list, named SpeechMike Premium

17.7. Version 3.0.300.15

Release Date: September August 2012

The following models are supported:

Device Category	Device Type
Digital Pocket Memo 3	LFH9620 LFH9600 LFH9520 LFH9500
SpeechMike 3	LFH3310 LFH3300 LFH3220 LFH3210 LFH3200
SpeechMike Air	LFH3020 LFH3010 LFH3000
SpeechMike 2	LFH5284 LFH5282 LFH5276 LFH5274 LFH5272 LFH5270 LFH5262 LFH5260
Foot Control	LFH2330 LFH2320 LFH2310 LFH6220 LFH6212 LFH210/90

The LFH 210/90, 6212, 6220, 2310, 2320 type Foot Controls have three pedals.
The four-pedal Foot Controls are called the 4-Pedal FootControl.

Software requirements:

- Microsoft Windows XP (32 bit) Service Pack 3 (Supported till mid April 2014)
- Microsoft Windows Server 2008 R2 Service Pack 1

- Microsoft Windows 7 Service Pack 1

The remote device management server needs one of the following SQL servers:

- Windows Server 2008 R2 Service Pack 1
- Microsoft SQL Server 2008 R2
- Microsoft SQL Server 2008 R2 Express

17.7.1. Changes und Improvements

- Support for DPM8000 series Support for PIN list – new button is added to main toolbar of the Management Console.
- Keyword list management – new button is added to man toolbar of the Management Console.
- SpeechExec Remote Device Manager is extended to support DPM8000 series firmware files
- Management Console – allows to select multiple items in the list of configurations in the right side panel on the Device list and move this to unassign or Organisational Units.
- Management Console – Drag and drop operation for the multiple selection operation.
- Management Console – Configuration templates can be used for creating new sets of preconfigurations and updating existing group configuration.
- Management Console – Central Login allow only Windows users in RDMAdmin Active Directory group to start the Management Console and connect to the server. The RDMAdmin Active Directory group has to be created manually. New checkbox “Central Login” is added to server options window.
- Management Console – if multiple administrators edit the same configuration then all of them are able to save their changes.
- Updater Client – Reset device functionality for the DPM8000 series.
- Updater Client – added German language for the Installer and User Interface.

17.8. Version 2.9.271.16

Release Date: March 2012

The following models are supported:

Device Category	Device Type
Digital Pocket Memo 3	LFH9620 LFH9600 LFH6520 LFH9500
SpeechMike 3	LFH3310 LFH3300 LFH3220 LFH3210 LFH3200
SpeechMike Air	LFH3020 LFH3010 LFH3000
SpeechMike 2	LFH5284 LFH5282 LFH5276 LFH5274 LFH5272 LFH5270 LFH5262 LFH5260
Foot Control	LFH2330 LFH2320 LFH2310 LFH6220 LFH6212 LFH210/90

The LFH 210/90, 6212, 6220, 2310, 2320 type Foot Controls have three pedals.

Software requirements:

- Microsoft Windows Server 2008 R2 Service Pack 1
- Microsoft Windows Server 2003 R2
- Microsoft Windows 7 Service Pack 1
- Microsoft Windows XP (32 bit) Service Pack 3

The remote device management server needs one of the following SQL servers:

- Windows Server 2008 R2 Service Pack 1
- Microsoft SQL Server 2008 R2
- Microsoft SQL Server 2008 R2 Express

18. Known Issues

This chapter describes known issues related to the Remote Device Manager. Basically, all the known issues have no particular impact on the whole functionality of the software.

RDM-58
Installer window appears not adjusted on high resolutions display (1920x1080 or more).

RDM-74
On the Tab Images, select a wallpaper for SpeechAir. Here is not possible to activate Set to all configuration button.



RDM-78
Philips Dictation Recorder crashes if you create authors name with one of these characters:
'/', ':', '"', '<', '>', '\\', '*', '?', '|','!', '~', '`','@','#','$','%','^', '&','+','(',')',';',':','=','{','}','[',']'

SPAD-528
For VPN Connection the screenlock PIN or password is required, otherwise the device aks for password for credential storage. On the PRDM the Admin must not dosable this in the configuration.





SPAD-487
Before you install APK packages to the SpeechAir device please check, if the application is compatible with Android version 4.4.2 (Android SDK Platform 19 or higher, Android SDK Tools 22.3 or higher). The result is that the application wasn't installed but the SA doesn't display any error message.

19. Purchase Unlimited Edition

SpeechExec Remote Device Manager free edition is limited to 10 connected devices.
You can upgrade this to unlimited Enterprise edition and order the registration key for the Product Number LFH 7470.

For more information please contact your local Speech Processing Solutions Partner.
Our dealer locator provides the most up-to-date information on certified partners close to you – please check https://www.dictation.philips.com/support-contact/where-to-buy/ .



Discover the comprehensive range of professional dictation products from Philips

http://www.philips.com/dictation

December, 2016
Doc. No: PRI-702/20161222

Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used by Speech Processing Solutions GmbH under license from Koninklijke Philips N.V.

Dragon NaturallySpeaking is a trademark of Nuance, Inc. and is used here under license
All other trademarks are the property of their respective owners.
Errors and omissions excepted.

Speech Processing Solutions GmbH reserves the right to change programs or the documentation from time to time without informing the user

© 2017 by Speech Processing Solutions GmbH.
All rights reserved. No part of this document may be reproduced or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without prior written permission of Company Name.