

Supplemental Instructions for Installing This Product to an 8' Workbench Frame

When installing this product on 8' workbench frame please remove stiffener "D" from rail "B" prior to installing the kit to the workbench.

