


## **ALL KEY FOBS MUST BE PRESENT AND REPROGRAMMED WHEN PROGRAMMING NEW FOBS**

### **Programming Instructions:**

- 1) Turn vehicle ignition key to ON position, without starting engine (Key-On Engine-Off - Position "1").
- 2) Insert Programmer into OBD connector DLC port ( - located under steering column, near pedals). Programmer will beep & you will see the message "Remote Key Learning Active" in the Driver Information Center.
- 3) Press and hold lock and unlock for 30 seconds or until you hear a beep from the programmer.
- 4) Turn off and remove key from ignition.
- 5) Remove programmer from the OBD port and test all remotes.
- 6) Repeat procedure for all remotes that are not properly working.

## **FCC WARNING**

Statement 15.19(a)(3): This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by Dorman Products Inc. could void the user's authority to operate the equipment.

## **IC WARNING**

**63999352IC**

**63999353IC**

**63999354IC**

**63999355IC**

The term IC before the Certification/Registration number only signifies that the Industry Canada technical specifications were met.

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference including interference that may cause undesired operation of the device.

**ALL KEY FOBS MUST BE PRESENT AND REPROGRAMMED WHEN PROGRAMMING NEW FOBS**

Cet appareil est conforme aux CNR exempts de licence d'Industrie Canada. Son fonctionnement est soumis aux deux conditions suivantes:

(1) Ce dispositif ne peut causer des interférences; et

(2) Ce dispositif doit accepter toute interférence, y compris les interférences qui peuvent entraîner un mauvais fonctionnement de l'appareil