



ALL KEY FOBS MUST BE PRESENT AND REPROGRAMMED WHEN PROGRAMMING NEW FOBS

Programming Instructions:

- 1) Turn Hazard lights ON (Located in upper center counsel )
- 2) Insert Programmer into OBD/ DLC connector & programmer will beep once ( - located under steering column, near pedals).
- 3) Press Start/Stop button twice to ON position without starting & programmer will beep twice.
- 4) Press Start/Stop button to OFF & programmer will beep once.
- 5) Press the Start/Stop button 1 time with the logo end of the 1st remote. Continue to hold remote in front of Start/Stop button until cluster lights up and security light blinks 5 times (do not continuously depress the Start/Stop button while continuing to hold remote in front of the Start/Stop button).
- 6) Press Start/Stop button to OFF.
- 7) Repeat steps 5 & 6 for all additional remotes. You can only program a maximum of 4 remotes.
- 8) Press Start/Stop button 1 time with the logo end of the 1st remote. Continue to hold remote in front of Start/Stop button until message in cluster says "Key Registration Complete".
- 9) Press Start/Stop button to OFF.
- 10) Remove Programmer & test functionality of each remote. Put foot on brake & start vehicle. Press lock & unlock several times on each remote to make sure functions work properly. Repeat procedure if process was not successful.

FCC WARNING

Statement 15.19(a)(3): This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by Dorman Products Inc. could void the user's authority to operate the equipment.

IC WARNING

The term IC before the Certification/Registration number only signifies that the Industry Canada technical specifications were met. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference including interference that may cause undesired operation of the device.

FVIN:

6399367IC

ALL KEY FOBS MUST BE PRESENT AND REPROGRAMMED WHEN PROGRAMMING NEW FOBS

6399368IC

6399369IC

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.