



9868 Scranton Road, San Diego, CA 92121

Customer Care: 866.227.7323 nwfsupport@verizon.com

www.networkfleet.com

Verizon Networkfleet 6500 Quick Start Installation Guide

1. Download 6500 Installation Guide:

- <http://www.networkfleet.com/portal/support/support-overview>

2. Before beginning installation, please complete the registration form included in your package.

3. For assistance with installation, contact Customer Care at NWFSupport@verizon.com or call 866.227.7323.

The Verizon name and logo and all other names, logos, and slogans identifying Verizon's products and services are trademarks and service marks or registered trademarks and service marks of Verizon Trademark Services LLC or its affiliates in the United States and/or other countries. All other trademarks and service marks are the property of their respective owners.

Light duty plug and play installation:

No harness necessary. Connect the device to the vehicle's OBD-II port.
Verify your installation.

Harness installation:

1. Connect harness to device.
2. Connect the other end of harness to the vehicle diagnostic port. Secure the harness without interfering with the brake or accelerator pedal.
3. Mount the device inside the dash and away from metal obstruction.
4. Verify your installation.

Note:

- Harness is required for heavy duty vehicles.
- Do not connect more than one (1) harness to the device.
- Other vehicles or accessories installation, please refer to the complete 6500 Installation Guide.

To verify successful installation:

1. Start the vehicle's engine and let idle for 15 minutes.
2. Verify successful installation.

LED pattern	Device status
Yellow LED slow blinking	Modem connectivity OK
Green LED slow blinking	GPS fix acquired and OK
Yellow & Green LED blink alternately	Modem connectivity and GPS OK
Yellow & Green LED blink slowly together	Device operating normally

LEDs will dim after 15 minutes.

Contact Customer Care at NWFSupport@verizon.com or call 866.227.7323 for assistance with installation.