



REMOVE GLASS STOP OR BEAD IN AREA OF DEVICE IF REQUIRED UNLESS GBK IS USED.

WIRING FOR E7500 & SS7500 LOCKS: GO THRU DOOR AND NOT DEVICE. MINIMUM RACEWAY CLEARANCE IS 1/4"

NOTE: MOUNTING HOLES TO BE PREPARED AT INSTALLATION ON DOOR

FOR OUTSIDE TRIM PREPARATION, WHEN REQUIRED, SEE ADDITIONAL TRIM TEMPLATE

LHR SHOWN
RHR OPPOSITE

9875/9975 & 9875-F/9975-F Series
Mortise Lock Device (Wood Door)

VON DUPRIN®

NOTES: SEE MASTER SHEET #10001 FOR SUGGESTED REINFORCING

TEMPLATE NUMBER:

W10305_a

DATE:
05-29-13