



CHEVY/GMC/CADILLAC				
Part #	CIPA #	Mirror Style	Vehicles	Years
<u>92-1125</u>	10000 (LH or RH)		GMC/Chevy Pickups and Vans <i>*will not fit Chrome mirrors with Black trim</i> <i>*Fits Chrome manual mirrors only</i>	1980-1995
<u>92-1126</u>	11000 (LH or RH)		Chevy S-10, S-15 <i>*Fits the chrome door-mount two-point break-away style mirror only</i>	1982-1993
<u>92-9188 (LH)</u> <u>92-9189 (RH)</u> <u>92-1880 (Both)</u>	10201 - left 10202 - right 10200 - pair		GMC/Chevy Full-size C/K body style Pickups Suburban, Yukon, Kodiak, Dually, Tahoe Safari, Astro Vans Cadillac Escalade	1988-2000 1992-1999 1991-2004 1992-1999
<u>92-1206 (LH)</u> <u>92-1207 (RH)</u> <u>92-1884 (Both)</u>	10801 - left 10802 - right 10800 - pair		Chevy/GMC Silverado, Sierra Tahoe, Suburban, Yukon, Yukon XL, Denali, Escalade Chevy Avalanche <i>*will not fit Full-Chrome mirrors or telescopic mirrors</i> <i>*will not fit mirrors w/ signal</i> <i>*Fits both Black and Chrome cap models</i>	1999-2006 2000-2006 2000-2006
<u>92-2032 (LH)</u> <u>92-2033 (RH)</u> <u>92-2031 (Both)</u>	10901 - left 10902 - right 10900 - pair		Chevy/GMC Silverado, Sierra Tahoe, Suburban, Yukon, Yukon XL, Denali, Escalade Chevy Avalanche Cadillac Escalade <i>*will not fit telescopic mirrors</i>	2007-2011 2007-2011 2007-2011 2007-2011
FORD/LINCOLN				

<u>92-1126</u>	11000 (LH or RH)		Ford Full-Size Pickups Ford Ranger <i>*Fits the chrome door-mount two-point break-away style mirror only</i>	1983-1998 1983-1991
<u>92-9186</u> (LH) <u>92-9187</u> (RH) <u>92-1863</u> (Both)	11501 - left 11502 - right 11500 - Pair		Ford Full-size Pickups Ford Aerostar Ford Explorer, Navajo, Bronco Ford Bronco Ford F-250 & F-350 HD w/old body style <i>*Fits full-Black, Black w/ Chrome cap *Add'l adapter needed for Explorer</i>	1992-1997 1990-1997 1988-1995 1992-1996 1997
<u>92-9210</u> (LH) <u>92-9211</u> (RH) <u>92-1889</u> (Both)	11601 - left 11602 - right 11600 - pair		Ford F-150/F-250 Light Duty Ford Expedition Lincoln Navigator <i>*Fits contour-style only *Does not fit mirrors w/ signal</i> <i>*Does not fit XLT models *Does not fit 2004 new-style pickups</i>	1997-2004 1997-2002 1997-2002
<u>92-1218</u> (LH) <u>92-1219</u> (RH) <u>92-1886</u> (Both)	11701 - left 11702 - right 11700 - pair		Ford Full-size Light Duty (manual only) <i>*Fits rectangular-style mirror only</i>	1997-2002
<u>92-1127</u> (LH) <u>92-1128</u> (RH) <u>92-1887</u> (Both)	11801 - left 11802 - right 11800 - pair		Ford F-150 & F-250 Light Duty Ford F-150 & F-250 XLT Models <i>*Will not fit STX style mirrors</i>	2004-2011 2004-2011
<u>92-1775</u> (LH) <u>92-1776</u> (RH) <u>92-1888</u> (Both)	11901 - left 11902 - right 11900 - pair		Ford F-250 & F-350 Super Duty Ford Excursion	1997-2008 2000-2008

DODGE

<u>92-1125</u>	10000 (LH or RH)		Dodge Pickups and Vans <i>* 1986-93 fits both electric & manual Chrome mirrors</i> <i>* 1994-95 fits Chrome manual mirrors only</i>	1986-1995
<u>92-1129</u>	10300 (LH or RH)		Dodge Pickups and Vans <i>* 1994-97 Fits both electric & manual Black mirrors</i> <i>* 1996-97 Fits chrome electric mirrors</i> <i>*Will not fit Dodge Dakotas with black sport mirrors</i>	1994-1997
<u>92-1195 (LH)</u> <u>92-1197 (RH)</u> <u>92-1848 (Both)</u>	10501 - left 10502 - right 10500 - Pair		Dodge Old Style 1500,2500,3500 Dodge Durango Dodge Dakota Dodge Full-size Van <i>*will not fit 5"x7" Sport Mirror size</i>	1994-2002 1998-2003 1998-2004 2000-2003
<u>92-0701 (LH)</u> <u>92-0702 (RH)</u> <u>92-1849 (Both)</u>	10701 - left 10702 - right 10700 - pair		Dodge Ram 1500 Dodge Ram 2500 & 3500 <i>*will not fit extendable mirrors on 3500's</i>	2002-2006 2003-2006
Toyota				
<u>92-0301 (LH)</u> <u>92-0302 (RH)</u> <u>92-0300 (Both)</u>	11301 - left 11302 - right 11300 - pair		Toyota Tundra	2007-2011
Universal Clip-On Mirrors			Return to top	
<u>92-1777</u>	11960		Most Vehicles	Any

<u>92-1132</u>	11953		Most Vehicles	Any
<u>92-1130</u>	30-0096 (not CIPA)		Most Vehicles	Any