

HD Headsets Direct, Inc.

Making Communication Easier

1470 W. Gurley St. • Prescott, AZ 86305

(800) 914-7996

(928) 777-9100

fax (928) 777-9120

The HDI PC/Phone Headset Switch (part# 05344-42) connects between the base of a telephone and a headset system (or a handset if no headset system is used). This device allows you to use a standard telephone headset (wireless or corded) for both your phone and computer. And, can easily be installed in 5 simple steps.

- Step 1 : Unplug the headset system or handset from the base of the phone.
- Step 2 : Plug the coiled cord (marked “Tel/Amp”) on the PC/Phone Headset Switch into the base of the phone (where the headset system or handset **was** plugged in).
- Step 3 : Plug the headset system (or handset) into the modular “headset jack” on the PC/Phone Headset Switch (there is only 1 open jack where this can plug in).
- Step 4 : Plug the supplied computer soundboard cable into the “PC jack” on the PC/Phone Headset Switch (this will only plug into 1 jack on the switch).
- Step 5 : Now take the other end of the supplied computer soundboard cable with the 3.5mm connectors (red and black) and plug it into the computer. The 3.5mm connector ends have icons (little pictures) on each to tell you which jack to plug them into (red plugs into the mic jack & black plugs into the speaker or headset jack on the computer).
- Here are some examples of installation:

