
## **ClearOne**

# DIALOG® 20 and DIALOG® 10 USB Wireless Microphone Systems

## **Antenna Installation Guide**



The ClearOne DIALOG 20 and DIALOG 10 USB Wireless Microphone System Receivers include two, built-in, passive antennas. When using a ClearOne DIALOG 20 or DIALOG 10 USB Antenna Cable Kit, the antennas can be extended to either 10' or 25' lengths in each direction easily accommodating most conferencing requirements and room types. These Plenum rated antennas adhere to most municiptle fire codes, and therefore, they can be extended inside ceiling crawl spaces for discreet installation. The available transmitters include: Boundary tabletop, Gooseneck podium, Handheld and Beltpack.



Example of "A" and "B" antennas with antenna kit configuration.

#### **Receiver Mounted Antennas:**

DIALOG 20 and DIALOG 10 USB Receivers come with two, Plenum rated, dipole antennas.

- Mount the antennas on the front of the receiver using a non-conductive adhesive on the threads of the Female TNC Connector.
- Tilt the antennas slightly outward.



#### **Antenna Cable Kits:**


DIALOG 20 and DIALOG 10 USB Antenna Cable Kits are available in two lengths.

The DIALOG Antenna Cable kit can be used to extend the passive,


Plenum rated, dipole antennas that are included with the DIALOG 20 and DIALOG 10 USB Receivers.

Choose either a 10' (ft) or 25' (ft) Antenna Cable Kit.

Includes required hardware. <u>Does not</u> include antennas or adhesive.




10' (ft) length for small rooms (RG58 Plenum Cable) SKU: 910-6105-011



25' (ft) length for large rooms (RG8 Plenum Cable) SKU: 910-6105-021

#### **Confirm the Box Contains the Following:**



Use these cable extension bracket templates to mark the pilot holes.

#### **Hollow Wall Antenna Installation:**

- 1 Determine required mounting location.
- 2 Using the antenna extension brackets or the templates (fig. 1; Pg. 2), mark the two (2) mounting hole locations.





Fig. 2 Wall Anchor

- 3 Drill two 5/16" (8mm) pilot holes (Fig 2).
- Fold the anchor (D) in the middle by pressing in middle with finger (Fig. 3).






Fig. 4 Wall Anchor Flush

Fig. 3

Wall

Anchor

Do not hammer nail or screwdriver.

7 Remove the nail or screwdriver.




Fig. 5 Wall Anchor open in wall

Repeat steps 4 - 7 for the second anchor.

To avoid interference, only one anchor should be installed vertically.

Secure antenna extension bracket (A) using two (2) wood screws (B) (Fig 6).
 Do not overtighten screws.




Fig. 6 Secure Bracket to Wall

Hollow wall anchors (D) may be used as wedge anchors in walls thicker than 3/4" or as expansion anchors in solid walls.

#### **Wood Stud Antenna Installation:**

- 1 Determine required mounting location.
- 2 Using the antenna extension bracket or the template (fig. 1; pg. 2), mark two (2) mounting hole locations.
- 3 Drill two 7/64" (2.5mm) pilot holes to a depth of 1-3/4" (45mm).
- 4 Secure the antenna extension bracket (A) to the structure using two (2) wood screws (B) (Fig. 7).




Fig. 7 Wood Stud Wall Mount Installation

#### Mounting Antennas to Wall, Ceiling or AV Rack:

- 1 Mount antenna over-head and within line of site to transmitters. The dipole antenna's reception is strongest at the sides of the antenna with a null point at the tip. Therefore, it is best to tilt the antenna so that the side faces the transmitters.
  - Wall Mount (Fig. 8).
  - Ceiling Mount (Fig. 9, 10, 11).
  - Ceiling Mount RX with PoE to CONVERGE Pro 2 or Beamforming Mic Array 2 (Fig. 11).
  - AV Rack Mount (Fig. 12).
- Separation distance of antennas should be a minimum of 2' (ft.) and maximum of 30' (ft.).
- 3 Attach TNC panel mount connector (C) and permanently secure both the antenna and the extension cable (E) to the antenna extension bracket (A) by using a non-conductive adhesive on the threads of both sides of the TNC Panel Mount Connector (Fig. 8).





Fig. 8 Antenna Bracket Assembly Wall Mounted

- 4 Attach the other end of the extension cable to the Dialog 20 Receiver and secure by using a non-conductive adhesive on the threads of the Female TNC Connector.
- 5 Repeat steps 1 to 4 for the second antenna and extension cable.



Professional installation is required. Installer is responsible for securing antennas with a non-conductive adhesive and ensuring mounting hardware is appropriate to their particular installation.

## ClearOne.

#### **CLEARONE LOCATIONS**

#### HEADQUARTERS:

Salt Lake City, UT USA 5225 Wiley Post Way Suite 500 Salt Lake City, UT 84116

Tel: 801.975.7200 Toll Free: 800.945.7730 Fax: 801.303.5711 e-mail: sales@clearone.com

EMEA
Tel: 44 (0) 1189.036.053
e-mail: global@clearone.com

Tel: 852.3590.4526 e-mail: global@clearone.com

**Tel:** 801.974.3621 e-mail: global@clearone.com

Tel: 800.707.6694 e-mail: techsales@clearone.com

**Technical Support** Tel: 800.283.5936

e-mail: tech.support@clearone.com

Other product names may be registered trademarks of their respective owners who do not necessarily endorse ClearOne or ClearOne's products. All rights reserved. Information in this document subject to change without notice. © 2022 ClearOne. DOC-0307-001 DIALOG20 ANTENNA INSTALLATION GUIDE V6.0 January 04, 2022