

# How to flash your Samsung phone?

1 FILE

- 1 Extract (un-rar) the firmware file (i.e. to folder c:\Odin)
- 2 [Download Odin](#)
- 3 Extract Odin ZIP file (i.e. to folder c:\Odin)
- 4 Open Odin
- 5 Power off your phone
- 6 Reboot Phone in Download Mode  
Connect USB-cable to your computer. Hold down **Volume up** and **Volume down** at same time. While holding down, connect the USB-cable to your phone
- 7 Wait until you get a blue sign in Odin
- 8 Add MD5-file in AP-field in Odin. **Do not tick any extra boxes.** The only options to be ticked are **F. Reset Time and Auto-Reboot.**
- 9 Click the start button to begin flashing the firmware update

If you have any questions or need help, our moderators on our [forum](#) are happy to help you