

Remote Key Finder---Model: CND1002
Instructions

Introduction:

Model CND1002--- Remote Key Finder can easily find your misplaced keys quickly. When pressing the transmitter button, the corresponding coloured receiver will respond with a beeping sound.

Transmitter:



Receiver:



Red



Blue

Installation

1. Pull out the battery insulating tab.
2. Attach receiver to your keys.



Operation

When pressing the colour-coded button on the transmitter for 2 seconds, the corresponding receiver will respond with a beeping sound and flashing light.

Low Battery Warning

When the battery power for the receiver becomes weak, it will send continuous sounds to warn you to change the battery.

Specification :

Battery: A27 12V (for transmitter), CR2032 (for receiver)

Frequency : 433.92MHz

Remote distance : Up to 30 meters

Sound Volume: 90-95 dB

FCC NOTE:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:(1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.