User Manual



JP26 True Wireless Stereo Wireless Earabuds

Specifications and features

- Twins.true wireless stereo
- Chipset:CSR from UK
- Wireless Version: 4.2
- Fireless Versiom: 4.2
- Frequency: 2.4GHz
- Wireless rang: one for about 15m, and a set for about 10m
- Receive sensitivity:-90dBm
- . Battery capacity: 65mAh for left and right one
- NOKIA charging port
 Work time: one for 5-6 hours and a set for 2-3 hours.
- Standby time: one for 120 hours, and a set for 60 hours
- Charging time: 1.5 hours
- Support one match two,connect two device Supports A2DP1.3/HFP1.6/HSP1.2/AVRP1.6/DI1.3
- Adopt the advanced CVC6.0 active noise-cancellation
- Built-in superior HD microphone provide clear and loud sound



Please wear wireless earphone like this to get the best experience!

Rebuild Twin relationship

You may rebuiuld the twin relationship tao earphone as follows:

1.press and hold the MFB button of any two earphones for about 8-10 seconds at the same time until blue light flash, 2.press and hold theMFB button of anyone of two earphone, two earphones will shut down at the same time.

3.repair the relationship between the set of TWS earphones and your mobile phone.

1.press and hold the MFB button of one earphone for 2 seconds until red light flash.

2.press and hold the MFB button of another earphone for 3 seconds until red light and blue light flash alternately, and at the same time the blue light of the first earphone will flash(one time in 5 seconds) 3.Turn on your mobile phone's bluetooth and search for the

device named "X1T" and connect to it. 4.After successfully pairing between your mobile phone and your

TWS earphones the next time you wish to use the TWS earphones, Simply power both TWS earphones on (red flashing light)(no need to enter pairing mode), Then TWS earphones may automatically connect to your mobile phone.

Turning off TWS earphone

To turn off the TWS earphones, press and hold either of the pieces for 3 seconds, both TWS earphones will turn off.

If you don't want to use TWS earphones for long time, turn off it in time please.

 To pause:short press the MFB button once. 2.Next song: short perss the MFB button twice. 3.Answer call: short perss the MFB button once. 4.End call: short perss the MFB button once. 5. Reject call: short perss the MFB button twice.

Charging for TWS earphones

Charging for TWS earphones just with special NOKIA charging line.

When you charge for your TWS earphones, the red light will shines, and When it be finished, the blue light will shines.

Dos and don'ts

1.Please don't beat the product and do not use heavy objects. to squeeze your TWS earphones.

2.This TWS earphones is prohibited immersion, and do not use this product when bathing and swimming. 3.Please stay away from the WIFI router and other Blurtooth

devices to avoid other devices that use 2.4GHZ signals to interfere with this product.

4.Please use this product within the effective distance (10m without occlusion).

5. This product is suitable for desktop and notebook computers, tablet PC and mobile phones.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to

radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and received
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be usedin portable condition without restriction.

True Wireless , So free

For Sports









True Wireless . So free ! True Wireless . So free! True Wireless . So free ! True Wireless . So free! True Wireless . So free! True Wireless . So free!