

Setting EURO and CUR Function

CUR and € : Press CUR or € key for 1~1.5 sec, the “CUR” or “Euro” indicator on the LCD will start flashing. Input your desire parameter then press CUR or € key again. The “CUR” or “Euro” indicator will disappear; it means the setting is accomplished. When LCD displays “0”, you can press the “CUR” and “Euro” to enable or disable the indicator on the LCD. When the numerals display on the LCD. Press the “CUR” or “Euro” button, and then it will exchange to the currency or tax rate.

For example : Supposing the CUR parameter is 34 and the Euro parameter is 105; the calculation result is 180.

The “CUR” or “Euro” indicator display on the LCD : Press CUR key, then the calculation result will be 6120 (180×34). Press Euro key, then the calculation result will be 18900 (180×105).

The “CUR” or “Euro” indicator didn't display on the LCD : Press CUR key, then the calculation result will be 5.29 ($180/34$). Press Euro key, then the calculation result will be 1.17 ($180/105$).

Setting Tax Function :

Press “%” key for 1~1.5 sec, the “TAX” indicator on the LCD will start flashing. Input your desire parameter then press “%” key again. The “TAX” indicator will disappear; it means the setting is accomplished.

For example : Supposing the Tax parameter is 10 and the calculation result is 180. Press Fn & Tax+ key, then the calculation result will be 198 ($180 \times (1+0.1)$). Press Fn & Tax- key, then the calculation result will be 163.63 ($180 / (1+0.1)$)

Keypad :

Operation Force	60±15gm	
Weight	150gm	
Total Travel	2.2 mm	
Operation Frequency	27 MHz/ 1 communication channel/ 1M distance	
Battery type	1 * AAA alkaline battery	
Dimension : L × W × H	136 × 75 × 21.95mm	
Receiver Connector	USB	
Power consumption	TX	Working mode : 10 mA max
		Suspend mode : <100 uA
	RX	Working mode : 16mA maPower
		Suspend mode : <500uA
Switch Life	3 million cycles	
Keycaps type	Low profile	
Agency Approvals	FCC, CE	

Mouse:

There is a power switch at back of the mouse. To save the power, you can turn it off when you don't need to use it.

Specification:

Weight	50 gm	
Operation Frequency	27 MHz/ 1 communication channel/ 1M distance	
Battery type	2 * AAA alkaline battery	
Dimension: L × W × H	88 × 51 × 31.6mm	
Receiver Connector	USB	
Power consumption	TX	Working mode : 40 mA max
		Suspend mode : <800 uA
Resolution	800 dpi	
Agency Approvals	FCC, CE	

FEDERAL COMMUNICATIONS COMMISSION STATEMENT

Notice 1

You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

Notice 2

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

The Following Information is Only for EU-member States :



The use of the symbol indicates that this product may not be treated as household waste. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

Les informations suivantes sont applicables uniquement dans les pays membres de l'Union Européenne :



L'utilisation de ce symbole indique que ce produit ne peut pas être traité comme un déchet ménager ordinaire. En vous débarrassant de ce produit dans le respect de la réglementation en vigueur, vous contribuez à éviter les effets négatifs potentiels sur l'environnement et sur la santé humaine. Pour plus d'informations détaillées concernant le recyclage de ce produit, veuillez contacter votre municipalité, votre service de collecte des déchets ménagers ou le magasin où vous avez acheté le produit.

Die folgenden Informationen betreffen nur Mitgliedsstaaten der EU :



Die Verwendung des Symbols gibt an, dass dieses Produkt nicht als Hausmüll behandelt werden darf. Durch das Sicherstellen der korrekten Beseitigung dieses Produkts tragen Sie dazu bei, mögliche negative Auswirkungen auf die Umwelt und die Gesundheit von Menschen zu vermeiden, die anderenfalls bei ungeeigneter Beseitigung dieses Produkts hervorgerufen werden können. Detaillierte Informationen zur Wiederverwertung dieses Produkts erhalten Sie bei den örtlichen Behörden, bei dem für Ihren Wohnsitz zuständigen Wertstoffverwerter bzw. dem Geschäft, in dem Sie dieses Produkt erworben haben.

De volgende informatie is alleen van toepassing op lidstaten van de EU :



Het gebruik van het pictogram geeft aan dat dit product niet als huishoudelijk afval mag worden behandeld. Door dit product op de juiste wijze weg te werpen, helpt u mogelijke negatieve gevolgen voor het milieu en de volksgezondheid te voorkomen, die anders mogelijk worden veroorzaakt door een onjuiste afvalverwerking van dit product. Neem voor meer gedetailleerde informatie over het recycleren van dit product contact op met de afvalverwerking in uw woonplaats, de dienst voor verwerking van huishoudelijk afval of de winkel waar u dit product hebt aangeschaft.

Le informazioni seguenti riguardano esclusivamente gli stati membri dell'Unione Europea :



L'uso di questo simbolo indica che il prodotto non può essere trattato come rifiuto domestico. Garantendo un corretto smaltimento di questo prodotto si contribuisce a evitare potenziali danni all'ambiente e alla salute, che potrebbero altrimenti essere causati dallo smaltimento errato del prodotto. Per informazioni più dettagliate sul riciclaggio di questo prodotto, rivolgersi all'apposito ufficio locale, al servizio di smaltimento dei rifiuti domestici o al negozio in cui è stato acquistato il prodotto.

La información siguiente solo se aplica a los Estados miembros de la Unión Europea :



La utilización del símbolo indica que el producto no se puede eliminar como cualquier otro residuo doméstico. Si garantiza la eliminación correcta del producto, contribuirá a prevenir eventuales consecuencias negativas para el medio ambiente y la salud humana, las cuales podrían ser ocasionadas por la eliminación inadecuada del producto. Para obtener más información acerca del reciclaje del producto, póngase en contacto con las autoridades locales, el servicio de recogida de basuras o el establecimiento donde adquirió el producto.

Troubleshooting

When you turn on the keypad, if the keypad's LCD shows abnormal or nothing, check your battery first. If the battery is working fine, try to find an acicular metal and plug into the reset hole (in the back of the keypad). Then the keypad will work normally. If the problem was still unsolved, please contact the technical support.

Technical Support

Technical support is available to all registered users of Kensington products.

Web Support

You may find the answer to your problem in the Frequently Asked Questions (FAQ) section of the Support area on the Kensington website: www.kensington.com.

Telephone Support

There is no charge for technical support except long-distance charges where applicable. Please visit www.kensington.com for telephone support hours. In Europe, technical support is available by telephone Monday to Friday 09:00 to 21:00 (Central European time).

Please note the following when calling support:

- Call from a phone where you have access to your Adapter
- Be prepared to provide the following information:
 - Name, address, and telephone number
 - Name of the Kensington product

For help with finding a compatible SmartTip® Tip for your Adapter, call 1-866-908-HELP (4357) (US and Canada) or +1-650-572-2700 (International). For other support questions, please call one of these numbers:

België / Belgique	02 275 0684	México	55 15 00 57 00
Canada	1 800 268 3447	Nederland	053 482 9868
Denmark	35 25 87 62	Norway	22 70 82 01
Deutschland	0211 6579 1159	Österreich	01 790 855 701
España	91 66 2 3833	Portugal	800 831 438
Finland	09 2290 6004	Schweiz / Suisse	01 730 3830
France	01 70 20 00 41	Sweden	08 5792 9009
Hungary	20 9430 612	United Kingdom	0207 949 0119
Ireland	01 601 1163	United States	1 800 535 4242
Italia	02 4827 1154	International Toll	+31 53 484 9135

The Kensington Promise™



La promesse de Kensington™

This product comes with a 2-year limited warranty & free technical support.
www.kensington.com
8 0 0 - 2 6 8 - 3 4 4 7

Ce produit comprend une garantie limitée de 2 ans et le soutien technique gratuit.
www.kensington.com
8 0 0 - 2 6 8 - 3 4 4 7



Kensington Computer Products Group
A Division of ACCO Brands
333 Twin Dolphin Drive, Sixth floor
Redwood Shores, CA 94065

Designed in California, U.S.A.
by Kensington
Made in China

ACCO Brands Europe
Oxford Road
Aylesbury
Bucks, HP21 8S2
United Kingdom

ACCO Canada Inc.
5 Precidio Court
Brampton
Ontario
L6S 6B7
Canada

ACCO Australia
Level 2, 8 Lord St
Botany NSW 2019
PO Box 311
Rosebery NSW 1445
Australia

www.kensington.com

901-1995-01