

FCC WARNING

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ☑ Consult the dealer or an experienced radio/TV technician for help





CONTROLS

1. MODE

Use the "MODE" button to switch between the multiple available sources (Bluetooth, Aux, and FM)

2. PLAY/PAUSE, MUTE/SCAN

Bluetooth Mode: Play/Pause FM Mode: Mute | Auto Scan (press and hold)

AUX Mode: Mute

3. PREVIOUS, (I◄◄/─) VOLUME DOWN

Bluetooth Mode

Press: Previous Track

Press and Hold: Volume Down

4. NEXT | VOLUME UP (►► /+)


Bluetooth Mode

Press: Next Track

Press and Hold: Volume Up




INPUT




Charging

Connect media device to the USB port on the back of SoundFloe to being charging your personal device.



Plug the micro USB connection to the charging port located on the back of the SoundFloe speaker. Connect the power adapter to your wall outlet. Charging will commence automatically.



AUX Input

Connect the 3.5mm (AUX) audio cable to the AUX input on the SoundFloe. Connect the other end of the cable to your mobile device.

Bluetooth

To insert Bluetooth mode, press and hold the Bluetooth button for 3 seconds. This will activate the search feature on the SoundFloe.

On your mobile device find the "SoundFloe" device and select. Bluetooth connection will automatically be established.

SPECS

Connected Protocol	.33 Feet
Control Buttons	. MODE Play/Pause Power Prev/Vol- Next.Vol+
LED Indicator	.FM AUX Bluetooth Battery
BatteryBattery Life	
Power Bank Output The Charging Port Input	USB, 5V/1A . Micro USB, 5V DC
FMSpeaker Output WattageAUX InTHD + Noise Ratio	.4W x 2 .3.5 mm .<10%
S/N	. Plastic
i lib-lob i aucer	. 1 C 3

