

# User Manual - AVN Grade



Please carefully read the manual before using the product and keep it properly for future use.



Manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories.

#### FCC CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines. This equipment has very low levels of RF energy that it deemed to comply without maximum permissive exposure evaluation (MPE).

# Preface

---

The manual mainly introduces the functions, applications and operation methods of car audio-visual system product. The manual is only used as operation instructions for user but not basis for maintenance / service. As for product update, function update and changes of relevant parameters, supplementary statements will be otherwise provided without prior notice. For details, please contact with Honda dealers.

---

**Tips** Picture example in the manual may be different from the actual picture.  
Content displayed in the picture may be different from the actual content.  
In addition, inherent nouns such as product name are the trademarks or registered trademark of each company.

---

## I. Precautions

---

### Important Safety Information

Before using the navigation system, please carefully read and fully understand the following safety information, and keep it accessible as reference for operation procedures and safety information.



- ★ Please do not install or repair the navigation system by yourself.
- ★ According to the relevant national laws and regulations, it is not allowed to watch video or make relevant operations during driving. Please do not watch video or carry out any relevant operation when driving for the safety of yours and others.
- ★ Please read and understand the user manual before using the system.
- ★ Please pay special attention to all notes and precautions in the manual and strictly follow operation instructions.
- ★ Keep the system away from any liquid, or else it will cause short circuit and may damage the system.

### Safety Declaration

- ▲ Navigation function (and reversing image function) of the product is just assistance for your driving. Please pay attention to the actual situation.
- ▲ Navigation function (and reversing image function) of the product is just assistance for your driving, but it does not mean you can divert your attention, be careless or lose your judgment. Our company will not bear any responsibility of accident caused by it.
- ▲ Route and navigation information displayed by the system are just for reference, and may not clearly reflect the latest allowable route, road condition, one-way street, and road closure or traffic limitation. The traffic limitation and advice implemented currently are always prior to the information displayed by the system, so please comply with the current traffic limitation.
- ▲ Data map recorded to SD card is the intellectual property of supplier. It is prohibited to copy or spread for other purposes.

**Note:** For any kind of Complaint, Please contact to Honda Authorised dealer



### Caution

Please keep the product free from moisture. Power failure or discharge of storage battery may cause the system to reset its memory.

### Guarantee of Safe Driving

- ▲ Ensure to comply with safe driving regulations and the traffic rules in force.
- ▲ If the operation of navigation system (and reversing image function) will divert your attention from safe driving, please do not carry out the operation.
- ▲ If you need to watch display to carry out system operation, please stop car at safe place and use parking brake.
- ▲ Don't set volume of the navigation system too high, or else you will be impossible to hear the traffic condition outside and SOS signal.
- ▲ For the consideration of safety, some functions will be not carried out, e.g., video play.


### Other Safety Information

- ▲ The system can check whether parking brake of vehicle is in use, and will stop you watching video in driving.
- ▲ Some menus of the navigation system cannot be operated in driving the same as part AV functions. If you want to watch video, please stop vehicle at safe place and use parking brake.
- ▲ To prevent storage battery from drained, please ensure to start motor when using the system. If not, it may drain the battery.
- ▲ If the product fails to work normally, please contact with the authorized HONDA sales service. HONDA Cars India Ltd. reserves all the right to the interpretation of the product manual.

## II. Basic Operations

### System Startup and Turnoff

#### ◆ Startup

When vehicle motor starts, the system power will connect automatically and then display the screen of cautions. click  to enter the previous model as shown below:



Enter the previous model

#### ◆ Close the Host

- ① Press power key and close the host.
- ② Turn off motor and then power will cut off automatically.

### Main Menu

In the condition of power on, press down icon [back] for a period and then the screen will display the interface of main menu as shown below:



Function menus of the system are as shown below:

- [Navigation]: to enter navigation system
- [Radio]: to listen to radio programs such as FM1, FM2 and AM
- [DISC]: to play DVD in the machine (DVD, VCD, CD, and Data Disc)
- [Phone]: Bluetooth phone/Bluetooth audio play/ phone book
- [USB]: to play USB audio and video (Note: USB player supports various mainstream audio and visual format)
- [iPod]: to connect iPod player
- [AUX]: external audio input Click
- [Setting]: to set relevant information of the system

### Operation buttons of front panel




- |               |              |
|---------------|--------------|
| ① EJECT       | ⑤ DEST       |
| ② CD SLOT     | ⑥ BACK       |
| ③ TOUCH PANEL | ⑦ MAP        |
| ④ LOC         | ⑧ MICROPHONE |

#### Tips

The picture is just for reference. Product appearance is subject to material object!

### Details of Front Panel

- ① EJECT  Press the key to eject disc. If no disc, the screen will display no disc.
- ② CD SLOT Window to insert and take disc out.
- ③ TOUCH PANEL To display various screens and to select control item.
- ④ LOC Press the key to check your position of GPS navigation map.
- ⑤ DEST To enter setting interface of GPS navigation destination/route
- ⑥ BACK Press promptly to return to the previous menu step by step; press down to return to main menu.
- ⑦ MAP Place to insert map card.
- ⑧ BLUETOOTH MICROPHONE Voice input during Bluetooth call

## III. Function Operations

### 1. Radio

Click [Radio] to enter radio model as shown below:



[90.20kHz]: frequency of the current channel

[Step-by-step]: click icons [◀ ▶] to adjust step-by-step

[SCAN]: click icon SCAN to scan the next channel automatically.

It will scan all channels in the band before stopping automatically.

[BAND]: click icon BAND to switch bands between FM1, FM2 and AM.

[Semi-auto]: click [◀▶] / [▶▶] And enter semi-auto model that it will Stop after automatic search.

[SAVE]: Radio will search channels automatically all bands, and then save the best six and display them In preset channel key. Click any key to stop it.

FM frequency range can save 12 channels (6 for each FM1 and FM2)

AM frequency range can save 6 channels



[Preset]: press frequency point on screen promptly to select the stored channel; press down the current channel as shown below:

[Sound]: 7 options: Pop, Live, Dance, Classic, Soft, Standard, and Rock.


### 2. DVD

The system can play disc in many formats such as DVD/VCD/CD/MP3 (standard 12cm disc)

Click [DISC] on main menu and enter DISC model

#### ◆ Read Disc

Insert DVD and then it will enter DVD play interface automatically as shown below:




#### ◆ Insert/Eject

Slightly insert disc into slot with printed surface upward; When the system detects the disc, it will take it in and play automatically.

If disc in it, press key [▲] on panel to eject it.

#### ◆ If disc inserted is not playing


Insert it in again and play. Click menu function statements to enter menu play interface. Click [OK] to play.



[◀▶] Click direction key to select program chapter.

[OK] click it to play the selected chapter.

[BACK] click it to return to disc play interface DVD control menu consists of 3 pages. Click page turning icon at bottom left corner to turn pages.



[◀◀] Previous


[◀◀] fast backward: 2X, 4X, 8X, 16X, 32X

[■] Click it to pre-stop disc play

[▶▶] Click it pause play when it is playing. If paused or stopped, click it to play.

[▶▶] fast forward: 2X, 4X, 8X, 16X, 32X.

[▶▶] Next




[AUDIO] When playing disc of several audio tracks, press the icon when playing to switch among different tracks (multiple tracks).

[SUBTITLE] If disc is of several subtitles, Press the icon to switch subtitles when playing the disc.

[MESSAGE] Click it to display the title, chapter and time of the current program or chapter.

[CYCLE] to cycle play the current chapter

[MENU] It is the first level menu. If disc is playing, it will pause and enter main menu of the disc.



[CHAPTER] Enter number by number keypad to select Chapter to play.

[PROPORTION] to select proportion when playing disc (disc of several proportion formats)

[ANGLE] If disc is of multi-angle format, click the key to Switch angles.

[TOP-LEVEL MENU] Pause what is playing, and enter main menu of the disc.

[EQ] to switch among different sound models: Standard, Rock, Pop, Live, Dance, Classic, and Soft

[←] previous menu; [→] next menu

### 3. VCD (Refer to DVD)


### 4. CD

Insert CD and read it, the system will play it in order automatically as shown below:



[▲]/[▼] to scan up and down the list  
DVD or VCD interface has the following icons,  
And their functions and operation methods are as shown below:

[Random]: to random play song in disc




[Cycle]: to cycle play the current song. In random status, Press cycle play all songs

[EQ]: to switch EQs: Classic, Soft, Standard, Rock, Pop, Live, and Dance



### 5. Data Disc

Insert data disc and the system will automatically play the first document when disc is read.



- When playing data disc:  
[◀◀]: fast backward: 2X, 4X, 8X, 16X, 32X.  
[■]: to stop play  
[||]: press the icon to pause playing.  
If disc paused or stopped, press it to play again.  
[▶▶]: fast forward: 2X, 4X, 8X, 16X, 32X.  
[Random]: to random play songs  
[Cycle]: to cycle play the current song. In press again songs.  
[EQ]: to switch EQs: Classic, Soft, Standard, Rock, Pop, Live, and Dance


### 6. Phone Bluetooth

The system is provided with Bluetooth communication function. If your phone is equipped with Bluetooth function, you can connect it with the system point to point, and implement functions on screen including dialing, answering, history, address book and Bluetooth music play, etc.

★Note: For Bluetooth module and software differ from phone to phone, some functions may be different in use and even non compatible. Sorry for the inconvenience.

◆ Enter/Exit

Click [Phone] icon on screen, at right side as shown below:



Press [back] on the panel to exit Bluetooth interface.

◆ Match/Connect

To use Bluetooth HFT function, match shall be built first between the host and Bluetooth phone. Enter setting interface, and click [Search Devices] to open Bluetooth function to search Bluetooth. of the host device connection password "0000" (Default).

If Bluetooth connection is successful, the phone interface will Display the name of phone device, and meanwhile on top of the screen will appear icon



◆ Dial

You can directly dial numbers on phone or by number keypad on the panel.



If dialing numbers on panel, the number column will display Numbers entered. If wrong number, click [Delete] to delete numbers. When entered, Click [Call Switch] to make phone call.



Click [Call Switch] to hang up phone.



During call, click [Call Switch] to switch between vehicular speaker phone and mobile phone.