

142.5mm




**968582**  
**BLUETOOTH MINI CAPSULE SPEAKER**  
**WITH BUILT-IN MICROPHONE**

**INSTRUCTION MANUAL**  
**PLEASE READ ALL INSTRUCTIONS CAREFULLY AND RETAIN FOR FUTURE USE**

1

**Description of Parts**



Number	Function	Description
1	On/Off Power / Volume	Press and hold to power on/off the speaker. Press and hold to decrease volume or stop music.
2	Play/Pause	Press and hold to play/pause music.
3	Stop Forward / Previous Volume	Press and hold to stop music or decrease volume or stop music.
4	Next	Press and hold to skip forward one track.
5	Microphone	Use for voice calls and music playback.
6	Microphone	Use for voice calls and music playback.
7	DC Charging Port	Use for charging the speaker.
8	Power ON/OFF	Use to turn on/off the speaker.

3

142.5mm

**Getting Started**

- Remove any packaging from the box.
- Please retain all packaging until you have checked and counted all the parts and the contents against the parts list.

**Package Contents**

- Bluetooth Stereo Speaker
- 3.5mm AUX cable
- Instruction Manual

**Key Features**

- Use as Hands-Free speaker phone device with a built-in microphone
- Compatible with all Bluetooth enabled devices such as Smart Phones, Tablets, etc.
- Compatible with all Bluetooth enabled devices such as Smart Phones, Tablets, etc.
- Wireless Range - 26 to 33 feet

**SAFETY INSTRUCTIONS**

- Keep the unit away from heat sources, direct sunlight, humidity, water and any other liquids.
- Do not use the unit in areas where it may be exposed to excessive heat, humidity, vapors, etc.
- Do not use the unit in areas where it may be exposed to excessive heat, humidity, vapors, etc.
- Do not use the unit in areas where it may be exposed to excessive heat, humidity, vapors, etc.
- Do not use the unit in areas where it may be exposed to excessive heat, humidity, vapors, etc.
- Do not use the unit in areas where it may be exposed to excessive heat, humidity, vapors, etc.
- Do not use the unit in areas where it may be exposed to excessive heat, humidity, vapors, etc.
- Do not use the unit in areas where it may be exposed to excessive heat, humidity, vapors, etc.
- Do not use the unit in areas where it may be exposed to excessive heat, humidity, vapors, etc.
- Do not use the unit in areas where it may be exposed to excessive heat, humidity, vapors, etc.

2

**INSTRUCTIONS FOR USE**

**Power On/Off**

To Turn On the device - Slide the On/Off button to "ON" position.  
To Turn Off the device - Slide the On/Off button to "OFF" position.

**Connect using Bluetooth Technology manually**

1. Turn on the Bluetooth function on your Bluetooth Device (Smart Phone or Tablet).  
2. Press and hold the On/Off button to power on the speaker.  
3. Press and hold the On/Off button to power on the speaker.  
4. Press and hold the On/Off button to power on the speaker.  
5. Press and hold the On/Off button to power on the speaker.  
6. Press and hold the On/Off button to power on the speaker.  
7. Press and hold the On/Off button to power on the speaker.  
8. Press and hold the On/Off button to power on the speaker.

**Talking using the Bluetooth Speaker**

Please ensure that you are paired with the Bluetooth Speaker to use the below functions.

Function	Operation
Answer Incoming Call	Press the MFB button to answer an incoming call.
Project Incoming Call	Press the MFB button until an indication tone is heard.
End Call	After your phone conversation, short press the MFB button.
Increase Volume	Press and hold the volume increase button will increase the volume.
Decrease Volume	Press and hold the volume decrease button will decrease the volume.
Pause/End Number	Short press the MFB button twice.
Standby mode	Press and hold the On/Off button to power on the speaker.

4

285mm

**Listening to Music Wirelessly**

1. Turn on the Bluetooth function on your Bluetooth Device (Smart Phone or Tablet).  
2. Press and hold the On/Off button to power on the speaker.

Function	Operation	Action
Increase Volume	Press and hold the volume increase button will increase the volume.	Press and hold the "+" button will increase the volume.
Decrease Volume	Press and hold the volume decrease button will decrease the volume.	A short press on the "-" button will decrease the volume.
Play	Press and hold the play/pause button will play/pause the music.	A short press on the MFB button will pause the music.
Stop Forward	Press and hold the stop forward button will stop forward the music.	Short press the stop forward or volume increase button will stop forward the music.
Stop backward	Press and hold the stop backward button will stop backward the music.	Short press the stop backward or volume decrease button will stop backward the music.

Note: The volume function only can be used in Bluetooth mode only. If Aux mode, you may need to control through your source device.

**Play music using "Auxiliary" Jack**

- Insert the 3.5mm Aux-in cable (provided) to the line-in jack of the speaker. And, the other end of the cable connects to the audio device (such as computer / tablet / ...etc.).
- Turn on the speaker.
- Select your favorite song at the source device.
- Press and hold the On/Off button to power on the speaker.

**Charging the speaker**

- Connect the DC charging cable to the DC charging port of the speaker. And, the other end of the cable connects to the power source (such as computer / tablet / ...etc.).
- Turn on the speaker.
- Select your favorite song at the source device.
- Press and hold the On/Off button to power on the speaker.

Note: The LED light indicates the charging status. When the battery is drained out, the LED light will turn on. When the battery is fully charged, the LED light will turn off.

5

**FCC Radiation Exposure Statement:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.  
This device must not be co-located or operating in conjunction with any other antenna or transmitter.

**WARRANTY**

The manufacturer's limited warranty extends to the original consumer purchaser of the product. Neither the manufacturer nor any other company makes this sale or promotion of the product as a warranty of this manufacturer's warranty.

**WARRANTY DURATION:**

This warranty is valid for a period of 12 months from the date of purchase.

**WARRANTY COVERAGE:**

This product is warranted against defects in materials or workmanship. This warranty does not cover damage caused by accident, misuse, or unauthorized repair or alteration. This warranty does not cover the product if it has been used for any purpose other than that intended by the manufacturer.

**WARRANTY PERFORMANCE:**

The product is warranted to perform in accordance with the specifications set forth in the user manual. The manufacturer is not responsible for any damage to the product or any other equipment caused by the use of the product.

**SERVICE AND REPAIR:**

For service and repair, please contact the manufacturer's authorized service center. The manufacturer is not responsible for any damage to the product or any other equipment caused by the use of the product.

285mm

**Specifications**

- Model: 968582
- Wireless Distance: 26 to 33 feet
- Speaker: 2.0" Tweeter
- Power: 5W
- Built-in Rechargeable Battery: 500mAh
- Charging Time: 2-3 hours
- Weight: 1.2 lbs

**Care and maintenance**

- Do not expose the unit to liquid, moisture or humidity to avoid the product's internal circuit being damaged.
- Do not expose the unit to extremely high or low temperatures as this will shorten the life of the product.
- Do not expose the unit to excessive heat or cold.
- Do not use the unit in areas where it may be exposed to excessive heat, humidity, vapors, etc.
- Do not attempt to disassemble the unit as it may get damaged if you are not professional.
- Do not use the unit in areas where it may be exposed to excessive heat, humidity, vapors, etc.

**FCC Instructions**

This product has been tested and found to comply with the limits for a Class B digital device. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

**NOTE:**

This product has been tested and found to comply with the limits for a Class B digital device. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product. This product is warranted against defects in materials or workmanship. This warranty does not cover damage caused by accident, misuse, or unauthorized repair or alteration. This warranty does not cover the product if it has been used for any purpose other than that intended by the manufacturer.

6

**United Warranty**

The manufacturer's limited warranty extends to the original consumer purchaser of the product. Neither the manufacturer nor any other company makes this sale or promotion of the product as a warranty of this manufacturer's warranty.

**WARRANTY DURATION:**

This warranty is valid for a period of 12 months from the date of purchase.

**WARRANTY COVERAGE:**

This product is warranted against defects in materials or workmanship. This warranty does not cover damage caused by accident, misuse, or unauthorized repair or alteration. This warranty does not cover the product if it has been used for any purpose other than that intended by the manufacturer.

**WARRANTY PERFORMANCE:**

The product is warranted to perform in accordance with the specifications set forth in the user manual. The manufacturer is not responsible for any damage to the product or any other equipment caused by the use of the product.

**SERVICE AND REPAIR:**

For service and repair, please contact the manufacturer's authorized service center. The manufacturer is not responsible for any damage to the product or any other equipment caused by the use of the product.

420mm

7