Model: ES-52045BT

Turn the speaker to Bluetooth pairing mode -

- * Switch on the main power to the "ON" position from the speaker underside.
- Wait 2-3 second until the light on the front starts blinking red and blue.
 This indicates that it is in pairing mode.

Note: Bluetooth speaker will stay in pairing mode for 1 minute. If you are not fast enough to complete the next step, simply turn "OFF" the speaker and then back to "ON" position, and repeat step 2.

Pairing your device with Bluetooth Speaker -

Your Bluetooth Boom Speaker can wirelessly stream audio from any Bluetooth enabled device within 10m (33 Feet). Simply follow the below steps.

- * Turn ON LED lights while flash Blue and Red lights.
- * Turn on the Bluetooth on your Mobile Phone or Tablet or Computer.
- * It will search for various devices.
- The name of our Bluetooth Speaker is "2Boom", pair it with this device.
- * Once paired, the LED light will turn to BLUE Color.

Taking calls on connected to Bluetooth speaker -

- When you receive an incoming call, an alert will sound from the speaker.
- If you are listening to music from your phone, the music will automatically pause.
- * To accept a call: You can accept a call as you usually do, using your phone to control or press the "Play/ Pause" button at the top of speaker. Speak normally, your call will come through the speaker and your voice picked up through the built-in microphone of the speaker.
- To end a call: Use your phone to control or press the "Play/ Pause" button at the top of the speaker.

Controlling playback when connected via Bluetooth -

- * Volume Increase: Using the volume controls on the front of speaker, Long press and hold the "Increase Volume/ Skip-Forward" button to increase volume.
- * Volume Decrease: Using the volume controls on the front of speaker, Long press and hold the "Increase Volume/ Skip-Forward" button to decrease volume.

Getting Started

Remove product from the packaging.

Retain packaging for storage purposes or future reference or dispose of safely.

In the Box

- * Rechargeable Bluetooth Boom Speaker
- * USB cable (For Charging Purpose)
- * 3.5mm audio connection cable
- Instruction manual
- Warranty card

Features

- Compatible with Bluetooth devices & connects via 3.5mm audio jack.
- * Use in a variety of electronic devices, indoors or outdoors.
- * Use as Hands-Free speaker phone device, with a built-in microphone.
- * Deep rich sound in a portable compact size that goes anywhere.
- * USB rechargeable built-in battery.

Instructions for Use

Charging the internal battery -

Fully charge the unit before use.

Connect the USB cord to the port on the back of the speaker and insert the other end into a port on your computer or other suitable USB outlet. The LED on the side will show that the battery is charging. It will take 3-4 hours to fully charge the Battery.

LED indicator -

There is an LED light located in the middle of the front speaker.

- * LED off Power off
- * Flashing BLUE Power ON
- * Flashing BLUE/RED Pairing mode
- RED Low Battery Level
- BLUE Battery almost drained
- * RED Battery is recharging
- * Skip Forward Track: Press one time on the "Increase Volume/ Skip-Forward" button.
- * Skip Backward Track: Press one time on the "Increase Volume/ Skip-Forward" button.
- Pause: Press the "Play/ Pause" button one time to pause the music. Press again one time to resume the music.
- Answer Call: Press "Play/ Pause" button one time to answer the call when you get the incoming call.
- * End Call: Press "Play/ Pause" button one time to end the call once you desire to end the call. If you were listening to music prior to receiving the call, then the music would resume once you end the call.

Do's and Don'ts

Do not play music at excessive levels as damage to hearing and/ or equipment may result.

Do not use outdoors in wet or in damp surroundings.

Specification

Speaker: 3W x 1 Size: 90mmH, 70mmD Power input: 5V, 500mA Bluetooth Range: 10m (33 feet)



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are desi gned to provide reasonable protection against harmful interference in a reside ntial installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following mea sures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to whi ch the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.