



BEP-12/5575

BLUETOOTH EARPHONE



INSTRUCTION MANUAL
PLEASE READ ALL INSTRUCTIONS
CAREFULLY AND RETAIN FOR FUTURE USE

85MM

Getting Started

- Remove the Bluetooth Earphone from the box.
- Remove any packaging from the product.
- Please retain all packaging until you have checked and counted all the parts and the contents against the parts list.

Package Contents

- Bluetooth Earphone
- USB Rechargeable Cable
- Instruction Manual
- Spare Ear Buds – 2 pairs (Diameter : 10 mm and 14 mm)

Key Features


- Compatible with all Bluetooth enabled devices such as Mobile Phones, Tablets, Computers
- Built-In Microphone
- Built-In Rechargeable Battery
- Wireless Range – 8 ~10 Meters (26 ~ 33 Feet)

Safety Instructions

Keep the unit away from heat sources, direct sunlight, humidity, water and any other liquids. Do not operate the unit if it has been exposed to water, moisture or any other liquids to prevent against electric shock, explosion and/or injury to yourself and damage to the unit. Do not use the unit if it has been dropped or damaged in any way. Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk. Do not use the unit with wet hands. Do not put objects into any of the openings. Keep the unit free from dust, lint etc. Do not use this unit for anything other than its intended use. Keep the unit out of reach of children. This appliance is not a toy. Do not use the earphones at excessive levels as damage to hearing may occur. Batteries (battery pack or batteries installed) shall not be exposed to excessive heat place, such as sunshine, fire or the like.

Description of Parts

1. Power On/Off Button/Receive call/End a call Multi-Function Button (MFB)
2. Volume Up / Skip Forward Button
3. Volume Down / Skip Backward Button
4. Microphone

**INSTRUCTIONS FOR USE****Charging the Internal Battery**

The earphones come with a built in rechargeable battery. Before using it for the first time we recommend you charge the battery fully. Only use the supplied USB Cable to charge the earphones. Connect the USB cable to a computer USB port and the USB plug to the charging jack of the earphones. The red LED illuminates while the earphones are charging. A full charge of the battery takes around 3 hours. When the battery is fully charged the LED will turn blue. When the battery is low, the LED will flash red and emit three tones every 20 seconds. When this occurs, please recharge the earphones.

Turning on/off the headphones

Power on: Press and hold the Power ON/OFF button for 3~4 seconds, the red and blue lights flashes together, then the LED flash blue.

Power off: Press and hold the Power ON/OFF button for 3~4 seconds, the red and blue lights flashes together, then stop flashing.

In order to save power, the earphones will automatically turn off if no devices are paired after 5 minutes.

Pairing the earphones with Bluetooth devices (phone or music device)

Ensure the earphones are turned off, otherwise turn it off first and then press and hold the Power ON/OFF button for 5~7 seconds until the LED flashes red and blue alternatively. The device will enter pairing mode.

Place the earphones and Bluetooth device (phone or music device) so that they are no further than 1 meter apart;

Activate the Bluetooth function on your Bluetooth device (phone or music device). Please refer to the manufacturer's instructions for instructions on enabling Bluetooth on your device.

Once you have activated Bluetooth on your device, select the earphones "SL EARPHONE" from the list of available Bluetooth devices.

If required, enter the password '0000' to confirm to finalize pairing.

Once paired successfully, the LED will not flash red and blue alternatively. It will continue to do this while paired.

You can now start to use the earphones.

If pairing is unsuccessful, turn off the headphones first and then re-pair following the above steps. Once you have paired the earphones with a device, the earphones will remember this device and will pair automatically when the device's Bluetooth is activated and in range. You do not need to re-pair any previously connected devices.

The earphones will attempt to automatically connect to the last device it was paired with when switched on. If you want to pair it with a new device please follow the steps outlined above. Once the earphones are paired with your device the music will transmit directly to the earphones. Please refer to your device's user manual for further information.

2

120MM

Function Summary**Listening to Music**

Once the earphones are paired to your device you can stream music wirelessly to the earphones. Select the track you wish to listen to and it will be streamed to your earphones. Should you encounter any problems while streaming please refer your device's user manual for further information.

Manual Key Functions

Function	Operation	Button
Increase Volume	Playing music	A short press on the + button once will increase the volume
Decrease Volume	Playing music	A short press on the - button once will decrease the volume
Play	Pausing	A short press on the MFB button will restart the music
Previous track	Playing music	A long press on the - button will return you to the previous track
Next track	Playing music	A long press on the + button will take you to the next track

Care and maintenance

Read the following recommendations before using the headset. Following these you will be able to enjoy the product for many years.

- Do not expose the earphones to liquid, moisture or humidity to avoid the product's internal circuit being affected.
- Don't use abrasive cleaning solvents to clean the earphones.
- Do not expose the earphones to extremely high or low temperature as this will shorten the life of electronic devices, destroy the battery or distort certain plastic parts.
- Don't dispose of the earphones in a fire as it will result in an explosion.
- Don't expose the earphones to contact with sharp objects as this will cause scratches and damage.
- Don't let the earphones fall down onto the floor. The internal circuit might get damaged.
- Don't attempt to disassemble the headset as it may get damaged if you are not professional.

In case the earphones doesn't function properly, send it to the store you bought it. The staff will help you to the problem.

3

Specifications

Bluetooth specification	Bluetooth V2.1+EDR
Bluetooth profiles	HSP, HFP, A2DP and AVRCP
Operating distance	8 ~ 10 meters
Working time	Music: about 4 hours (VOL 60%) Talk: about 3 hours
Standby time	50 hours
Charging input voltage	DC5V---140mA
Charging time	About 3 hours
Dimensions	15.5 x 25 x 700 mm
Weight	10g

FCC Statements

The device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

NOTE: This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the product and receiver.
- Connect the product into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without RF restriction.

4

Limited Warranty

This manufacturer's product warranty extends to the original consumer purchaser of the product. Neither the retailer nor any other company involved in the sale or promotion of this product is a co-warrantor of this manufacturer warranty.

WARRANTY DURATION: All materials and workmanship are warranted to the original consumer purchaser for a period of thirty (30) days from the original purchase date.

WARRANTY COVERAGE: This product is warranted against defective materials or workmanship. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty doesn't cover the following which may be supplied with this product, including but not limited to: LCD Screens, glass parts, lenses, etc. This warranty is effective only if the product is purchased and operated in USA, and does not extend to any units which have been used in violation of written instructions furnished by manufacturer or to units which have been altered or modified or, to damaged products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

WARRANTY DISCLAIMERS: This warranty is in lieu of all warranties expressed or implied and no representative or person is authorized to assume for manufacturer any other liability in connection with the sale of our products. There shall be no claims for defects or failure under any theory of tort, contractor commercial law including but not limited to, negligence, gross negligence, strict liability, breach of warranty and breach of contract.

WARRANTY PERFORMANCE: During the above 30 day warranty period, a product with a defect will be either repaired or replaced with a reconditioned comparable model (at manufacturer's option). The repaired or replacement product will be in warranty for the balance of the 30 day warranty period and an additional one-month period. No charge will be applicable for such repair or replacement.

SERVICE AND REPAIR: If service is required for this product, you should first contact Midwest Trading Group Customer Service at info@midwesttradinggroup.com or by calling 1 (866) 815-4714, Monday to Friday 9am to 5pm CST.

NOTE: Manufacturer cannot assume responsibility for loss or damage during incoming shipment. As a precautionary measure, carefully package the product for shipment, and insure it with the carrier. Be sure to enclose the following details with the product: your full name, return address and daytime phone number, a note describing the problem you experienced, a copy of your sales receipt or other proof of purchase to determine warranty status. C.O.D. shipments cannot be accepted.

5