


BLUECUBE - AQ-BC-6BT WATERPROOF MEDIA PLAYER

for Bluetooth MP3 devices

OWNER'S MANUAL







PLEASE READ THIS INSTRUCTION MANUAL BEFORE INSTLAATION AND OPERATION

1	Getting Started					
	1.1	Contents	3			
	1.2	Connections				
	1.3	12-pin Harness Connection				
	1.4	Mounting the BlueCube Media Player.				
	1.5	Power On				
	1.6	Handheld Remote Control Charging	5			
	1.7	Handheld Remote Control Synchronizing				
2	Location of Controls 6					
	2.1		6			
	2.2	Wired Remote Control	6			
3.	Listening to Devices					
	3.1					
		3.1.1 Pairing with Bluetooth Device				
		3.1.2 Listening via Bluetooth Device.				
	3.2	Listening via Auxillary Input				
	3.3	Adjusting Volume Level				
	3.4	Using VBass				
	3.5	External Trigger				
	4.1	Using Audio Menu on Handheld Remote Control				
5.	Specifications and Dimensions					
	4.1	Specifications	8			
	4.2	Dimensions	8			
6.	Warr	anty Information	9			
7	FCC	FCC Statements				

1.1 Contents

- AQ-BC-6BT BlueCube Media Player
- Wiring Harness (AQ-UNH-2)
- Four (4) Staineless Steel Mounting Screws
- Owner's Manual

1.2 Connections

1: 12-pin Watertight Harness

The 12-pin harness supplies power and ground connection to the BlueCube Media Player and four (4) speaker channel output connections from the BlueCube Media Player.

2: Auxiliary Outputs

Allows external amplifiers to be connected to power additional speakers.

3: Auxiliary Inputs

Connect to a portable audio player through the AUX IN cable on the back of the BlueCube Media Player.

4: 8-pin DIN Cable for remotes

Connect to optional wireless or wired Remote Control (sold separately). There are totally 2 DIN cable for remotes.

5: EXT Trigger


Provide 12Vdc when EXT trigger is pressed on remote control (sold separately). There are two EXT triggers.

6: Power On LED

When the BlueCube is powered On, the LED will lit.

7: Bluetooth Antenna Connection


Connect to the Male SMA connector of the Bluetooth antenna. Do not excess torque on the SMA connector (no more than 0.5N-m). Use hands to tighten the connection. (No wrench is used)



1.3 12-pin Harness Connection


The AQ-BC-6BT includes the universal harness AQ-UHN-2 in order to connect the BlueCube to power and speakers.

All open wire connections should be soldered and protected against water and dust for best long term performance.



1.4 Mounting the BlueCube Media Player

- Make sure the outside surface is clean and clear of debris
- The BlueCube Media Player has four (4) front screws. Drive the screws using a screw driver.
 Make sure screws are snug and do not over tighten.



1.5 Power On

The AQ-BC-6BT requires +12V dc to both the red and yellow wires. When both of these wires have power, the AQ-BC-6BT is always powered on and is indicated by a red LED coming out of the heatsink of the stereo. Ground is connected to the Black wire.

In a SPA application, this requires the red and yellow wires to be jumped together and tehn connected to +12V dc output of the power source. In this set up, the AQ-BC-6BT will always be on, with a very low current draw when idle.

In a bot, ATV or other application requiring power from a battery, the yellow wire (constant power) should be connected to the battery, and the red wire connected to the ignition or a switch.

For detailed instructions, you can check out our online video:

"How to wire your Aquatic AV stereo system" http://www.aquaticav.com/support/videos

1.6 Handheld Remote Control Charging (AQ-DM-6UBT-T sold separately)

The remote has a built-in Polymer Lithium rechargeable battery. It comes with a custom made charging cable. Connect one end to the blades of the remote control and another the other end to any USB female device (5V dc) for charging.

Make sure the remote has been charged before used.

1.7 Handheld Remote Control Synchronizing (AQ-DM-6UBT-T sold separately)

The remote has a receiver dongle (AQ-DM-6UBT-R) with a builtin male DIN connector. Connect the dongle to the female DIN connector of BlueCube Media Player (AQ-BC-6BT).

The remote should already be paired from the factory, but if you need to synchronize the remote, follow below steps.

- 1. Make sure BlueCube Media Player (AQ-BC-6BT) is powered ON (red LED lit)
- 2. Put the remote close to the dongle (AQ-DM-6UBT-R) (within 0.5 meter)
- 2. Press and hold MODE until the LCD shows "Pairing in Progress". Release the button.
- 3. Within 2 seconds, the LCD will show "Paired". If it fails to pair, the LCD will show "Retry again". If this happens, wait 5 seconds and repeat the above procedures.

For any additional remote controls, you will also need to synchroize those remote controls to the BlueCube Media Player (AQ-BC-6BT).

- If the pairing process is not successful, try again to put your remote close to the dongle.
- Depending on the frequency of usage, the remote might drain its battery. Please charge the remote before use. If the LCD shows nothing, it means that the battery has been drained.
- If you have lost your remote control and buy a new remote control, please follow the above steps to pair the remote control

2.1 Wireless Handheld Remote Control AQ-RF6UBT-T (sold separately)



Button	s	AUX IN Mode	Bluetooth Mode	
Power		Press once: Toggle Operational mode to Standby mode or vice versa		
Mode/Pair	MODE	Press once: Change the source Press and hold: Pair		
Volume Up	+	Press once: Volume up Press and hold: Fast volume up		
Volume Down	_	Press once: Volume down Press and hold: Fast volume down		
Fast Forward	≫ I	Press once: no function Press and hold: no function	Press once: Next track Press and hold: Fast Forward	
Fast Rewind	I∢	Press once: no function Press and hold: no function	Press once: Previous track Press and hold: Fast backward	
Play/ Pause	►II	Press once: Toggle mute Press and hold: no function	Press once: Play/Pause Press and hold: no function	
1	1	Press once: Pop Preset Equalizer Press and hold: no function		
2	Press once: Classic Preset Equalizer Press and hold: no function		er	
3	Press once: Rock Preset Equalizer Press and hold: no function			
EXT Trigger	Press once: Toggle EXT trigger 1 (12V dc) Press and hold: Toggle EXT trigger 2 (12V dc)			
Audio	AUDIO Press once: no function Press and hold: no function			
VBass	Press once: Toggle VBass ON or OFF Press and hold: no function			

2.2 Wired Remote Control AQ-WR6 (sold separately)

Coming Soon!

3.1 Listening via Bluetooth

3.1.1 Pair with Bluetooth Device

- 1. Switch on your Bluetooth device.
- 2. Select 'AQUATIC AV' from the list of available devices to pair (no password is needed).

3.1.2 Listening via Bluetooth Device

- 1. Bluetooth mode will be activated once a Bluetooth device is paired.
- 2. Play the song from device and the sound will play through the Bluecube Media Player.
- 3. Press ▶ II to play/pause the song.
- 5. Track and volume can be controlled directly from your Bluetooth device or remote control.

3.1.3 Multi-link Feature

A second Bluetooth device an always pair to the BlueCube Media Player even when it has been paired to another Bluetoot device.

3.2 Listening via Auxiliary Input

- 1. Connect your MP3 device of the RCA inputs
- 2. Press **MODE** on the remote control to select 'AUX IN' mode. IMPORTANT: Only one Auxiliary input (RCA) can be used at any one time.

3.3 Adjust Volume Level

- 1. Press + once to increase the volume.
- 2. Press once to reduce the volume.
- 3. Press and hold either +/- to increase or decrease audio volume continuously.

3.4 Using VBass

- 1. VBass is a features to boost up the bass of the audio using latest DSP technology.
- 2. Press Veass once to toggle it ON or OFF.

3.5 External Trigger


Press EXT on the remote to toggle the External Trigger ON/OFF. When Ext Trigger is turned on, there will be +12V dc from EXT wire. This can be used for turning ON/OFF other devices.

4. Using Audio Menu on Handheld Remote Control (purchased separately)

BlueCube+ Media Player (AQ-BC-6UBT) has equiped with a audio DSP to meet different listening experiences.

- 1. To enter audio menu, press once **AUDIO** button.
- 2. Each press of **AUDIO** button will advance to the next audio setting as described on the right.
- 3. In the audio menu, press and hold will save and exit the audio menu to the original mode.

If you have chosen preset equalizer (Rock, Classic, or Pop), the previously set Bass, Treble will be overrided.



5.1 Specifications

Media Bluetooth/MP3

Supported media via Bluetooth / MP3 device

(sold separately)

Inputs

Outputs

Pre-Out 1x stereo pair RCA (4V rms)

Power

 Output voltage @2 Ohm.
 4x 72W

 Output voltage @4 Ohm.
 4x 45W

 Operation voltage.
 9.6V - 14.4V

 Max current draw.
 7A


 Standby current draw.
 6mA

Multi-Environment Certifications

Waterproof / Dustproof Yes IP64
Conformal PCB coating Yes

UV Protection 500 hours stable. ASTM D4329 compliant Salt/Frog protection 500 hours stable. ASTM B117 compliant

Stainless steel mountings Yes



Aquatic AV offers a limited warranty of our products on the following terms:

Length of Warranty

2 years on audio systems, electronics, speakers, and accessories (receipt required).

Coverage

This warranty covers only the original purchaser of a Aquatic AV product purchased from an authorized Aquatic AV dealer in the United States. In order to receive service, the purchaser must provide Aquatic AV with a copy of the receipt stating the customer name, dealer name, product pruchased and date of purchase.

Defective products

Products found to be defective during the warranty period will be repaired or replaced (with a product deemed to be equivalent) at Aquatic AV's discretion.

What is not covered

Damage caused by accident, abuse, improper operation, theft. Any cost or expernse related to the removal or reinstallation of the product. Service performed by another other than an authorized Aquatic AV service center. Any product with the serial number or tamper labels defaced, altered or removed. Subsequent damage to other components. Any product not purchased from an authorized Aquatic AV dealer.

Limit on implied warranties

Any implied warranties including warranties of fitness for use and merchantability are limited in duration to the period of the express warranty set forth above. Some states do not allow limitation on the length of an implied warranty, so this limitation may not apply. No person is authorized to assume for Aquatic AV any other liability in connection with the sale of the product.

How to obtain service

You must obtain a return material authorization number (RMA) to return any product to Aquatic AV. You are responsible for shipping charges of returned products to Aquatic AV.

Please record the model and serial number[s] of your equipment in the spaced provided below as your permanent record and will assist us with your factory warranty coverage. These numbers can be found on the rear of the BlueCube Media Player.

Serial number[s]:

FCC ID:WBQAQRFDM6B MADE IN CHINA

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Consult the dealer or an experienced radio/TV technician for help.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.

Aquatic AV 282 Kinney Drive San Jose, CA65112, USA

E-mail: info@aquaticav.com US & Canada: 1 877 579 2782 International: +1 408 559 1668 Fax: +1 408 559 0125

www.aquaticav.com



products with watertight reputation