User's Guide



H7062 Bluetooth Headset

BEFORE USING YOUR HEADSET

Please read this user's guide to get started, and to make the best use of the headsets many features.

Product Specification

Bluetooth Specification: Bluetooth Version 2.1+EDR

Power Level: Class II.

Support Profile: Hands-Free, Headset (Headset role only).

Standby Time: 100 hours. Talk Time: Up to 4 hours

Operating Range: Up to 10 meters (30 feet).

*Above mentioned standby time and talk time will be different depending on mobile phone setting and usage environment. The figures above show the average values tested by laboratory.


Your headset overview

The headset contains the following parts:

- 1. Charging Socket
- 2.Speaker
- 3.Ear Hook
- 4. Multi-function Button
- 5.Indicator Light
- 6.Microphone

Package Includes:

- A. Bluetooth Headset
- B. AC charger
- C. USB Charging Cable
- D. User manual




Charging the headset

Your headset uses a rechargeable battery.

You must charge the battery fully before using the headset for the first time.

- 1. Plug the charger into charging socket.
- 2. Plug the charger into the electrical outlet, the red light will illuminate.
- 3. Fully charge the headset until the red light turns off. (approximately 1 hours)





IMPORTANT

- If you hear the low battery warning sound (beep every 5 seconds) and the red indicator light is flashing every 5 seconds, this means the battery needs to be charged.
- 2. If you turn the headset on and the ending melody is immediately played, that also means the battery needs to be charged.
- 3. The headset is not functional while charging.

Storage of the headset

- Always store the headset with the power off and make sure it is safely protected.
- Avoid storage at high temperatures (above 40 C/104F), such as in a hot vehicle or in direct sunlight. (Storage at high temperatures can damage performance and reduce battery life).
- Do not expose the headset or any of its supplied parts to rain or other liquids.

BASIC OPERATIONS

Turning headset On/Off

- To turn the headset on, press and hold the Multi-Function button for 4 seconds.
 The blue indicator light will illuminate for 3 seconds and you will hear a long beep tone. The blue light will then flash every 5 seconds.
- To turn the headset off, press and hold the Multi-Function button for 4 seconds or until you hear a short beep tone. The indicator light will flash red. Release the button, an ending melody will be played indicating the headset has powered off.

Pairing with your Bluetooth phone

Pairing will create an encrypted wireless link between your bluetooth phone and bluetooth headset.

- Ensure that your phone's Bluetooth function is actived (see your phone's guide for details).
- 2. Ensure that the headset is off (see Turning the headset on/off).
- 3. Press and hold the Multi-Function button for about 6-8 seconds until the indicator light alternately flashes blue and red.
- 4. Set your Bluetooth phone to discover the headset by following your phone's guide. Typically, the steps involve going to set up, connect, or Bluetooth menu on your phone and the selecting the option to discover Bluetooth devices.
- 5. Your phone will find the headset and ask if you want it to pair, select the pairing name "H706". confirm this by pressing the "Yes" or "OK".
- 6. Enter passkey or PIN, 0000 (4 zeros), then press the "Yes" or "OK".
- Follow instructions on your phone to complete pairing. (You can also press the Multi-Function button once to complete this step).

If the above steps are not successful, please delete the pairing data (see Deleting the pairing data) and repeat steps 1-7.

5

To confirm your phone and headset are operating properly, make a test call:

- 1. Place the headset over your ear.
- 2. On your phone, dial the number you want to call and press the "send" key.
 - 3. If paired successfully, you will hear the ring tone on the headset.


After headset is successfully paired, you should not need to repeat these initial setup steps each time you use the headset, unless pairing data is deleted on your phone.

Wearing the headset

The headset is provided with an ear hook that you can use for a better fit on your ear.

To use the headset without the ear hook, plug the headset into you ear and point the headset toward your mouth.

- To use the headset with the ear hook, insert the ear hook into the small opening at the back of the headset.
- The headset can be worn on either the left or right ear by change the direction of the ear hook



Making a call

Making a voice activated call

If the voice recognition feature is on, you can make a voice activated call.

- 1. Press the Multi- Function button once, you will hear the voice-activation tone.
- 2. Say the name of the person you wish to call.

Depending on your phone, this feature may not be supported.

Re-dialing the last number

To make a call to the last number you have dialed:

In the stand-by mode, by double press Multi-Function button, the last number you diald will be re-dialed.

Answering a call

After you hear the ring tone, press the Multi-Function button once.

Ending a call

Press the Multi-Function button once.

7

Rejecting a call

When you hear the ring tone, press and hold Multi-function button until you hear a short beep. The call will be rejected.

Adjusting the volume

There is no Volume Button has been provide for the headset, you should adjust the volume via your mobile.

Deleting all pairing data

When the headset is on and disconnected from your phone, the pairing information can be deleted by pressing and holding the Multi-Function button about 7 seconds until a long beep tone is heard.



To prevent possible harm to the environment, please separate this device from other types of waste and recycle it responsibly to promote the sustainable reuse of material resources.

FCC & IC Statement

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Note: The manufacturer is not responsible for ANY interference, for example RADIO or TV interference, caused by unauthorized modifications to this equipment.

Such modifications could void the user's authority to operate the equipment.

EU

This product is CE certified according to the provision of the R&TTE Directive (99/5/EC). Declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Please note that this product uses radio frequency bands not harmonized within EU. Within the EU this product is intended to be used in Austria, Belgium, Denmark,

Finland, France, Germany, Greece, Ireland, Italy, Luxembourg,

The Netherlands, Portugal, Spain, Sweden, United Kingdom and within EFTA in Iceland, Norway and Switzerland.

Bluetooth is a trademark owned by the Bluetooth SIG, Inc.

Warranty

The condition of this warranty and our responsibilities under this warranty are as follows: Warranty is non-transferable, and is limited to the original purchaser only.

- * You must be able to prove the date of original purchase of the unit with a dated receipt.
- * The warranty is not applicable if the product has been subject to physical abuse, improper installation, modification or repair by unauthorized third party.
- * The responsibility of suppliers products shall be limited to the repair or replacement of the product at its'sole discretion.
- * Specifically exempt from any warranty are limited-life consumable components subject to normal wear and tear, such as, batteries and other accessories.
- * Supplier will not take any responsibility if the failure of the unit has resulted from accident, abuse, misuse, or any unauthorized repair, modification or disassemble.
- * Modification and repair of the unit this device must be done by an authorized and qualified service center or returned to the manufacturer.
- *This warranty gives you specific legal rights, and you may also have other rights which vary under local laws.

