

1. About your TOSCAZERO

- a. Multi-Function Button (MFB)
- b. Power On / Off
- c. Pair with mobile phone
- d. Answer / End a call
- e. Volume Down Button
- f. Volume Up Button
- g. Status Indicator
- h. Charging Contacts
- i. Built-in microphone
- j. Stabilizer
- k. Earbud
- l. Micro USB Charging Socket
- m. Charging Cradle Status Indicator

2. Charging Your Headset

The Headsets and Charging Cradle come with built-in rechargeable batteries. Prior to using the headsets and Charging Cradle for the first time, it is recommended to fully charge the batteries.

Charge the Headsets

- Put both Right and Left headsets into the supplied Charging Cradle.
- Fully charging the headsets takes around 2 hours. The red indicator will turn on during charging.
- When the batteries are fully charged, the red indicator lights will turn off. The headsets are ready to use.

Charge the Charging Cradle

- Connect the USB cable to the micro USB port of the Charging Cradle.
- Fully charging the Charging Cradle takes around 2 hours. The red indicator will turn on during charging.

When the Charging Cradle is fully charged, the red indicator light will turn off. Disconnect the cable from the Cradle.

NOTE:

- The fully charged headsets bring up to 2 hours of music playing time, and 40 hours of standby time. The Charging Cradle can provide 4 times extra recharges for the headsets.
- Use only the supplied charger / USB charging cable to charge the Charging Cradle.

Headset Status	Status Indicator Light
Low battery	Flash red 3 times every minute with voice prompt "Battery Low"
Charging	Solid red
Fully charged	Off

3. Pairing Your Headset with a Bluetooth Device

1) Ensure both headsets are off.

2) To activate the pairing mode, press and hold the MFBs of both Right and Left headsets for 8 seconds without releasing your fingers until their status indicators flash blue and red alternately.

3) Right and Left headsets will pair each other in around 10 seconds.

4) Once the headset pairing is successful, the headsets will be ready to pair with phone.

5) Activate your mobile phone's Bluetooth, search Bluetooth devices, select "TOSCAZERO" and enter the passcode "0000". When the pairing is completed, the headsets' status indicators will flash blue every 5 seconds.

Note:
If the Right and Left headset pairing is not completed within 2 minutes, the headset will turn to standby mode. If this happens, please turn off the headsets and repeat the pairing steps.

4. Basic Operation

Function	Button	Alert Tone / Voice Prompt	Status Indicator
Power on	Press & hold the MFB for 6 seconds	Power on	Blue light for 1 second
When you turn on your headset for the first time, the headset proceeds into pairing mode, i.e. the status indicator flashes blue and red alternately, you can immediately pair it with your mobile phone.			
Power off	Press & hold the MFB for 4 seconds	Power off	Red light for 1 second
Answer / End a call	Press the MFB once	--	--

Function	Button	Alert Tone / Voice Prompt	Status Indicator
Volume up	Short press Volume Up button	--	--
Volume down	Short press Volume Down button	--	--
Music track forward	Long press Volume Up button for 2 seconds	--	--
Music track backward	Long press Volume Down button for 2 seconds	--	--

Safety Information

- Check and observe local laws regarding the use of a mobile phone and a headset while driving. If you use the headset while driving, ensure your full attention and focus. It is your responsibility to drive safely. Consider to pull off the road before making or answering a call.
- Never leave your headset above any air bag deployment area inside your car as serious injury may result when an air bag deploys.
- Never allow children to play with the headset – Small parts may be of choking hazard.
- Observe all signs and displays that require an electrical device or RF radio product to be switched off in designated areas. These could include hospitals, blasting areas, and potentially explosive atmospheres.
- Turn off your headset prior to boarding an aircraft. Do not use your headset inside an aircraft.

- To prevent damage to your hearing, please do not set the listening volume too high.
- Do not attempt to modify the headset.
- Do not keep the headset near a wash basin or other wet places.
- Do not use the headset outdoors in the rain.
- Do not use the headset in stormy weather.
- Do not clean the headset while it is being charged.
- Always disconnect the charger from the headset before cleaning.
- Do not attempt to force open the built-in battery.
- Only charge the headset's built-in battery in accordance with the instructions described in this user guide.

Care and Maintenance

Headset

- Turn off your headset before placing it in your pocket or bag. If the MFB is accidentally depressed, your mobile phone may place an unintended call.
- Do not keep to submerge your headset in liquid or try to wash in any circumstance not more than 5 minutes.
- Do not use abrasive cleaners to clean the headset.
- Do not expose the headset to extremely high or low temperatures.
- Do not leave the headset in direct sunlight for an extended period of time.
- Do not leave the headset near open flames such as cooking burners.
- Do not dispose of the headset in a fire, as it will result in explosion.
- Do not bring the headset into contact with any sharp objects, as this will cause scratches and damages.

Built-in Battery

- Do not stick anything inside the headset, as this may damage internal components.
- Do not attempt to disassemble the headset as it does not contain serviceable components.
- If you do not plan to use the headset for a long period, please store it in a dry place that is free from extreme temperatures and dust.
- Avoid charging the headset in extremely high or low temperatures.
- Dispose of the battery and the headset according to local regulations. Do not dispose of them as household waste.

Built-in Battery

- Do not attempt to replace the headset's battery as it is in-built and is not changeable.
- Dispose of the battery according to local regulations. Do not dispose of the battery as household waste.
- Charge the battery in accordance with the instructions supplied with this user guide.

Charger

- Use only the USB cable supplied by the headset's original manufacturer to charge the headset. Other USB cable may look similar but using them could be dangerous and could damage the headset.
- Do not attempt to disassemble the charger as it may expose you to dangerous voltages or other risks. Incorrect reassembly can cause electric shock when the headset is subsequently used.
- Do not use the charger outdoors or in damp areas.

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled Environment.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help
- This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.