


WATER DANCING SPEAKERS



Power Supply Set Up


1. Connect the Left Speaker Connector Cable (B) to the Right Speaker Input Jack (F).
2. Plug USB Power Cable (H) into Left Speaker USB Power Input Jack (D).
3. Connect to your computer or USB power supply with the USB Cable (H). Slide Power Switch (E) to "ON" position.

Connect with Blue Tooth

1. Set up power supply. Activate the Blue Tooth function in your Blue Tooth device.
2. Select "19T" on your Blue Tooth device for pairing.
3. Start music play on your Blue Tooth device. Adjust the volume to activate an amazing sound and light show!

Connect with Stereo Plug

1. Set up power supply. Plug 3.5 mm Mini Plug Cable (G) into Audio Jack (C) on Left Speaker. Reduce volume to minimum and connect the 3.5 mm Mini Plug Cable to your music player.
2. Adjust the volume to activate an amazing sound & light show!



Troubleshooting

No Sound/ No Response

- Adjust volume on your music source
- Make sure that your Blue Tooth device is within range.
- Check if you have selected the correct audio source.
- Restart the speakers by turning off the Power Switch.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.