



SoundSOUL®




**WIRELESS
Water
SPEAKERS**

User Manual

www.soundsoulaudio.com



SoundSOUL®




With SoundSOUL AWD-22TBT Wireless Water Speakers, you can enjoy audio from the compatible Bluetooth device or your PC/Mac.

PLAY FROM A BLUETOOTH DEVICE

- Step 1: Connect two speakers
- Step 2: Activate the Bluetooth function in your Bluetooth device
- Step 3: Select "water speaker" on your Bluetooth device for pairing. (For some devices, you may need to input "0000" as pairing password.)
- Step 4: Start music play on your Bluetooth device.

Note: The effective operation range between the speaker and your Bluetooth device is approximately 10 meters (30 feet).



PLAY FROM AN EXTERNAL DEVICE

- Step 1: Connect your speaker with an external device via the supplied audio cable.
- Step 2: Start music play and adjust the volumes and tracks on your device.

POWER SUPPLY

The speaker can only operate on plug-in USB power. Please connect the USB socket with PC or adapter through supplied USB cable.

TROUBLESHOOTING

Warning

- Never remove the casing of this apparatus.

To keep the warranty valid, never try to repair the system yourself. If you encounter problems when using this apparatus, check the following points before requesting service.

No sound

- Adjust volume on your mobile phone or PC/Mac.
- Make sure that your Bluetooth mobile phone is within the effective operation range.
- Check if you have selected the correct audio source.

No response from the speaker

- Restart the speaker.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and**
- (2) this device must accept any interference received, including interference that may cause undesired operation.**