USB 10/100M FAST ETHERNET

User's Guide

M73-APO08-050

REGULATORY STATEMENTS

FCC Certification

Part15, Class B

The United States Federal Communication Commission (FCC) and the Canadian Department of Communications have established certain rules governing the use of electronic equipment.

FCC Part 15 Registration

This device complies with Part 15 of FCC rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interface, and
- 2. This device must accept any interface received, including interface that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the distance between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

INTRODUCTIONS

The USB 10/100M Fast Ethernet Adapter provides outside-the-box plug-and-play local area network connections for USB-enabled PCs, notebooks and laptops. This adapter uses a B type USB port to connect with the USB host, and an RJ-45 port to connect with a 10/100 Fast Ethernet LAN link. Installation is easy and no external power is required! The network sharing is easier than ever.

Specifications

Network standard

- IEEE 802.3 for 10BaseT
- IEEE 802.3u for 100BaseTX

Data Rate

- 10/100 Mbps¹
- Double data transfer rate in full duplex mode

Supported operating systems

Windows 98/2000/Millennium

Physical

Ports: 1 RJ-45, 1 USB A-Plug

LED indicators: Link/Act, 10/100


■ Dimensions: 75.9 x 37.8 x 21.66 (mm)

(LxWxH)

¹ CAT5 cable is required for 100M data transfer rate

Parts Names and Functions

① USB Connection Cable: connects the USB host port to the USB 10/100M Fast Ethernet Adapter.




- ② USB Fast Ethernet Adapter
- 3 10/100 LED indicator: glows amber when 100M Network is linked; when it dims, it means the 10M Network is linked.
- Link/Act LED indicator: glows green when it is linked; blinks green when the Fast Ethernet Adapter is transmitting/receiving data.
- ⑤ Network Port: connects the Fast Ethernet Adapter to the HUB with the LAN cable.

INSTALLATION

Precaution


Before the installation, make sure the USB port exists in your computer and is enabled. To check this, go to My Computer Control Panel System. Open the Device Manager tab. If the Universal Serial Bus controller device is found, it means your USB port is installed and enabled. If not, either no USB port is installed or the USB bios is not properly enabled. In this case, consult your computer dealer for USB support.




Getting Hooked Up


1. Locate the USB host port of your system. Align the USB connector toward the USB host port, push evenly and steadily until it is seated.

- 2. Connect the UTP cable to the Fast Ethernet Adapter.
- 3. Connect the other end to a Hub.
- 4. Windows 98 will automatically detect the new hardware device. Perform the following procedures for installing the device driver.







5. Insert the device driver disk into your floppy drive. When the above figure appears, click Next.




6. The installation program will proceed automatically. Follow the on-screen instruction to finish.



7. When Windows prompts you to restart your computer, click **No** to make some changes to your network settings.



8. Go to the Start menu. Point to Settings. Click Control Panel. Double-click Network.



9. When the Network dialog box appears, select USB 10/100 Fast Ethernet and click Add. Set the appropriate protocols and client for you needs. When completed, click OK.

10. Remember to restart your computer to activate the new device

Setup Diagnostics

You can perform the following steops to check if this USB 10/100M Fast Ethernet Adapter is well installed.

- 1. Go to **Desktop**.
- 2. Right-click My Computer.
- 3. Click Properties.
- 4. Open the Device Manager tab.
- 5. Click the plus sign "+".

If the 10/100 USB Network Adapter appears as illustrated below, it means your 10/100 Fast Ethernet Adapter is well installed. If otherwise or a question mark "?" is found next to it, then the 10/100 Fast Ethernet Adapter is not properly installed.

