



Liquid | Z3

(Model: Z130)

Quick guide

© 2013 All Rights Reserved

Acer Liquid Z3 Smartphone Quick Guide

Model : Z130

This revision: 8/2013

Product information

For detailed product information, please go to **www.acer.com**.

For service and support information, or to download the User Guide, drivers and applications, please follow the instructions below:

1. Go to **www.acer.com** and click **Support > DRIVER DOWNLOADS**.
2. Select appropriate items from **Select Product Family > Select Product Line > Select Product Model**.
3. Select the operating system from the pop-up list.

Acer Liquid Z3 Smartphone

Model number: _____

Serial number: _____

Date of purchase: _____

Place of purchase: _____

Android is a trademark of Google Inc. Use of this trademark is subject to Google Permissions.

Setting up for the first time


Inserting the SIM card, battery and microSD Card

Quick Guide

Insert your fingernail into the cutout between the battery cover and the phone. Unclip the cover and lift off the battery cover.


Insert the SIM and microSD Card as shown.

1



2

microSD Card




Note: Specifications vary depending on region and configuration.

Note: Ensure that the microSD Card is inserted all the way into the card slot.

Place the battery into the battery compartment, lining up the battery connectors with those at the bottom of the compartment.

Align the tabs on the bottom into the slots on the phone. Gently press the cover until it snaps in place.

3



4




Charging your phone

Prior to initial use, you will need to charge your smartphone for eight hours. After that you can recharge the battery as needed.

Connect the AC adapter cord to the micro USB connector on your smartphone. Plug the AC adapter into any AC outlet and charge the device.

It is normal for the phone to heat up when charging or during long periods of use.

All phones are factory tested before they are released.



Download and install the latest USB driver on your computer before connecting your smartphone to the computer. Visit www.acer.com/worldwide/support/download.htm for the latest driver.

Resetting the phone

Open **Settings** from the Applications menu, then tap **Backup & reset**. Tap **Factory data reset** and then tap **Reset phone**. Tap **Erase everything** to format your phone.

Safety

Replacing the battery

Your smartphone uses a Lithium battery. Replace the battery with the same type as that which came bundled with your product. Use of another battery may present a risk of fire or explosion.



Warning! Batteries may explode if not handled properly. Do not disassemble or dispose of them in fire. Keep them away from children. Follow local regulations when disposing of used batteries.

Disposal and recycling information




Do not throw this electronic device into the trash when discarding. To minimize pollution and ensure utmost protection of the global environment, please recycle. For more information on the Waste from Electrical and Electronics Equipment (WEEE) regulations, visit www.acer-group.com/public/Sustainability

EEE yönetmeligine uygundur.

It is compliant with EEE regulation.

RoHS compliance

This product is in compliance with Directive 2011/65/EU of the European Parliament and of the Council of 8 June 2011, on the restriction of the use of certain hazardous substances (RoHS) in electrical and electronic equipment and its amendments.





Recyclable Paper