


# Wireless Keyboard

KBJ

*USER'S GUIDE*

Ver.:1.00



CAUTION: To use this product properly, please read the user's guide before installing.

## **Federal Communication Commission Interference Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:



- Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.
- You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.











This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation

**Keyboard Buttons**

**Media Player Hot Keys**




AAA battery X2


Media Player Hot Keys			
1.		My Computer	My Computer
2.		Homepage(www/e)	Start the default Web browser and loads the home Web page
3.		Outlook(E-mail)→Default	Start the default e-mail program
4.		Homepage(www/e)	Start the default Web browser and loads the home Web page
5.		Search	Open the Internet Explorer Search panel
6.		Play/Pause	Switch between playing and pausing media
7.		Stop(Media)	Stop playing the media in the media player
8.		Volume up (Voice+)	Increase the computer's sound volume.
9.		Mute	Mute (turns off) the computer's sound
10.		Volume down (Voice-)	Decrease the computer's sound volume.
11.		LED Indicator	Low Battery & Pairing Indicator
12.		<b>Connect Button</b>	
13.		Battery Cover	

**Setup the Connection between the Receiver and the Mouse, Keyboard.**

1. Plug the RF receiver into the USB port of your computer.



2. Insert the batteries into the keyboard, then follow the steps below.
3. If the keyboard is not working, please put them into pairing mode.
4. Pairing: Re-plug the receiver into the USB port of your computer, then press connect button of the keyboard. If the keyboard does not work after 10 seconds, pair them again. (The receiver has auto pairing function).
5. The LED indicators on receiver flashes when the keyboard is in use.
6. When the batteries of the keyboard is low, the Low Power indicator will start to blink.



**\*Keyboard Indicator**

**Red LED is on for 10 sec.**  
Power ON

**Red LED Blinks for 10 sec.**  
Low Battery Warning

**Red LED Blinking**  
Pairing (LED OFF when paired or failed after 10 sec.)