

單張式英文版
70磅雙交紙，W222.75*H105mm雙面印刷再彈簧折

折線

折線

正面



INFINITIVE
Compact Wireless Keyboard
USER GUIDE

WIC# 584632 FCC ID: FR0K631 / FR0K1F

Important Safety Precautions/Cleaning & Maintenance Instructions


When using your compact wireless keyboard, basic safety precautions should always be followed, including the following:

1. READ ALL INSTRUCTIONS BEFORE USING YOUR COMPACT WIRELESS KEYBOARD.
2. Never expose your compact wireless keyboard to high temperatures, extreme cold, high humidity or any moisture or water.
3. In order to avoid the risk of electric shock, never attempt to open your compact wireless keyboard or repair it without the assistance of certified professionals.
4. Your compact wireless keyboard is not to be used by children or the infirm without suitable adult supervision.
5. Do not drop your compact wireless keyboard, throw it, or subject it to strong impacts or physical trauma.
6. Clean your compact wireless keyboard using a soft, moist cloth or paper towel. Do not use harsh chemicals when cleaning your compact wireless keyboard, and never submerge compact wireless keyboard in water.
7. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (ni-cad, ni-mh, etc.) batteries.

CAUTION Risk of Fire and Burns. Always Follow All Manufacturer's Instructions When Using.

CAUTION Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Package content



1. OFF/ON switch
2. LED indicator
3. USB nano receiver
4. Battery cover
5. User manual
6. 2 x AAA batteries

Specification

- Operating Systems: Microsoft Windows 7/8/10/11, Mac OS 10.5 or newer version
- Ultra slim design
- Number of keys: 78
- Connection: 2.4 GHz wireless connection
- Wireless range: Up to 32 ft / 10 m
- Battery Details: 2 x AAA (included)
- Dimension: (L) 285.5 x (W) 120.5 x (H) 21.8 mm (L) 11.24 x (W) 4.74 x (H) 0.85 inch

反面

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Statement.
The product complies with the FCC portable RF exposure limit set forth for an uncontrolled environment and are safe for intended operation as described in this manual. The further RF exposure reduction can be achieved if the product can be kept as far as possible from the user body or set the device to lower output power if such function is available.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Getting started

Open battery cover, pull the tab to activate the batteries



Plug USB Nano receiver into USB-A port on your computer, turn on power and you are ready to go

Function Keys

Press and hold Fn + F1 - F12 will perform as shortcut function	
F1	Media Player
F2	Volume down (Voice-)
F3	Volume up (Voice+)
F4	Mutes (turns off) the device's sound
F5	Previous track
F6	Next track
F7	Play/Pause
F8	Stop
F9	Homepage
F10	Default E-mail application
F11	Open This PC
F12	Open Chrome Bookmarks

LED Indicator

Battery LED Indicator

Press F1 - F12 will perform as standard function keys

Trouble shooting

keyboard is not working?

1. Is the mouse powered on?
2. Is the USB Nano receiver securely plugged into a USB-A port? Try switching to another USB-A port
3. If it is plugged into a USB hub, try plugging it directly into a USB-A port on your computer
4. Check the orientation of the batteries inside of the keyboard

If it is still not working, try the steps below to connect the keyboard and the receiver

- A. Unplug and replug in the receiver
- B. Turn off and turn on the power again
- C. Press and hold ESC + Q (Keep it close to the receiver)


If it does not work after 10 seconds, repeat steps A and B

Trademark notice

Infinite
DISTRIBUTED BY: WALGREEN CO. DEERFIELD, IL 60015
100% SATISFACTION GUARANTEED
walgreens.com ©2024 Walgreen Co.
Questions or comments ? 1-800-925-4733

折線

折線



Project Name: **KGB_for Walgreens(infiniteve LOGO)_Manual(China)_Outline_20240318.ai**

REV. A

印刷順序：印單色，*雙面印刷再彈簧折

PROCESS COLORS

DATE: 2024.03.18

紙質：雙交紙，70磅



比例 1:1

—— 裁切線
- - - - 折線

尺寸：
未折合前-寬222.75mm x 長105mm
折合後-寬74.25mm x 長105mm

簽核：

製作者：Jones