ADEMCO

K0011 2/01 No. 5800SS1 Shock Sensor/Transmitter

Installation Instructions

Use the 5800SS1 shock sensor only with alarm systems that support 5800 series wireless devices. The transmitter has its own unique serial number permanently assigned during manufacture, which must be entered into the control panel prior to the transmitter's usage. Refer to the control unit's installation instruction for programming details.

Note: During programming of the control unit, 5800SS1 transmitters should be treated as "RF" (i.e. supervised RF) Type. The 5800SS1 is assigned as one zone.

Mounting

Before mounting the transmitter permanently, conduct Go/No Go tests (see control's instructions) to verify adequate signal strength from the mounting location.

- 1) Learn serial number as described in the control panel installation instructions. To cause the sensor to transmit, remove the battery pull tab. For additional transmissions, lightly tap on the base of the sensor.
- 2) Determine mounting location. For best sensitivity, the sensor should be mounted in one inch from the edge of the window.
- 3) Verify range by holding the sensor in the approximate mounting location and tapping on the base. The panel (in test mode) should respond to the transmissions. If not, find a more suitable mounting location.
- 4) Clean the glass, where the sensor is to be mounted, with a mixture water and isopropyl alcohol. Once the glass is dry remove the tape backing paper and firmly press the sensor in the desired mounting location.
- 5) Verify operation by striking the opposite edge of the window with the handle of a screwdriver check for trip at alarm panel.

FCC Statement FCC ID: CFS8DL5800SS1

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Specifications

Glass coverage:

Plate, Laminate, and Tempered, up to 1/4" thick and 10' distance from mounting location.

Unit Dimensions:

1.6" (40.64mm) x 1.6" (40.64mm) x 0.8" (20.32mm)

Battery:

Panasonic CR2, Sanyo CR2, and Duracell DLCR2.

Refer to the installation instructions for the receiver/control with which this device is used for warranty information, and details regarding the limitations of the entire alarm system.

ADEMCO GROUP

165 Eileen Way, Syosset NY 11791 Copyright© 2001 Pittway Corporation