



**Installation Manual for bracelet
TRX900F-2**

Installation Manual for bracelet unit TRX900F-2

Bracelet

To Attach the Bracelet

Match the Bracelet serial number on the Bracelet case to the number on the Bracelet serial number in the hardware list in PCE. The ankle transmitter and strap will be shipped unattached. You must insert one end of the strap into the transmitter and push the locking pins into place. Make sure that the locking pins are flush with the case. Measure the strap to the offender's leg and cut the strap to fit around the offender's ankle. You should size the strap so that it allows approximately ¼ inch of space between the offender's leg and the strap to ensure comfort.



Once you have the strap attached, push the locking pin through the holes on the bracelet and into the strap until it locks into place



Make sure the locking pin is pushed far enough so that the top of the pin is flush with the bracelet case



To Remove the Bracelet

Cut the strap



Using the screwdriver provided, turn the right locking pin counter clockwise and the left locking pin clockwise to remove



Lift each side of the pin up from the strap and remove. Slide both ends of the strap out of its channel. Dispose of the strap

Clean the bracelet with mild detergent. Rinse, dry, and return to your inventory.

FCC Notices

The ankle transmitter TRX-900F-2 complies with Part 15 of the FCC Rules. Operation is subject to the following conditions:

- 1) This device may not cause harmful interference and
- 2) This device must accept any interference received, including interference that may cause undesired operation.
- 3) Changes or modifications not expressly approved by Elmo Tech Ltd could void the user's authority to operate the equipment.