

Quick Start Guide [DRAFT]

WHAT'S IN THE BOX

- Device
- Power adaptor
- Device Remote Control
- 2 AAA batteries

CONNECTING DEVICE

1. Connect one end of the HDMI cable (not included) into the HDMI port on your Device. Connect the other end into the HDMI port on your TV.
2. Plug the included power cable into your Device and then into a power outlet.
3. Turn on your TV, and select the appropriate input
4. Insert the included batteries into the remote. If the remote does not automatically connect, make sure that the batteries are properly installed.
5. Your Device is now connected to your TV. Simply follow the on-screen guide to complete your setup.

CONNECTING DEVICE TO YOUR HOME NETWORK

You can connect your Device to your network using one of the methods below:

Wired network

1. Connect one end of an Ethernet cable (not included) to your router. Connect the other end to the Ethernet port on the back of your Device.
2. Your Device will automatically detect your network and continue the set up process.

Wi-Fi network

1. Using the remote control, select your network from the list displayed on the screen. If your network is hidden, enter your network name.
2. If required, enter your network password using the on-screen keyboard.

REGISTERING YOUR DEVICE

If you purchased your Device online, it is already registered to you.

If you received your Device as a gift or if it is not yet registered, please follow the on-screen instructions to register your Device.

IMPORTANT PRODUCT INFORMATION

For safety, compliance, recycling, and other important information regarding your Device, please refer to the Legal & Compliance section on the Settings menu of your Device.