


LOVE & SPORTS

TRUE WIRELESS EARBUDS



USER MANUAL

Love & Sports Earbuds



- A. Touchpad
- B. Earbuds
- C. Charging Case with USB-C charging port

CHARGING

Working time: 5 hours

Charging time*: ~1.5 hours (via USB-C cable)

OPERATING INSTRUCTIONS

Fully charge your device before using.

POWER ON Remove the earbuds from the charging case to power on each earbud. When both earbuds are on, they will automatically pair to each other within a couple of seconds.

POWER OFF Insert the earbuds into the charging case to shut down. You can also long-press the touchpad for 5 seconds to power them off. The light will flash red to indicate that they are powering off.

BLUETOOTH PAIRING The earbuds will pair to each other (left & right) automatically. When paired to each other, the left earbud will flash blue & the right earbud will continue to flash red & blue to indicate that the earbuds are ready to pair with a device.

Make sure your device's Bluetooth settings are turned on. The earbuds will appear as **Love & Sports Earbuds** in your device list.

Select **Love & Sports Earbuds** to pair with your device.

USING YOUR EARBUDS

TOUCHPAD CONTROLS

- Click: play/pause, answer/hang up
- Double click (L): Restart or go to Previous
- Double click (R): Next song
- Long press for 2 seconds: Reject call
- Long press for 5 seconds: Power on/off

LED LIGHT INDICATOR

- Device Connected: no LED light (light off)
- Pairing Mode: Flashing **RED AND BLUE**
- Earbuds being charged in case: solid **BLUE**
- Earbuds in case with no charge: flashing **BLUE**
- Case charging via USB-C: flashing **RED**
- Case fully charged: light off

REGULATORY NOTICE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



DO NOT RETURN PRODUCT TO THE STORE FOR SUPPORT



FOR TECHNICAL ASSISTANCE, WARRANTY AND CUSTOMER SERVICE, EMAIL: support@loveandsports.help

OR VISIT US AT: loveandsports.help

FCC ID: 2ARUI-AMP3